

PATENTED · MADE IN USA

Roll Puller™ RP3XL & RP4XL

One-operator unloading for geosynthetic rolls in vans, containers, and flatbeds.



Why Roll Pullers

Manual unloading of geosynthetic rolls from vans and containers is where crews get hurt and rolls get damaged. The Roll Puller™ eliminates the pry-bar-and-shoulder routine.

- **One operator** pulls the roll — no team lift.
- **Up to 10x faster** with multiple pullers.
- **Protects cardboard cores** so rolls stay usable.
- **Pays for itself in a few shipments.**

Model Specifications

MODEL	CORE ID RANGE	MIN. CORE THICKNESS	BEST FIT
RP3XL	2.75" – 3.25"	0.5"	Standard paving-fabric and geotextile rolls, singly or banded in pairs and trios.
RP4XL	3.75" – 4.50"	0.5"	Oversized geosynthetic rolls, hybrid mats, and larger cardboard cores.

Engineering (2016 Redesign)

- **Grabs 4" deeper** into the cardboard core, multiplying its effective capacity.
- **Patent-pending laser-cut armor plate teeth** maintain grip and reduce core tearing.
- **Forged ring, double-welded** onto machined shaft steel.
- **Handles multi-roll banded groups** in one pull.

Field Performance

"3 RP4XL Roll Pullers pulling a 75-roll tier of paving fabric in 25 banded groups of 3 rolls in one pull. I was amazed."

— Contractor, name withheld

Watch a 3-Roll Puller set pull 6 banded groups of 18 rolls:
[youtube.com/shorts/7I6ESZXjh4Y](https://www.youtube.com/shorts/7I6ESZXjh4Y)

Courtesy of US Silt & Site Supply · Bow, NH 03304

Pricing & ordering: Pricing and shipping quoted on request — include quantity, model, and shipping ZIP code. Full accessory chain, hook, and O-ring systems available for complete kits.

SAFETY FIRST

Roll Pullers do not break with proper use. Chains, cables, ropes, and slings do break.

1 Never exceed the Working Load Limit

The WLL is less than breaking strength — that's the point. OSHA requires you stay below it, every pull.

2 Stand to the side of the truck

Never stand behind the ropes, chains, or in line with the pull. A snapped rigging line kills.

3 Pull horizontally, not down

Insert the puller horizontally, then lift slightly or pull level. Downward pulls tear the core wall.

4 Train every operator

Speed and safety come from operators who understand the rig. Walk every new operator through the drill.

Recommended Technique

- Insert horizontally until the teeth seat, then lift slightly or pull level.
- Guide rolls along rails, a dolly, or a waiting forklift to prevent core drag.
- For loosely wrapped rolls where cores start to pull out, use multiple Roll Pullers — one in each core — to distribute load.
- Pyramided rolls can be pulled until roll weight exceeds the puller's tested capacity.

Rigging Configurations

Puller Set	Chain Configuration
2 Puller Set	Two 6-foot chains
3 Puller Set	One 4-foot center chain + two 6-foot outer chains
4 Puller Set	Two 4-foot chains + two 6-foot chains

Chain, hooks, and O-rings sized for complete Roll Puller systems are available on request.

Warranty

90-day warranty against defects from date of purchase with proper use. Full operating instructions are included with every order. Contact GAC for warranty claims, replacement parts, or additional operator training.