Slave, 9600 baud rate, N, 8, 1. Pincode 1234
AT command:
1. Communications Test :
Sent: AT
receive : OK
2. Change baud rate :
Sent: AT+BAUD1
receive: OK1200
Sent : AT+BAUD2
receive: OK2400
11200
22400
34800
49600
519200
638400
757600
8115200
Baud rate setting can be save even power down.

Default:

Sent : AT+NAMEdevicename

3. Change Bluetooth device name:

receive: OKname

(devicename is the name you want the device to be, and it will be searched with this name)

Name setting can be save even power down.

## 4. Change Pincode:


Sent : AT+PINxxxx

receive: OKsetpin

(xxxx is the pin code you set)

Pin code can be save even power down.

## Pin Map:



Demonstration Circuit:

