ENCE260 Notes - Computer Systems

General Info About Course

The goal of this course is to introduce and get familiar with Linux and to teach you how to program in C. In this course the notes will be split into 3 major chunks throughout the year.

- 1. C Programming
- 2. Computer Architecture
- 3. Embedded System's

Textbook: None

Recommended text to read (C programming)

Grading

- 10% C Programming Assignment
 - (this is a three part super quiz)
- 10% Embedded Systems Assignment (Term 4)
 - Date: Monday 12th October
- 10% Weekly Quiz's
 - Dates: Each one will be on quiz server
 - There will be around 13 of these (0.8% each)
- 20% Test
 - Date: Monday 7th September 7pm
- 50% Final Exam (does not include C programming)

Resources

- K. N. King, C programming: a modern approach (2nd Edition) (Recommended not required)
- Lecture notes, Recordings and slides
- C Style Guide
- C Reference

Tutorials This is some tutorial questions for computer architecture, It contains both questions and model answers.

- Tutorial one
- Tutorial two
- Tutorial three

C Programming

Memory Organisation

- C programs should be structured as follows:
 - Program code (text)
 - Global and static data (data)
 - Uninitialized global data (bss)
 - Dynamic memory (heap)
 - scratch pad memory (stack)

Basic Hello World!

Declaring Variables

```
#include <stdio.h>
# define A_CONSTANT 30 //this is how to define constants
int main(void) {
//Declarations are as follows
  int number1; // int means dedicate 4 bits to a number
  int number2;
```

```
int total;

//Manipulation of variables
  number1 = 10;
  number2 = 20;
  total = number1 + number2;
  printf("The sum of %d and %d is %d\n", number1, number2, total);
  return 0
}
```

Using Macro's The #define tag is used to assign macro's in C, this will be completed in-line with other arithmetic. This is used to re-assign stock symbols and will execute the arithmetic where it is placed in the file.

```
// These are known as Macro's
#define SECOND_NUMBER 20
#define FIRST_NUMBER 20 this is still legal 2020
```

This line is defining second number as 20, this means that every time we call the parameter second number it means 20, As we can see by the FIRST_NUMBER definition, this is not the same as assigning an integer within the body of the function, this is defining a term as a replacement for the symbol.

Macro's for arithmetic As previously noted, we can re-define symbols using Macro's. This means that arithmetic works in the same way as you would expect, so if we define a calculation as the macro, every time we use it it will be evaluated in line with the expression. Here is an example.

```
#define TEST 4 + 2
int main(void) {
  int val = TEST * TEST;
  printf("%i\n" val);
}
```

This will use in-line math to result in the following output: 14

Statements General Expressions

These are mostly like python except:

- No exponential operator
- / operator behaves like Python's // (integer devision by default)

• Logical operators are different

```
- and = &&
    * single & acts as bitwise
- or = ||
    * single | acts as bitwise
- not = !
- ++, -- are used as increment operators
    * pre-increment + + j
```

* post-increment j - -

- Assignment operator = is used anywhere in expressions
 - * e.g. foobar = (foo = 2) + (bar = 10)
 - * only use in simple assignment statements

If Statements

- · Syntax in BNF notation
 - ::= means is defined as
 - | denotes *or*
 - Tokens in double quotes are *terminals*
 - Other tokens are expanded by their own syntax definitions
- · Note the parentheses around the condition expression

To use Boolean Values

To use boolean values, we must include *stdbool.h* into the program, this will give us a boolean value to use, the following will be the code to use boolean values.

```
#include <stdbool.h>
int main(void)
{
   bool bigger = 6 > 5;
}
```

Loops

The loops act very similarly to that of the python loops, there are both While loops and For loops, that act in much the same way that they would in python. The following is a basic implementation of a while loop.

```
int main(void)
{
  int i = 10;
  while (i < 100) {
    printf("%i\n", i);
    i++;
  }
}</pre>
```

It is also important to note that there is also another version of the while loop that is called a Do while loop, this is mostly useless, however it can come in useful occasionally. Here is an example of a Do while loop.

```
int main(void)
{
  int i = 10;
  do {
    printf("%i\n", i);
    i--;
  } while (i > 0);
}
```

Here is an example of a For loop, this is used to specify a loop within a range of values. To use this we need to give it an initialisation expression, a condition to continue and a loop body indication, this is in this order and is found in the brackets in the body below.

```
int main(void)
{
for (int i = 10; i > 0; i--) {
   printf("%i\n", i);
   }
}
```

We have been asked to with-hold from using for loops for anything other then simple counting, this is because when we use a for loop, the check condition is preformed after the increment is completed. This is very counter intuitive as we would assume by the presentation of the statement that the counter would be implemented before the check.

The Switch Statement The switch statement uses a series of cases, and acts similar to that of the switch statement found in Java.

```
// Example of switch statement
switch ( expression ) {
```

Example of switch: Simple Calculator

```
// Takes in an operand, then two numbers; this will determine the

→ calculations result

#include <stdio.h>
int main() {
    char operator;
    double n1, n2;
    printf("Enter an operator (+, -, *, /): ");
    scanf("%c", &operator);
    printf("Enter two operands: ");
    scanf("%lf %lf",&n1, &n2);
    switch(operator)
    {
        case '+':
            printf("%.1lf + %.1lf = %.1lf",n1, n2, n1+n2);
            break;
        case '-':
            printf("%.1lf - %.1lf = %.1lf",n1, n2, n1-n2);
            break;
        case '*':
            printf("%.1lf * %.1lf = %.1lf",n1, n2, n1*n2);
            break;
        case '/':
            printf("%.1lf / %.1lf = %.1lf",n1, n2, n1/n2);
            break;
        // operator doesn't match any case constant +, -, *, /
        default:
            printf("Error! operator is not correct");
    return 0;
```

}

The above code is a simple calculator, it will enable the user to add, subtract, multiply and divide. This is done by scanning for the type of operand (+, -, *, /), this will allow the user to define what type of operation to address (defined by cases) then we will enter the two numbers to use the desired operand on.

C Error Messages The C error messaging system is considerably more cryptic than that seen in the Python interpreter. It is harder to follow, and the key point to take away is that **Not all error messages** will point to exactly where the error is unlike python sometimes you will have to find the error yourself.

The Celsius function

```
#include <stdio.h>
#include <stdlib.h>

#define FREEZING_PT 32.0
#define SCALE_FACTOR (5.0 / 9.0)

int main(void) {
   float fahrenheit = 0.0;
   float celsius = 0.0;
   printf("Enter Fahrenheit temperature: ");
   scanf("%f", &fahrenheit);
   celsius = (fahrenheit - FREEZING_PT) * SCALE_FACTOR;
   printf("Celsius equivilent: %.1f\n", celsius);
   return EXIT_SUCCESS;
}
```

How Memory Works

Memory at the lower levels is just a series of bits. C treats memory the same way as it has no object store or *heap*. Each piece of memory used is allocated a byte sized number to tell us where it is stored, this is known as an *address*, (if we have a 4GB machine, then there is 4 Billion bytes to store this information).

a = b Because of the above, the assignment operator a = b, is actually saying, go to memory location b and copy all the bytes of b to memory location a. This is raw byte copying, this is different to python in the fact that python stores the name in a dictionary as an object.

Data Types and Interesting Functions

- Integers
 - unsigned
 - signed
 - long
 - short
 - int
- Floating Point Integers
 - float
 - double
- Characters
 - char
 - always 8-bit ASCII encoding (1-byte)
- Complex Floating Point
 - not covered in ENCE260
- Boolean
 - Bool (or just bool if #include <stdbool.h>)

Integers

```
int a = 0;
short int b = 1;
signed long long int x = 256;
short c = 20; // Don't have to expand
long d = 50;
```

The different variables tell it how much memory to allocate to each variable, for instance **char** allocates 1-byte, **short** allocates 2-bytes, **int** allocates 4-bytes and **long long int** allocates 8-bytes.

Chars

```
char someChar = 0;
someChar = '*';
printf("'%c'", someChar);
```

```
Return: '*'
```

This will return the actual character, however if we do an arithmetic operation on the char it will treat it as an integer.

```
char someChar = 0;
someChar = 42;
printf("'%c'", someChar);
    Return: 42
```

Because we have now assigned the char to a numeric variable, it will then treat this as an ASCII value for a character in the alphabet.

Using getchar()

int c = 0;

```
printf("Enter a line: ");
c = getchar();

while (c != '\n' && != EOF) {
    printf("c = '%c' dec %d hex %x\n", c, c, c);
    c = getchar();
}

Here is a sexier way of writing this

int c = 0;
printf("Enter a line: ");
while (c = getchar()) != '\n' && c != EOF) {
    printf("c = char '%c' dec %d hex %x\n", c, c, c);
}
```

This will take a string of characters, and then print every character as a char, int and hex.

Note: That this will buffer each char and print at the end of the loop rather then printing them after each character is entered.

Arrays in C

```
char line[100] = {0}; // this will set 100 bytes to a value of 0
char line2[5] = {0, 1, 2, 3, 4};
```

```
// Note we can also find the size of an array using the following syntax
printf("The size of line2 is %zu", sizeof line2);
int c, i, n = 0;
puts("Enter a line: ");
while ((c = getchar() != '\n' && c != EOF)) {
    line[i++] = c;
}
n = i;
for (i = n - 1; i >= 0; i--) {
    putchar(line[i]);
}
```

In the code above, we can see that we have allocated 100 bytes to a line of chars. This means that if we go over 100 bytes of code in that line, we will find that there is going to be an overflow, because of this we will only see the first 100 bytes and the rest will be lost.

Functions

```
#include <stdio.h>

double average(double a, double b)
{
    return (a + b) / 2;
}

int main(void)
{
    printf("Average is: %lf", average(10, 200));
}
```

Take away things about functions:

- you cannot nest functions in C
- you must define the function before use, therefore we need to define above the main function

Strings In C

```
#include <stdio.h>
#define MAX_NAME_LENGTH 80
```

```
void readName(int maxLen, char name[])
{
   int c = 0;
   int i = 0;
   printf("Enter your name: ");
   while ((c = getchar() != '\n' && c != EOF && i < MAX_NAME_LENGTH)) {
      name[i++] = c;
   } name [i] = 0;
}
int main(void)
{
   char name[MAX_NAME_LENGTH] = {0};
   readName(MAX_NAME_LENGTH, name);
   printf("%s\n", name);
}</pre>
```

We can indicate strings by having an array of chars and then ending with a 0, this would look something like this $s[] = \{'t', 'h', 'i', 's', 0\}$, we can also define a string like the following:

```
char s[] = "This";
char str = "This";

puts(s);
puts(str);

s[1] = '*'; // will work
str[1] = '*'; // will not work
```

If we use the second example str[1], we will run into a segmentation fault, this is because we will be pointing into a defined spot in memory, and therefore causing memory errors. We can use the **valgrind** program on Unix systems in order to spot these memory errors.

We can use the <string.h> header to get string operands when needed, these include the strlen() function, along with many others.

Finding string Lengths

```
#include <string.h>
char s = "String";
size_t n = strlen(s);
printf("%zu", n);
```

Returns: 6

Above is an example of how to get the length of a string in C or any array of chars. It is important to note that this is not returned as an int, but is returned as a size_t attribute.

From figure one, we cannot do something like if (s == str), this is because the equals operand compares two places in memory rather than the values.

String Functions

Note: We can use the Man page to find the input parameters for the below functions

We can use strLen() to get length of string.

We can use strcmp() to compare two strings.

We can use strncpy() to copy a string to another object.

We can use strncat() to concatenate strings.

Pointers In C all memory is treated as a large array, there are no *run-time checks*, programming errors with pointers and arrays usually results in a crash of the program: this can be *segmentation fault, core dumped*. Sometimes a corrupted memory location causes a problem much later in the execution of the program **This is hard to debug**.

The * operator in C can be interpreted in a couple of ways depending on context. When being used in **Declarations** it is read as int* point means define this as a pointer to an int. When used in **Expressions**, it is read as *Indirectly via*, so *p = j means get a value indirectly via p and store it in variable j.

Something that we must understand about C, is that everything

Addressing memory

```
uint8_t varA;
char varB;
int16_t temp[2];
```

This translates to the following byte array | Memory | Location | Allocation | |-|-|-| | 0x100 | byte 0 | varA | | 0x101 | byte 1 | varB | | 0x102 | byte 2 | temp[0] | | 0x104 | byte 3 | temp[0] | | 0x105 | byte 4 | temp[1] | | 0x106 | byte 5 | temp[1] | | 0x107 | byte 6 | EMPTY |

Pointers in C syntax

```
char varA = 'a'
char* point_to_varA;

point_to_varA = &varA;

printf("%c", *point_to_varA);
```

Malloc & Free Because we do not want to have to declare DEFINE statements every time we want to use a list, we only need to do this as it allows us to make a maximum size. Instead we can use the malloc() function to allocate space.

Here is an example of using the malloc() function to allocate space for a student structure

Something to note is that when we are using strings we need to append the null terminator, this will mean that malloc() will take StringSize = n; n + 1 bits of memory to store the value.

```
// We must allocate the string size and another bit for '\0' (Terminator)
char[] string = "This is a string";
char* name = malloc(strlen(name) + 1);
```

Remember to use the Man page if you don't understand dipshit!

Usually we want to check the return type of malloc() as it is good practice to make sure it is not a NULL value, the most important part of this is once we free up memory, we MUST NOT LOOK BACK INSIDE IT!

```
// This is freeing a piece of memory
free(name);
```

An actual implementation of Dynamic Memory Allocation

```
#include <stdio.h>
#include <stdlib.h>
#include <string.h>
typedef struct {
    char* description;
    float duration; // hours
    int priority;
} Task;
Task* newTask(char* description, float duration, int priority);
void freeTask(Task* task);
int main(void)
    Task* task = newTask("Studying for ENCE260", 2.5f, 1);
    printf("Task \'%s\' (priority %d) takes %.1f hours.\n",
   task->description, task->priority, task->duration);
    freeTask(task);
}
Task* newTask(char* description, float duration, int priority)
{
    Task* task = NULL;
    size_t allo = strlen(description) + 1;
    task = malloc(sizeof(Task));
    if (task != NULL) {
        task->description = malloc(allo);
        if (description != NULL) {
            strncpy(task->description, description, allo);
            task->duration = duration;
            task->priority = priority;
        } else {
            free(task);
            task = NULL;
        }
    return task;
}
void freeTask(Task* task)
{
```

```
// Freeing the allocated memory to description
free(task->description);
// Freeing the actual Task instance
free(task);
}
```

But how does it work?

- malloc and free are the two main functions in the memory allocator module.
- They manage the **Heap**
 - the free memory area above the initialized data segment
 - the maintain a booking sheet of available and unavailable memory.
 - * a global variable in the module
- The size of the heap grows or shrinks by OS calls brk or sbrk
 - Use the man page to read on these functions

Here is a simple view of malloc() & free():

Malloc and Free

If you either underflow or overflow, you will end up having a messy heap, this will result in either errors or miss-allocated bytes this will cause hell in debugging.

If we need to re-allocate a value to a new place in memory, we can use the realloc() function.

```
void* realloc(void* memPtr, int newSize);

// Here is a real example ( from slides )
char* readLine(void)
{
    char* buff = NULL;
    int numBytes = 0;
    int c = 0;
    while ((c = getchar()) != EOF && c != '\n') {
        buff = realloc(buff, numBytes + 1); // Get a new bigger block
        buff[numBytes++] = c;
        }
        if (buff != NULL) {
             buff[numBytes] = '\0';
        }
        return buff; // NULL if no data read
}
```

if Result = NULL; we have run out of memory

This is a big fucking issue if this happens, its hard to diagnose and is really really annoying.

```
else: Result != Null, we have not run out of memory
```

When we are using malloc() and free(), for every time we use malloc(), we MUST use free() at some point for every malloc(). If this is not satisfied, we will have *memory leaks*, this means that we will have a memory footprint that will grow with no upper bound.

To detect this, we can use the Unix valgrind tool.

Here is an example of simplification using malloc AND free. The example is from Lab 6:

```
for (i = 0; i < NUM_REPEATS; i++)</pre>
studs = readStudents(inFile);
printStudents(&studs );
freeStudents(&studs );
rewind(inputFile);
}
Student* readStudent(FILE* fp)
    // Read from file then call ...
    // newStudent which does ...
    sp = malloc(sizeof(Student));
    buffSize = strlen(name) + 1;
    sp->name = malloc(buffSize);
    strncpy(sp->name, name, buffSize);
    sp->age = age;
    sp->next = NULL;
    return sp;
}
void freeOneStudent(Student* sp) {
    free(sp->name);
    free(sp);
}
StudentList readStudents(FILE* fp)
{
```

```
StudentList studs = {NULL, NULL};
Student* sp = NULL;
while ((sp=readStudent(fp))!=NULL)
{
    addStudent(&studs, sp);
};
return studs;
}

void freeStudents(StudentList* studs) {
    /* **** TBS **** */
}
```

Dealing with Heap Corruption

- Over-running a malloc'd buffer is fatal
 - Probably
 - Eventually
- · Difficult to debug
 - Solution: don't bug! Not-bugging is easier than de-bugging!
- Again there are many tools to help you find heap corruptions valgrind checks every heap memory reference (great tool for small projects but too slow and expensive for large projects)
 Link program with -lmcheck _ Uses versions of malloc, free that do some runtime checks
 _ Aborts on error But checks only when malloc, free called Should always use this when developing code that uses malloc/free

Computer Architecture

Digital Logic Analog Information

defined by quantity

Digital Information

- true/false
- yes/no
- pairs well with logic values
- switches on/off

Logical variable, represents true or false, and is denoted by varName = true

Logical functions

- the limited set of values that logical variables can take (0, 1, true or false)
- makes it feasible to write out every possible combination

Fundamental Functions

NOT

•
$$f(a) = a'$$

AND

•
$$f(a,b) = a * b$$

OR

•
$$f(a,b) = a + b$$

Boolean Algebra

- closure
 - for $a,b \in B$ then $a*b \in B$
- Identity a*i=a therefore

$$-a*1=a$$

$$-a+0=a$$

- Associative a*(b*c) = (a*b)*c
- Communicative a * b = b * a

Logic Gates We use logic gates to create electronic circuits that describe logical variables and their related statements.

S	В	!B	W=S!B
0	0	1	0
0	1	0	0
1	0	1	1
1	1	0	0

Each entry in the sequence can have one of two values (M = 2), since logical variables have two logical values (0, 1). A sequence of N bits can be arranged into 2^N patterns.

Patterns Example

- we have six differently coloured LED's that we can use to represent information
- we arrange these LED's into two groups, each with three colours (R, G, B).

Question: How many patterns can we make with the LED's.

```
Answer: 9 patterns or 3^2
```

What happens if we re-arrange the colors into three groups and two possible options (R, B).

```
Answer: 8 patterns or 2^3
```

How can we work this out without brute force?

In general, a sequence that is N entries long, where each entry has M values, this will give a ${\cal M}^N$ patterns.

Address Bus

This tells us the location of what we care about

Data Bus

This tells us what the data is that we care about

Control Bus

This specifies which way transfers happen over the data bus

The Computer

The CPU

Arithmetic Logic Unit (ALU)

- calculations (+, -, ·, ÷)
 - + = OR gate
 - ·= AND gate
- comparisons (=, !=, <= >=)

- logical operations ()
- binary operands ()

If we want to map this to hardware, we will need to use combinational circuits that use logic gates. (An example of this can be found in the slides).

Here are some real world examples of logic circuits that are often found within an ALU.

Decoder

Used to get the memory location from an observed address.

- Typically used for selecting a memory location given an address
- N address bits $\rightarrow 2^N$ locations
- We want to separate output to be high for each possible combination of inputs
- Below is an example of what a decoder might look like in a logic circuit.

Decoder Diagram

Encoder

Multiplexer

They act as a traffic cop, deciding which of two values go to the output. It essentially routs a single input to the output.

- Multiplexers select one of several inputs and send it to output
- For example: ALU can operate on operands from the general purpose register file but they can also user the output of the previous operation for one of the operands.
- A mux at one of the ALU inputs allows the execution unit to select the source of the operand.

Mux Diagram

 $\begin{array}{c|c} \mathsf{Input} \, | \, \mathsf{Output} \, | \\ \mathsf{S} \, | \, \mathsf{O} \, | \\ - \, | \, - \, | \\ \mathsf{0} \, | \, I_0 \, | \\ \mathsf{1} \, | \, I_1 \, | \end{array}$

Demultiplexer

This acts like a multiplexer except it can output to multiple outputs. There will be a diagram below that will show this:

• The way that this works is that it is conceptually similar to a Mux, however the inputs and outputs are switched.

Demultiplexer (1 to 4)

Adder

The following is an example of a full adder:

Full Adder

Here is an example of a 3-Bit Adder

3-Bit Adder

General Purpose Registers

- a set of memory locations located physically close to the ALU
- stores data that we are intending to manipulate
- Is a file

Control Registers

- holds the meta data associated with the data we wish to manipulate
- Contains
 - Address of next instruction (PC)
 - Address of Top of stack (SP)
 - Status of last operation (STATUS)

Control/Execution Unit

- A finite state machine that controls what happens and when
- · sends data to the ALU
- sets ALU mode
- Control address and control buses
- inputs to the FSM are program instructions and the control registers.

Memory

Sequential Memory SR Latch

• Simplest form of a sequential circuit (This table is from Slide 23)

S AND R are inputs into the table, Y AND Z are outputs (this particular SR latch takes in two inputs and spits out four outputs)

S	R	y_k	z_k	$y_{(k-1)}$	$z_{(k-1)}$
0	0	1	0	1	0
0	0	0	1	0	1
0	1	1	0	1	0
0	1	0	1	1	0
1	0	1	0	0	1
1	0	0	1	0	1

D Flip Flop

• Outputs ignore input until *triggered* by the **Rising edge** of a clock signal

Input	Current	Next		
D	Q	Q	$Q_{(k+1)}$	$Q_{(k+1)}$

Complete later To store a byte of information we will need 8 D Flip Flops, a register typically stores a single byte.

Addressing memory

```
uint8_t varA;
char varB;
int16_t temp[2];
```

This translates to the following byte array | Memory | Location | Allocation | | - | - | - | 0x100 | byte 0 | varA | | 0x101 | byte 1 | varB | | 0x102 | byte 2 | temp[0] | | 0x104 | byte 3 | temp[0] | | 0x105 | byte 4 | temp[1] | | 0x106 | byte 5 | temp[1] | | 0x107 | byte 6 | EMPTY |

Pointers in C

```
char varA = 'a'
char* point_to_varA;

point_to_varA = & varA;

printf("%c", *point_to_varA);
```

Memory Architecture

- Von Neumann
 - This is the simpler approach, it is less expensive.
 - It was desired up until the 1990's
- Harvard
 - This is faster and more costly.
 - Has more buses
 - Came as a way to increase processing speed

IO Architecture

- Memory Mapped Architecture
- Separately Mapped Architecture

Combinational and Sequential Logic We measure *frequency* in hz and *period* in s

Notation:

T = period f = frequency clk = clock time

Formulae for Logic circuits:

$$T_Q = \frac{1}{f_Q}$$
 where $f_Q = \frac{1}{2}(f_{clk})$

Program Execution To execute a program, we use a control execution unit. It is built using a number of cycles, namely fetch, Decode and execute this is known as a Finite State Machine.

- Fetch an instruction from memory
- Decode the instruction
- Execute the instruction

Here is what this looks like visually:

finite stage machine

Here is how these are built with reference to memory:

FSM

Exam Question

Question: If you were designing a control unit, state whether you would implement it as a Moore FSM or a Mealy FSM. Choose and justify why?

Mealy FSM's depends on both the input and its current state, as appose to a Moores finite state machine because it the output only depends on the current state (and not on any input), this means that it is syncrhonus (as because the input is not changing the result, it will always be in sync with the clock signal transitions).

We can ask the CPU to do a number of different tricks and conditions. These are as follows:

ALUTricks

We can group these instructions into a set that is known as the *Instruction Set Architecture*

- These instructions read by the control unit into 3 categories:
- Complex instruction set computer (CISC)
 - Arithmetic / Logic instructions assess registers or memory
 - Instructions do not all complete in the same number of clock cycles
 - instructions do not have the same length
- Reduced Instruction set computer (RISC)
 - Arithmetic / logic only accesses registers
 - separate data transfer instructions
 - Design philosophy: instructions are simple, can be completed in the same time frame

The Stack and Function Calls The stack is a region in memory that is used to record a program context.

It contains:

- function arguments
- local variables
- return variables
- copies of the contents of some of the general and special purpose registers, including PC.

The stack

Here is an example of a conceptual idea of a stack frame:

stack frame

To leave a function, we need to record where we are in the stack. This is how we can call a function and then return to our original function.

Finite State Machines

Intro	Stopwatch
	Example

Example Finite state are used for many things in computing, they are a system where particular inputs cause particular changes in states. An example of this is a stop watch with three distinct states, here is an example:

FSMStopwatch

An example of a stopwatch in software is the following:

This can be achieved via software, and is commonly seen in communication software such as phones.

We can also achieve a similar idea from hardware, here is some examples:

Mealy Machine	Moore Machine
Mealy	Moore
Good because we have less flip flops	Good for asynchronous design

We will now go over how to design a finite state machine (FSM), in order to do this we must do the following:

- 1. Determine inputs and outputs
- 2. Draw FSM state transition diagram
- 3. Choose a state encoding
- 4. Choose the implementation structure
- 5. Design the next-state and output logic

We must develop a solution to reach all states using boolean algebra (NOT, AND, OR, XOR) gates in a physical machine.

We can simplify expressions from boolean logic tables to produce a simplified alternative expression.

Example; [rules used] to solve the following:

Question:

$$y = A b c + a b c + a b c + a b c$$

Working:

$$y = A b c + a b c + a b c + a b c$$

[Commutative]

$$y = A b c + a b c + a b c + a b c$$

[Distributive]

$$y = (\not a + a) \not bc + a \not c(\not b + b)$$

[OrComplement]

$$1\dot{b}c + a \dot{c}1$$

[Commutative]

$$bc + a c$$

Embedded Systems

An Embedded System is a system that is made for a single purpose, it is unlike a general purpose computer in the fact that it is not suppose to many things, they are more simple and efficient at a single thing.

The labs will not be assessed, however will be important in preparing you for the lab test and the final exam, we will write our programs in modules to simplify code and keep certain ideas separate.

The stack frame is being held in Data Memory, and the registers hold the stack frame

When we want to call a function, we push the register holding our previous function in order to allow us to get back to it. We then push the new item to the stack to indicate that we are using it.

Bit shifting and binary

$$(1 << 4)|(1 << 2) = 00010100 = 0x14 = 20$$

The above equation involes a bitshift by four and two respectively, and uses a bitwise OR to distinguish when to take the byte or when not to.

Bitwise operations in C

- 1. ~ is bitwise complement NOT
- 2. | is bitwise OR
- 3. & is bitwise AND
- 4. ^ is bitwise XOR
- 5. << is bitwise left shift
- 6. '»' is bitwise right shift

Examples of bitwise operations:

```
NOT > (0101) = 1010

OR > 0101 \mid 1010 = 1111

AND > 0101 \& 1010 = 0000

SHIFT > 0001 << 2 = 0100

XOR > 0101 ^ 1011 = 1110
```

Timing and flashing LED's

```
Frequency f = \frac{cycles}{second}
Period T = \frac{1}{f}
```

Delaying with a loop

In C code, this will add a delay to a LED that is turning on and off. With the following method, the delay_ms function will hog the CPU by remaining idle while the delay is on (nothing can be calculated in this time), Another problem with this method is that it will result in a delay that is > 500 ms.

```
int main(void)
{
   system_init();

DDRC != (1 << 2);</pre>
```

```
while (1) {
  PORTC ^= (1 << 2);

  delay_ms(500);
  }
  return 0;
}</pre>
```

Here is a better method of using timers, we can use the TCNT1 timer unit on our micro-controller. The following is an example in C:

```
void timer_delay (uint16_t ticks)
{
   TCNT1 = 0;

   // This timer will automatically tick until we want it to break out.
   while (TCNT1 < ticks) {
      continue;
   }
}</pre>
```

Another delay function (the one we want to implement) is to be used as the following in C:

```
void delay_ms (uint16_t delay)
{
  timer_delay(delay * (F_CPU / TIMER1_PRESCALE) / 1000);
}
```

Multiplexing With Funkit

Because we have a light matrix of 5 x 7 lights, we can either use a single pin to be paired with a light. If we want to use multiple inputs and outputs per pins, we must use multiplexing (with regards to funkit we have 35 output lights and 23 PIO pins)

A multiplexer is a switching circuit that provides a path from many inputs to select a single output. These can be constructed with AND/OR gates. With N bits, we can choose between 2^N inputs.

LedHighLow

The above sheet shows us how the voltages define whether the LED is on or off.

On the funkit to turn on an LED, we must turn the ROW and COLUMN to be on low voltage in order to turn the LED on. This is for the reasons below.

We can use MOSFET's to turn on multiple lights at a single time. This is displayed below.

MOSFET

Setting LED's to be initially off in C

```
#include "pio.h"
#include "system.h"

int main(void)
{
    // We must do the following for the entire matrix of LED's
    pio_config_set(LETMAT_ROW1_PIO, PIO_OUTPUT_HIGH);
}
```

We can use two states that are changing at a high frequency to give the appearance of an LED being on the entire time, here is an example below to make it appear like we have the 3 corners displaying at the same time.

MultiplexingExample

This is an example of using a MUSFET to display two states at one time

Methods of implementing Round Robin Scheduler

We do things in sequence, this tends to be implemented with a loop and is done in order.

- easy to implement
- Response times are the same for every task
- Good for background tasks
- In most applications not all tasks will have the same priority
- If a task takes too long it will be hogging the CPU

Paced Loops

A paced loop allows us to synchronise tasks, however, it blocks the CPU while it is waiting.

This ensures that the tasks are being done at a specific frequency.

```
void pacer_wait(void)
{
   while (TCNT1 < pacer_period) {
      continue;
   }
   // Reset the counter
   TCNT1 = 0;
}</pre>
```

Periodic Scheduler

periodic scheduler

Tutorial 2

Question2

Question 3

Consider the LED flashing program:

```
#include "pio.h"
void tempo(uint16_t bravo)
  while(TCNT1 < bravo) {</pre>
    continue;
  TCNT1 = 0;
}
void flasher(uint16_t huey, uint16_t dewey, uint16_t louie)
  TCCRIB = 0 \times 05;
  TCNT1 = 0;
  while (louie--) {
    pio_output_high(LED1);
    tempo(huey);
    pio_output_low(LED1);
    tempo(dewey - louie);
 }
}
```

```
int main(void)
{
    system_init();
    pio_config_set(LED1, PIO_OUTPUT_LOW);
    flasher(10, 400, 10);

    return 0;
}

A. How many times will the LED flash?

B. Magic numbers are used in Listing 1. Add appropriate lines of code and rewrite others to show how magic numbers are removed from this program

C. Neglecting the time it takes to call pio_output_low and pio_output_high determine the duty cycle of the LED
```

D. State one advantage for using data abstraction functions in pio.h for IO operations

Communicating between two fun kits

- Bit polarity: does a high or low indicate 1 or 0
- Bit order: do we send the MSB or LSB first
- Message encoding: ASCII or Unicode
- Bit synchronisation: when does each bit start

Simplex system

• data can only be sent in one direction

simplex

Full Duplex

• Data can be sent both directions at the same time (there may only be a single line).

full duplex

Half Duplex

- Data can be sent in both directions, but only in a single direction at a time.
- Only one person can talk at a single time.

Half Duplex

UART

- · UniversalAsynchronousReceiver/Transmitter
- Most commonly used form of serial communications (ie bit by bit) for micro controllers.
- One wire per direction (plus common ground).
- Asynchronous (TX and Rx need to use preset clock frequencies)

UART

Above is an example of a Full Duplex system, as we can send and receive at the same time.

Baud Rate

- Since transmission is serial, the transmission speed is given in the maximum number of bits per second.
- Known as the Baud rate (max number of bit transitions per second).
- We need a start bit to indicate the start of the frame (also synchronises the receiver).
- We need stop bit(s) to indicate the end of the frame.
- We may also use a parity bit for error checking.
 - we need to have either an even or an odd number of 1's.

```
// Receive a character from USART, blocks until char is received
int8_t usart1_getc(void)
{
   while(UCSR1A & (1 << RXC1 == 0)) continue;
   return UDR1;
}

// transmit a character from USART blocks until the char can be sent
void usart1_putc(char ch)
{
   while(UCSR1A & (1 << UDRE1) == 0) continue;
   UDRT = ch;
}</pre>
```

Timers These are extremely useful, to the point where pretty much all micro-controller's include timers at this point in time.

On our micro controller, we have one 8-bit timer and another 16-bit timer, we can use separate prescaler's and Compare mode (using two 8-bit PWM channels) the 16 bit timer is a bit more fancy.

Example exam questions on PWM Timers can be found at 27:00

C Compiler and Tool Chains The **Preprocessor** rads the C source file, the header files and they expand Macros.

GCC Toolchain

We use the GCC compiler (made by GNU), this is the C compiler that is used on most Unix operating systems despite the name GNU Not Unix.

Makefile syntax

```
# this is to build the `main.o` object file
main.o: depend1.h depend2.h depend3.h
$(CC) -c $(CFLAGS) $< -o $@</pre>
```

The above shows a file to build, the dependency files that are used to build it, then the compiler will build the game.out and create the exe file.

Git (info I don't know) Dealing with conflicts in Git

When both users have the same lines, we need to manually change the values. (use git fugitive binds) We can use <Leader>gs to get git status, then use dv on the conflict file to open the differences in views, this will allow us to see one commit from each person, conflicts/changes will show in green and red on both sides.

Final Exam (Information)

Format

- two questions on computer architecture, two on Embedded systems
 - All of these are weighted evenly (25%)

- UC calculators are allowed
- grade of < 45% is considered a fail of the course.
 - Formal evaluation: $(TestPercent \times 0.2 + FinalPercent \times 0.5) \div 0.7 >= 45$

$$66.7 \times 0.2 + final \times 0.5) \div 0.7 > 45 where final >= 36.32$$

Embedded systems content	Architecture content
content	content

No cheat sheet available

|content|

Exam Study Question Answers

2019 Exam (Question 1)

If we have a selection of three options, and we are allowed to chose two of them, we use exponents in order to find the number of permutations M, $M=Num_Selections^{N_Choices}$

If we need to have 100 different options, what is the minimum number of choices to create unique codes for all 100 people?

We can find this out by finding the lowest exponent > 100 (2^7)

To preform 2 compliment on a number from decimal we do the following: Input −41, use 12-bit representation.

Convert number to binary

41: 000000101001 (12-bit as question specifies)

Next flip bits to get 1's Complement

41:111111010110

Then finally add 1 to get 2's complement

Result: 111111010111 == -41

If we want to convert Hexidecimal to Decimal we can achieve this by using the following method:

Take $0 \times 0 \text{AB}$ as an example, we know that A = 10, and B = 11, then multiply these by 16^{index}

$$10 \times 16^1 + 11 \times 16^0 = 171_{10}$$