



Fog Machine XF-11 User Guide



Please Read These Instructions Carefully Before Use

PACKAGE INCLUDES

Open the carton and check whether all necessary spare parts include accord the specification list. Please contact us if there is something missed.


- Machine Body: 1 PC
- Iron Handle: 1 PC
- Wireless Remote: 1 PC
- Power Cable: 1 PC
- Screws: 2 Sets
- User Guide: 1 PC

TECHNICAL SPECIFICATIONS

- Voltage: AC 90-130 Volts 50/60 Hertz
- First Warm-up time: 3-4 minutes
- Tank Capacity: 1.3 liters
- Power: 1500 Watts
- Output distance: 6-8m/20-30 ft
- Weight: 5.9 kg/ 13 lbs

OPERATION


1. First, install the iron handle and tighten the screws.
2. Before connecting this unit to the mains power supply for the first time you must first fill the fluid tank with fog fluid and check that the nozzle is clean and unobstructed.
3. Plug in the manual control and connect the power cord. This fog machine has been designed to function on a mains power supply of 90-130V~50/60Hz and has been fitted with a suitable power plug for use with your local voltage. Check the label on the unit and the power plug for the correct voltage.



4. Press the power switch and the machine starts to preheat. The LCD screen shows that the temperature is rising. When the temperature reaches above 280 degrees Celsius, the machine preheating is complete, and the LCD screen will display "FOG".
5. After the machine has finished preheating, you can use the wireless remote to turn the fog on or off. You can also press the **ENTER** button to operate the machine in a timed mode. Additionally, you can connect a DMX console to control the machine.

MENU SETTINGS

1. **DMX Address Setting:** Press the **MENU** button and select the DMX address setting page. The LCD screen will display "dXXX". Press the ▲ and ▼ buttons to set the DMX address parameters within the range of 001-512. The settings will be automatically saved upon completion.



2. **Set the Interval Time for the Timer Mode:** Press the **MENU** button and select the interval time setting page. The LCD screen will display "bXXX". Use the ▲ and ▼ buttons to set the interval time parameters within the range of 001-900 seconds. The settings will be automatically saved upon completion.



3. **Set the Duration Time for the Timer Mode:** Press the **MENU** button and select the duration time setting page. The LCD screen will display "PXXX". Use the ▲ and ▼ buttons to set the interval time parameters within the range of 001-900 seconds. The settings will be automatically saved upon completion.



4. **Smoke Volume Setting:** Press the **MENU** button and select the smoke volume setting page. The LCD screen will display "Axxx". Use the ▲ and ▼ buttons to set the interval time parameters within the range of 001-100. The settings will be automatically saved upon completion.



WIRELESS REMOTE

1. Button : Smoke On
2. Button : Smoke Off
3. Button ▲ : Smoke volume increases. Each press increases by 20%.
4. Button ▼ : Smoke volume decreases. Each press decreases by 20%.



OTHER TIPS:

1. When the DMX console is connected to the machine, the letter 'F' will flash on the LCD display as a prompt.
2. This machine has only one DMX channel to control the smoke and smoke volume. Channel values from 0-10 indicate the smoke is off, while values from 10-255 indicate the smoke is on, with the smoke volume gradually increasing.
3. Once the machine has finished preheating, press the ENTER key to enter the timer mode. Press the ENTER key again to exit the timer mode.
4. The waterproof rating of this machine is IPX2, which means it is protected against vertically falling water drops. Please use caution when operating it outdoors in heavy rain.
5. This machine has cooling vents at the bottom of the case, resulting in slower heat dissipation. After using the machine, please wait for the temperature to return to normal before storing it to avoid damage.

CAUTION

1. Do not obstruct the nozzle. Fog output is of the nozzle during operation. Never aim the nozzle directly at people or naked flames.
2. Danger of burns. Keep out of reach of children. Do not leave machine unattended.
3. Output nozzle becomes very hot during operation(300 degree).Keep flammable materials at least 50cm(20").away from the nozzle.
4. The item does not include fog fluid. You will need to purchase your own. Any water-based fog fluid will work for this fog machine.
5. This fog machine can also be used to sanitize your home or car. By adding a disinfectant to the tank and mixing a specific percentage of water, the fog machine can atomize the disinfectant solution for effective disinfection.
6. Never drink fog liquid. If it's ingested, call a doctor immediately. If fog fluid comes into contact with skin or eyes, rinse thoroughly with water.
7. All fog machines may splutter small amounts of fog occasionally during operation and for a minute or so after being turned off.
8. Always allow the fogger to cool down before cleaning or servicing.
- 9.After every 40 hours of continuous operation or when the machine will be idle for a long time it is recommend to run a cleaning solution composed of 80% distilled water and 20% white vinegar through the system to prevent the accumulation of particles in the heating element.
- 10.Cleaning your fog machine regularly will help reduce costly parts replacement and repair charges.
11. The body of the unit may be cleaned with a dry cloth and store dry.
12. No user serviceable parts inside, please refer to us for service.
13. If you experience low output, pump noise or no output at all, unplug immediately. Check fluid level, the external fuse, remote connection and main power supply, if all appear to be ok, plug the unit in again. If fog does not come out after holding the remote control button for 30 seconds, check the hose attached to the tank to make sure there is fluid going through the hose. If you are unable to determine the cause of the problem, do not simply continue to push the remote control button as this may damage the unit, contact us for servicing.
14. We would greatly appreciate it if you could share your user experience under our product listing to help others who are interested in purchasing this item. If you have any questions or concerns about this product, please make sure to email our customer service at **xuanwupower@163.com** first to save your valuable time.