User Manual

FAQ Document on Film Equipment

1. Cameras

Q1: What are the different types of film cameras? **A:** The main types are digital cinema cameras, DSLRs, mirrorless cameras, and camcorders.

Q2: How do I choose the right camera for my film project? **A:** Consider factors such as resolution, sensor size, lens compatibility, and budget.

Q3: How do I maintain my camera? **A:** Regularly clean the lens, sensor, and body. Use appropriate cleaning tools and store the camera in a dry, dust-free environment.

2. Lenses

Q1: What are the different types of lenses used in filmmaking? **A:** Common types include prime lenses, zoom lenses, wide-angle lenses, telephoto lenses, and macro lenses.