

Exhaustive Technical Analysis of Refrigerant Charge Verification and Adjustment Protocols in HVAC/R Systems

The verification, adjustment, and precise calibration of refrigerant charge represent the most critical, yet frequently mishandled, thermodynamic procedures in the commissioning and maintenance of Heating, Ventilation, Air Conditioning, and Refrigeration (HVAC/R) systems. A vapor-compression cycle operates as a carefully balanced ecosystem of mass flow, phase changes, and heat transfer. The exact mass of the circulating refrigerant dictates the thermodynamic limits of this cycle. Minor deviations from the manufacturer's specified charge mass cascade through the system, fundamentally altering volumetric efficiency, latent heat capacity, compressor motor cooling, and internal oil return mechanics.

Historically, technicians have relied on rudimentary heuristics and rules of thumb to adjust system charge. However, the advent of high-efficiency scroll compressors, electronically commutated motors, micro-channel heat exchangers, and Variable Refrigerant Flow (VRF) architectures has rendered these legacy methods obsolete. Today, charge verification requires a rigorous, mathematically grounded approach utilizing digital psychrometrics, mass-based gravimetric weighing, and proprietary OEM software interfaces.

This comprehensive technical report examines the quantified performance impacts of improper refrigerant charge, details the exhaustive application of empirical charging methodologies—including gravimetric, superheat, subcooling, and approach temperature methods—and provides an in-depth breakdown of manufacturer-specific digital commissioning protocols for modern VRF architectures. Furthermore, this analysis explores the thermodynamic nuances of zeotropic blends and outlines the severe systemic consequences of common field errors.

1. The Physics, Economics, and Environmental Impact of Charge Verification

The assumption that an HVAC system's performance and efficiency degrade linearly with the loss of refrigerant is a fundamental thermodynamic fallacy. The impact of charge deviation on the Seasonal Energy Efficiency Ratio (SEER), the Heating Seasonal Performance Factor (HSPF), and overall sensible cooling capacity follows a distinct, highly accelerated polynomial curve, where specific mass thresholds trigger precipitous drops in operational viability.

1.1 Thermodynamic Tipping Points and Efficiency Curves

Extensive laboratory testing documented by the Department of Energy (DOE) and the American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE) reveals a non-linear relationship between the circulating refrigerant mass and the resulting energy

efficiency.¹ As the refrigerant charge drops, the system's coefficient of performance (COP)—the ratio of useful cooling output to electrical energy input—begins to fall sharply, forcing the compressor to run longer and consume exponentially more electricity to maintain the same environmental comfort level.²

For residential and light commercial systems utilizing a fixed orifice metering device without a suction line accumulator, a reduction to 75% of the factory-specified refrigerant charge (equivalent to a 25% undercharge) yields an immediate 15% reduction in overall energy efficiency, subsequently decreasing the SEER value by 20%.³ When the charge level drops further, the efficiency penalties multiply. At a 60% charge level (a 40% undercharge), the SEER ratio plummets by a catastrophic 46%.³

This degradation marks a critical thermodynamic tipping point, typically occurring when a system loses more than 20% of its total charge.² At this threshold, the system can no longer maintain a saturated liquid seal at the expansion device. Consequently, subcooling drops to zero, and uncondensed hot gas bypasses the condenser coil, entering the evaporator. This "flash gas" occupies critical internal volume without providing any latent heat of vaporization, devastating the cooling capacity.

Conversely, overcharging a system also yields severe efficiency penalties, though the degradation curve differs. Studies have noted a "cross-over" point on performance curves at approximately 96% of the correct charge.⁴ Below this 96% charge level, higher outdoor temperatures produce greater capacity than low outdoor temperatures. However, above a 96% correct charge, higher outdoor ambient temperatures produce lower overall capacities due to the exponential rise in condensing pressures and the subsequent increase in compressor power consumption.⁴

The financial implications of these efficiency losses are severe and compound annually. An efficiency loss of just 10% to 20% can quietly add \$72 to \$144 to an average residential summer cooling bill based on historical utility averages.² In commercial applications or regions with higher baseline utility rates, a 25% undercharge increases annual operating costs by approximately \$100 per ton of cooling capacity.³ The 40% undercharge scenario results in a staggering estimated annual cost penalty of \$500 per ton, rapidly eclipsing the cost of proper maintenance.³

Degradação da Eficiência e Penalizações de Custo Associadas à Falta de Fluido Frigorígeno



Os dados dos testes demonstram que a eficiência não diminui linearmente com a perda de fluido frigorígeno. Quando um sistema perde mais de 20% da sua carga, cruza um limiar termodinâmico crítico, fazendo com que as classificações SEER despenhem e as penalizações nas faturas disparem.

Fontes de dados: [RMI](#), [Purdue University](#)

1.2 Compressor Reliability and Motor Thermodynamics

Beyond utility costs, incorrect refrigerant charge is the primary catalyst for premature compressor failure. The hermetic compressor relies entirely on the returning suction vapor to cool its internal electric motor windings (the stator). In an undercharged system, the limited mass of refrigerant boils off too early in the evaporator coil, resulting in highly superheated vapor returning to the compressor. This vapor lacks the density and heat capacity to absorb the massive thermal load generated by the motor. Consequently, the internal winding

temperatures soar, leading to the thermal breakdown of the motor's dielectric insulation, acid formation in the polyolester (POE) or mineral oil, and eventual electrical short-circuiting (a "burnout").

Conversely, overcharging a system floods the condenser, driving up head pressures and forcing the compressor to push against extreme compression ratios. This mechanical strain degrades the compressor's scroll sets, valves, and bearings. More critically, an overcharge destroys the superheat buffer in the evaporator, allowing liquid refrigerant to travel down the suction line. Compressors are strictly vapor pumps; attempting to compress an incompressible liquid results in hydraulic slugging, which violently shatters internal components and washes the critical lubricating oil film away from the mechanical bearing surfaces.

1.3 The Myth of "Topping Off" and ASHRAE 15 Compliance

A pervasive, deeply entrenched, and highly detrimental practice in the HVAC service industry is the routine "topping off" of refrigerant during seasonal maintenance calls. A vapor-compression system is a hermetically sealed, closed-loop circuit; it does not consume, burn, or metabolize refrigerant over its operational lifespan.⁵ If a system requires additional charge, a physical leak exists in the copper piping, the coil matrices, or the brazed joints. Continuing to add refrigerant without utilizing electronic leak detectors or nitrogen isolation tests to locate and repair the leak presents significant environmental and legal consequences. The Intergovernmental Panel on Climate Change (IPCC) estimates a 1% to 10% annual emission rate for small residential and commercial air conditioning systems, contributing substantially to global greenhouse gas inventories and ozone depletion.⁶

Furthermore, simply adding a "drop-in" replacement refrigerant to an existing leaking system triggers stringent compliance requirements under ASHRAE Standard 15. This standard establishes strict safeguards for the design, construction, and modification of mechanical refrigeration systems.⁷ Changing or substituting a refrigerant with a different safety designation fundamentally alters the system's risk profile. Standard 15 dictates that such modifications require validation of the Effective Dispersal Volume Charge (EDVC).⁹ The EDVC calculates the maximum allowable mass of refrigerant in an independent circuit based on the volume of the occupied space, ensuring that the Lower Flammability Limits (LFL), toxicity thresholds (OEL), and Refrigerant Concentration Limits (RCL) are not breached in the event of a catastrophic, total system release.⁹ Failing to repair leaks and simply topping off with newer A2L (mildly flammable) refrigerants without calculating the EDVC is a severe violation of mechanical codes and safety protocols.

2. The Gravimetric Weighing Method: The Standard of Precision

The gravimetric method, universally referred to as the "weigh-in" method, is the most precise, empirical, and definitive charging protocol available to an HVAC technician. By relying entirely on the mass of the fluid, it completely eliminates the environmental variables of ambient temperature, unpredictable airflow restrictions, and latent heat loads that routinely confound pressure-temperature methodologies.

2.1 Absolute Requirements for Gravimetric Charging

While pressure-based methods are suitable for routine verification, the gravimetric method is unconditionally required in specific, high-stakes diagnostic and repair scenarios:

1. **Compressor Replacement or Major System Repair:** Following the replacement of a primary component—such as a compressor, reversing valve, filter drier, or evaporator coil—the system must be sealed, pressure-tested with oxygen-free nitrogen, and evacuated to a deep vacuum of 500 microns or below. Once the deep vacuum is achieved, the virgin refrigerant charge must be weighed in exactly according to the factory nameplate.¹¹
2. **System Contamination:** If diagnostic testing reveals the presence of non-condensable gases (air), moisture, or acid in the oil, the entire charge is compromised. The remaining refrigerant must be fully recovered, the system flushed with an approved solvent, dehydrated via deep vacuum, and a fresh charge weighed in.
3. **Unknown Current Charge Level in Micro-Channel Coils:** Modern high-efficiency systems frequently utilize micro-channel aluminum condenser coils. These heat exchangers have an exceptionally small internal volume compared to traditional copper tube-and-fin designs. Because the volume is so minimal, standard subcooling methods are dangerously sluggish; adding just a few ounces too many can cause head pressures to skyrocket instantly, resulting in severe overcharging before analog gauges even register a change. Weighing the charge from an empty state is the only reliable method for these architectures.
4. **Zeotropic Blend Fractionation:** If a system operating on a zeotropic blend (such as R-407C or R-410A) has suffered a significant leak originating from the vapor phase, the remaining chemical composition has likely fractionated. The residual fluid inside the system no longer matches the intended pressure-temperature curve. The compromised charge must be fully recovered into a dedicated cylinder and replaced by weight.¹²
5. **VRF and Multi-Split Base Charging:** Variable Refrigerant Flow systems rely strictly on weighed-in base charges and meticulously calculated volumetric additions based on the precise length of the installed copper piping network.¹³

2.2 Equipment Calibration and Cylinder Handling Safety

To properly execute the gravimetric method, the technician must locate the engineering data plate on the outdoor condensing unit, which specifies the factory-calibrated charge. Proper equipment is paramount. Technicians must utilize a professional digital refrigerant scale with a

high resolution of ≤ 0.1 ounces (or 2 to 5 grams) to prevent microscopic overcharges, which are especially critical in capillary tube systems or small self-contained refrigeration units. During the recovery phase, technicians must use a Department of Transportation (D.O.T.) approved recovery cylinder.⁵ Local and national codes strictly prohibit venting refrigerants into the atmosphere. For appliances containing flammable or A2L refrigerants, the system must be rigorously purged with oxygen-free nitrogen to render the internal piping safe before brazing

or unsealing.¹⁵

When charging by weight, particularly during cold weather or low ambient conditions, the internal pressure of the virgin refrigerant cylinder will drop, equalizing with the system pressure and severely impeding the flow of refrigerant into the liquid line. Technicians must handle cylinders safely; under no circumstances should open flames or unapproved heat sources be used to elevate internal tank pressure. Instead, technicians must utilize approved, thermostatically controlled cylinder warming blankets to safely increase vapor pressure, or carefully meter liquid refrigerant into the suction line while the system is running, ensuring it flashes to vapor before hitting the compressor.

2.3 Line Set Mathematics and EPA Documentation

The baseline factory charge printed on the nameplate typically accounts for the internal volume of the outdoor condensing unit, a matching indoor evaporator coil, and a standard length of line set (frequently standardized at 15 linear feet).¹¹ If the actual physical line set installed at the site exceeds this standard length, an additional mathematical adjustment must be made by the technician, calculating the internal volume of the extra copper pipe.

For example, a common residential 3/8-inch outer diameter (O.D.) liquid line typically requires an additional 0.6 ounces of refrigerant per linear foot beyond the factory 15-foot baseline.¹¹ In

metric VRF applications, specific multipliers are provided by the manufacturer. A $\Phi 6.35$ mm

(1/4") liquid line might require an addition of 0.022 kg per meter, while a larger $\Phi 9.52$ mm (3/8") line demands 0.057 kg per meter.¹⁴

Following the weigh-in procedure, proper charge documentation is required. The technician must log the exact amount of recovered refrigerant and the precise mass of the newly weighed-in charge. This documentation is critical for EPA compliance, refrigerant tracking, and establishing a baseline for future service calls, ensuring that the system's mass balance is historically traceable.

3. The Superheat Method: Dynamic Calibration for Fixed Orifice Systems

The superheat charging method is empirically designed and exclusively reserved for HVAC systems utilizing a fixed metering device, such as a piston, restrictor, or capillary tube. Because a fixed orifice has no moving mechanical parts or sensing bulbs to modulate the flow of refrigerant based on the thermal load, the amount of liquid refrigerant entering and boiling in the evaporator is directly and passively proportional to the indoor heat load and the outdoor ambient condensing pressure.

3.1 Latent Heat, Sensible Heat, and Evaporator Thermodynamics

Superheat is defined thermodynamically as the sensible heat added to the refrigerant vapor *after* it has completely boiled out of its saturated liquid state inside the evaporator coil.¹⁶ Inside the evaporator, the refrigerant absorbs heat from the return air, causing the fluid to undergo a

phase change (boiling) at a constant temperature (the saturation point).¹⁷ Once every molecule of liquid has evaporated, any additional heat absorbed by the vapor raises its physical temperature above the saturation point. This temperature increase is the superheat. Maintaining a specific margin of superheat is the only mechanical safeguard that ensures 100% pure vapor enters the suction line, fundamentally protecting the compressor from the catastrophic damage of liquid slugging.¹⁸ A superheat of 0°F indicates that liquid is actively exiting the evaporator and traveling toward the compressor.¹⁸ Conversely, an abnormally high superheat indicates that the evaporator coil is starved of refrigerant, boiling off too early and drastically reducing the system's latent heat removal capacity.¹⁸

3.2 Executing the Target Superheat Calculation

Because fixed orifice systems cannot automatically regulate mass flow, their target superheat fluctuates continuously with environmental conditions. A technician cannot rely on a static, universal rule-of-thumb target (e.g., "always charge to 12 degrees of superheat"). If the outdoor temperature rises, head pressure increases, forcing more refrigerant through the fixed orifice and lowering the superheat. If the indoor heat load drops, less refrigerant boils, causing liquid to travel further through the coil, also lowering the superheat.

Therefore, the target superheat must be calculated precisely at the exact moment of service, utilizing the indoor latent and sensible heat loads alongside the outdoor ambient temperature. This dynamic target is derived using the established industry psychrometric formula:

$$TargetSuperheat = \frac{(3 \times WB) - 80 - DB}{2}$$

Where:

- **WB (Wet Bulb):** The indoor return air wet-bulb temperature. This is the most critical variable, as it represents the total enthalpy of the air—both the sensible heat (temperature) and the latent heat (humidity).⁵ Moisture in the air requires massive amounts of energy to condense, profoundly affecting the boiling rate of the refrigerant.
- **DB (Dry Bulb):** The outdoor air dry-bulb temperature entering the condenser coil, which dictates the high-side condensing pressure.¹⁸

If the calculation yields a negative number, or a number below 5°F, the ambient conditions are generally too cold or the indoor load too low to accurately and safely charge the system using this method. Alternatively, technicians utilize a manufacturer-provided sliding superheat chart or modern digital manifold gauges equipped with onboard psychrometric algorithms to determine this target dynamically.

3.3 Field Procedures, Sensor Placement, and the 15-Minute Rule

Executing the superheat method requires meticulous adherence to procedural steps to avoid false readings:

1. **Airflow Verification:** Before attaching any pressure gauges, the technician must verify that the indoor airflow is correct (typically calibrated to 350-400 CFM per ton of cooling)

and that the air filter, blower wheel, and evaporator coil are completely clean.¹⁸ Low airflow severely limits heat transfer, artificially depressing the superheat and tricking the technician into a false diagnosis of an overcharge.¹⁸

2. **Measurement Points:** The technician attaches the low-loss fitting of the low-side manifold gauge to the true suction service valve at the outdoor unit. A high-precision digital pipe-clamp thermocouple is attached to the copper suction line within 6 inches of the compressor inlet.¹⁹ Crucially, this temperature sensor must be heavily insulated from the ambient air and direct sunlight to ensure it is reading the true temperature of the copper pipe, not the surrounding environment.¹⁹
3. **Data Acquisition:** The saturation temperature is read from the low-side pressure gauge (Suction Saturation Temperature or SST).¹⁶ The actual physical line temperature is read from the thermocouple.
4. **Calculation:** Actual Superheat = Suction Line Temperature - SST.
5. **Adjustment and The 15-Minute Rule:** If the actual measured superheat is *higher* than the calculated target superheat, the evaporator is starved, and refrigerant must be **added** to the system. If the actual superheat is *lower* than the target, the evaporator is flooded, and refrigerant must be **recovered**.
 - Refrigerant must be adjusted slowly, in small volumetric increments of 2 to 4 ounces.
 - Following any adjustment, the technician must enforce the **15-Minute Rule**. The system must be allowed to run continuously for a minimum of 10 to 15 minutes without interruption.¹⁸ This stabilization period is mandatory; it takes time for the new mass of refrigerant to circulate, for the expansion process to reach a new equilibrium, and for the indoor latent load (humidity) to respond to the changing coil temperature. Taking a reading before 15 minutes will result in "chasing the charge" and inevitable system miscalibration.

4. The Subcooling Method: Regulating TXV and EEV Architectures

For HVAC systems equipped with a Thermostatic Expansion Valve (TXV) or an Electronic Expansion Valve (EEV), the superheat method is thermodynamically invalid as a charging metric. A TXV is an active, modulating mechanism designed specifically to maintain a constant, pre-set evaporator superheat (typically factory-calibrated between 10°F and 15°F) regardless of the indoor heat load or the total system refrigerant charge.¹⁸

The TXV accomplishes this via a sensing bulb strapped to the suction line, which exerts pressure against a diaphragm to open or close the valve orifice, continuously hunting for equilibrium. Therefore, adding or removing charge in a TXV system will not significantly alter the superheat reading until the system is so critically starved or flooded that the valve physically runs out of stroke and loses control. To verify charge on these advanced architectures, technicians must evaluate the high side of the system by measuring Subcooling.

4.1 The Mechanics of Liquid Stacking and Valve Modulation

Subcooling is the measurable reduction in temperature of the liquid refrigerant below its

high-side saturation (condensing) point.¹⁸ It represents the sensible heat removed from the refrigerant after it has completely condensed from a high-pressure vapor into a liquid within the lower passes of the condenser coil.

Adequate subcooling is non-negotiable for system performance. It guarantees that a solid, continuous column of dense liquid refrigerant reaches the expansion valve. If the subcooling is zero, the refrigerant is in a saturated state, meaning vapor bubbles (flash gas) are mixed with the liquid. When vapor bubbles reach the orifice of a TXV or EEV, they severely reduce the volumetric mass flow capacity of the valve, causing a dramatic loss of cooling capacity, erratic valve hunting, and an irritating hissing sound in the liquid line. Subcooling essentially acts as a liquid seal, driving efficiency.

4.2 Establishing Baselines from Manufacturer Nameplates

Unlike superheat, the target subcooling does not float dynamically with ambient psychrometric conditions. Instead, the manufacturer heavily engineers the internal volume of the condenser coil to "stack" a very specific amount of liquid under normal operating conditions.

The technician must consult the engineering data plate physically riveted to the outdoor unit to find the exact target subcooling for that specific model. Target subcooling generally ranges from 8°F to 14°F, depending entirely on the SEER rating, the physical size of the condenser, and whether the system utilizes a standard tube-and-fin or a micro-channel heat exchanger.¹⁸

4.3 Condenser Airflow Verification and Field Execution

Executing the subcooling method requires analyzing the high-pressure side of the thermodynamic cycle:

1. **Condenser Assessment:** Before trusting any subcooling reading, the technician must visually inspect and ensure the outdoor condenser coil is thoroughly washed and free of debris (cottonwood, grass clippings, dirt). The condenser fan motor must be operating at the correct RPM, moving the engineered volume of air.¹⁸ A dirty condenser coil severely restricts heat transfer, causing the head pressure to elevate artificially. This lack of heat rejection means the liquid does not cool down, resulting in an artificially low subcooling reading. If a technician fails to clean the coil and trusts this false low reading, they will mistakenly add refrigerant, creating a dangerous and potentially catastrophic overcharge.⁵
2. **Measurement Points:** The technician attaches the high-side manifold gauge to the liquid line service valve. A precision temperature clamp is attached directly to the liquid line, ensuring maximum surface contact and insulated from radiant solar heat.¹⁸
3. **Calculation:** The technician reads the Condensing Saturation Temperature from the high-side pressure gauge. They then subtract the actual measured liquid line temperature.

$$\textit{Subcooling} = \textit{SaturationTemperature} - \textit{LiquidLineTemperature}$$

4. **Adjustment:**

- If the actual measured subcooling is *lower* than the manufacturer's target, the condenser is not stacking enough liquid, meaning the system is undercharged. Refrigerant must be **added**.
- If the actual subcooling is *higher* than the target, excessive liquid refrigerant is backing up into the condenser, occupying valuable heat-transfer surface area and driving up head pressure. Refrigerant must be **recovered**.
- Similar to the superheat method, technicians must allow 10 to 15 minutes of uninterrupted run time for the system temperatures to stabilize after any volumetric adjustment before taking final validation readings.¹⁸

5. The Approach Temperature Method: Assessing Heat Exchanger Efficiency

The Approach Temperature Method evaluates the fundamental efficiency of a heat exchanger by comparing the physical temperature of the refrigerant fluid exiting a coil against the temperature of the ambient environmental medium entering it.²⁰ While often used as a powerful secondary diagnostic metric to judge coil health and fouling, it is explicitly mandated as a primary charging method by specific OEM manufacturers, most notably Lennox Industries.¹⁸

5.1 Condenser Approach: The CTOA Estimation Technique

The condenser approach temperature is strictly defined as the temperature difference between the liquid refrigerant leaving the condenser coil and the outdoor ambient air entering the condenser coil.¹⁸ Because the fundamental thermodynamic purpose of the condenser is to reject internal heat to the outdoor air, the liquid line exiting the coil will always be warmer than the entering outdoor air. The approach value tells the technician exactly *how much* warmer it is.

$$\text{Condenser Approach} = \text{LiquidLineTemperature} - \text{EnteringOutdoorAirTemperature}$$

A smaller approach temperature difference indicates a highly effective heat transfer process, meaning the condenser is easily shedding heat into the atmosphere.²² When these values start to rise, it is often a critical red flag that the condenser is under strain—consuming more energy to do the same amount of work, likely due to fouled tubes, non-condensable gases in the circuit, or restricted airflow.²⁰

Estimating the Target Approach: In scenarios where a manufacturer does not print an exact approach value on the unit's nameplate, an expert technician can estimate the target approach by evaluating the system's designed Condensing Temperature Over Ambient (CTOA) metric.¹⁸ As federal system efficiencies (SEER ratings) have mandated larger and more efficient designs over the decades, condenser coils have physically enlarged to reject heat more effectively at much lower temperature differentials.

- **6 – 10 SEER** (Pre-1991 Equipment): 30°F CTOA ¹⁸
- **10 – 12 SEER** (1992 – 2005 Equipment): 25°F CTOA ¹⁸

- **13 – 15 SEER** (2006 – Present): 20°F CTOA ¹⁸
- **16+ SEER** (2006 – Present): 15°F CTOA ¹⁸

By subtracting the nameplate design subcooling value from the system's corresponding CTOA, the technician isolates the estimated approach target. For instance, a modern 14 SEER system operating with a design subcooling of 13°F and a 20°F CTOA yields a calculated target approach of 7°F ($\pm 3^\circ\text{F}$).¹⁸

5.2 Lennox-Specific Protocols and Ambient Constraints

Lennox requires utilizing the approach method specifically to verify charge when the outdoor ambient temperature is $\geq 65^\circ\text{F}$ (18.3°C).²¹ Standard Lennox high-capacity units often dictate extremely tight approach values constrained between 5°F and 9°F, depending on the exact model match of the indoor and outdoor units.²³

If the outdoor temperature falls below 65°F, the heat transfer rate is too rapid, and the pressures will drop too low to properly evaluate the approach. In these low-ambient conditions, the technician must artificially restrict the condenser airflow (e.g., by safely blocking equal sections of the louvered intake panels with cardboard) to drive the high-side liquid pressure up into the 325–375 psig (2240–2485 kPa) range. This simulates a heavy summer thermal load, allowing the approach values to stabilize correctly for accurate charging.¹¹


5.3 Evaporator Approach (DTD) in DX and Refrigeration Systems

While primarily utilized as a deep diagnostic metric in medium and low-temperature refrigeration (e.g., walk-in freezers), the evaporator approach—often referred to as the Design Temperature Difference (DTD)—measures the thermal differential between the indoor return air temperature entering the coil and the low-side Saturated Suction Temperature (SST) of the refrigerant boiling inside the coil.¹⁶

In a perfectly calibrated standard residential Direct Expansion (DX) air conditioning system pulling the standard 400 CFM of air per ton of cooling, the empirical rule of thumb holds that the DTD should be approximately 35°F.¹⁸ Therefore, if a home is 75°F indoors, the refrigerant should be boiling at roughly 40°F (75°F – 35°F).¹⁹

Deviations from this evaporator approach indicate severe airflow restrictions or massive charge imbalances. For instance, if the DTD stretches to 45°F, it indicates an abnormally low suction pressure, pointing toward a starved coil (undercharge), a failing expansion valve, or a severely restricted air filter. In commercial refrigeration applications, the target DTD is significantly tighter; walk-in coolers generally aim for a 10°F DTD ($\pm 3^\circ\text{F}$) to maintain high humidity levels and prevent the dehydration of stored food products.¹⁶

Matriz de Decisão para Seleção de Métodos de Verificação de Carga de Fluido Frigorígeno



A seleção do método correto de verificação de carga requer a identificação do dispositivo de expansão, da arquitetura do sistema (inverter vs. estágio único) e das condições ambientais. A aplicação de um protocolo incorreto resultará numa calibração incorreta e severa do sistema.

Fontes de dados: [HVAC RSchool](#), [Lennox \(Doc 1\)](#), [Lennox \(Doc 2\)](#), [LG](#)

6. Manufacturer-Specific Digital Protocols: VRF and VRV Architectures

Traditional analog gauge-based charging protocols are rendered entirely obsolete by the complex control architecture of modern Variable Refrigerant Flow (VRF) and Variable Refrigerant Volume (VRV) systems. These sophisticated networks utilize variable-frequency, inverter-driven compressors paired with vast, multi-zone networks of Electronic Expansion

Valves (EEVs) located on both indoor branch boxes and outdoor units.²⁴

6.1 The Inverter Problem and the Necessity of Steady-State Forcing

Because the VRF compressor speed modulates continuously (ramping up and down in precise hertz increments) to match the real-time partial thermal load of the building, and the EEVs constantly alter their pulse counts to dynamically redefine superheat across dozens of indoor coils simultaneously, the entire system never naturally reaches a traditional thermodynamic steady-state baseline.

Attaching standard analog gauges to a VRF system provides wildly fluctuating, erratic, and ultimately uninterpretable pressures. Therefore, charge verification, leak diagnostics, and commissioning require bypassing the system's dynamic adaptive control loop. The technician must use proprietary manufacturer software interfaces to artificially lock the system into a high-frequency, steady-state test mode, forcing the pressures to stabilize long enough to evaluate the mass flow.

6.2 Daikin: D-Checker Diagnostics and Mode [2-20] Charging

Daikin's VRV architecture requires the use of their proprietary **D-Checker** software (or the Bluetooth BTSC/i2S module) for deep system diagnostics.²⁵ The D-Checker interface allows technicians to monitor live EV pulse data, compressor hertz, subcooling degrees, and up to 59 different thermistor points simultaneously across the network.²⁶

However, to physically verify or adjust the charge, the technician cannot rely passively on the software interface alone; they must interact physically with the main Printed Circuit Board (PCB) inside the outdoor unit. Daikin employs a highly specific "Mode 2" field setting protocol. By carefully navigating the BS1, BS2, and BS3 push buttons on the outdoor unit PCB and observing the 7-segment display, the technician activates setting [2-20] = 1.²⁸ This initiates the **Manual Refrigerant Charge Mode**.

Once initiated, the inverter locks into a fixed, high-capacity cooling mode, intentionally driving the suction pressure down to facilitate rapid refrigerant intake. The technician then opens the refrigerant cylinder to the designated charge port (Valve A or B, depending on the chassis type) and weighs in the precisely calculated trim charge.²⁸ Once the exact calculated mass is achieved on the digital scale, the technician must close the valve and push the BS3 button to manually terminate the procedure and return the system to adaptive control.²⁸ If left unattended, the internal logic will automatically abort the charging mode after 30 minutes as a safety precaution.²⁹

6.3 Mitsubishi Electric: M-NET, Maintenance Tool, and Commissioning

Mitsubishi Electric's CITY MULTI systems rely fundamentally on the M-NET transmission line for communication. Diagnostics and charge verification are executed through the powerful **Maintenance Tool** (MTools) software interface.³⁰ The technician connects their laptop to the system using the PAC-USCMS-MN-1 (MN Converter), interfacing locally via USB or RS-232C directly into the M-NET terminal block (TB3 or TB7).³²

(Note: In field vernacular, some technicians mistakenly refer to the commissioning interface

utilizing legacy or generic part numbers, occasionally conflating automotive or generic electronic module terms such as "MCC" or "1699".³⁵ However, the sole official and required diagnostic interface for Mitsubishi VRF systems is the Maintenance Tool software paired with the MN Converter).

When verifying a system's health, the Maintenance Tool allows the technician to perform extensive online monitoring.³³ To accurately verify performance and validate the charge, the technician forces the system into a test run via the software, deeply observing the specific condenser subcooling parameters and the discharge pipe temperature. Mitsubishi relies heavily on rigorous, precise line-length mathematical formulas to dictate the initial charge. During commissioning, particularly if the system utilizes a Branch Box architecture (such as M-Series or P-Series SMART MULTI systems), technicians must follow the strict rule that these systems often require a baseline addition of 5 lbs of refrigerant, plus meticulous calculations for every foot of liquid line pipe installed.³⁸

6.4 LG: LGMV, DIP Switches, and the Integrated Test Run (ITR)

LG's approach to VRF charging and diagnostics is comprehensively managed through the **LGMV** (LG Monitoring Viewer) software, connecting via a dedicated Wi-Fi module or direct interface cable.³⁹ Mobile LGMV provides technicians with real-time access to every sensor embedded in the Multi V series.⁴⁰

A defining and highly advanced feature of LG's modern Multi V 5 systems is the **Integrated Test Run (ITR)** and the **Refrigerant Auto Charging** function.¹⁵ To initiate charge verification, the technician connects LGMV, utilizes the 7-segment display (SSD) on the Master outdoor unit, and selects the **ID7** function code to initiate the ITR.⁴³ The system will prompt the technician to input the total calculated system refrigerant charge (the sum of the factory charge plus the field-supplied trim charge) exactly in kilograms.⁴³

Unlike older Multi V generations where the technician had to guess the best mode, the Multi V 5 automatically determines whether to run the test in heating or cooling mode based on ambient outdoor thermistor readings.⁴³ Furthermore, if LGMV is unavailable, technicians can manipulate the SW01 DIP switch bank directly on the PCB (setting switches 1, 2, and 7 to ON) to initiate the manual Refrigerant Auto Charging sequence.⁴⁵ LG's Fault Detection and Diagnosis (FDD) algorithms actively monitor this process, outputting codes such as E01 (indicating the system is operating wildly outside rated capacity due to mass flow errors) or confirming normal termination once the system's sensors verify optimal liquid saturation and superheat profiles.¹⁵

6.5 Samsung: S-Checker, S-NET Pro, and AI Refrigerant Monitoring

Samsung utilizes the highly portable **S-Checker** mobile app or the comprehensive **S-NET Pro 2** PC software suite for their DVM systems.⁴⁷ Samsung's advanced DVM S2 systems push the boundaries of charge verification by featuring AI-powered low refrigerant monitoring.⁴⁹ This system utilizes data aggregated from various sensors embedded in both indoor and outdoor units to dynamically and autonomously assess the volume of refrigerant required to maintain optimal performance, displaying real-time warning codes on the PCB if the mass flow begins to

degrade.⁴⁹

During initial commissioning or following major repairs (such as a compressor replacement), technicians heavily utilize the "refrigerant quantity decision function" within the S-Checker interface to accurately calculate trim additions.⁵⁰ Following repairs, the technician initiates an **Auto Trial Operation**.⁵² The DVM system modulates autonomously through a rigorous 50-minute testing sequence, evaluating subcooling, superheat, and the specific behavior of the EVI (Enhanced Vapor Injection) bypass states.⁴⁷ Upon completion, S-NET Pro automatically generates a formal result report, highlighting any "inspection required" flags pertaining to refrigerant mass imbalances or valve failures.⁴⁷

6.6 Midea/Carrier: Automated Weighing and Factory Charging Tables

Midea and Carrier VRF systems prioritize highly structured pre-installation mathematical calculations over purely adaptive software-driven charging. While the **Carrier VRF Service Technical Tool** provides an excellent graphical interface for system analysis and port check functions⁵³, initial charge validation requires strict, unwavering adherence to factory piping tables.

The total additional refrigerant charge is calculated by mathematically summing the internal volume of all installed liquid lines based on strict diametric multipliers. For example, a $\Phi 6.35$ mm (1/4") liquid line requires exactly 0.022 kg per meter of equivalent length, while a larger $\Phi 9.52$ mm (3/8") line demands 0.057 kg per meter.¹⁴ Following this rigorous mathematical calculation, modern Midea V6 systems offer a highly sophisticated automatic refrigerant charging procedure. The technician connects the refrigerant tank to the outdoor unit and initiates the process; the system's onboard logic monitors the internal high and low-side saturation pressures and automatically halts the filling process when the system detects the thermodynamically optimized charge mass.⁵⁴

7. Zeotropic Blends and Temperature Glide Considerations

The global regulatory phaseout of single-component refrigerants (like the ozone-depleting R-22) and near-azeotropic blends (like the high-GWP R-410A) has ushered the HVAC industry into a new era dominated by complex zeotropic refrigerants. This includes the 400-series blends like R-407C and the new generation of mildly flammable (A2L) refrigerants like R-454B.¹² Verifying the charge on these systems introduces the profound thermodynamic complexity of **Temperature Glide**.

7.1 The Physics of Fractionation in 400-Series and A2L Refrigerants

Unlike single-component refrigerants that boil at a single, consistent temperature, zeotropic blends are formulated mixtures of different refrigerant molecules that possess divergent, independent boiling points.¹² Consequently, they do not boil or condense at a single, sharp temperature inside the heat exchangers.⁵⁵

As the zeotropic refrigerant mixture travels through an evaporator coil, the specific chemical component with the lowest boiling point vaporizes first. As it boils out of the liquid phase, the chemical composition of the remaining liquid physically changes, becoming richer in the higher-boiling-point components. This alters the thermodynamics of the fluid mid-phase change, raising the boiling point of the remaining liquid. This continuous temperature shift across the phase change at a constant pressure is known as the "Temperature Glide".¹² For example, R-407C exhibits a massive, highly significant temperature glide of nearly 10°F, while newer A2L refrigerants like R-454B also exhibit measurable, impactful glides.¹² Because the liquid and vapor phases physically contain different chemical compositions inside a stationary cylinder, **zeotropic blends must exclusively be charged in the pure liquid phase.**⁵⁵ Charging a system with vapor from a zeotropic cylinder will cause immediate "fractionation," selectively drawing off only the high-pressure components and permanently destroying the chemical balance of both the remaining cylinder and the HVAC system itself.

7.2 Navigating Bubble Point and Dew Point Divergence

The presence of a severe temperature glide forces a fundamental change in how HVAC technicians read and interpret analog or digital manifold gauges. For zeotropic blends, two entirely distinct saturation points exist for any given measured pressure:

1. **Bubble Point (Saturated Liquid Temperature):** This is the exact temperature at which a pure liquid first begins to boil, or conversely, the temperature at which the last microscopic vapor bubble condenses back into liquid.¹²
2. **Dew Point (Saturated Vapor Temperature):** This is the exact temperature at which the last drop of liquid boils off entirely into vapor, or conversely, the temperature at which a pure vapor first begins to condense into liquid droplets.¹²

The Mandatory Rule for Technicians:

- When calculating **Subcooling**, the dense liquid side of the system is the reference point. The technician must exclusively use the **Bubble Point** temperature column from the pressure-temperature (PT) chart.⁵⁵
- When calculating **Superheat**, the vaporous suction side of the system is the reference point. The technician must exclusively use the **Dew Point** temperature column from the PT chart.⁵⁵

Failure to respect this critical thermodynamic distinction leads to severe diagnostic errors. For instance, calculating evaporator superheat using the bubble point value on a high-glide refrigerant like R-407C will result in an artificially low or even negative superheat reading.⁵⁶ This false reading will prompt an uneducated technician to mistakenly recover refrigerant from the system, ultimately leaving the evaporator dangerously starved, drastically reducing capacity, and risking catastrophic compressor motor burnout.

8. Diagnostic Matrix: Common Charging Errors and Systemic Consequences

Improper charging manifests in a highly predictable, mathematically defined matrix of thermodynamic symptoms. Recognizing these pressure and temperature patterns prevents

catastrophic mechanical failure and ensures system longevity.

8.1 The Anatomy and Mechanics of an Overcharge

An overcharged system physically holds excess liquid refrigerant in the condenser coil. The condenser's primary job is to provide surface area for vapor to condense into liquid; when it is flooded with excess liquid, it loses the internal volume required to effectively reject heat to the atmosphere.

- **Symptoms:** This loss of heat transfer area drastically and rapidly elevates the condensing (head) pressure. Subcooling will read abnormally high because the massive volume of excess liquid is trapped in the condenser, cooling down further as it sits against the ambient air.¹⁸ In a fixed orifice system, the extreme high-side pressure forces far too much liquid refrigerant through the restrictor into the evaporator, causing the superheat to plummet toward zero. Consequently, the condenser approach temperature will be abnormally low, as the liquid line temperature is forced closer to the ambient air.¹⁸
- **Consequences:** High head pressures force the compressor to operate against extreme compression ratios, skyrocketing the electrical amperage draw and inevitably triggering internal thermal overloads. More dangerously, a superheat reading of zero indicates that raw, unboiled liquid refrigerant is bypassing the evaporator entirely and returning down the suction line to the compressor. Compressors are precision vapor pumps; attempting to compress an incompressible liquid results in catastrophic "slugging." This hydraulic shock shatters internal valves, breaks connecting rods, and washes the critical polyolester (POE) oil film away from the mechanical bearing surfaces, causing total seizure.

8.2 The Anatomy and Mechanics of an Undercharge

An undercharged system simply lacks the physical mass of fluid required to sustain the continuous thermodynamic cycle, failing to provide enough liquid to the metering device to maintain a seal.

- **Symptoms:** Because the system is starved, the suction pressure drops significantly. The minimal amount of liquid refrigerant entering the evaporator coil boils off entirely within the first few passes. The remaining length of the coil acts only to heat the vapor, absorbing excessive sensible heat. This results in an extremely high superheat reading.¹⁸ Conversely, subcooling will be extremely low (often zero) because the condenser is practically empty of liquid. The evaporator approach (DTD) expands wildly, often exceeding 45°F, as the boiling point drops dangerously low.
- **Consequences:** A severe undercharge prevents the system from generating sufficient mass flow velocity to carry the lubricating oil back up the vertical suction lines to the compressor crankcase, causing the mechanical bearings to run dry and seize. Furthermore, the returning refrigerant vapor acts as the primary cooling medium for the hermetic compressor motor windings. An excessively high superheat means hot, thin vapor is returning to the compressor, completely failing to cool the stator. This inevitably burns out the motor windings, turning the internal oil highly acidic and requiring a total,

hazardous system teardown.

8.3 Phase State Violations and Chemical Cross-Contamination

Charging a zeotropic blend in the wrong phase state (vapor instead of liquid), or mistakenly cross-contaminating systems with different refrigerants (e.g., adding R-410A to a system designed for the A2L R-454B), destroys the engineered pressure-temperature relationship of the fluid.¹⁸

Mixing refrigerants creates unpredictable, off-chart operating pressures that completely invalidate the PT charts, rendering all superheat and subcooling calculations useless. Furthermore, cross-contamination often leads to violent chemical reactions with the compressor oil, causing severe acid formation, sludging, and the rapid degradation of copper piping. It instantly invalidates all manufacturer warranties and creates severe, highly illegal safety hazards, necessitating a complete, EPA-mandated hazardous-waste recovery, a deep nitrogen purge, and the total replacement of the system's infrastructure.

Diagnostic State	Suction Pressure	Head Pressure	Superheat	Subcooling	Approach Temp	Primary Mechanical Risk
Optimal Charge	Normal (Design)	Normal (Design)	Target Achieved	Target Achieved	Target Achieved	None (Optimal Longevity)
Severe Overcharge	High	Very High	Very Low / Zero	Very High	Low	Liquid Slugging, Blown Valves
Severe Undercharge	Very Low	Low	Very High	Low	High	Motor Burnout, Seizure, Oil Loss
Liquid Line Restriction	Very Low	Normal / Low	High	High	Low	Starved Evaporator, Freezing
Dirty Condens	Normal / High	Very High	Normal / Low	Low	High	Compressor

er Coil						Thermal Trip, High Amperage
---------	--	--	--	--	--	-----------------------------

Table 1: Matrix of Thermodynamic Symptoms and Diagnostic Indicators.

Final Synthesis

Refrigerant charge verification is not a perfunctory maintenance task; it is the absolute thermodynamic anchor of HVAC/R operational integrity, energy efficiency, and environmental compliance. The rapid shift from low-efficiency baseline systems to complex, inverter-driven architectures utilizing mildly flammable zeotropic blends demands that technicians abandon antiquated heuristics and unscientific "rules of thumb."

Whether executing a highly precise gravimetric weigh-in following a major repair, calculating a real-time dynamic superheat utilizing advanced psychrometrics, aligning subcooling to strict fixed approach temperatures on a high-SEER system, or navigating the dense proprietary digital interfaces of modern VRF networks, absolute adherence to empirical methodologies is non-negotiable. Rigorous charge verification protects the immense financial investment of the end-user, mitigates catastrophic environmental emission risks, and ensures the mechanical longevity of the vapor-compression cycle across its entire designed lifespan.

Referências citadas

1. Measured Effect of Air Flow and Refrigerant Charge on a High-Performance Heat Pump, acessado em junho 13, 2026, https://www.aceee.org/files/proceedings/2008/data/papers/1_734.pdf
2. Why Refrigerant Matters More Than You Think for AC (or Heat Pump) Efficiency - RMI, acessado em junho 13, 2026, <https://rmi.org/resources/why-refrigerant-matters-more-than-you-think/>
3. Impacts of Refrigerant Charge on Air Conditioner and Heat Pump Performance - Purdue e-Pubs, acessado em junho 13, 2026, <https://docs.lib.purdue.edu/cgi/viewcontent.cgi?article=2121&context=iracc>
4. The Impact of Residential Air Conditioner Charging and Sizing on Peak Electrical Demand, acessado em junho 13, 2026, https://www.aceee.org/files/proceedings/1992/data/papers/SS92_Panel2_Paper23.pdf
5. 3.8 evaluating refrigerant charge | nascsp, acessado em junho 13, 2026, https://nascsp.org/wp-content/uploads/2018/02/us-doe_evaluating-refrigerant-charge.pdf
6. Analysis of Refrigerant Use for AC Equipment Maintenance - ASHRAE, acessado em junho 13, 2026, <https://www.ashrae.org/technical-resources/ashrae-journal/featured-articles/october-2022-analysis-of-refrigerant-use-for-ac-equipment-maintenance>

7. ASHRAE Refrigeration Resources, acessado em junho 13, 2026,
<https://www.ashrae.org/technical-resources/bookstore/ashrae-refrigeration-resources>
8. Understanding ASHRAE Standard 15 Requirements for Direct Systems in Comfort Cooling Applications, acessado em junho 13, 2026,
https://ashraemadison.org/images/meeting/090924/Meeting_presentations/understanding_ashrae_standard_15_requirements_for_direct_systems_in_comfort_cooling_application_9_24_.pdf
9. ANSI/ASHRAE Addendum p to ANSI/ASHRAE Standard 15-2019, acessado em junho 13, 2026,
https://www.ashrae.org/file%20library/technical%20resources/standards%20and%20guidelines/standards%20addenda/15_2019_p_20220831.pdf
10. Safety Standard for Refrigeration Systems - ASHRAE, acessado em junho 13, 2026,
https://www.ashrae.org/file%20library/technical%20resources/standards%20and%20guidelines/standards%20addenda/15_2019_g_20220831.pdf
11. INSTALLATION INSTRUCTIONS - Lennox, acessado em junho 13, 2026,
https://www.lennox.com/dA/52c86c54ab/Lennox_AC
12. Temperature Glide in Freon™ MP, Freon™ HP, and Freon™ 407C (R-407C) Series Refrigerant Blends, acessado em junho 13, 2026,
<https://www.freon.com/en/-/media/files/freon/temperature-glide-freon-mp-hp-407c-refrigerant-blends.pdf?rev=42e7a6ee8dbd4006b19a6d8748300aa4>
13. Installation and operation manual, acessado em junho 13, 2026,
https://www.daikin.eu/content/dam/document-library/installation-manuals/ac/vrv/rxytq-tyf/RXYTQ-TYF_IOM_4PEN388987-1_2015_03_Installation%20Manuals_English.pdf
14. Mini Series VRF - Engineering Data, acessado em junho 13, 2026,
<https://mdhome.com.au/wp-content/uploads/2024/07/MDV-V200WN1AU-Mini-VRF-Engineering-Data-0531-1.pdf>
15. Outdoor Unit SERVICE MANUAL - LG Electronics, acessado em junho 13, 2026,
https://media.us.lg.com/m/70d01d6c99887c7f/original/MFL71986707_250725_IM.pdf
16. TD of Refrigeration Evaporators - HVAC School, acessado em junho 13, 2026,
<http://www.hvacrschool.com/td-refrigeration-evaporators/>
17. The Refrigeration Cycle Explained | HVAC Know It All, acessado em junho 13, 2026, <https://hvacknowitall.com/blog/the-refrigeration-cycle-explained>
18. The "Approach" Method of Charging and Condenser Efficiency - HVAC School, acessado em junho 13, 2026,
<http://www.hvacrschool.com/approach-method-charging-condenser-efficiency/>
19. Suction Line Temperature - YouTube, acessado em junho 13, 2026,
<https://www.youtube.com/watch?v=wirQjHsMeEI>
20. Technical Bulletin TB2-048: Importance of Monitoring Chiller Approach Temperatures - Chem-Aqua, acessado em junho 13, 2026,
<https://www.chemaqua.com/fr-ca/wp-content/uploads/sites/5/2024/07/TB2-048.pdf>

21. Extended Charge Procedure Commercial Application - Elite® Series 6 – 20 Ton - Lennox, acessado em junho 13, 2026, <https://www.lennox.com/dA/55d84c4995/508349-02.pdf>
22. 3 Ultimate Steps to Approach Temperature Mastery - Chemstar WATER, acessado em junho 13, 2026, <https://www.chemstarwater.com/approach-temperature/>
23. Extended Charge Procedure Commercial Application - Lennox, acessado em junho 13, 2026, <https://www.lennox.com/dA/403a189a19/508349-01a.pdf>
24. VRF system City Multi VRF | Mitsubishi Electric, acessado em junho 13, 2026, <https://www.mitsubishi-les.com/en-de/null-9860.html>
25. Daikin: How to use your D-Checker – Setup & Operation - YouTube, acessado em junho 13, 2026, https://www.youtube.com/watch?v=tW-sLKpc_no
26. Service tooling info, acessado em junho 13, 2026, https://www.daikin.eu/en_us/qr/7.html
27. D-checker User Manual, acessado em junho 13, 2026, <https://daikinspare.com.ua/download/dchecker/User%20Manual%20D-Checker%20v3400%20EN.pdf>
28. Installation manual - Daikin Comfort, acessado em junho 13, 2026, https://daikincomfort.com/docs/default-source/vrv-t-series/im-rweq_tb-4pen739861-2023.pdf
29. VRV System air conditioner - installation manual - daikincomfort.com, acessado em junho 13, 2026, <https://backend.daikincomfort.com/docs/default-source/product-documents/commercial/manual/installation-manuals/3p657316-4.pdf>
30. Software Registration and Updates | Mitsubishi Electric Americas, acessado em junho 13, 2026, <https://us.mitsubishielectric.com/fa/en/support/resources/software-management-and-updates/>
31. MTools-v5.53 - MyLinkDrive by METUS, acessado em junho 13, 2026, https://www.mylinkdrive.com/USA/Software/Troubleshooting_and_Service/Maintenance_Tools/MTools_v553?product
32. Mitsubishi Electric PAC-USCMS-MN-1 Maintenance Tool - Rfwel Engr E-Store, acessado em junho 13, 2026, <https://shop.rfwel.com/mitsubishi-electric-pac-uscms-mn-1-maintenance-tool/>
33. Maintenance Tools for MN converter Mitsubishi Electric CMS-MNG-E, acessado em junho 13, 2026, https://planetaklimata.com.ua/instr/Mitsubishi_Electric/Mitsubishi_Electric_CMS-MNG_Maintenance_Tools_Eng.pdf
34. MANUFACTURED FOR: MITSUBISHI ELECTRIC TRANE HVAC US LLC, acessado em junho 13, 2026, https://www.mitsubishitechinfo.ca/sites/default/files/IM_PAC-USCMS-MN-1_32TB0932X01.pdf
35. QH Clutch cable for Fiat Panda 769cc 1986 - engine 4104780 920 mm | eBay UK, acessado em junho 13, 2026, <https://www.ebay.co.uk/itm/364831864303>
36. Motorcraft HVAC Blower Motor Resistor YH-1699 | AutoZone, acessado em junho 13, 2026,

- <https://www.autozone.com/p/motorcraft-hvac-blower-motor-resistor-yh-1699/80878>
37. 7802A240 OEM Mitsubishi OUTLANDER ECLIPSE CROSS HVAC, acessado em junho 13, 2026,
https://www.ebay.com/itm/137027095620?_skw=blower+motor+control+module&itmmeta=01KH2ZJ9B3DF4JWFXBWKH2MFM6&hash=item1fe7738c44:g:qlMAAeSwjddpir3F&itmprp=enc%3AAQALAAABALB2JXbe%2Bh2pdWBqbR2c2DuQUI74txZ0TSQiU%2FF1xaFsimZ4niO5QXvvP3fln1irTsWmx0BQB2JsljhtchQkpGQFZNk6NO9jouy%2FdaSctHEXNDgpgdiLVThjoVDJJbMhrSkmHOOctO3AA57ciG4W%2BjflcEhVYxsGRGVBBW5QKqORuq78x6l%2FknebPOm0JQLWR9Kc4PoPGQGqERySqlwaSzpvrvtJgzyqAfbCN3WMES9z47XD97MwtK6UVO2fJ8dOHEnfCwGyR%2F6UDX%2Bwj%2FWzxdoyzbKUAi5L3K%2BZhssGcK46UVkuslLkYclFi2Ts27YSWcvJlICfuE%2FxlmyOfPZK6l%3D%7Ctkp%3ABk9SR_6Vyd-IZw
 38. Mitsubishi M series and Maintenance Tool : r/HVAC - Reddit, acessado em junho 13, 2026,
https://www.reddit.com/r/HVAC/comments/xzuoe3/mitsubishi_m_series_and_maintenance_tool/
 39. LGMV User Manual - DMG HVAC, acessado em junho 13, 2026,
https://www.dmgm.com/wp-content/uploads/2020/06/LGMV_Manual_ENG_Versio-n-7.4.5.pdf
 40. MOBILE LG MONITORING VIEW USER MANUAL - Rackcdn.com, acessado em junho 13, 2026,
https://a1ac1dcb67cc9f847a73-0b6da349d0197cd2922796e57d5f1d84.ssl.cf5.rackcdn.com/CMSFiles/PMAssets/PMAssets/Resource/general/1916/UM_MobileLGMV_Android.pdf
 41. LGMV User Manual - LG Klimaat, acessado em junho 13, 2026,
https://www.lgklimaat.be/Media/Downloads/lgm-v-7_manual.pdf
 42. Smarter Solutions for Smarter HVAC Technicians: LGMV | LG Australia Business, acessado em junho 13, 2026,
<https://www.lg.com/au/business/air-solution/air-solutions-blog/smarter-solutions-smarter-hvac-technicians/>
 43. INSTALLATION MANUAL WITH - LG HVAC, acessado em junho 13, 2026,
https://lghvac.com/resource-service?filename=IM_MultiV5_LGRED_OutdoorUnits.pdf
 44. Outdoor Unit SERVICE MANUAL - Rackcdn.com, acessado em junho 13, 2026,
https://a1ac1dcb67cc9f847a73-0b6da349d0197cd2922796e57d5f1d84.ssl.cf5.rackcdn.com/CMSFiles/PMAssets/PMAssets/Resource/general/1211/2011-8-15%20service%20manual_general_multi%20v%20iii%20208v%20heat%20recovery%20unit_mfl67400005_20120105122839.pdf
 45. OPERATION AND MAINTENANCE MANUAL - LG Electronics, acessado em junho 13, 2026,
https://media.us.lg.com/m/532a1f0c47275b65/original/OM_MULTI-V-5-OPERATION-MAINTENANCE-MANUAL_06_24-pdf.pdf
 46. System Heat Recovery Outdoor Unit SERVICE MANUAL R410A - Rackcdn.com, acessado em junho 13, 2026,

- https://a1ac1dcb67cc9f847a73-0b6da349d0197cd2922796e57d5f1d84.ssl.cf5.raccdn.com/CMSFiles/PMAssets/PMAssets/Resource/general/1201/2008-11-16%20service%20manual_general_multi%20v%20sync%20ii%20outdoor%20unit_mfl50459504_20120105122839.pdf
47. DVM S, Standard, Heat Pump R410a, 380~415V, 50Hz, 3Φ, Outdoor Unit - Samsung, acessado em junho 13, 2026,
<https://www.samsung.com/levant/business/system-air-conditioners/vrf-dvm/ac-dvm-amxxxfxvagh-am220fxvagh-tk/>
 48. Samsung DVM S Installation & Start Up Training - Cloudinary, acessado em junho 13, 2026,
<https://res.cloudinary.com/govimg/image/upload/v1594418095/5b294f9467c0d0489028b276/Full%20Color%20DVM%20S%20Installation%20and%20Startup%20Training%20V12302019.pdf>
 49. DVM S2+ - Samsung HVAC, acessado em junho 13, 2026,
https://www.samsunghvac.com/commercial/DVM_S2Plus
 50. DVM S WATER Service Manual.indd - Frigus Systems, acessado em junho 13, 2026,
https://frigus-systems.ru/upload/iblock/702/yruvoyf7e2eioqrsthrzrvh1akujt42m/M anual_AM_MXWANR.pdf
 51. SYSTEM AIR CONDITIONER - Amazon S3, acessado em junho 13, 2026,
https://s3.amazonaws.com/samsung-files/Tech_Files/DVM/DVM+S/Service+Manuals/DVM+S+ODU+Service+Manual_AC-00076E_6_180605.pdf
 52. DVM-S-Eco-installationsmanual-eng.pdf, acessado em junho 13, 2026,
<https://www.essencompany.com/wp-content/uploads/2025/02/DVM-S-Eco-installationsmanual-eng.pdf>
 53. Carrier VRF Catalog, acessado em junho 13, 2026,
<https://www.shareddocs.com/hvac/docs/1001/Public/OC/01-VRF-016-01.pdf>
 54. VRF CATALOG - Carriercca.com, acessado em junho 13, 2026,
https://carriercca.com/pdf/products_pdf/CA_VRF_Platform20250304_250311_095902.pdf
 55. Refrigerant PT Calculator / HVAC Calcs - Jersey Mike HVAC, acessado em junho 13, 2026, <https://www.jerseymikehvac.com/hvac-calcs/refrigerant-pt-calculator>
 56. The Definitive Guide to Temperature Glide, Part 2 | ACHR News, acessado em junho 13, 2026,
<https://www.achrnews.com/articles/147494-the-definitive-guide-to-temperature-glide-part-2>