

Comprehensive Guide to HVAC Energy Auditing and Optimization During Maintenance Service

The built environment is one of the largest consumers of global energy, and heating, ventilation, and air conditioning (HVAC) systems are consistently the most energy-intensive subsystems within these structures. According to extensive survey data, HVAC operations typically account for 40% to 60% of total commercial building energy consumption, vastly outweighing other end-uses such as lighting, domestic hot water, and plug loads.¹ Despite continuous advancements in equipment efficiency standards, digital building automation, and high-performance architectural design, a significant performance gap remains between the theoretical thermodynamic limits of HVAC equipment and its actual operational efficiency in the field.¹

This systemic performance gap is predominantly driven by poor installation practices, inevitable operational drift, and neglected maintenance, all of which manifest as substantial, compounded energy penalties over the lifecycle of the equipment. For facilities managers, maintenance technicians, and energy engineers, routine maintenance services present an invaluable, yet often overlooked, opportunity to conduct concurrent, rigorous energy audits. By leveraging fundamental thermodynamic principles, advanced psychrometric field measurements, and targeted diagnostic protocols, practitioners can identify, quantify, and rectify hidden energy waste.

This comprehensive report provides an exhaustive, expert-level framework for executing HVAC energy audits during routine mechanical service. It covers the fundamental metrics of energy consumption, exhaustive fault diagnostics for common waste streams, advanced field measurement techniques, actionable Energy Conservation Measures (ECMs), detailed financial analysis methodologies, and the rigorous measurement and verification (M&V) protocols required to prove energy savings to stakeholders.

1. HVAC Energy Consumption Fundamentals


A mandatory prerequisite to identifying and quantifying energy waste is establishing a robust foundational understanding of baseline consumption patterns, equipment efficiency metrics, and theoretical performance limits. Without an accurate baseline and a thorough understanding of ideal performance metrics, quantifying the financial impact of system degradation or evaluating the efficacy of a proposed engineering intervention is impossible.

1.1 Macro-Level Energy Baselines and Benchmarking

The Commercial Buildings Energy Consumption Survey (CBECS), administered by the U.S. Energy Information Administration (EIA), provides critical empirical data regarding energy use across the diverse commercial building stock in the United States.³ Organizations utilizing CBECS data can facilitate the benchmarking of a facility's Energy Use Intensity (EUI), typically

expressed in $\text{kBtu}/\text{ft}^2/\text{yr}$ or $\text{kWh}/\text{m}^2/\text{yr}$. EUI is a standardized metric that normalizes total energy consumption against the gross square footage of the building area, allowing for accurate relative performance comparisons across peer groups and building typologies.⁵ Benchmarking reveals that HVAC energy intensity varies significantly depending on the principal building activity and the requisite environmental controls. For instance, the energy requirements in hospitals and healthcare facilities are driven by stringent ventilation codes, continuous 24/7 operation, strict indoor air quality (IAQ) mandates, and rigorous humidity control. This leads to a much higher median EUI compared to educational or warehouse facilities, which feature intermittent occupancy and looser thermal parameters.⁶

Intensidade de Uso de Energia (EUI) Fonte Mediana por Tipo de Edifício Comercial



Os valores medianos nacionais do EUI fonte indicam a intensidade de energia de base para vários tipos de instalações. Edifícios que excedem estes benchmarks exibem frequentemente falhas operacionais graves no AVAC ou manutenção adiada.

Fontes de dados: [ENERGY STAR Portfolio Manager](#), [MEP Academy](#).

Table 1 outlines typical median Source EUI values derived from national datasets, providing

context for what constitutes good, average, or poor performance for various building classifications.⁶

Building Type	Median Source EUI (kBtu/ft²/yr)	HVAC Load Characteristics and Drivers
Hospital (General)	426.9	Continuous operation, 100% outside air requirements in critical zones, strict humidity controls, high internal heat gains from medical imaging equipment. ⁶
Medical Office	232.8	High internal heat gains, elevated ventilation rates compared to standard offices, extended operating hours. ⁶
Hotel / Lodging	208.0	Variable occupancy, continuous operation, high domestic hot water loads, and decentralized cooling systems (e.g., PTACs) that often suffer from poor maintenance. ⁶
Office (General)	167.0	Predictable diurnal schedules, economizer-friendly due to distinct occupied/unoccupied periods, dense plug loads. ⁶
Retail (Non-Refrigerated)	160.0	High lighting loads, variable transient occupancy, large envelope exposures (glazing and frequent door openings). ⁶

K-12 School	153.0	Intermittent scheduling, summer shutdowns, but very dense occupancy ventilation requirements during operating hours. ⁶
Warehouse	~80.0	Minimal conditioning, low occupancy density, massive volume but low thermal demand per square foot. ⁶

When an auditor encounters a standard office building operating at an EUI of 250

$\text{kBtu}/\text{ft}^2/\text{yr}$, the data immediately suggests severe operational anomalies, such as failing economizers, simultaneous heating and cooling, or massive infiltration, prompting a deeper mechanical investigation.⁹

1.2 Understanding Equipment Efficiency Metrics

Evaluating equipment performance in the field requires absolute fluency in standard efficiency metrics. These metrics define the thermodynamic yield of the system relative to its electrical input.¹¹

- **kW Demand and kWh Consumption:** Kilowatt (kW) demand refers to the peak rate of electrical power drawn by the equipment at a specific moment, heavily impacting utility demand charges. Kilowatt-hour (kWh) consumption measures total electrical energy used over time.
- **Coefficient of Performance (COP):** A dimensionless ratio of useful heating or cooling output to the total electrical energy input. It is calculated as:

$$COP = \frac{P_c}{P_w}$$

Where P_c is output cooling power (in Watts) and P_w is input electrical power (in Watts).¹¹ A higher COP indicates greater efficiency. For example, a system with a COP of 3.52 moves 3.52 units of thermal energy for every 1 unit of electrical energy consumed.

- **Energy Efficiency Ratio (EER):** The ratio of cooling capacity (in BTU/hr) to electrical input (in Watts) at a specific peak operating condition (typically 95°F outdoor ambient). EER is calculated as:

$$EER = \frac{\text{Capacity (BTU/hr)}}{\text{Power (Watts)}}$$

Given that $1 \text{ kW} = 3412 \text{ BTU/hr}$, EER and COP are mathematically related:

$$EER = 3.412 \times COP \quad .^{11}$$

- **Seasonal Energy Efficiency Ratio (SEER / SEER2):** An evolution of EER that accounts for seasonal temperature variations, representing total cooling output over a typical cooling season divided by total electrical energy input in watt-hours.¹¹ SEER is critical for residential and light commercial equipment because it accounts for part-load conditions over varying weather.
- **Integrated Part Load Value (IPLV) and Non-Standard Part Load Value (NPLV):** Crucial for large applied systems like chilled water plants, IPLV is defined by AHRI Standard 550/590. Systems rarely operate at 100% design capacity; in fact, a properly sized system is larger than it needs to be 99% of the time, operating primarily at part-load.¹² IPLV weights efficiency across four part-load conditions (100%, 75%, 50%, and 25%) to reflect realistic operation.¹² The IPLV formula is:

$$IPLV = \frac{1}{\frac{0.01}{A} + \frac{0.42}{B} + \frac{0.45}{C} + \frac{0.12}{D}}$$

Where A, B, C, and D represent the efficiency (e.g., kW/ton or COP) at 100%, 75%, 50%, and 25% load, respectively.¹² NPLV is utilized when a chiller is designed for non-standard entering condenser water temperatures.

- **kW/ton:** Common in commercial chilled water systems, this metric indicates the electrical demand (kW) required to produce one ton of cooling ($12,000 \text{ BTU/hr}$). Lower values denote superior efficiency. High-performance, water-cooled magnetic bearing centrifugal chillers can achieve values of $\leq 0.500 \text{ kW/ton}$ IPLV, while older, air-cooled reciprocating machines may exceed 1.2 kW/ton .¹⁵

1.3 Calculating Actual System Efficiency from Field Measurements

Nameplate ratings reflect factory laboratory conditions under perfect installation parameters. Actual field efficiency consistently degrades due to installation variables, aging, and load mismatches. Field calculation of delivered capacity relies heavily on psychrometrics and airflow measurements.¹⁷

To calculate the sensible cooling capacity (Q_s in BTU/hr) of an air-handling unit, the auditor must utilize the following formula:

$$Q_s = 1.08 \times \text{CFM} \times \Delta T$$

Where CFM is the actual cubic feet per minute of airflow, and ΔT is the dry-bulb

temperature differential between return and supply air. The constant 1.08 is derived from the specific heat of standard air ($0.24 \text{ Btu/lb} \cdot ^\circ \text{F}$) multiplied by the density of standard air (0.075 lb/ft^3) and then multiplied by 60 to convert minutes to hours.¹⁸

For latent heat (Q_l), representing moisture removal:

$$Q_l = 0.68 \times \text{CFM} \times \Delta W$$

Where ΔW is the difference in humidity ratio (grains of moisture per pound of dry air), and 0.68 is the latent heat constant derived from the vaporization heat of water.¹⁹

For total heat (Q_t), which accounts for both sensible temperature drop and latent dehumidification, enthalpy (Δh , measured in BTU/lb of dry air) must be obtained using wet-bulb measurements and a psychrometric chart:

$$Q_t = 4.5 \times \text{CFM} \times \Delta h$$

The constant 4.5 is simply the standard air density (0.075) multiplied by 60 minutes .¹⁹

By dividing the calculated total capacity (Q_t) by $12,000 \text{ BTU/ton}$, the actual field tonnage is determined.¹⁸ Comparing this delivered output against the concurrently measured electrical input (using a true RMS power analyzer) yields the actual field EER and COP, which can then be contrasted against nameplate data to precisely quantify capacity degradation and energy loss.¹⁷

2. Common Energy Waste Identification

HVAC systems are highly susceptible to entropy and operational drift. Identifying these modes of failure transforms routine mechanical maintenance into a high-value energy audit. The following subsystems represent the most common and financially detrimental sources of energy waste in commercial buildings.

2.1 The Dirty Coil Energy Penalty

Fouling of evaporator and condenser coils represents one of the most pervasive sources of energy waste. A thin layer of particulate accumulation acts as an insulator, severely retarding heat transfer while simultaneously obstructing aerodynamic flow.²¹

For a condenser coil, fouling restricts the volume of air passing over the fins, forcing the compressor to operate at a higher discharge pressure and elevated condensing temperature to reject the system heat. Empirical research indicates that increasing the condensing

temperature from **95°F** to **105°F** due to fouling reduces cooling capacity by 7% while simultaneously increasing electrical power draw by 10%.²³ Depending on the operating environment, a coil with merely **0.042** inches of fouling can increase overall equipment energy consumption by up to 21%.²⁴ The energy penalty typically increases by 5% to 25% for every year of neglect.²⁴


Similarly, evaporator fouling reduces the boiling pressure of the refrigerant and restricts system airflow, leading to reduced capacity and an elevated risk of coil freezing. Laboratory tests simulating multiple faults have demonstrated that a combination of a 20% blocked evaporator and a 30% blocked condenser can decrease system efficiency by an additional 3% to 9%, demonstrating the compounding nature of deferred maintenance.²⁵

2.2 Incorrect Refrigerant Charge: The Hidden Drain

Improper refrigerant charge—either undercharge from continuous micro-leaks or overcharge from poorly executed maintenance—drastically impairs the thermodynamic cycle. According to the National Institute of Standards and Technology (NIST) Technical Note 1848, improper charge is a dominant fault across the HVAC sector.²⁶ The severity of the energy penalty depends heavily on the type of expansion device utilized: Fixed Orifice (FXO) or Thermostatic Expansion Valve (TXV).²⁸

- **Undercharge:** Reduces the mass flow rate of the refrigerant, leading to low suction pressures, high superheat, and elevated compressor discharge temperatures.²⁹ For FXO systems, undercharge causes a rapid, linear collapse in both cooling capacity and energy efficiency. Conversely, TXV systems are designed to modulate flow to maintain a constant superheat, effectively masking the symptoms of undercharge. In TXV systems, capacity and COP do not collapse significantly until the charge level drops below 70% of the optimal factory charge. At this critical threshold, the TXV opens completely, loses its ability to regulate, and the system behaves like a starved FXO system, suffering massive efficiency degradation.²⁸
- **Overcharge:** Results in excessive liquid refrigerant backing up into the condenser, reducing the effective heat transfer surface area. This causes high head pressures, high subcooling, and reduced superheat, forcing the compressor to consume excess electrical power to overcome the elevated high-side pressure.²⁹ A 30% overcharge can result in a COP degradation on the order of 4%, while a 30% undercharge can degrade efficiency by up to 15%.²⁶

Impacto da Carga Insuficiente de Refrigerante na Eficiência: TXV vs. Orifício Fixo



Sistemas com Válvulas de Expansão Termostática (TXV) mascaram uma subcarga moderada, mantendo a eficiência até a carga cair abaixo de 70-80%. Sistemas de Orifício Fixo (FXO) sofrem uma queda imediata e acentuada na eficiência com qualquer desvio de carga.

Fontes de dados: [US Department of Energy](#)

2.3 Excessive Runtime: Controls and Economizer Failures

Air-side economizers are designed to provide "free cooling" by utilizing outdoor air when ambient temperatures and enthalpy are favorable, shutting down the mechanical compressor. However, mechanical dampers are notorious for failing in either the open or closed position due to broken linkages, seized pneumatic actuators, or sensor drift.²¹

A damper stuck open during extreme summer or winter conditions introduces massive unintended thermal loads, causing severe energy penalties as the system attempts to condition 100% raw outdoor air. Conversely, a damper stuck closed eliminates the free cooling benefit entirely, forcing the compressor to operate during mild weather, drastically inflating runtime

hours. Furthermore, Building Automation System (BAS) setpoints often drift 2°F to 4°F from design intent annually if sensor calibration is neglected, leading to excessive runtime and compromised zone control.²⁴

2.4 Duct Leakage: The Silent Aerodynamic Loss

In ducted systems, air leaks present a severe twofold penalty: the loss of conditioned thermal energy and the wasted aerodynamic work performed by the supply fan. Duct leakage to unconditioned spaces (e.g., attics, drop ceilings, or crawlspaces) bypasses the building envelope entirely.

Duct leakage is quantified using a pressurization test, typically measuring the cubic feet per minute of air that escapes when the ductwork is pressurized to 25 Pascals (CFM_{25}).³¹ The leakage rate is expressed as a percentage of total nominal airflow.³² Research from the Department of Energy indicates that unsealed ductwork can waste 10% to 30% of heating and cooling energy.³³ If an 80,000 BTU system moving 2,000 CFM loses 300 CFM to a crawlspace, the system suffers a direct 15% capacity loss, forcing longer runtimes.³¹ Furthermore, return duct leakage in unconditioned spaces draws in extreme temperatures and humidity, forcing the cooling coil to expend up to 30% of its capacity purely on latent moisture removal rather than sensible space cooling.³²

2.5 Simultaneous Heating and Cooling (Reheat Waste)

Simultaneous heating and cooling is a catastrophic inefficiency common in Variable Air Volume (VAV) systems with terminal reheat. In these configurations, central air handling units cool

incoming mixed air to a fixed supply air temperature (typically 55°F) to ensure adequate dehumidification across the entire building.²³ When a specific perimeter zone does not require maximum cooling, the VAV box modulates down to its minimum airflow position. If the zone temperature drops further, the terminal unit activates a reheat coil (electric or hot water) to

warm the 55°F air back up before it enters the space.²³

The energy waste here is dual-pronged: energy is expended to cool the air at the central plant, and additional energy is immediately expended to reheat it at the terminal unit. This issue is exacerbated when VAV box minimum airflow setpoints are programmed too high. ASHRAE Standard 90.1 aggressively targets this waste by requiring VAV minimums to be reduced to the absolute minimum ventilation requirements (often as low as 20% of design flow) before reheat is permitted to engage.³⁶ Identifying abnormally high VAV minimums or chilled water supply temperatures that are unnecessarily low is a critical audit objective.

2.6 Poor Building Envelope and Infiltration

The efficiency of the HVAC plant is inextricably linked to the integrity of the building envelope. Poor insulation and air infiltration increase the base thermal load the equipment must satisfy.

Heat transfer through the envelope is calculated by the equation $Q = U \times A \times \Delta T$,

where U is the thermal transmittance (the inverse of R-value), A is the area, and ΔT is the temperature difference.¹⁹

Infiltration, driven by wind pressure and the thermal stack effect, introduces unconditioned air through gaps in fenestration, wall joints, and roof penetrations. In cold climates, infiltration not only demands massive sensible heating but also causes severe drafts. In humid climates, infiltration introduces immense latent loads, overwhelming the cooling coil's ability to dehumidify and leading to indoor air quality issues and mold growth.

2.7 Oversized Equipment and Part-Load Penalties

A pervasive issue in the HVAC industry is the intentional oversizing of equipment, often driven by a conservative desire to avoid capacity shortages. However, oversized equipment suffers from severe operational penalties.²⁶

An oversized air conditioner satisfies the sensible temperature setpoint rapidly and shuts off, leading to frequent short-cycling. The primary mechanism for dehumidification (latent cooling) requires the evaporator coil to remain cold and active for extended continuous periods to condense moisture from the air. Short-cycling prevents the coil from effectively removing moisture, resulting in a cold, clammy indoor environment.²⁸ Furthermore, the greatest electrical draw and mechanical wear on a compressor occur during startup; an oversized unit cycling frequently consumes significantly more energy over its lifespan than a properly sized unit running longer, steadier cycles. Finally, oversized equipment masks other severe faults, such as massive duct leakage or undercharge, as the sheer excess capacity allows the system to satisfy the thermostat despite crippled efficiency.²⁶

3. Field Measurement Techniques for Energy Assessment

A robust energy audit relies on accurate, empirical field measurements to diagnose the aforementioned faults. Technicians must be equipped to gather and interpret data across electrical, aerodynamic, and thermodynamic domains. Relying purely on visual inspection or the building automation system's uncalibrated sensors will yield flawed conclusions.³⁷

3.1 Electrical Power Measurement

Accurate power assessment goes beyond simply reading nameplate amperage or utilizing a basic multimeter. Because alternating current (AC) motors—especially those driving fans and pumps—operate with varying power factors (PF), a true RMS power analyzer or data logger equipped with Current Transformers (CTs) is required to calculate actual real power (kW).¹¹ For three-phase equipment, the actual power consumed is calculated as:

$$P(\text{kW}) = \frac{V \times I \times \text{PF} \times \sqrt{3}}{1000}$$

Deploying CT loggers on compressor and fan circuits over a multi-day period provides high-resolution data on duty cycles, identifying hidden short-cycling events, erratic staging, and excessive runtime hours indicative of control failures.³⁸

3.2 Aerodynamic Profiling: Airflow and Pressures

Airflow verification is fundamental to any audit, as deficient airflow depresses evaporator temperatures, triggers frost accumulation, and drastically degrades cooling capacity.²⁶

Standard techniques include:

- **Anemometer Traverses:** Using a hot-wire or rotating vane anemometer to take a grid of velocity measurements across the duct cross-section. The average velocity (in feet per minute, **FPM**) multiplied by the cross-sectional area (**sq ft**) yields total volumetric flow in **CFM**.¹⁸
- **Static Pressure Profiling:** Measuring the total external static pressure (TESP) across the air handler using a digital manometer. High static pressure (e.g., due to heavily pleated, dirty filters or crushed ductwork) forces variable speed electronically commutated motors (ECMs) to ramp up RPM, exponentially increasing fan watt draw, or causes permanent split capacitor (PSC) motors to slip and lose airflow entirely.²¹

3.3 Thermodynamic and Psychrometric Profiling

Evaluating the state of the refrigerant cycle and the airstream requires highly precise temperature and pressure measurements.

- **Superheat and Subcooling:** Superheat (the suction line temperature minus the evaporator saturation temperature) and subcooling (the condenser saturation temperature minus the liquid line temperature) are the definitive diagnostics for verifying refrigerant charge and metering device health.³⁰ A system with high subcooling and low superheat indicates an overcharge or a severe liquid line restriction, while low subcooling and high superheat indicate a leak.²⁹
- **Enthalpy Assessments:** Using digital psychrometers to measure wet-bulb and dry-bulb temperatures of the return and supply air streams allows the auditor to plot thermodynamic points on a psychrometric chart. This identifies exactly how much cooling capacity is dedicated to sensible temperature drop versus latent moisture removal, critical for verifying the sensible heat ratio (SHR).⁴²

3.4 Economizer Operation Verification

To mathematically verify if an air-side economizer is modulating and mixing air streams correctly, the Outdoor Air Fraction (OAF) must be calculated using temperature differentials.

The basic mixed air equation relies on dry-bulb temperatures:

$$\text{OAF} = \frac{T_{\text{RA}} - T_{\text{MA}}}{T_{\text{RA}} - T_{\text{OA}}}$$
Where T_{RA} is return air temperature, T_{MA} is mixed air temperature, and T_{OA} is outdoor air temperature.^[45, 46] For greater accuracy—especially when humidity varies significantly—enthalpy (h) should be substituted for dry-bulb temperature:
$$\text{OAF} = \frac{h_{\text{RA}} - h_{\text{MA}}}{h_{\text{RA}} - h_{\text{OA}}}$$

Measurements must be taken precisely to avoid stratification errors: return air should be measured just upstream of the return damper, and supply/mixed air must be measured before the cooling coil but *after* the supply fan to ensure adequate aerodynamic mixing.⁴⁶ An OAF that does not match the BAS command indicates a mechanical failure in the damper actuator or

linkages.

4. Energy Conservation Measures (ECMs) for Maintenance Technicians

Upon identifying waste through diagnostic measurement, the energy audit must prescribe actionable Energy Conservation Measures (ECMs). These interventions are typically categorized by their capital requirement and implementation complexity, allowing facility owners to prioritize high-ROI projects.⁴⁸

4.1 Low-Cost and No-Cost Measures

These measures require minimal capital expenditure, relying primarily on maintenance labor, and focus on restoring the equipment to its original design performance.²¹

- **Coil and Blower Remediation:** Instituting routine, deep chemical cleaning of condenser and evaporator coils, alongside power-washing blower wheels. Removing a **0.042**-inch fouling layer can recover up to 21% of total system efficiency and eliminate the 10% compressor power penalty associated with high head pressure.²³
- **Filter Optimization:** Transitioning from rigid, calendar-based filter replacements to condition-based replacements utilizing differential pressure sensors across the filter bank. This prevents the severe static pressure drops that exponentially increase fan energy consumption, while ensuring filters are not prematurely discarded.²¹
- **Schedule and Setpoint Adjustments:** Correcting BAS schedules to strictly align with actual building occupancy, instituting optimum start/stop sequences to prevent pre-conditioning too early, and widening temperature deadbands (the gap between heating and cooling setpoints) to prevent simultaneous heating and cooling battles between perimeter zones.²⁴

4.2 Medium-Cost Measures: VFD Retrofits and the Affinity Laws

One of the most lucrative medium-cost ECMs available to the commercial HVAC sector is the installation of Variable Frequency Drives (VFDs) on constant-speed centrifugal pumps and fans. The energy savings generated by VFDs are governed by the Pump Affinity Laws, which dictate that power consumption is proportional to the cube of the motor's speed.⁴⁹

The power affinity law is mathematically expressed as:

$$P_2 = P_1 \times \left(\frac{N_2}{N_1} \right)^3$$

Where P is the electrical power and N is the rotational speed (RPM or Hz).

Calculation Example:

Consider a **100 HP** (requiring **79.36 kW** of input power assuming 94% motor efficiency)


centrifugal chilled water pump running continuously at a fixed **60 Hz**. If a VFD is installed and the speed is reduced to 70% (**42 Hz**) during periods of lower building load, the new power draw is not 70% of the original. Instead, it follows the cubic law:

$$P_2 = 79.36 \text{ kW} \times (0.7)^3 = 79.36 \times 0.343 = 27.22 \text{ kW}$$

Therefore, a mere 30% reduction in speed results in a massive 65.7% reduction in electrical power consumption.⁵¹

Crucial Caveat: The Affinity Laws apply strictly to centrifugal loads (fans, blowers, and centrifugal pumps). Positive displacement pumps feature a linear, not cubic, power-to-speed relationship. Furthermore, technicians must verify the system's static head requirements; reducing speed too far may cause the pump to stall—failing to overcome the static pressure of the pipe network and stopping fluid flow entirely, which can lead to catastrophic mechanical seal failure.⁴⁹

Leis de Afinidade de Bombas Centrífugas: O Poder da Velocidade Variável



De acordo com as Leis de Afinidade, o caudal diminui linearmente com a velocidade, a pressão diminui ao quadrado, mas a potência diminui ao cubo. Reduzir a velocidade do motor em apenas 20% (para 80% da velocidade) reduz o consumo de potência em quase 50%.

Fonte de dados: [Industrial Monitor Direct](#)

4.3 Capital Improvement Recommendations

When equipment reaches the end of its useful life, or when individual component retrofits are economically inviable, auditors must recommend comprehensive capital expenditures.⁴⁸

- **System Replacement:** Upgrading from legacy constant-volume direct expansion (DX) units to highly efficient Variable Refrigerant Flow (VRF) systems, or replacing aging reciprocating chillers with water-cooled, magnetic bearing centrifugal chillers capable of sub-0.500 kW/ton IPLV performance.¹⁵
- **Energy Recovery Ventilation (ERV):** Installing ERV or enthalpy wheels in the ductwork to transfer sensible (temperature) and latent (moisture) heat between the conditioned exhaust air and the incoming raw outdoor air stream. In winter, exhaust air pre-heats the

incoming air; in summer, it pre-cools and dehumidifies it, substantially reducing the conditioning load required for mandatory ventilation.²³

5. Calculating and Presenting Energy Savings

An energy audit holds no intrinsic value unless the resulting report successfully compels the facility owner or Chief Financial Officer to act. Translating thermodynamic waste into clear, defensible financial metrics is the primary mechanism for driving project implementation.⁵¹

5.1 Simple Payback and Cost Avoidance Calculations

The primary financial metric utilized in maintenance-level energy auditing is the Simple Payback Period. This metric defines the time required to recover the initial capital investment through the generated utility cost savings.⁵⁰

$$\text{Payback Period (Years)} = \frac{\text{Total Implementation Cost}}{\text{Annual Energy Cost Savings}}$$

Detailed Financial Calculation Example:

Utilizing the VFD example from Section 4.2, assume the baseline **100 HP** constant-speed motor operates **6,000 hours/year** at a blended utility rate of **\$0.12/kWh** (factoring in both consumption and demand charges).

1. **Baseline Cost Calculation:** $79.36 \text{ kW} \times 6000 \text{ hrs} \times \$0.12 = \$57,139/\text{yr}$ ⁵¹
2. **Proposed VFD Operation Calculation:** Assume the VFD allows the motor to operate at 100% speed for 3,000 hours (peak load) and 70% speed for 3,000 hours (part load).
 - 100% operation: $79.36 \text{ kW} \times 3000 \text{ hrs} = 238,080 \text{ kWh}$
 - 70% operation: $27.22 \text{ kW} \times 3000 \text{ hrs} = 81,660 \text{ kWh}$
 - Total Proposed Annual Energy: $238,080 + 81,660 = 319,740 \text{ kWh}$
 - Total Proposed Cost: $319,740 \text{ kWh} \times \$0.12 = \$38,368/\text{yr}$ ⁵¹
3. **Annual Savings:** $\$57,139 \text{ (Baseline)} - \$38,368 \text{ (Proposed)} = \$18,771 \text{ per year}$
4. **Payback:** If the total turnkey VFD installation (including parts, labor, and commissioning) costs **\$25,000**, the simple payback is $\frac{25000}{18771} = 1.33 \text{ years}$ (approximately 16 months).⁵¹

5.2 Leveraging Utility Rebates and Funding Programs

To further accelerate the payback period and improve the internal rate of return (IRR), energy auditors must actively identify and integrate utility rebates into the financial models. Many

jurisdictions operate under mandated energy efficiency frameworks. For instance, in Brazil, the Agência Nacional de Energia Elétrica (ANEEL) mandates the Programa de Eficiência Energética (PEE).⁵³

Under this framework, regional utility concessionaires such as CPFL and Enel issue "Chamadas Públicas de Projetos" (Public Calls for Projects). These programs offer substantial funding for performance contracts and capital injections aimed at hospitals, public buildings, and industrial facilities looking to upgrade chillers, HVAC infrastructure, and lighting.⁵⁵ Facilities often partner with Energy Service Companies (ESCOs) to navigate the complex M&V requirements for reimbursement under these programs.⁵⁴ Integrating specific local funding mechanisms into the audit report drastically improves the feasibility of capital-intensive ECMs and demonstrates comprehensive value to the client.

6. Energy Monitoring and Verification (M&V)

Once an Energy Conservation Measure is successfully implemented, the promised savings must be empirically proven to satisfy financiers, utility rebate programs, and internal stakeholders. The International Performance Measurement and Verification Protocol (IPMVP) provides the definitive global standard framework for quantifying these savings.⁴⁸ Energy savings cannot be measured directly; they are calculated indirectly as the difference between the baseline energy use and the post-installation energy use, subject to routine weather adjustments and non-routine facility changes.⁵²

6.1 The Four IPMVP Options and Decision Logic

The auditor must meticulously select the appropriate M&V strategy based on the complexity of the ECM, the variability of the load, and the availability of historical data.⁶⁰ The selection of an appropriate IPMVP Option operates on a structured decision logic framework. Initially, the auditor must determine if historical baseline utility data is available; if absent, the facility must utilize Option D (Calibrated Simulation). If historical data exists, the next determination is whether the Energy Conservation Measure impacts the whole building or highly interactive systems. If so, Option C (Whole Facility Measurement) is required. Conversely, if the ECM involves isolated systems, the auditor must evaluate the variability of the operational parameters. If parameters like operating hours and load are highly variable and demand continuous measurement, Option B (Retrofit Isolation with All Parameter Measurement) is applied. If the isolated system has constant loads where certain parameters can be reliably estimated rather than measured continuously, Option A (Retrofit Isolation with Key Parameter Measurement) is the correct path.⁴⁸

- **Option A (Retrofit Isolation with Key Parameter Measurement):** Applied when the potential to perform needs verification, but some parameters can be reliably estimated using standard tables. For example, replacing a constant-speed fan motor with a higher efficiency model. The power (kW) is measured before and after, but the operating hours are estimated based on predictable facility schedules.⁴⁸
- **Option B (Retrofit Isolation with All Parameter Measurement):** Applied to variable loads where estimation introduces unacceptable error margins. If a VFD is installed on a

cooling tower fan, both the varying power draw (kW) and the varying operating hours are continuously metered via data loggers to calculate savings accurately over the performance period.⁶⁰

- **Option C (Whole Facility Measurement):** Utilizes macro-level utility meter data to assess building-wide changes. Best suited when ECMs interact extensively (e.g., a holistic chiller plant upgrade combined with building envelope sealing) and the expected savings comfortably exceed 10% of the total facility energy use, ensuring the savings are not lost in the statistical noise of the utility meter.⁶⁰
- **Option D (Calibrated Simulation):** Utilizes comprehensive building energy modeling software (e.g., EnergyPlus or TRACE 3D Plus). This option is deployed when baseline historical data is absent (e.g., new construction or major additions) or when massive operational changes to the facility render historical utility data completely irrelevant.⁶⁰

6.2 Weather Normalization and Regression Modeling

When employing Option C (Whole Facility), a direct, simplistic comparison of utility bills year-over-year is mathematically invalid because weather conditions inevitably vary. A milder winter will naturally result in lower heating bills, artificially inflating the apparent "savings" of an ECM. To find the true savings, the baseline data must be "weather-corrected" to determine exactly what the building *would have* consumed during the post-retrofit period if the ECM had never been installed.⁵²

This normalization is accomplished using Heating Degree Days (HDD) and Cooling Degree Days (CDD). These meteorological metrics quantify the severity of the climate by measuring how far the average daily outdoor temperature deviates from a standard thermal balance point

(typically 65°F).⁶⁴

- If the daily average temperature is 80°F , the day contributes 15 CDD .
- If the daily average temperature is 40°F , the day contributes 25 HDD .⁶⁵

Auditors use linear regression modeling to map historical energy consumption against historical HDD and CDD, generating a mathematical "Best Fit Line" equation. This model's accuracy is validated using statistical indicators such as the Net Determination Bias Error (NDBE) and the Coefficient of Variation of the Root Mean Square Error, CV(RMSE).⁵² Once validated, this baseline equation is then applied to the actual weather data of the post-retrofit period to calculate the normalized baseline. This mathematical rigor ensures that reported savings are genuinely attributable to the engineering intervention, satisfying stringent IPMVP requirements and ensuring the financial integrity of performance contracts.⁵²

7. Field Application: Audit Checklists & Worksheets

To operationalize the extensive theoretical and mathematical frameworks provided in this report, field practitioners require structured diagnostic tools. The following templates synthesize ASHRAE Level 1 and 2 energy audit parameters into actionable checklists designed specifically for use during routine mechanical maintenance.⁶⁶

Table 2: HVAC Commercial Energy Audit Field Checklist

Category	Assessment Parameter	Field Measurement / Observation	Diagnosis / Actionable Waste Indicator
Airflow & Ductwork	Total External Static Pressure (TESP)	Measure with digital manometer; verify against nameplate max	High TESP indicates dirty filters/coils or severely restricted ductwork, elevating fan energy and reducing mass flow. ²⁵
	Duct Leakage	Visual inspection / Pressurization Test (CFM_{25})	Leakage outside the thermal envelope causes immediate thermal loss, pressure drops, and severe latent infiltration penalties. ³¹
Heat Transfer	Evaporator ΔT	Measure supply and return dry-bulb	Abnormally low ΔT indicates restricted airflow, severe undercharge, or compressor valve failure. ¹⁸
	Condenser Approach Temperature	Ambient air temp vs. Liquid line saturation temp	A high approach indicates severe condenser coil fouling or the presence of non-condensable gases in the circuit. ³⁰

Refrigeration Circuit	Subcooling (SC) & Superheat (SH)	Saturation pressures vs. physical line temperatures	High SC + Low SH = Overcharge. High SH + Low SC = Undercharge. ²⁹
	TXV / Metering Device	Temperature drop across the liquid line filter drier	A drop > indicates a severe liquid line restriction, starving the TXV and simulating undercharge. ⁴¹
Controls & Economizer	Mixed Air Temperature & OAF	Compare T_{OA} , T_{RA} , and T_{MA}	An unfavorable OAF indicates stuck dampers or broken linkages, wasting massive energy during extreme ambient conditions. ⁴⁶
	Short-Cycling	Compressor runtime monitoring via data loggers	Oversized equipment limits latent moisture removal and drastically increases startup electrical draw and mechanical wear. ²⁶

Table 3: VFD Retrofit Feasibility & Savings Worksheet

Data Point Requirement	Field Input Parameter	Calculation Purpose / Engineering Justification
Motor Specifications	Nameplate HP, Full Load Amps (FLA), Voltage	Establish the maximum power ceiling (kW) and baseline energy calculations. ⁵¹

Load Profile	Estimated Operating Hours per Year	Required to extrapolate calculated kW into annual kWh consumption. ⁵¹
System Constraints	Static Head / Minimum Flow Requirements	Crucial check: Centrifugal pumps cannot be slowed below the static pressure requirements of the pipe network; doing so will cause the pump to stall. ⁴⁹
Utility Costs	Blended Rate (\$/kWh)	Used to convert thermodynamic energy savings directly into fiscal returns. ⁵¹
Affinity Law Projection	Proposed Speed Reduction (%)	Apply the $P_2 =$ formula to mathematically determine the theoretical reduced electrical draw at part load. ⁴⁹

8. Conclusion

Routine HVAC maintenance is conventionally viewed by facility operators as a necessary operational expense focused purely on preventing catastrophic mechanical failure. However, integrating rigorous energy auditing protocols into these maintenance schedules transforms standard service activities into high-yield financial strategies. By evaluating the system's thermodynamic baseline against CBECS benchmarks, executing precise psychrometric and electrical measurements, and diagnosing insidious faults like coil fouling, refrigerant charge drift, and economizer malfunction, technicians can uncover massive streams of hidden energy waste.

Deploying targeted Energy Conservation Measures—ranging from simple setpoint tuning and coil remediation to capital-intensive VFD retrofits validated by the mathematical certainty of the Affinity Laws—can drastically lower a commercial facility's Energy Use Intensity. Ultimately, mathematically verifying these engineering interventions through rigorous IPMVP protocols and weather-normalized regression modeling ensures that engineering estimates translate into verified financial performance. This approach cements HVAC maintenance and optimization as a cornerstone of commercial building sustainability, operational resilience, and long-term fiscal management.

Referências citadas

1. Full article: Exploring the theoretical minimum energy use in the U.S. office building sector, acessado em junho 13, 2026, <https://www.tandfonline.com/doi/full/10.1080/23744731.2024.2421727>
2. Comparison of Multiple Fault Impacts on a Heat Pump and an Air Conditioner in Cooling Mode - Purdue e-Pubs, acessado em junho 13, 2026, <https://docs.lib.purdue.edu/cgi/viewcontent.cgi?article=3365&context=iracc>
3. How CBECS Data Affects Standard 90.1 Development and Implementation - ASHRAE, acessado em junho 13, 2026, <https://www.ashrae.org/technical-resources/ashrae-journal/how-cbecs-affects-90-1>
4. Benchmarking Your Buildings with CBECS—an Easy Way - EnergyCAP, acessado em junho 13, 2026, <https://www.energycap.com/blog/benchmarking-your-buildings-with-cbecs-an-easy-way/>
5. Why Benchmarking Your Building's Energy Efficiency Is So Important - Halff, acessado em junho 13, 2026, <https://halff.com/news-insights/insights/why-benchmarking-your-buildings-energy-efficiency-is-so-important/>
6. US Energy Use Intensity by Property Type - Benchmark Your Building With Portfolio Manager, acessado em junho 13, 2026, <https://portfoliomanager.energystar.gov/pdf/reference/US%20National%20Median%20Table.pdf>
7. Commercial Buildings Energy Consumption Survey (CBECS) building type - EIA, acessado em junho 13, 2026, <https://www.eia.gov/consumption/commercial/building-type-definitions.php>
8. ENERGY STAR Building Rating vs. Energy Use Intensity (EUI) - MEP Academy, acessado em junho 13, 2026, <https://mepacademy.com/energy-star-building-rating-vs-energy-use-intensity-eui/>
9. Building Energy Asset Score Program Overview and Technical Protocol (Version 1.2), acessado em junho 13, 2026, https://buildingenergyscore.energy.gov/assets/energy_asset_score_technical_protocol.pdf
10. Effective Energy Benchmarking | EnergyCAP, acessado em junho 13, 2026, <https://www.energycap.com/ebooks/effective-energy-benchmarking/>
11. Air Conditioner Efficiency - The Engineering ToolBox, acessado em junho 13, 2026, https://www.engineeringtoolbox.com/air-conditioner-efficiency-d_442.html
12. IPLV, NPLV Explained, How to Calculate - Chiltrix, acessado em junho 13, 2026, <https://www.chiltrix.com/documents/IPLV-NPLV-Explained-Comparison.pdf>
13. AHRI Standards 550/590 (I-P)-2015 & 551/591 (SI) - ResearchGate, acessado em junho 13, 2026, https://www.researchgate.net/profile/Md_Washim_Akram/post/What-is-the-ASHRE-standard-design-pressures-for-condenser-and-evaporater/attachment/5ab0

[Obea4cde266d58926e78/AS%3A605973823631360%401521486826116/download/AHRI-550_590%26551_591-Presentation.pdf](https://www.scribd.com/document/484697377/AHRI-Standard-550-590-I-P-2011-pdf-pdf)

14. AHRI Standard 550/590 Overview | PDF | Temperature - Scribd, acessado em junho 13, 2026, <https://www.scribd.com/document/484697377/AHRI-Standard-550-590-I-P-2011-pdf-pdf>
15. ANSI/ASHRAE/IES Addendum x to ANSI/ASHRAE/IES Standard 90.1-2019, acessado em junho 13, 2026, https://www.ashrae.org/file%20library/technical%20resources/standards%20and%20guidelines/standards%20addenda/90_1_2019_x_20220204.pdf
16. Item Page PE Stamped Calculation Report 1 Calculation Summary 2 IPLV Calculation 3 Air-Cooled vs Water Cooled Energy Usage Calcu - Portland.gov, acessado em junho 13, 2026, https://www.portlandoregon.gov/bds/appeals/index.cfm?action=getfile&appeal_id=14762&file_id=16033
17. HVAC Efficiency Calculator (%) - CalcEngineer, acessado em junho 13, 2026, <https://calcengineer.com/hvac/hvac-efficiency-calculator/>
18. HVAC Formulas and Calculations Field Reference Guide for Technicians: CFM, BTU, Cv, GPM, ΔT , and More | Belimo, acessado em junho 13, 2026, https://www.belimo.com/us/en_US/blog/hvac-formulas-and-calculations-guide
19. All In One HVAC Calculation Formula's, acessado em junho 13, 2026, <https://hvacsimplified.in/wp-content/uploads/2022/02/All-In-One-HVAC-Calculation-Formulas.pdf>
20. HVAC – Practical Basic Calculations - PDH Online, acessado em junho 13, 2026, <https://www.pdhonline.com/courses/m378/m378content.pdf>
21. Operations & Maintenance Best Practices Guide: Release 3.0 - Department of Energy, acessado em junho 13, 2026, https://www.energy.gov/sites/prod/files/2020/04/f74/omguide_complete_w-eo-disclaimer.pdf
22. Operations & Maintenance Guide - The Building Energy Hub, acessado em junho 13, 2026, <https://www.buildinghub.energy/operations---maintenance-guide>
23. Advanced Energy Retrofit Guide — Healthcare Facilities - Publications | NLR, acessado em junho 13, 2026, <https://docs.nlr.gov/docs/fy13osti/57864.pdf>
24. Commercial HVAC Energy Efficiency Optimization Guide - Oxmaint, acessado em junho 13, 2026, <https://oxmaint.com/industries/facility-management/commercial-hvac-energy-efficiency-optimization-guide>
25. Laboratory Test Results of Commercial Packaged HVAC Maintenance Faults - CALMAC.org, acessado em junho 13, 2026, https://www.calmac.org/publications/RMA_Laboratory_Test_Report_2012-15_v3.pdf
26. Sensitivity Analysis of Installation Faults on Heat Pump Performance - NIST Technical Series Publications, acessado em junho 13, 2026, <https://nvlpubs.nist.gov/nistpubs/TechnicalNotes/NIST.TN.1848.pdf>
27. Common Faults and Their Prioritization in Small Commercial Buildings -

- Publications | NLR, acessado em junho 13, 2026,
<https://docs.nlr.gov/docs/fy18osti/70136.pdf>
28. Residential HVAC Installation Practices: A Review of Research Findings - Department of Energy, acessado em junho 13, 2026,
<https://www.energy.gov/sites/default/files/2018/06/f53/bto-ResidentialHVACLitReview-06-2018.pdf>
 29. Aux 2 Unit 9 Q1 - SVE Study, acessado em junho 13, 2026,
https://svestudy.com/?page_id=8644
 30. Refrigerant Overcharge Troubleshooting and Prevention - YouTube, acessado em junho 13, 2026, <https://www.youtube.com/watch?v=S2lt3x3qGj0>
 31. Duct Leakage Tests | JADE Learning, acessado em junho 13, 2026,
<https://www.jadelearning.com/blog/duct-leakage-tests/>
 32. Duct Leakage Calculator - Efficiency First California, acessado em junho 13, 2026,
<https://efficiencyfirstca.org/resources/duct-leakage-calculator/>
 33. High Energy Bills | Crawlspace Duct Leakage and Loss, acessado em junho 13, 2026, <https://crawlspaceenergyinstitute.com/symptoms/high-energy-bills/>
 34. Duct Leakage and Retrofit Duct Sealing in Minnesota Commercial and Institutional Buildings, acessado em junho 13, 2026,
<https://mn.gov/commerce-stat/pdfs/card-duct-leakage.pdf>
 35. energy consumption analyses of frequently-used hvac system types in high performance office buildings a, acessado em junho 13, 2026,
https://etda.libraries.psu.edu/files/final_submissions/9398
 36. Energy Savings Analysis: ANSI/ASHRAE/IES Standard 90.1-2019, acessado em junho 13, 2026,
https://www.energycodes.gov/sites/default/files/2021-07/Standard_90.1-2019_Final_Determination_TSD.pdf
 37. Duct Leakage Testing: Methods, Standards, and Acceptable Rates, acessado em junho 13, 2026, <https://airductauthority.com/duct-leakage-testing/>
 38. Chapter 18: Variable Frequency Drive Evaluation Protocol - Department of Energy, acessado em junho 13, 2026,
<https://www.energy.gov/sites/prod/files/2015/01/f19/UMPCchapter18-variable-frequency-drive.pdf>
 39. Detection of Rooftop Cooling Unit Faults Based on Electrical, acessado em junho 13, 2026,
https://emsg.mit.edu/wp-content/uploads/2024/05/27_Detection-of-Rooftop-Cooling-Unit-Faults-Based-on-Electrical-Measurements.pdf
 40. California Appliance Standards and Equipment Certification - Energy Code Ace, acessado em junho 13, 2026,
<https://energycodeace.com/content/1152-california-appliance-standards-and-equipment-certifica>
 41. High Head Pressure & Low Suction Diagnosis (2026 Troubleshooting Guide), acessado em junho 13, 2026,
<https://hvacprosales.com/low-suction-pressure-diagnosis-guide>
 42. Navigating the Cooling process on the Psychrometric Chart | CaptiveAire, acessado em junho 13, 2026,

- https://www.captiveaire.com/catalogcontent/fans/sup_mpu/doc/navigating-the-psychrometric-chart.pdf
43. Air Conditioning Psychrometrics - CEDengineering.com, acessado em junho 13, 2026,
<https://www.cedengineering.com/userfiles/M05-005%20-%20Air%20Conditioning%20Psychrometrics%20-%20US.pdf>
 44. HVAC Made Easy - Overview of Psychrometrics - PDH Online, acessado em junho 13, 2026, <https://pdhonline.com/courses/m135/m135content.pdf>
 45. Energy Conservation Potential of Economizer Controls Using Optimal Outdoor Air Fraction Based on Field Study - MDPI, acessado em junho 13, 2026,
<https://www.mdpi.com/1996-1073/13/19/5038>
 46. Percent Outdoor Air (%OA) Calculation and Its Use Application Note TI-138 - TSI, acessado em junho 13, 2026,
[https://tsi.com/getmedia/5e5e04c6-f29d-4a92-80f6-2287f97c29db/Percent-Outdoor-Air-App-Note-\(TI-138\)-US](https://tsi.com/getmedia/5e5e04c6-f29d-4a92-80f6-2287f97c29db/Percent-Outdoor-Air-App-Note-(TI-138)-US)
 47. M&V Guidelines: Measurement and Verification for Performance-Based Contracts Version 4.0 - Department of Energy, acessado em junho 13, 2026,
<https://www.energy.gov/documents/mvguide40pdf>
 48. How to Calculate VFD Energy Savings on Centrifugal Pumps ..., acessado em junho 13, 2026,
<https://industrialmonitordirect.com/blogs/knowledgebase/calculating-vfd-pump-energy-savings-affinity-laws-explained>
 49. Complete Guide to VFD Efficiency, Energy Savings, and ROI, acessado em junho 13, 2026,
<https://vfds.com/blog/complete-guide-to-vfd-efficiency-energy-savings-and-roi/>
 50. A Practical Guide to VFD Energy Savings - E&I Sales, acessado em junho 13, 2026,
<https://eandisales.com/uncategorized/vfd-energy-savings/>
 51. A Facility Manager's Intro to Weather Correction for Utility Bill Tracking | Abraxas Energy Consulting, acessado em junho 13, 2026,
<https://www.abraxasenergy.com/articles/intro-weather-correction/>
 52. TJSP e CPFL Energia firmam parceria de eficiência energética, acessado em junho 13, 2026,
<https://portal.tjsp.jus.br/Imprensa/Noticias/Noticia?codigoNoticia=20113&pagina=1692>
 53. Avaliação do Programa de Eficiência Energética das Distribuidoras de Energia Elétrica - PEE - e Propostas para seu Aprimora - energypedia, acessado em junho 13, 2026,
https://energypedia.info/images/0/07/Avalia%C3%A7%C3%A3o_do_Programa_de_Efici%C3%Aancia_Energ%C3%A9tica_das_Distribuidoras_de_Energia_El%C3%A9trica.pdf
 54. CPFL nos Hospitais – O maior programa para eficiência energética em Hospitais do Brasil - Semil, acessado em junho 13, 2026,
https://semil.sp.gov.br/sp-carbono-zero/wp-content/uploads/sites/27/2025/09/L45g6f98ep3d-CPFL-nos-hospitais_SP_v2.pdf
 55. CHAMADA PÚBLICA SPF/PEE-CPFL ENERGIA_001/2025, acessado em junho 13,

- 2026,
https://www.grupocpfl.com.br/sites/default/files/Mala_Direta_CPP2025-Pos_recurso.pdf
56. Prefeitura inicia elaboração de projeto de consumo eficiente de energia elétrica, acessado em junho 13, 2026,
<https://casimirodeabreu.rj.gov.br/prefeitura-inicia-elaboracao-de-projeto-de-consumo-eficiente-de-energia-eletrica/>
57. CHAMADA PÚBLICA SPF/PEE-CPFL ENERGIA_001 ... - Grupo CPFL, acessado em junho 13, 2026,
<https://www.grupocpfl.com.br/sites/default/files/Edital%20CHAMADA%20PUBLICA%202026%20-%20CPFL%20ENERGIA.pdf>
58. chamada pública spf/pee-cpfl energia_001/2021, acessado em junho 13, 2026,
https://www.grupocpfl.com.br/sites/default/files/2021-12/FAQ_Principais%20Perguntas%20e%20Respostas%20sobre%20CPP.pdf
59. IPMVP Options // International Performance Measurement & Verification Protocol, acessado em junho 13, 2026, <https://www.energycap.com/blog/ipmvp-options/>
60. Understanding IPMVP: The Cornerstone of Accurate Energy Savings Measurement - AEPV, acessado em junho 13, 2026,
<https://aepv.energicloud.com/blog/understanding-ipmvp-the-cornerstone-of-accurate-energy-savings-measurement/>
61. Retrofit Program - M&V Guidelines - Save on Energy, acessado em junho 13, 2026,
<https://saveonenergy.ca/-/media/Files/SaveOnEnergy/Industry/Retrofit-Documents/Retrofit-M-V-Guidelines.pdf>
62. M&V Guidelines: Measurement and Verification for Performance-Based Contracts Version 5.0 - Department of Energy, acessado em junho 13, 2026,
https://www.energy.gov/sites/default/files/2024-10/mv_guide_5_0.pdf
63. Building Energy Modeling API | Developer Portal - Schneider Electric Exchange, acessado em junho 13, 2026,
<https://exchange.se.com/devportal/?api=analytics-building-energy-modeling-api&id=38969>
64. BPA Regression for M&V: Reference Guide - Energy Efficiency Title, acessado em junho 13, 2026,
<https://www.bpa.gov/-/media/Aep/energy-efficiency/measurement-verification/3-bpa-mv-regression-reference-guide.pdf>
65. Audit Template: Quick Start Guide, acessado em junho 13, 2026,
https://www.energy.gov/sites/default/files/2024-01/audit-template-quick-start-guide_012224.pdf
66. A GUIDEBOOK for PERFORMING WALK-THROUGH ENERGY AUDITs of INDUSTRIAL FACILITIES, acessado em junho 13, 2026,
http://eec.oregonstate.edu/sites/eec.oregonstate.edu/files/walkthrough_checklist.pdf
67. R-410A Operating Pressures: Normal Ranges, Symptoms of Issues & How to Read, acessado em junho 13, 2026,
<https://www.acdirect.com/blog/r410a-operating-pressures/>
68. HVAC Compressor Overheating: 10 Causes and the Repair Sequence, acessado

em junho 13, 2026,

<https://oxmaint.com/industries/hvac/hvac-compressor-overheating-10-causes-repair-sequence>

69. General Outdoor Air Economizer Fault Detection & Diagnostics Assessment Method - Purdue e-Pubs, acessado em junho 13, 2026,

<https://docs.lib.purdue.edu/cgi/viewcontent.cgi?article=2248&context=iracc>