Software Release Process

Austin Green

July 2, 2024 V0.4

Contents

1	Initial Release			
	1.1	Tortoi	seSVN	. 2
		1.1.1	Check In Code	. 2
		1.1.2	Create Tag	. 3
		1.1.3	Release	. 4
	1.2	SmarT	Геат	. 4
		1.2.1	Updating Files	. 5
		1.2.2	Submitting an ECO	. 7
2	\mathbf{ECC}) Kick	rhack	9

1 Initial Release

1.1 TortoiseSVN

1.1.1 Check In Code

Checking in code in Tortoise SVN is relatively simple. You can tell that code is modified and needs to be checked in based on the green check mark turning into a red exclamation point.






To check in, right click in the folder and select SVN Commit....



The files to be committed will be in the bottom portion of the window, selecting the check box will indicate you wish to commit them. You can double click on the files to bring up a diff between the current and previous versions of the file. When you are ready, type a description of the commit in the upper window and click OK.




1.1.2 Create Tag

To create a tag, go to into the trunk directory and right click and select TortoiseSVN->Branch/tag....



The *To path*: on the top is where to create the tag. This should be in a folder in the *tags* folder with the cproject>-<version>-<date> format. In the Log message section, write a message associated with this tag. And finally, you can click Show Log to select the version you want to include in this tag.



1.1.3 Release

To release software, create a folder in the *releases* folder with the Release_<version number> format. In this folder, create *bin* and *src* folders. Inside each of these folders should be a .zip file (of output files in *bin* and source files in *src*), a *Software Release Notes* word document, and a PDF of this document. Commit this folder to SVN using the above steps when you finish with this folder.

1.2 SmarTeam

Notoe: It is important to have all documents filled out in the way that they should be submitted before submitting an ECO, because any edits to the files will kick back the ECO to you.

1.2.1 Updating Files

SmarTeam is a bit tricky to get right so follow these steps carefully. First, in SmarTeam, navigate to your project, then the files you with to update (*Design NoteBook->Detailed Design General->Top Level Design General->Software*).

```
Documents

TLD-0026643 A.000 C - PM0 NoteBook - A2013 General

FLD-0026674 A.000 Phase Gate Reviews General

D-1026673 A.000 Engineering / Technical Data General
       ⊕ ► FLD-0026668 A.000 Risk General
⊕ ► FLD-0026667 A.000 Action Items General
       FLD-0026663 A.000 Cost General

FLD-0026662 A.000 Schedule Genera
       ⊕ > FLD-0026659 A.000 Scope General

→ FLD-0026657 A.000 Project Managerr

→ FLD-0026655 A.000 CDRL General
FLD-0026647 A.000 Correspondence General
FLD-0026644 A.000 Contract General
FLD-0026588 A.000 Design NoteBook · A2013 General
       FLD-0026679 a. Requirements and Planning

FLD-0026640 A.000 d. Production General
        ► FLD-0026589 A.000 b. Detailed Design General

► FLD-0026590 A.000 i. Top Level Design General

    SOUTH ON THE STATE OF THE 
                           ■ 0212108002SRN_PDF B.002 YOKOHAMA MIRROR CONTROLLER BINARY SOFTWARE RELEASE NOTES PDF v1.1.0 PDF
                             ☐ ■ SWP-0000430 B.001 SOFTWARE RELEASE FOR YOKOHAMA MIRROR LABWINDOWS GUI SOURCE ∨1.1.0


⊕ ☐ □ 0214044002SRC B.001 YOKOHAMA MIRROR LABWINDOWS GUI SOURCE ∨1.1.0 ZIP
                                                     0214044002SRN B.001 YOKOHAMA MIRROR LABWINDOWS GUI SOURCE SOFTWARE RELEASE NOTES v1.1.0 Microsoft Word
                                                        0214044002SRN_PDF B.000 YOKOHAMA MIRROR LABWINDOWS GUI SOURCE SOFTWARE RELEASE NOTES v1.1.0, PDF PDF
```

Next, right click on the SWP (Software Package) and select Life Cycle->Check Out. If this does not exist, you will need to right click on the Software folder and select Add->Design->Software Package and fill out the information.



Next, right click and select *Update* and update the *DESCRIPTION* and *COMMENTS* on the right to reflect the new version number. Additionally, update the *Part Number* by increasing the number by one. You are actually increasing what is known as the *slash number* which is just the last three digits after the part number. Click OK when done.

Next, right click and select $Life\ Cycle->Check\ Out$ any files below the SWP you are changing, paying attention to the $Destination\ directory$: field. Click OK when you select the destination.



If the file does not already exist in SmarTeam, right click on the SWP and select $Add{-}>Document$ and fill out the information similar to the other documents.

Next, navigate to the folder you selected as the destination folder in Windows


Explorer and replace the checked out files with the ones you created in the releases folder above.

Next, back in SmarTeam, update the file similar to the way you updated the SWP above by right clicking the file and selecting Update. You will need to update the ID and PART NUMBER by incrementing the slash number and update the DESCRIPTION and COMMENTS on the right to reflect the new version number.

Finally, right click and select $Life\ Cycle->Check\ In$ when you are done. Add a description of the change and select OK.

1.2.2 Submitting an ECO

There should be one ECO submitted per SWP update. When you are done updating all of the files in an SWP, right click on one of the changed files, select $Initiate\ Process->LAP\ ECO-LAP\ Software\ -\ Cert/NonCert\ depending.$




This will bring up the ECO Window.




Your ECO will only have one item to start. Drag the rest of the files, including the SWP, from the Projects Documents pane (where you were checking in and out files) onto the *ECO* item. The structure should look like the above with the documents being a subset of the ECO.

Next right click the ECO and click Update. Fill out all the fields, the Description of Change and Reason for Change can be the same. The Project Number is the number associated with the project you are in.

Next, select the *Flowchart* tab at the top. Right click the *LAP Peer Review* box and select *Executors*. From here click *Add New...* and add an people that you wish to review or see the the ECO by clicking the To-> or Cc-> buttons respectively.






When you are finished, select the *Send To Review* button in the top left and click *OK*. This will pull up an Outlook email which you can go ahead and send. You have now submitted an ECO!

2 ECO Kickback

If an ECO is kicked back to you (rejected) it will show up in your SmarTeam inbox.



If you double click on the message, it will open up the ECO. Resubmitting the ECO is easy, all the files you submitted are already in there, so if you need to change any go through the same Checkout-Checkin process listed above. Likewise, if you need to add more files, go through the Add files process listed above. Any modified and checked in files should automatically be reflected in the ECO. All you need to do from here is double check that the documents in the ECO are correct, and if not replace them. From there click the *Send To Review* button again.