

[illegible][illegible]

Pin configuration diagram for the J7 module. The module is a yellow rectangle with pins 1-10 on the left and TestPoint SWDIO, SWDCLK, and nRESET on the right. Pin 1 is connected to +3V3, pin 2 to SWDIO, pin 3 to SWDCLK, pin 4 to SWDCLK, pin 5 to SWDCLK, pin 6 to SWDCLK, pin 7 to SWDCLK, pin 8 to SWDCLK, pin 9 to SWDCLK, and pin 10 to nRESET. A red 'X' is marked on the connection between pin 7 and SWDCLK.

The schematic shows the power supply section of the TP563000. Key components and connections include:

- VIN** and **VREG\_IN** inputs.
- JP3** Current Measurement point.
- R25** (100) and **C19** (10u) forming a voltage divider for **VREG\_IN**.
- PWR\_FLAG** TestPoint.
- TPS63000** (TP563000) IC.
- VOUT** (10) output pin.
- R33** (1.2M) and **R34** (215k) forming a feedback network.
- C24** (1.8p) and **C25** (22u) capacitors.
- VoutTestPoint** and **+3V3** output.
- TPS63000** pin connections: **VIN** (5), **VINA** (6), **IN** (7), **P5/SYNC** (8), **FB** (9), **SGND** (12), **SGND** (13).
- LPS0015-2222MR8** inductor.
- JP4** VDD\_JUMPER.
- VUSB** and **+BATT** inputs.
- VIN** output.

The image shows two circuit diagrams for nRF91 buttons, SW1 and SW2, which are part of a larger PCB layout. Both buttons are connected to the nRF91\_BUTTON1 and nRF91\_BUTTON2 pins, respectively. The SW1 circuit includes a 1k resistor (R31) and a 1uF capacitor (C21) connected to GND. The SW2 circuit includes a 1k resistor (R32) and a 1uF capacitor (C22) connected to GND. A reset button is also shown, connected to the SW1 circuit.

The top diagram shows a current source (R20, 120) and a diode (D1, LED) in series, with a +3V3 supply. The bottom diagram shows a current source (R22, 120) and a diode (D3, LED) in series, with a +3V3 supply. Both diagrams include a feedback path (R21, 120) and a diode (D2, LED) in parallel with the current source and diode.

Rev. Version 26.0  
Id: 1/1

|  |  |
|--|--|
|  |  |
|--|--|