


A LITTLE GRAVITY THEATER

Cradle Crescent

PICK ONE HORN · TAP · WATCH HOME



POINT-UP = HOME

WHAT'S HERE

1 × one-piece Cradle Crescent


Moon, neck, and star are one rigid body.
Nothing to assemble.

2 · SET + TAP

Give the moon room.

Clear a hard, clean, level desk away from its edge.

Set the curved rail down, broad faces upright, horns up.



CHOOSE LEFT OR RIGHT

One high horn pocket. One gentle side tap. Let go.



DON'T SQUEEZE BOTH HORNS.


The star and long low belly are not controls.

3 · WATCH + HOME

Let gravity finish.

The moon, neck, and star move together as one piece.

The design is intended to rock side to side toward HOME.



HOME = STAR POINTS UP

The star stays attached and may remain visible.
Its point-up pose is the reveal.

AGAIN

Wait for it to stop, then tap either horn again.

To reset: lift by the broad body and place the curved rail centered, with the star pointing up.

TAP GENTLY · RELEASE · KEEP THE RAIL CLEAR

4 · KEEP IT KIND

Quick fixes

1

It does not rock

Curved rail down. Broad faces upright.
Tap one high side landing sideways—not down.

2

The star never hides

That is expected. It stays attached and may remain visible. Point-up HOME is the reveal.

3

It scrapes, walks, or catches

Stop. Clear the rail and desk; retry gentler.
If it persists, stop using it.

CARE + PACK AWAY

- Lift by the broad crescent body—never by the star or horns.
- Wipe with a soft, dry cloth.
- Store protected, with no weight on the star or horn tips.

SAFE DESK USE

Use on a stable surface, away from edges.
Tap, release, and keep clear of the moving rail.
Stop if cracked, chipped, warped, or sharp.