

Phase 5 — the Safety Island alone, every node

The last zoom. All 37 island nodes — 18 migrated Autoware I-nodes and 19 new **N**-nodes — plus the optional N20. Colour is still the Autoware stack, as in `ArchitectureMain.pdf`; the island runs a reduced version of nearly every stack. The HPC is off the page: it reaches this diagram only through N1.

