

Numerics

10 MHz Clock Output 4-38

5HG

Installation 5-20

Prism assembly 5-20

A

A/D Converter Window 7-20

AC Line Voltage Low 4-8

AC Phase Rotation 4-11

Acousto-Optic Modulator

Theory 8-10

Ambient Temperature 5-4

Amplifier

ASE 8-12

Small Signal Gain 8-11

Theory 8-11

B

Beam Diagnostic Equipment 6-20

Boosterboard Fan Not Turning 4-8

Bragg Diffraction 8-11

Brightness 8-7

C

Calibration

Cap Bank 7-20

Constant List 7-20

Depolarized Energy 4-29, 7-20

IR Energy 4-27, 7-20

Cap Bank Not Charged 4-8

CFC 113 1-3

Cleaning and Inspection 6-3

Clipboard messages 7-28

Coherence 8-7

Computer Interface

Applications Window 7-11

Crystal Temperature Window 7-22

Energy Ramp 7-15

General 7-3

Lamp Timing Window 7-23

Main Control Window 7-8

Menu Bars 7-5

Monitor Window 7-16

Peek Window 7-19

Serial Port Configuration 7-14

Service Window 7-18

Servo Window 2-6, 7-24

Slide Bars 7-6

Contact Fan Not Turning 4-8

Control Board EPROM Replacement 6-14

Control System Failure 4-8

Cooling Water 5-4

D

Daily Start-up Procedure 4-3

Daily turnon 4-3–4-5

DDE messages 7-28

Deionization Cartridge 6-7

Depolarized Energy 3-4, 7-17

Fault Message 4-8

Pulse Guard 2-5

Diagnostic Equipment

CCD Camera 6-21

IR Viewing Card 6-20

IR Viewing Scope 6-21

Photodiode 6-21

Power Meter 6-20

Directional 8-8

DPSS (DPMO) 8-9

Electronic Fault Message 4-8

Heater 7-20

Heater Adjustment 4-16, 4-26

Optical layout 8-9

E

Electrical Safety. See Safety

Electrical Service 5-5

Electrical Specifications. See Infinity

EPROM Hardware Fault 4-9

External (CDRH) Interlock Open 4-9

External Heat Exchanger Requirements 5-5

External Interlock Installation 5-6

External Lamp Triggering 4-34

External Q-Switch Triggering 4-35

Setup 4-36

F

Fault Messages. See System Fault Messages

FHG Installation 5-15

Flash Lamp 7-19

History 7-19

Replacement 6-8

Timing Window. See Computer Interface

Zero Counter 7-19

FlashTrack 2-6, 7-24

FlashTrack at Limit Fault 4-9

G

General Specifications 2-10

H

Harmonics

5HG

Installation 5-20

Optical Layout 5-21

Crystal Holding Assembly 5-9

FHG 8-22

Beam Path 5-17

Installation 5-15

Optical Layout 5-15

SHG 8-20

Installation 5-7

Optical Layout 5-7

Temperature Regulation 7-22

Theory 8-17

THG 8-21

Beam Path 5-12

Installation 5-11

Optical Layout 5-11

Heat Exchanger

Changing DI Cartridge 6-6

Changing Water Filter 6-6

Flow Sensor

Fault 4-11

High Water Temperature Fault 4-9

Level Sensor

Fault 4-10

Water Heater 7-21

I

Infinity

Control Windows. See Computer Interface

Dimensions 5-3

Electrical Service 5-5

Specifications 2-9

Telescope 5-27

Weights 5-3

Infinity command language 7-26

Inputs 4-33

Interlocks 4-3

External Interlock Fault 4-9

External Interlock Installation 5-6

Open Fault 4-9

IR Viewing Card 6-20

L

Lamp Not Simmering Fault 4-9

Lamp Ready Output 4-34

Lamp Timing 6-17, 7-23

Lamp Trigger Synch Output 4-37, 4-39

Laser Physics

Gain Medium 8-6

Pump Source 8-6

Resonator 8-6

Laser Principles 8-3–8-5

Light Characteristics

Brightness 8-7

Coherence 8-7

Directional 8-8

Monochromatic 8-8

Tunable 8-8

Low Cap Bank Voltage Fault 4-9

Low Water Level Fault 4-10

M

Master Oscillator 8-9

Maximum Voltage Regulation 4-5

Monitor Lamp Voltage 7-21

Monitor Window. See Computer Interface

Monochromatic 8-8

N

Noise

Long Term 7-17

Specification 2-9, 7-17

O

Optical Layout

5HG 5-21

FHG 5-15, 8-22

SHG 8-20

THG 5-11, 8-21

Optical layout

5HG 5-20

Optics Cleaning 6-3

Polarization Rotator 6-4

Relay System 6-5
 Oscillator Theory 8-9
 Outputs 4-33

P

Particle Filter 3-12, 6-6
 Peek Window. See Computer Interface
 Phase Conjugate Mirror 8-15
 Phase Matching 8-18
 Photodiode 6-21
 Polarization
 During Amplification 8-12
 FHG 8-22
 SHG 8-20
 THG 8-21
 Power Module A or B Over Current 4-10
 Power Module A or B over Temperature 4-10
 Power Module A or B Over Voltage 4-10
 Power Supply
 Electrical Service 5-5
 Flow Rate Valve 5-4
 Phase Rotation Error 4-11
 Trigger Layout 4-42
 Pulse Energy 2-9
 Pulse Energy Control 2-4
 Pulse Width 2-9

Q

QS Ready Output 4-35
 QS Synch Output 4-39
 Q-Switch (AO) 8-10, 8-11
 Q-Switch Inhibit Input 4-34

R

Relay Imaging 8-14
 Remote Buffer Overflow 4-10
 Remote Framing Error 4-10
 Remote Parity Error 4-10
 Remote System Control 7-25
 Remote UART Overrun 4-10
 RS232
 Commands 7-26
 Example program 7-30
 Serial port configuration 7-29
 Syntax 7-29
 System control 7-25

S

Safety 1-3–1-19
 3-Phase 6-15
 Chemical Safety 1-5
 CFC 113 1-3, 1-5
 Electrical Safety 1-5
 Eye Safety 1-3
 Government Compliance 1-6–1-7
 Interlocks 4-3
 Optical Safety 1-3
 Safety glasses 1-4
 Safety labels 1-7
 Safety References 1-19
 Voltage Regulation 4-3, 7-3
 Warning Signs 1-4
 SBS Cell 8-15
 SCR Failure 4-10
 Servo Error
 No Lasing 4-10
 Setting Up the Work Space 5-3
 SHG Installation 5-7
 Shut-Down Procedure 4-6
 Shutter 2-5
 Stimulated Brillouin Scattering 8-15
 System Fault Messages 4-8
 System Faults 4-7
 System timing 6-17

T

Telescope
 Base Plate Location 5-29
 Installation 5-27
 Optics 5-27
 THG Installation 5-11
 Transformer Fan Not Turning 4-11
 Trigger Signal Relationships 4-40
 Triggering 4-33
 10 MHz Clock 4-38
 External Lamp 4-34
 External Q-Switch 4-35
 External Q-Switch Setup 4-36
 Input Signals 4-33, 4-41
 Interface 4-42
 Lamp Ready Output 4-34
 Lamp Trigger Synch 4-37, 4-39
 Modes 4-33
 Output Signals 4-33, 4-41

- QS Ready Output 4-35
- QS Synch 4-39
- Q-Switch Inhibit Input 4-34
- Synchronization 4-38
- Var QS Synch 4-39

Tunable 8-8

V

- Var QS Synch Output 4-39
- Voltage Regulation 4-3, 7-3

W

- Water Cooling System 2-7
 - Maintenance 6-6
 - Specifications 5-4
 - Temperature 7-17
 - Fault 4-9
 - Water Heater 7-21
- Water Flow Low Fault 4-11
- Water Resistivity
 - Changing DI Cartridge 6-6
 - High Fault 4-11
 - Location of Regulating Valve 3-12
 - Low Fault 4-11
 - Monitor Readout Window 7-17
- Wrong AC Phase Rotation 4-11

