


Flash Partition Diagram

Neon Flash Storage Layout Visualization

Main Partition Layout



Address Range Scale



Color Legend

- APU Image
- System (System Partition)
- NPU Image
- OTA (Firmware Update)
- User (User Data)

Partition Detailed Information Table

No.	Partition Name	Start Address	End Address	Size	Percentage
1	APU Image	0x00000000	0x001FFFFFFF	2MB	25.00%
2	System	0x00200000	0x0027FFFF	512KB	6.25%
3	NPU Image	0x00280000	0x0037FFFF	1MB	12.50%
4	OTA	0x00380000	0x0057FFFF	2MB	25.00%
5	User	0x00580000	0x007FFFFFFF	2560KB	31.25%
Total				8192KB (8MB)	100%

Table shows precise address ranges and technical specifications for all main partitions


Partition Detailed Information

Subdivision Partition Description

The first 4KB of the APU image partition contains the **Head Blob**. The APU image partition also includes the **NPU bootloader image**.



Head Blob Subdivision (4KB Total Capacity)

Detailed layout of Head Blob's 3 sub-partitions is shown below



System Partition Subdivision (512KB Total Capacity)

Detailed layout of System partition's 2 sub-partitions is shown below



Flash Total Capacity: 8MB

Address Range: 0x00000000 - 0x007FFFFFFF