

Design and Tuning of Dampers and Vibration Absorbers

Jan Høgsberg

Technical University of Denmark


Local dampers on flexible structures

Cable vibrations

Erasmus Bridge



Sutong Bridge



Felix Weber




Eiland Bridge

Local dampers on flexible structures


Smart Structures Technology

Shunted Electromagnets



Larsen, Zhang & Høgsberg

Shunted Piezo-electrics






Richardt, Lossouarn, Høgsberg & Deü

Local dampers on flexible structures

Smart Structures Technology

Toftekær & Høgsberg



Local dampers on flexible structures

Smart Structures Technology


Toftekær & Høgsberg



Local dampers on flexible structures

The SDOF model

Single degree-of-freedom (SDOF) structure:



- m, k, c = modal mass, stiffness, damping
- Mode shape normalized to ?
- Modal damping $c = 0$ in tuning!

What approximations are made?

... and how valid are they?


Complex natural (angular) frequency:

$$\omega = \omega_0 \left(i\zeta \pm \sqrt{1 - \zeta^2} \right)$$

Damping ratio:

$$\zeta = \frac{c}{2\sqrt{km}} = \frac{c}{2m\omega_0}$$


Complex root locus for increasing c :



Local dampers on flexible structures

The MDOF model

Multi degree-of-freedom (SDOF) structure:



Equation of motion in frequency domain:

$$(-\omega^2 \mathbf{M} + \mathbf{K}) \mathbf{q} + \mathbf{w} f = \mathbf{f}_{\text{ext}}$$


Damper motion by connectivity vector:

$$u = \mathbf{w}^T \mathbf{q}$$

Viscous damper force:

$$f = i\omega c u = i\omega c \mathbf{w}^T \mathbf{q}$$


Complex root locus for increasing c :



- Viscous damping => Roots along *half-circles*
- Maximum damping = crossing with quarter circle (*).
- Max damping → Difference btw limit freqs → ○ to □

Local dampers on flexible structures

Two-component expansion



MDOF to 2-DOF system reduction:

$$\begin{bmatrix} \omega_0^2 - \omega^2 + H(\omega) & \kappa(\omega_0^2 - \omega^2) \\ \kappa(\omega_0^2 - \omega^2) & \omega_\infty^2 - \omega^2 \end{bmatrix} \begin{bmatrix} \xi_0 \\ \xi_\infty \end{bmatrix} = \begin{bmatrix} f_0 \\ f_\infty \end{bmatrix}$$




Optimal tuning:

$$c^{\text{opt}} = \frac{2(\omega_\infty - \omega_0)}{u^2}$$

$$\zeta^{\max} \simeq \frac{\omega_\infty - \omega_0}{\omega_\infty + \omega_0}$$

Local dampers on flexible structures

Cable damper



$$\zeta_n^{\max} \simeq \frac{\Delta\omega_n^\infty}{2\omega_n^0} = \frac{1}{2} \frac{a}{\ell} \quad , \quad c^{\text{opt}} \simeq \frac{T}{\omega_n^0 a}$$

Local dampers on flexible structures

Cable damper





Optimal viscous damping



General absorber models

Inertia and stiffness absorbers

Absorbers installed in shear frame model



Elements:

- Inerter Inertance m
- Dashpot Viscous coeff c
- Spring Stiffness k

Absorber force:

$$f = [D(\omega)v] = G(\omega)(u - v)$$

- Inertia-absorber: $m-[c \parallel k]$
- Stiffness-absorber: $k-[c-m]$




Equation of motion with v as absorber variable:

$$(-\omega^2 \mathbf{M} + \mathbf{K} + G(\omega) \mathbf{w} \mathbf{w}^T) \mathbf{q} - G(\omega) \mathbf{w} v = \mathbf{f}_{\text{ext}}$$


General absorber models

Inerters – the missing link


Inerter (J-damper) invented for F1 suspension




Translation into Rotation




Large inertia at low mass



fluid inerter






mechanical inerter



General absorber models

Limiting eigenvalue problems



Free EVP for $v = u$:

$$(\mathbf{K} - \omega_j^2 \mathbf{M}) \mathbf{u}_j = \mathbf{0}$$

Clamped EVP for $v = 0$:

$$(\mathbf{K} + G(\bar{\omega}_j) \mathbf{w} \mathbf{w}^T - \bar{\omega}_j^2 \mathbf{M}) \bar{\mathbf{u}}_j = \mathbf{0}$$

- Inertia-absorber: m -[c...] $(\mathbf{K} - \bar{\omega}_j^2 [\mathbf{M} + m \mathbf{w} \mathbf{w}^T]) \bar{\mathbf{u}}_j = \mathbf{0}$
- Stiffness-absorber: k -[c...] $(\mathbf{K} + k \mathbf{w} \mathbf{w}^T - \bar{\omega}_j^2 \mathbf{M}) \bar{\mathbf{u}}_j = \mathbf{0}$

Modal equations

Free-mode expansion

Modal representation by free modes:

$$\mathbf{q} = \sum_j \mathbf{u}_j r_j$$

Normalization to unit absorber displacement:

$$\mathbf{w}^T \mathbf{u}_j = 1$$

Modal structural equation:

$$(k_j - \omega^2 m_j) r_j + f = f_j$$

Modal mass and stiffness:

$$m_j = \mathbf{u}_j^T \mathbf{M} \mathbf{u}_j \quad k_j = \mathbf{u}_j^T \mathbf{K} \mathbf{u}_j$$

... and load: $f_j = \mathbf{u}_j^T \mathbf{f}_{\text{ext}}$

Aborber force equation:

$$f = G(\omega) (u - v) = G(\omega) \mathbf{w}^T \mathbf{q} - G(\omega) v$$

Modal representation of absorber displacement:

$$\mathbf{w}^T \mathbf{q} = \sum_j \mathbf{w}^T \mathbf{u}_j r_j = \sum_j r_j$$

Split into target mode $j = s$ and rest (residual modes):

$$\mathbf{w}^T \mathbf{q} = r_s + \sum_{j \neq s} r_j = r_s - \underbrace{\sum_{j \neq s} \frac{1}{k_j - \omega_j^2 m_s}}_{1/R_s(\omega)} f$$


Modal absorber force equation:

$$G(\omega)v - G(\omega)r_s + \left(1 + \frac{G(\omega)}{R_s(\omega)}\right) f = 0$$

Modal equations

Effective Modal Coupling Factor (EMCF)

Inertia absorber function: $G(\omega) = -\omega^2 m$



Modal absorber force equation:

$$-\omega^2 m v + \omega^2 m r_s + \left(1 - \frac{\omega^2 m}{R_s(\omega)}\right) f = 0$$

Clamped limit $v = 0$

Single frequency: $\omega^2 = \bar{\omega}_s^2$

Characteristic equation for $v = 0$:

$$\omega^4 \frac{m_s m}{R_s(\omega)} - \omega^2 \left(m_s + m + \frac{k_s m}{R_s(\omega)} \right) + k_s = 0$$

Single solution requires $R = \text{inertia}$: $R_s(\omega) \simeq -\omega^2 m'_s$


Residual mode mass ratio:

$$\frac{m}{m'_s} = \frac{\mu}{\mu_*} - 1$$

Corrected absorber force equation:

$$-\omega^2 m \frac{\mu_*}{\mu} v + f + \omega^2 m \frac{\mu_*}{\mu} r_s = 0$$

EMCF replaces mass ratio !



Mass ratio:

$$\mu = \frac{m}{m_s}$$

EMCF:

$$\mu_* = \frac{\omega_s^2 - \bar{\omega}_s^2}{\bar{\omega}_s^2}$$

Modal equations

Corrected SDOF model

Inertia absorber function: $G(\omega) = -\omega^2 m$

Structural equation for target mode $j = s$:

$$(k_s - \omega_s^2 m_s) r_s + f = f_s$$

Modal inertia-absorber equation:


$$-\omega^2 m \frac{\mu_*}{\mu} v + f + \omega^2 m \frac{\mu_*}{\mu} r_s = 0$$

Damper function: $f = D(\omega)v$


Modal frequency response function (FRF):

$$\frac{r_s k_s}{f_s} = \frac{-\frac{\omega^2}{\omega_s^2} \mu_* + D(\omega)/k_s}{\left(1 - \frac{\omega^2}{\omega_s^2}\right) \left(-\frac{\omega^2}{\omega_s^2} \mu_* + D(\omega)/k_s\right) - \frac{\omega^2}{\omega_s^2} \mu_* D(\omega)/k_s}$$

Corrected SDOF model




Parallel $m-[c||k]$



$$D(\omega) = k + i\omega c$$

Series $m-[c-k]$




$$\frac{1}{D(\omega)} = \frac{1}{k} + \frac{1}{i\omega c}$$


Absorber tuning

TID vs. TMD

Tuned Mass Damper (TMD)




Tuned Inerter Damper (TID)




Absorber tuning

Fixed-point tuning

Frequency response amplitudes



$$\mu = 0.05 \quad , \quad \zeta_d = 0.0 \text{ (---)} , \quad 0.1 \text{ (—)} , \quad 0.3 \text{ (—·—)}$$





- Response amplitude independent of TMD damping (ζ_d) at neutral or fixed points A and B
- Tune TMD stiffness k so that: $|x_0|_A = |x_0|_B$

Absorber tuning

Fixed-point tuning

Frequency response amplitudes



Optimal TMD stiffness k :

$$k_{opt} = \frac{\mu}{(1 + \mu)^2} k_s$$


Tune TMD damping (c):

- Flat plateau at intermediate point C: $\omega_C = \bar{\omega}_s$
- Equal amplitudes: $|x_0|_A = |x_0|_C = |x_0|_B$

Absorber tuning

Fixed-point tuning


Frequency response amplitudes



$$\mu = 0.05 \quad , \quad \zeta_{classic} \text{ (---)} \quad , \quad \zeta_{opt} \text{ (—)} \quad , \quad \zeta_* \text{ (— —)}$$

Optimal TMD damper c :

$$c_{opt} = \sqrt{\frac{2\mu^3}{(1+\mu)^3}} \sqrt{k_s m_s}$$




Classic TMD damper c (Den Hartog):

$$c_{classic} = \sqrt{\frac{3}{2}} \frac{\mu^3}{(1+\mu)^3} \sqrt{k_s m_s}$$

Absorber tuning

Pole placement calibration



Desired polynomial equation:

$$\rho^4 - \rho^2 (2 + (2\zeta_{\text{bif}})^2) + 1 + 2i\rho(2\zeta_{\text{bif}})(-\rho^2 + 1) = 0$$

TID characteristic equation (denominator of FRF):

$$\rho^4 - \rho^2 \left(1 + \mu_* + (1 + \mu_*)^2 \frac{\kappa}{\mu_*} \right) + (1 + \mu_*)^2 \frac{\kappa}{\mu_*} + i\rho \left(\sqrt{1 + \mu_*} \right)^3 \frac{\beta}{\mu_*} (-\rho^2 + 1) = 0$$

Tuning by comparison of terms

1) Ratio btw ρ^3 and ρ terms:

$$\rho = \frac{\omega}{\omega_s} \sqrt{1 + \mu_*}$$

2) Constant terms:

$$\kappa = \frac{\mu_*}{(1 + \mu_*)^2}$$

3) ρ^2 terms:

$$\zeta_{\text{bif}} = \frac{1}{2} \sqrt{\mu_*}$$

4) ρ^3 (or ρ) terms:

$$\beta = \frac{1}{\sqrt{2}} \beta_{\text{bif}} = \sqrt{2 \frac{\mu_*^3}{(1 + \mu_*)^3}}$$

5) Absorber (TID) parameters:









$$c = \beta \sqrt{m_s k_s}, \quad k = \kappa k_s$$

EMCF

$$\mu_* = \frac{\omega_s^2 - \bar{\omega}_s^2}{\bar{\omega}_s^2}$$


Damping of shear frame

Frequency response amplitude (FRF)



Damping of shear frame





Root locus diagrams



Mode $s = 1$ damping ratios for $\mu = 0.02$

	free	
	$\mu_* = 0.0219$	$\mu_* = 0.0200$
$m-[c\ k]$	0.0473	0.0582
	0.0480	0.0299
$m-[c-k]$	0.0479	0.0655
	0.0470	0.0298


+ 30% reduction in damping ratio by $\mu_* = \mu$



Piezoelectric RL shunt damping

Mechanical equivalence

Piezoelectric effect: Deformation \leftrightarrow Voltage



Electric balance:

$$q(t) = -\theta u(t) + Cv(t)$$


Series Resistive-Inductive (RL) shunt:

$$v(t) = -(R\dot{q}(t) + L\ddot{q}(t))$$


Shunted piezo equation:

$$LC\ddot{v}(t) + RC\dot{v}(t) + v(t) = \theta(L\ddot{u}(t) + R\dot{u}(t))$$

Shunt resonance at frequency: $\omega_e = 1/\sqrt{LC}$




Benchmark: Piezo-pair on cantilever:



Equation of motion with piezo force $f = \theta v$:

$$\mathbf{M}\ddot{\mathbf{u}}(t) + \mathbf{K}\mathbf{u}(t) = -\mathbf{w}\theta v(t) + \mathbf{f}_e(t)$$


Equivalent mechanical absorber $k-[c||m]$




Piezoelectric RL shunt damping

EMCF and tuning

Limiting absorbers:



$$(\mathbf{K} - \omega_j^2 \mathbf{M}) \mathbf{u}_j = 0$$



$$(\mathbf{K} + k \mathbf{w} \mathbf{w}^T - \bar{\omega}_j^2 \mathbf{M}) \bar{\mathbf{u}}_j = 0$$

free
clamped
 $k = \theta^2/C$

Effective Modal Coupling Factor EMCF:

$$\kappa_* = \frac{\bar{\omega}_s^2 - \omega_s^2}{\omega_s^2} = \frac{\omega_{oc}^2 - \omega_{sc}^2}{\omega_{sc}^2} = K^2$$

(Effective Electro-Mechanical Coupling Factor EEMCF)

Tuning by pole placement:

$$\mu = \frac{\kappa_*}{(1 + \kappa_*)^2} \quad \beta = \sqrt{2 \frac{\kappa_*^3}{(1 + \kappa_*)^3}} \quad \zeta_{des}^2 = \frac{1}{8} \kappa_*$$

Shunt components:

inductor

$$L = \mu \frac{m_s}{\theta^2}$$





resistor

$$R = \beta \frac{\sqrt{m_s k_s}}{\theta^2}$$





Numerical analysis




Piezoelectric RL shunt damping

Experiments – free beam



Flexural mode	1	2	3	4	5
$\omega/(2\pi)$ (Hz)	152.6	415.0	806.8	1320	1958.0
$\hat{\omega}/(2\pi)$ (Hz)	153.2	416.2	808.9	1324	1968.1
κ_*	0.80	0.59	0.53	0.53	1.03





OC (---), L (- - -), and LR (—)
absorbers 1 (···), 2 (---), 3 (—), and 4 (···)



Piezoelectric RL shunt damping

Experiments – free plate


(Toftekær)



- Mode $s = 3$: piezos 2 and 3
- Mode $s = 4$: piezos 1 and 4




(Weber – Maurer.de)




(Toftekær)

That's it!



(Richardt, Lossouarn, Deü - CNAM

Exercise



Equation of motion for augmented system:

$$\tilde{\mathbf{M}}\ddot{\tilde{\mathbf{q}}}(t) + \tilde{\mathbf{C}}\dot{\tilde{\mathbf{q}}}(t) + \tilde{\mathbf{K}}\tilde{\mathbf{q}}(t) = \tilde{\mathbf{f}}(t)$$

$$\tilde{\mathbf{q}}(t) = \begin{bmatrix} \mathbf{q}(t) \\ u(t) - v(t) \end{bmatrix}$$

$$\tilde{\mathbf{M}} = \begin{bmatrix} \mathbf{M} & \mathbf{0} \\ \mathbf{0}^T & m \end{bmatrix}, \quad \tilde{\mathbf{C}} = \begin{bmatrix} \mathbf{C} + c\mathbf{w}\mathbf{w}^T & -c\mathbf{w} \\ -c\mathbf{w}^T & c \end{bmatrix}, \quad \tilde{\mathbf{K}} = \begin{bmatrix} \mathbf{K} + k\mathbf{w}\mathbf{w}^T & -k\mathbf{w} \\ -k\mathbf{w}^T & k \end{bmatrix}$$

Tuning and time integration by python script: **shearframe_damp.py**

Exercises:

1. Download and run **shearframe_damp.py**
2. What is the modal mass ms ? Compare with total weight of shear frame ($5*mf$)
3. Compare mass ratios $mu(\mu)$ and $mua(\mu_*)$. How large is the difference in % ?
4. How large is the reduction in top-floor amplitude when installing TID?
5. Compare TID amplitude with structural amplitude.
6. Use detuned parameters (for $\mu_* = \mu$) and compare top-floor amplitude with optimal tuning