


PC BOARD/DIRCUIT DIAGRAM

▼ COUNTER UNIT (X54-1360-00)



Q1, 2, 3, 4, 5, 8, 9, 10, 13	: 2SC1815(Y)	IC1	: SN74LS90N	IC10	: TC4042BP
Q7	: 3SK73(GR)	IC2	: TC5026BP	IC11, 12, 13	: TC4019BP
Q11, 12	: 2SC1959(Y)	IC3, 4	: TC4518BP	IC14	: TC4049BP
Q6	: 2SC785(O)	IC5	: TC4027BP	IC15	: TC5022BP
		IC6, 7, 17	: TC4011BP	IC16	: TC5066BP
D1	: WZ-071	IC8	: TC5051BP	IC18	: TC5012BP
	: WZ-090	IC9	: TC4029BP	IC19	: TC5064BP