




NEEdle Plates







<u>Japanese Zig Zag Needle Plates</u>




NZZ04LG





NEEdle Plates

















Needle Plates are Shown Actual Size




Needle Plates/Slide Plates

European Zig Zag Needle Plates











Needle Plates are Shown Actual Size





Slide Plates



Slide Plates are Not Shown Actual Size

NEEDLE PLATES

Singer Zig Zag

170313 Singer 5123, 5124, 5127

172200 Singer 401, 403, 401A, 500, 503, 600, 603, 620, 625, 626, 628, 629, 635, 636, 638, 639,

645, 646, 648, 649, 620E31, 630E3, 640E3

174198 Singer 417, 714/717 (schoot), 714, 717, 719, 724, 734, 737, 750, 755, 756, 758,

770, 774, 775, 776, 778, 1000, 1000G, 1060, 6700 series (312391)

181871 Singer 900, 920

283007 Singer Quantum XL-1, CXL

310703 Singer 240/250 series, 247AP, 288, 328, 327, 337, 338, 347, 348, 350/360 series.

413, 413K13, 416, 418, 457, 466, 476, 477, 478, 6100/7100 series, 5mm zig zag

(352461-892)

310706 Singer 502, 507, 509, 513, 514, 518, 522, 527, 533, 534, 538, 560, 800 series, 935U,

6100/6500/7100 series, 5mm zig zag [312391] 312777 Singer 1872, 4600/5800/5900/6200 series

381245 Singer 1200

382795 Singer 925, 1030, 1036

382806 Singer 2000, 2005

383339 Singer 2001

383952 Singer 2010 409286 Singer 935, 1040G, 1411U, 1425U 444443 Singer 177, 237

Singer 2210, 6mm zig zag 531663 Singer 3102, 3103, 6012, 1280, 6mm zig zag

542362 Singer 698U 549841 Singer 223

116585001 Singer 5522, 5528 NZ660LG Singer 5102, 5107, 5122

Singer S.S. & S.S. for ZZ Machines

8323 Singer 27, 127, 128

15280 Singer 15 class, 15-30, 201, 1200-1, HA-1

32602 Singer 66 (32783)

447580

44985 Straight stitch version of 310703

45940 Singer 221, complete w/position bracket 125319 Singer 15-88, 15-90 (173585-852)

163727 Singer 404, 604

170098 Singer 301

171137 Straight stitch version of 174198 171392 Straight stitch version of 310706

171470

Straight stitch version of 181871 174529 Straight stitch version of 172200

313066 Straight stitch version of 312777, Singer 9022, 9410

352262 Singer 239

SAZ10-1A S.S. version of 58501, left needle position

Z11064 S.S. version of Z11063, left needle position

<u>Japanese Zig Zag Machines</u>

Match your needle plate with the illustrations, Z11063, 58501, & Z95C are the most used needle plates.

120817 Brother 461, 751, flat bed 121191001

Brother XL703, free arm 116585001 Brother XL700, free arm

515501 Brother 1243, free arm

B2437 Brother 441, 691, flat bed

B4139 Brother 210, 991, flat bed X54373051

Brother XL2010 193 Flat Bed

264 Flat Bed

266 Flat Bed 55C Flat Bed

7010LC Flat Bed, Necchi 522

267 Free Arm

NZ531FA Free Arm

58501 Japanese zig zag, side load

33861B Kenmore 57860B Kenmore

NZ203LG Morse, Free Arm

See Singer Chart Pages 68-73

NEEDLE PLATES (Con't) Plates for Japanese Zig Zag Machines (Con't.)		
1 10100 101		
NZ204LG	Morse, Free Arm	
NZ793FA	Necchi, Free Arm, 523	
Z11063	Necchi, New Home, Riccar	
268	Nelco, Free Arm	
N250	Nelco, Flat Bed	
NZ660LG	Nelco	

NZ660LG 607814004 New Home, Free Arm Riccar 8500, Free Arm 53635

58654 Riccar, Flat Bed **R555** Riccar, Flat Bed R666 Riccar, Flat Bed

<u>Plates for European Zig Zag Machines</u>

53161 Adler 153, 153A, 189, 189A, 289, 589, 789, 989

87148 Adler 87, 187 O.S., Bell 301

0016337100 Bernina 1230 327.000.03 Bernina N.S.: 730, 830

327.002.03 Bernina F/B: 117L, 540, 542, 640, 740, etc.

327.043.18 Bernina - early models: 530, 532, 534, 730 403100 Elna 62

403401 Elna "Air Electronic" Z11063

Necchi BU Nova, Mira, Nora, Lylia: 512, 513, 514, 515 (D26376)

85111 Necchi Supernova 48262 Pfaff 360 48450 Pfaff 260, 262

46693 Pfaff 130, 230 (46479)

Viking Needle Plates

4010496 Viking 4013177 Viking 49E, 51, combination with slide (**4013011** - plate only)

4110364-01 Viking 6310 4111555 Viking 19A, 21, 21A, 21E, 2000, 6000,

6430 - 2 screw holes 4115177-02 Viking 5610, 5710

Viking 6440, 6460, 6690 412005401 Viking 900, 1050, 1090, 1100

4120073-01 Viking 90, 100, 105, 120, 150, 180, 185, 190, 610, 620, 630

4122881-01 Viking 205, 215, 225, 230

White Needle Plates

4115628

11032W White 3900 11717 White 208

White 264R, 455, 464R, 530, 535, 1465, F-30, F101, W-40, W-60, W-800 White 7234, Toyota 6300

3681 White 988, 1088 4342 White 510, Morse FA630

4539 White 690 5850 White 977, 999, 1077, 1099, 1111, 1112

17297

11930

6529 White 1505, 1510, 1810 6580 White 2220, 2221, 2222

6764 White 1710 6901 White 1523, 1577, 1599

6478, 6479

693 White 221, Nelco 4102FA, Supreme \$386FA 76008 White 578, 673, 970, 1065, 2137, 2334, 3077, 3354, 5437, 5438, 5439, 6477,

78039 White 764, 769, 782, 793, 804, 970, 1665 79154 White 915, 925, 935, 940, 951, 954, 955, 967, 976

9306 White Rotary US **Z95C** White, Morse (NSZ1)

Straight Stitch Needle Plates

15280T Japanese HA1, Singer 15-30 S1163 Combination w/slide, HA-1, Singer 15-30 15-86 Combination with slide, wedge shape 9306 White Rotary 75, 77 - 31/2" long (73054) EXB71 Reversew, ELD

Slide Plates & Springs

Singer

172956

<u>omgor</u>		
Slide Plate	Machines	Slide Spring
15147	15-30, 115 (15-88, 15-90, 15-91)	2824
15147	15-88, 15-90, 15-91	125337
55503	27, 127, Free Vibrator, rear slide	
55504	27, 127, Free Vibrator, front slide	
32569	66, 99	32570
116080	500 & 800 Series free arm	103344
310739-451	500 & 800 Series flat bed	103344
172015	401, 403, 404, 500, 503, 600 Series (163744)	172016

417, 714, 717, Apollo flat bed

172957

179522

37239

382713

408035

179521 328/9, 337/8, 347,8K, 357, 466, 477 (44838-891) 179521 360, 362, 368

382859 770, 775, 778 408034 935 (slide with window)

See Slides & Springs Pages 32-33