

## This is what you receive.

... in a very attractive box:



your sewing machine « ELNA Junior » with a no. 90 needle already attached, and with a sample sewn on your machine,



a plastic bag containing:

a clamp to fasten the machine on the table,



a spool of no. 50 sewing thread,



Fig. 1

a screw-driver to attach the needle.





a miniature sewing machine that really sews and has a free arm just like the automatic « ELINA ».

It sews with a chain stitch and therefore uses no bobbin. This makes it easy for children to use, for you can quickly teach them how to thread the needle and do real sewing jobs.

If you will teach the children how to make plain seams and hems, how to baste on pockets, lace and bands, and how to press as they sew, you will help them to establish neat sewing habits and to feel proud of their work.

Sewing with an «ELNA Junior» can be fun for everyone.



# STUDY THIS PAGE THOROUGHLY

You will understand all the working parts of the «ELNA Junior ».




Fig. 2

- 1. Handle.
- 2. Support for spool of thread.
  - 3. Thread take-up lever.
    - 4. Thread guide.
- 5. Tension adjusting device.
  - 6. Lever to lift the foot,
    - 7. Needle bar.
      - 8. Needle clamp.
        - 9. Needle.
- 10. Stitch length adjusting knob




- 11. Hook.
- 12. Foot with finger guard.
  - 13. Free arm.
- 14. Hole for clamp to fasten the machine on the table.
- 15. \* Key to wind the musical box.
- \* Only on machines with a musical 16. \*Button to start the music.

box.




#### FASTEN

THE « ELNA Junior » TO THE EDGE OF A TABLE Insert clamp (17) in hole (14) of the machine and tighten screw (18).




## HOW TO INSERT A NEEDLE

First lower foot (12) by means of lever (6). Turn handle (



in the direction of the arre until the needle bar (7) b come up completely. U the needle clamp (8) wi the screw-driver (19) an insert the needle (9) as f as it will go, with its  $\theta$ side (20) facing to the rigl tighten the scre screw slightly the screw Then again. Important: «ELNA Junion uses standard needles (s stem 705 or  $15 \times 1$ ).






### THIS IS HOW TO THREAD THE MACHINE:

Place the spool on the support (2) so that the thread unwinds Now pass it through the thread guide (4) and through the slot of the tension device (21), on the side of the machine. from back to front (see dotted The foot remains lowered. line). Important: Hold the spool of thread with the right hand and with the left hand pull the

Fig. 5


thread firmly up, so that it is properly inserted in the tension Then let go of the spool and continue to pull the You should now feel a considerable resistance. device. thread.



Finally pass the thread through the hole of the needle (9) from from right to left and through the thread take-up lever (3) left to right. Lift the foot with lever (6), pull the thread under the foot towards the back (22), until you have a loose end of approximately 2".



By turning knob no. 10 (under the needle plate), (fig. 2), you can choose three different stitch lengths, as may be required for the type of thread and material used.



short stitches. white mark:

Number «1» at the

Number «2» at the white mark:

medium stitches.



white mark:

Number «3» at the

long stitches.





## NOW START TO SEW

The needle bar and the foot are both raised. Place your work below the foot and lower the foot with lever (6) (see fig. 2). Start to sew, guiding the material with the left hand and turning the handle with the right in the direction of the arrow.

Important: To avoid tangling the thread, never turn the wheel backwards.




Fig. 8




# THE TENSION OF THE THREAD IS TO BE ADJUSTED AS FOLLOWS

The «ELNA Junior» has a sewing sample under the foot and is threaded with a no. 50 cotton thread. The tension is adapted to this type of thread. Other threads of slightly differing thicknesses may however be used without readjusting the tension.


With a good seam, the material will not gather and the chain appearing underneath is tight.

If the material gathers, the tension is too tight; to loosen it, turn the knob (5) in the direction of the arrow (fig. 9) away from you.

If the chain underneath the material is too loose, the tension is too loose; to tighten it, knob (5) must be turned in the direction of the arrow (fig. 10) (turn knob towards you).







#### THE MATERIAL TO REMOVE

desired length, stop the After having sewn the (fig. 2). Hold the the thread take up lepull it about 4" to «ELNA Junior» with the needle bar in its thread halfway between ver and the needle and the foot with lever (6) upper position. the left (fig. 11). With your scissors then thread out to the left from underneath the foot (fig. 12). Cut it pull your material in the middle. Then pull this length backwards firmly.

Fig. 12

In this manner, the seam will not be-« ELNA » will remain come undone and your threaded for the next job.


If you wish to secure your seam even more efficiently, make

a few stitches by hand as shown by fig. 13.

MUSIC WHILE YOU WORK

fitted with a musical box, If the «ELNA Junior» is

you will find a winding key (23) on its front, as well as



the musical box, turn the key in the direction of the arrow. By pulling the button (24) you will hear the

stop the music. To wind

a button (24) to start and

Fig. 14

## of the « ELNA Junior ».

will stop. The name of the

tune is shown on the label glued underneath the base

music. If you push it, it

### MAINTENANCE

Clean the machine regularly with a brush, principally below the foot and around the hook.







Fig. 13

The following are some suggestions for sewing jobs, which can easily be done on the «ELNA Junior». To do them, just follow the advice given hereafter...



#### 6



## STRAIGHT SEAM

Place the pieces of material one on top of the other, the right sides facing each other. To hold them in place, fasten them with pins. Then sew the seam, pulling the pins out, as you go along, guiding the edge of the material below the right edge of the foot. Unfold the material.

Fig. 17

### FELLED HEM

Fig. 18

Place the pieces of material one on top of the other, the right sides facing each other, the lower piece protruding by approximately ¼ " (a). Then sew at a distance of approximately ½ " (b) from the edge of the lower material. Unfold the two pieces of material and fold the larger edge over the smaller. Flatten the resulting fold and fasten it with pins. Then sew along the folded edge (see dotted line c).

#### HEM

Fig. 20

Fig. 19

Fold the edge of the material and sew as shown in fig. 20.

To obtain rolled hems fold the material a second time and sew it once more



Fig. 21

(fig. 21).

#### 13

#### OF DECORATIVE FIXATION RIBBONS

To bind a piece of material, the market.

Fig. 22

central seam (b).

ferent ously.



Use the ribbons available on

fold the ribbon in its middle and place it along the edge of the material, then sew.

When decorating a piece of work with ribbons, they can be fixed either by seams on both edges (a) or by one

Fig. 23

tained by sewing on ribbons in broken lines or by fixing Pretty patterns are also obtwo or three ribbons of difcolours simultane-



### GATHERING

To obtain a nice small distance one from the ly sew with too strong a several parallel seams at a To gather the material, simpeffect, it is necessary to sew tension.

Fig. 25

other (fig. 25).

If you wish to gather lace, sew two seams at a distance of approximately 14" with too strong a tension. Once prepared in this manner, the lace can be sewn onto the material with a normal tension.



Fig. 26






Fig. 24

#### 15

### OUILTING

To do quilting (fig. 27) place upon each other:



b) a layer of quilting material,

c) a piece of good material, possibly with decorative patterns.

Fig. 27

It is advisable to baste them with a few stitches (d), see fig. 28. Then start to sew diagonally from the middle of the work (e).

Fig. 28

The edges of a quilted piece of work can furthermore be bound (fig. 29), if desired.

#### HOW TO MAKE A DOLL'S BLOUSE

Draw the pattern of the blouse on a piece of paper, taking into account the following dimensions (fig. 30):

a =  $\frac{1}{2}$  circumference of the waist +  $\frac{1}{2}$ " for the hems.

b = Distance from the waist to the shoulders  $+ \frac{1}{2}$  for the hems.

c = Circumference of the neck of the doll.


After having drawn the pattern, cut it out and place it on the material. Cut the material accordingly, also cut out the opening of the neck c and the middle line of the back f. Before starting the seams, remember that they must be sewn on the wrong side of the material, so that in the end they are on the inside of the completed blouse. Make two small hems of ¼ " along the line of the middle of the back f. Proceed likewise on the sides of the blouse. If you want to decorate the neck line c, bind it with a coloured

Fold the blouse in two so that the right side of the material is turned inward (fig. 31). Sew half of the height of the blouse with the seams d.

ribbon as explained on page 12.

Fix three snap-buttons at the points marked g.

Then turn the material again inside out.



you want to deco

3



14

Fig. 29

## The Elna Junios

is the baby sister of the  $\ll ELNA \gg$  household sewing machines which are known the world over.

Their queen is known under the name of

# Elna Supermatic

Easiest for beginners and fastest for experts, it does either straight or decorative stitches as simply as a straight seam. These are obtained entirely automatically, never before possible on a household sewing machine.



# IT CAN EVEN DO REAL EMBROIDERY

For further information, please consult the  $\ll ELNA \gg$  dealer nearest you.



#### CHOICE

OF THE MATERIAL, THE NEEDLE, THE THREAD AND THE STITCH LENGTH

Use only needles of system 705 (15  $\times$  1) which is the most common for household sewing machines. Their size should be adapted to the material and the thread used. The « ELNA Junior » is equipped with a no. 90 needle enabling you to sew any average job.

Stitch Length		1 or 2	2	2 0r 3	ಣ
Silk		24 to 30	20	16 to 18	10 to 12
Cotton		80 to 100	60 to 80	40 to 60	30 to 50
Needle	X	70 or 80	80 or 90	06	100
Material		Sheer material	Ordinary material	Thick material	Very thick material







TAVARO S.A. GENÈVE