

FORM 8941  
SUPERSIDES FORM 8620  
NOVEMBER, 1923  
PRINTED IN U. S. A.

# PRICE LIST OF PARTS



FOR FAMILY SHOPS

---

## MACHINES

Nos. 15-22, 15-30, 15-41,  
15-43 and 15-50

---

THE SINGER MANUFACTURING COMPANY

COPYRIGHT, U. S. A., 1919, 1922 AND 1924,  
BY THE SINGER MANUFACTURING CO.  
ALL RIGHTS RESERVED FOR ALL COUNTRIES

# INDEX

	PAGE
ACCESSORIES.....	26
ATTACHMENT SET COMPLETE No. 25623.....	26
"      "      "      " 35918.....	27
BIAS GAUGE.....	29
BOBBIN WINDERS.....	32
BRAIDER.....	29
CORDER (Bow).....	29
DARNING FOOT (SPRING).....	29
EDGE STITCHER.....	29
EMBROIDERY ATTACHMENT FOR ONE THREAD.....	27
"      "      " TWO THREADS.....	28
FELLER (Foot).....	30
HAND ATTACHMENTS.....	42
HEMMERS.....	30
HEMSTITCHER.....	30
MACHINE No. 15-22.....	7
"      " 15-30.....	11
"      " 15-41.....	16
"      " 15-43.....	21
"      " 15-50.....	25
NUMERICAL LIST OF PARTS.....	71
OBSOLETE PARTS.....	61
PRESSER FEET.....	30
QUILTERS.....	31
RUFFLERS.....	31
STAND No. 25281.....	51
"      " 82953.....	53
TRIMMINGS FOR CABINET TABLE.....	55
"      " COVER SET.....	54
"      " DRAWING ROOM CABINET.....	56
"      " OPEN-SIDE DRAWING ROOM CABINET.....	58
"      " PORTABLE CASE.....	60
TUBULAR TRIMMING ATTACHMENT.....	31
TUCK FOLDER.....	31
UNDER BRAIDERS.....	32

## INSTRUCTIONS FOR ORDERING

---

In ordering from this list, use ONLY the part NUMBER in the FIRST column.

The number stamped on a Sewing Machine part is in every case the number of the single part only.

Every combination of parts sent out as such has its specific number, which, although not stamped on the parts, must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only.
- D. Polished only.
- E. Soft, not Polished.
- F. Hardened and Polished.
- G.
- H. Blued.
- J. Plated only.
- K. Hardened and Plated.
- L. Brass or Gilt.
- M. Oxidized.
- P. Japanned.
- R. Parkerized.
- T. Copper-plated.

These letters MUST BE USED *when* they appear in the list, and AFTER the number *as* in the list.

In this series:

- 1 to 1500 and 50001 to 51500 are Screw Numbers.
- 1501 to 1800 are Nut Numbers.
- 1801 to 2000 are Roller Numbers.
- 2001 to 50000 and 52001 and upward are numbers of Machine Parts.

The figures in the second column refer only to the plates, illustrating the parts, and are NOT TO BE USED in ordering.

Parts marked with an asterisk (\*) are furnished only when repairs are made at factory.

## LIST OF PARTS COMPLETE

**FOR**

## **MACHINE No. 15-22**

**FAMILY, LONG BEAK SHUTTLE, DROP FEED, H. O.**

NO.	PLATE	NAME	EACH
*15495	—	Arm.....	\$6 00
15496	—	" 15495 with 435c, 448c, 15486 and 15498.....	6 70
2002	703	Arm Dowel Pin.....	02
138E	705	" Screw.....	07
15497	4917	" Shaft.....	1 50
15498	4917	" " Bushing.....	35
435c	4923	" " " Set Screw.....	06
15427	4917	" Side Cover.....	25
286B	706	" " " Thumb Screw.....	20
2007	703	" Spool Pin.....	02
8879	700	" " " Washer (cloth).....	01
15282	699	Balance Wheel, 2½ in. pulley.....	1 50
*2805	—	Bed.....	6 00
256B	700	Clamp Stop Motion Clamp Screw.....	50
248A	705	" " " " Stop Screw.....	02
2020	700	" " " " Washer.....	07
*15312	—	" " " " Flanged Bushing.....	55
15313	1902	" " " " " 15312 with two 462c.....	55
2022	703	Clamp Stop Motion Flanged Bushing Pin	01
462c	706	" " " " " Set Screw.....	02
15314	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....	1 15
125011	4917	Crank Connecting Rod with 125012 and two 896E.....	95
*125012	—	Crank Connecting Rod Cap.....	—
896E	4923	" " " " Screw.....	06
375C	705	" " " " Hinge Screw.....	20
1518E	706	" " " " " Nut.....	06
*15406	—	Face Plate.....	90
*15407	—	" " 15406 with 15428.....	1 25
15432	4917	" " 15407 with 857B, 2827, 15410, 15412 and 50292B.....	1 85
15408	—	Face Plate Tension Seat.....	30
15428	—	" " " " 15408 with 15395	35

NO.	PLATE	NAME	EACH
55644	—	Face Plate complete, Nos. 15432 and 15471	\$2 50
190B	705	Face Plate Screw.....	05
2827	703	" " Thread Guard with 8505.....	02
8505	703	" " " " Rivet per 100	20
2037	700	Feed Bar.....	55
315c	705	" " Screw Centre.....	06
1519J	706	" " " " Nut.....	05
15306	1902	" Cam with 1285c.....	35
1285c	706	" " Set Screw.....	06
2040	702	" Dog.....	35
191c	705	" " Screw.....	05
15319	699	" Forked Connection with 175J.....	85
175J	706	" " " Adjusting Screw	02
1381K	706	" " " Hinge Screw (eccentric).....	20
1520J	706	Feed Forked Connection Hinge Screw Nut	05
1832	706	" " " Roller with 1085E	30
1085E	1909	" " " " Screw Stud	10
2816	699	" Lifting Rock Shaft.....	55
2817	—	Feed Lifting Rock Shaft complete, Nos. 2573 and 2816.....	1 15
2573	702	Feed Lifting Rock Shaft Crank with 157J and 1935.....	60
157J	705	Feed Lifting Rock Shaft Crank Clamping Screw.....	06
1935	706	Feed Lifting Rock Shaft Crank Roller and Stud.....	30
307c	705	Feed Lifting Rock Shaft Screw Centre...	10
1513J	706	" " " " " Nut	07
2044	704	" Regulator.....	35
8217	4918	" " Friction Washer.....	01
50353E	4918	" " Hinge Screw.....	10
747B	705	" " Thumb Screw.....	20
15297	699	" Rock Shaft.....	80
307c	705	" " " Screw Centre.....	10
1513J	706	Feed Rock Shaft Screw Centre Nut.....	07
50380c	6317	Machine Hinge Connection Set Screw ...	05
2050	700	Needle Bar.....	55
*15248	1909	" " Connecting Link with 930E...	80
15374	—	" " " " 15248 with 2052.....	1 15
930E	1909	Needle Bar Connecting Link Adjusting Screw.....	06
570c	706	Needle Bar Connecting Link Hinge Screw	10
1520J	706	" " " " " Nut.....	05

NO.	PLATE	NAME	EACH
2052	704	Needle Bar Connecting Stud with 155c...	\$ 35
155c	705	" " " " Set Screw...	05
15068	711	" " Thread Guard.....	01
251A	705	" " " " Screw.....	02
2054	703	" Clamp with 552c.....	35
552c	705	" " Thumb Screw.....	20
125013	4917	Oscillating Rock Shaft.....	80
307c	705	" " " Screw Centre.....	10
1513J	706	" " " " Nut.	07
2056	699	" Shaft.....	35
*2163	—	" " Crank with 1813.....	80
2057	702	" " " 2163 with two 462c.....	80
2049	703	Oscillating Shaft Crank Pin.....	01
1813	706	" " " Roller and Stud..	30
462c	706	" " " Set Screw.....	02
15257	700	Presser Bar.....	50
15236	4906	" " Lifter.....	30
15486	4923	" " " Hinge Stud.....	25
448c	705	" " " " Set Screw..	05
8399	700	" " Spring.....	07
2068	704	" " " Bracket with 453c....	35
453c	705	" " " " Set Screw....	02
2070	703	" " " Washer.....	01
15281	4909	" Foot.....	35
15262	4909	" " (rounded heel) for riding seams.....	50
286B	706	Presser Foot Thumb Screw.....	20
263J	705	Pressure Regulating Thumb Serew.....	30
2073	702	Shuttle Bobbin.....	07
2211	702	" " Retaining Spring.....	05
2212	702	" " " " Rivet .....per 100	35
*2213	—	Shuttle Body with 398E, 2082, 2084, 2211 and two 2212.....	85
*2075	—	Shuttle Cover.....	55
*44001	—	" " 2075 with 112d, 466H, 2078, 2080, 2086 and 2090.....	85
2076	702	Shuttle Cover Hinge Pin.....	01
2078	702	Shuttle Delivery Eye Thread Guard.....	05
2080	702	" " " " " Rivet	01
2082	702	" Main Spring.....	20
398E	702	" " " " Screw.....	02
2084	702	" " " Steady Pin.....	01
466H	702	" Tension Regulating Screw.....	06
2086	702	" " " Spring.....	05
2090	702	" " " Plate.....	07

NO.	PLATE	NAME	EACH
112D	702	Shuttle Tension Spring Screw.....	\$ 02
2208	702	Shuttle complete, Nos. 2073, 2076, 2213 and 44001.....	1 50
*2176	—	Shuttle Driver.....	80
2092	702	" " 2176 with two 457c.....	80
2049	703	" " Pin.....	01
457c	705	" " Set Screw.....	02
2095	701	" Race Back.....	30
190c	705	" " Screw.....	05
2096	—	" " Body.....	65
2093	701	Shuttle Race complete, Nos. 2095, 2096 and two 190c.....	1 15
158D	705	Shuttle Race Screw.....	05
2994	—	" " Slide.....	35
2995	4910	Shuttle Race Slide complete, Nos. 2824, 2994 and two 50216J.....	50
2824	704	Shuttle Race Slide Spring.....	07
50216J	704	" " " " Screw.....	02
2102	1909	Tension Disc.....	07
1560B	706	" Regulating Thumb Nut.....	06
32572	4906	" Releasing Disc.....	07
15238	4906	" " Pin.....	01
13710	4918	" Spring.....	05
50291J	4918	" Stud.....	20
15410	4918	" " Bushing.....	20
50292B	4918	" " Set Screw.....	02
15471	—	Tension complete, Nos. 1560B, 13710, 15238, 32572, 50291J, 55645 and two 2102.....	55
15395	4918	Tension Thread Guard.....	05
26075	704	Thread Cutter and Holder.....	07
15271	701	" Take-up Cam with 1293c.....	80
1293c	706	" " Cam Position Screw....	20
*15493	4917	" " Lever with 1822.....	80
15494	—	" " " 15493 with 50527c	90
50527c	4923	" " " Hinge Screw.....	10
1822	706	" " " Roller and Stud ..	30
55645	4918	" " Spring.....	05
15412	4918	" " " Regulator.....	35
857B	4918	" " " " Set Screw	02
2986	704	Throat Plate for 2040.....	60
691A	705	" " Screw.....	06

**LIST OF PARTS COMPLETE****FOR****MACHINE No. 15-30****FAMILY, C. B., DROP FEED, H. O.**

NO.	PLATE	NAME	EACH
*15495	—	Arm.....	\$6 00
15496	—	" 15495 with 435c, 448c, 15486 and 15498.....	6 70
2002	703	Arm Dowel Pin.....	02
138E	705	" Screw.....	07
15497	4917	" Shaft.....	1 50
15498	4917	" " Bushing.....	35
435c	4923	" " " Set Screw.....	06
15427	4917	" Side Cover.....	25
286B	706	" " " Thumb Screw.....	20
2007	703	" Spool Pin.....	02
8879	700	" " " Washer (cloth).....	01
15282	699	Balance Wheel, 2½ in. pulley.....	1 50
*2805	—	Bed.....	6 00
256B	700	Clamp Stop Motion Clamp Screw.....	50
248A	705	" " " Stop Screw.....	02
2020	700	" " " Washer.....	07
*15312	—	" " " Flanged Bushing....	55
15313	1902	" " " " 15312 with two 462c.....	55
2022	703	Clamp Stop Motion Flanged Bushing Pin	01
462c	706	" " " " Set Screw.....	02
15314	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....	1 15
125011	4917	Crank Connecting Rod with 125012 and two 896E.....	95
*125012	—	Crank Connecting Rod Cap.....	—
896E	4923	" " " " Screw.....	06
375c	705	" " " Hinge Screw.....	20
1518E	706	" " " " Nut	06
*15406	—	Face Plate.....	90
*15407	—	" " 15406 with 15428.....	1 25
15432	4917	" " 15407 with 857B, 2827, 15410, 15412 and 50292B.....	1 85
15408	—	Face Plate Tension Seat.....	30
15428	—	" " " " 15408 with 15395	35

NO.	PLATE	NAME	EACH
55644	—	Face Plate complete, Nos. 15432 and 15471.....	\$2 50
190B	705	Face Plate Screw.....	05
2827	703	" " Thread Guard with 8505.....	02
8505	703	" " " " Rivet...per 100	20
2835	708	Feed Bar.....	60
315C	705	" " Screw Centre.....	06
1519J	706	" " " " Nut.....	05
15306	1902	" Cam with 1285C.....	35
1285C	706	" " Set Screw.....	06
15359	4912	" Cover Plate.....	20
15279	4905	" Dog, 12 teeth (14 teeth to the inch) three teeth at right of needle, square corner.....	80
15304	4905	Feed Dog, 15 teeth (18 teeth to the inch) three teeth at right of needle, square corner.....	80
208E	706	Feed Dog Screw.....	02
15319	699	" Forked Connection with 175J.....	85
175J	706	" " " " Adjusting Screw	02
1381C	706	" " " " Hinge Screw (eccentric).....	20
1520E	706	Feed Forked Connection Hinge Screw Nut	05
1832	706	" " " " Roller with 1085E	30
1085E	1909	" " " " Screw Stud	10
2816	699	" Lifting Rock Shaft .....	55
2836	—	Feed Lifting Rock Shaft complete, Nos. 2509 and 2816.....	1 15
2509	709	Feed Lifting Rock Shaft Crank with 157J and 1813.....	60
157J	705	Feed Lifting Rock Shaft Crank Clamping Screw.....	06
1813	706	Feed Lifting Rock Shaft Crank Roller and Stud.....	30
307C	705	Feed Lifting Rock Shaft Screw Centre...	10
1513J	706	" " " " " " Nut	07
2044	704	" Regulator.....	35
8217	4918	" " Friction Washer.....	01
50353E	4918	" " Hinge Screw.....	10
747D	705	" " Thumb Screw.....	20
15297	699	" Rock Shaft.....	80
307C	705	" " " Screw Centre.....	10
1513J	706	" " " " " " Nut.....	07
50380C	6317	Machine Hinge Connection Set Screw...	05
2050	700	Needle Bar.....	55
*15248	1909	" " Connecting Link with 930E...	80

NO.	PLATE	NAME	EACH
15374	—	Needle Bar Connecting Link 15248 with 2052.....	\$1 15
930E	1909	Needle Bar Connecting Link Adjusting Screw.....	06
570c	706	Needle Bar Connecting Link Hinge Screw	10
1520J	706	" " " " " "	
		Nut.....	05
2052	704	Needle Bar Connecting Stud with 155c...	35
155c	705	" " " " Set Screw...	05
15068	711	" " Thread Guard.....	01
251A	705	" " " " Screw.....	02
2054	703	" Clamp with 552c .....	35
552c	705	" " Thumb Screw.....	20
125013	4917	Oscillating Rock Shaft.....	80
307c	705	" " " Screw Centre.....	10
1513J	706	" " " " Nut.	07
2510	708	" Shaft.....	35
*2416	—	" " Crank with 1813.....	80
2511	708	" " " 2416 with two 462c.....	80
2049	703	Oscillating Shaft Crank Pin.....	01
1813	706	" " " Roller and Stud..	30
462c	706	" " " Set Screw.....	02
15257	700	Presser Bar.....	50
15236	4906	" " Lifter.....	30
15486	4923	" " " Hinge Stud.....	25
448c	705	" " " " Set Screw	05
8399	700	" " Spring.....	07
2068	704	" " " Bracket with 453c....	35
453c	705	" " " Set Screw....	02
2070	703	" " " Washer.....	01
15281	4909	" Foot.....	35
15262	4909	" " (rounded heel) for riding seams	50
286B	706	" " Thumb Screw .....	20
263J	705	Pressure Regulating Thumb Screw.....	30
2996	709	Shuttle Bobbin.....	07
62739	—	" " Case.....	50
15140	709	" " " Latch.....	20
2973	709	" " " Lever.....	20
2974	709	" " " " Fulerum Pin.....per 100	20
2975	709	Shuttle Bobbin Case Latch Spring.....	02
592E	709	" " " " Stop Screw...	02
15141	—	" " " Hinge, Nos. 2973, 2974 and 15140.....	35
15027	709	Shuttle Bobbin Case Position Finger.....	07

NO.	PLATE	NAME	EACH
2523	709	Shuttle Bobbin Case Position Finger Rivet	
		..... per 100	\$ .35
15277	709	Shuttle Bobbin Case complete, Nos. 591f, 592e, 2523, 2975, 15027, 15141, 15278 and 62739.....	1 .15
2515	709	Shuttle Body.....	1 .15
591f	709	" Tension Regulating Screw.....	.02
15278	709	" " Spring.....	.20
15100	709	Shuttle, $1\frac{1}{16}$ in. diam., Nos. 2515, 2996 and 15277.....	2 .30
*2542	—	Shuttle Driver.....	1 .15
2441	708	" " 2542 with two 462c.....	1 .15
2049	703	" " Pin.....	.01
462c	706	" " Set Screw.....	.02
2531	708	" Race Back.....	.60
2532	711	" " Position Pin..... per 100	.20
2533	708	" " Spring.....	.20
648j	709	" " " Screw.....	.10
2530	—	" " Body.....	1 .15
15420	—	" " 2530 with 2535 and two 662d.....	1 .45
2535	708	Shuttle Race Cap.....	.25
662d	706	" " " Screw.....	.02
2528	708	Shuttle Race complete, Nos. 648j, 2531, 2533, 15420 and two 2532.....	2 .30
145d	706	Shuttle Race Screw.....	.06
15188	—	" " Slide.....	.35
15147	700	Shuttle Race Slide complete, Nos. 2824, 15188 and two 50216j.....	.50
2824	704	Shuttle Race Slide Spring.....	.07
50216j	704	" " " " Screw .....	.02
2102	1909	Tension Disc.....	.07
1560B	706	" Regulating Thumb Nut.....	.06
32572	4906	" Releasing Disc.....	.07
15238	4906	" " Pin.....	.01
13710	4918	" Spring.....	.05
50291j	4918	" Stud.....	.20
15410	4918	" Bushing.....	.20
50292B	4918	" " Set Screw.....	.02
15471	—	Tension complete, Nos. 1560B, 13710, 15238, 32572, 50291j, 55645 and two 2102.....	.55
15395	4918	Tension Thread Guard.....	.05
26075	704	Thread Cutter and Holder.....	.07
15272	4910	" Take-up Cam with 1293c.....	.80
1293c	706	" " " Position Screw.....	.20
*15491	4917	" " Lever with 1822.....	.80

## PARTS FOR MACHINE No. 15-30 15

NO.	PLATE	NAME	EACH
15492	—	Thread Take-up Lever 15491 with 50527c	\$ .90
50527c	4923	" " " Hinge Screw.....	.10
1822	706	" " " Roller and Stud..	.30
55645	4918	" " Spring.....	.05
15412	4918	" " " Regulator.....	.35
857b	4918	" " " " Set Screw	.02
15316	4905	Throat Plate, large needle hole, for 15279 and 15304.....	.60
15280	—	Throat Plate, medium needle hole, for 15279 and 15304.....	.60
15317	—	Throat Plate, small needle hole, for 15279 and 15304.....	.60
691A	705	Throat Plate Screw.....	.06

**LIST OF PARTS COMPLETE  
FOR  
MACHINE No. 15-41**

**FOR HOME MANUFACTURING, C. B., DROP FEED,  
H. O., FITTED FOR ROUND SHANK NEEDLES**

NO.	PLATE	NAME	EACH
*15495	—	Arm.....	\$6 00
15496	—	" 15495 with 435c, 448c, 15486 and 15498.....	6 70
2002	703	Arm Dowel Pin.....	02
138E	705	" Screw.....	07
15497	4917	" Shaft.....	1 50
15498	4917	" " Bushing.....	35
435c	4923	" " " Set Screw.....	06
15427	4917	" Side Cover.....	25
286B	706	" " " Thumb Screw.....	20
2007	703	" Spool Pin.....	02
8879	700	" " " Washer (cloth).....	01
15282	699	Balance Wheel, 2½ in. pulley.....	1 50
*2805	—	Bed.....	6 00
256B	700	Clamp Stop Motion Clamp Screw.....	50
248A	705	" " " " Stop Screw... ..	02
2020	700	" " " " Washer.....	07
*15312	—	" " " Flanged Bushing....	55
15313	1902	" " " " " 15312 with two 462c.....	55
2022	703	Clamp Stop Motion Flanged Bushing Pin	01
462c	706	" " " " " Set Screw.....	02
15314	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....	1 15
125011	4917	Crank Connecting Rod with 125012 and two 896E.....	95
*125012	—	Crank Connecting Rod Cap.....	—
896E	4923	" " " " Screw.....	06
375c	705	" " " " Hinge Screw .....	20
1518E	706	" " " " " Nut.....	06
*15406	—	Face Plate.....	90
*15407	—	" " 15406 with 15428.....	1 25
15432	4917	" " 15407 with 857B, 2827, 15410, 15412 and 50292B.....	1 85

NO.	PLATE	NAME	EACH
15408	—	Face Plate Tension Seat.....	\$ 30
15428	—	" " " " 15408 with 15395	35
55644	—	Face Plate complete, Nos. 15432 and 15471	2 50
190B	705	Face Plate Screw.....	05
2827	703	" " Thread Guard with 8505.....	02
8505	703	" " " " Rivet...per 100	20
2835	708	Feed Bar.....	60
315C	705	" " Screw Centre.....	06
1519J	706	" " " " Nut.....	05
15306	1902	" Cam with 1285C.....	35
1285C	706	" " Set Screw.....	06
2506	704	" Dog, for cloth.....	60
4641	1965	" " four teeth at right of needle, square corner.....	60
208E	706	Feed Dog Screw .....	02
15319	699	" Forked Connection with 175J.....	85
175J	706	" " " " Adjusting Screw	02
1381K	706	" " " " Hinge Screw (eccentric).....	20
1520J	706	Feed Forked Connection Hinge Screw Nut	05
15182	1909	" " " " Slide Block.....	30
15183	—	Feed Forked Connection Slide Block com- plete, Nos. 1085C and 15182.....	35
1085C	1909	Feed Forked Connection Slide Block Screw Stud.....	10
2816	699	Feed Lifting Rock Shaft.....	55
2836	—	Feed Lifting Rock Shaft complete, Nos. 2509 and 2816.....	1 15
2509	709	Feed Lifting Rock Shaft Crank with 157J and 1813.....	60
157J	705	Feed Lifting Rock Shaft Crank Clamping Screw.....	06
1813	706	Feed Lifting Rock Shaft Crank Roller and Stud.....	30
307C	705	Feed Lifting Rock Shaft Screw Centre...	10
1513J	706	" " " " " " Nut	07
2044	704	" Regulator.....	35
8217	4918	" " Friction Washer.....	01
50353E	4918	" " Hinge Screw.....	10
747B	705	" " Thumb Screw.....	20
15297	699	" Rock Shaft.....	80
307C	705	" " " " Screw Centre.....	10
1513J	706	" " " " " " Nut.....	07
50380C	6317	Machine Hinge Connection Set Screw....	05
15067	1902	Needle Bar.....	55
*15248	1909	" " Connecting Link with 930E...	80

NO.	PLATE	NAME	EACH
15374	—	Needle Bar Connecting Link 15248 with 2052.....	\$1 15
930E	1909	Needle Bar Connecting Link Adjusting Screw.....	.06
570c	706	Needle Bar Connecting Link Hinge Screw	.10
1520J	706	" " " " "	
		Nut.....	.05
2052	704	Needle Bar Connecting Stud with 155c...	.35
155c	705	" " " " Set Screw...	.05
15068	711	" " Thread Guard.....	.01
233B	706	" " " " Screw.....	.02
15069	1909	" Clamp with 246A.....	.30
	246A	" " Screw.....	.05
*4304	1902	Oscillating Rock Shaft with 4784.....	1 .50
5747	—	" " " 4304 with 635c, 1513J and 56812.....	2 .60
3052	1902	Oscillating Rock Shaft Hinge Pin.....	.80
56812	—	" " " " " 3052 with 1513J.....	.85
1513J	706	Oscillating Rock Shaft Hinge Pin Nut...	.07
635c	706	" " " " " Screw Bearing.....	.10
1513J	706	Oscillating Rock Shaft Hinge Pin Screw Bearing Nut.....	.07
4784	1909	Oscillating Rock Shaft Oil Pad.....	.01
2510	708	" Shaft.....	.35
*15163	—	" " " Crank for 15164.....	.35
15426	—	" " " " " 15165.....	.35
*15164	—	Oscillating Shaft Crank complete, Nos. 462c, 1519E, 15163 and 15171.....	1 .20
15165	1909	Oscillating Shaft Crank complete, Nos. 1519E, 15171, 15426 and two 462c....	1 .20
2049	703	Oscillating Shaft Crank Pin.....	.01
462c	706	" " " Set Screw.....	.02
15170	1909	" " " Slide Block.....	.55
229D	1909	" " " " " Cap Screw.....	.02
12424	1909	Oscillating Shaft Crank Slide Block Cap Screw Washer.....	.02
1035c	1909	Oscillating Shaft Crank Slide Block Screw Stud.....	.25
1519E	706	Oscillating Shaft Crank Slide Block Screw Stud Nut.....	.05
15171	1909	Oscillating Shaft Crank Slide Block com- plete, Nos. 229D, 1035c, 12424 and 15170	.80

NO.	PLATE	NAME	EACH
2058	4910	Presser Bar.....	\$ .50
15236	4906	" " Lifter.....	.30
15486	4923	" " " Hinge Stud.....	.25
448c	705	" " " " Set Screw.....	.05
8399	700	" " Spring.....	.07
2068	704	" " Bracket with 453c.....	.35
453c	705	" " " Set Screw.....	.02
2070	703	" " " Washer.....	.01
15281	4909	Foot.....	.35
15262	4909	" " (rounded heel) for riding seams.....	.50
286B	706	Presser Foot Thumb Screw.....	.20
263J	705	Pressure Regulating Thumb Screw.....	.30
2996	709	Shuttle Bobbin.....	.07
62739	—	" " Case.....	.50
15140	709	" " " Latch.....	.20
2973	709	" " " Lever.....	.20
2974	709	" " " " Fulcrum Pin..... per 100	.20
2975	709	Shuttle Bobbin Case Latch Spring.....	.02
592E	709	" " " " Stop Screw.....	.02
15141	—	" " " " Hinge, Nos. 2973, 2974 and 15140.....	.35
15027	709	Shuttle Bobbin Case Position Finger.....	.07
2523	709	" " " " Rivet ..... per 100	.35
15277	709	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 15027, 15141, 15278 and 62739.....	1.15
2515	709	Shuttle Body.....	1.15
591F	709	" Tension Regulating Screw.....	.02
15278	709	" " Spring.....	.20
15100	709	Shuttle, $1\frac{1}{16}$ in. diam., Nos. 2515, 2996 and 15277.....	2.30
*2542	—	Shuttle Driver.....	1.15
2441	708	" " 2542 with two 462c.....	1.15
2049	703	" " Pin.....	.01
462c	706	" " Set Screw.....	.02
2531	708	" Race Back.....	.60
2532	711	" " " Position Pin... per 100	.20
2533	708	" " " Spring.....	.20
648J	709	" " " " Screw.....	.10
2530	—	" " Body.....	1.15
15420	—	" " " 2530 with 2535 and two 662d.....	1.45
2535	708	Shuttle Race Cap.....	.25
662d	706	" " " Screw.....	.02

NO.	PLATE	NAME	EACH
2528	708	Shuttle Race complete, Nos. 648J, 2531, 2533, 15420 and two 2532.....	\$2 30
145D	706	Shuttle Race Screw.....	.06
15188	—	" " Slide.....	.35
15147	700	Shuttle Race Slide complete, Nos. 2824, 15188 and two 50216J.....	.50
2824	704	Shuttle Race Slide Spring.....	.07
50216J	704	" " " Screw.....	.02
2102	1909	Tension Disc.....	.07
1560B	706	" Regulating Thumb Nut.....	.06
32572	4906	" Releasing Disc.....	.07
15238	4906	" " Pin.....	.01
13710	4918	" Spring.....	.05
50291J	4918	" Stud.....	.20
15410	4918	" " Bushing.....	.20
50292B	4918	" " Set Screw.....	.02
15471	—	Tension complete, Nos. 1560B, 13710, 15238, 32572, 50291J, 55645 and two 2102.....	.55
15395	4918	Tension Thread Guard.....	.05
26075	704	Thread Cutter and Holder.....	.07
15275	4910	" Take-up Cam with 1293C.....	1 .50
1293C	706	" " " Position Screw....	.20
*15491	4917	" " Lever with 1822.....	.80
15492	—	" " " 15491 with 50527C	.90
50527C	4923	" " " Hinge Screw.....	.10
1822	706	" " " Roller and Stud..	.30
55645	4918	" " Spring.....	.05
15412	4918	" " " Regulator .....	.35
857B	4918	" " " " Set Screw	.02
2831	1965	Throat Plate, large needle hole, for 2506	.60
2832	—	" " small needle hole, for 2506	.60
4737	1965	" " large needle hole, for 4641	.80
4645	—	" " small needle hole, for 4641	.80
691A	705	" " Screw.....	.06

**LIST OF PARTS COMPLETE  
FOR  
MACHINE No. 15-43**

**FOR HOME MANUFACTURING, LONG BEAK SHUTTLE, DROP  
FEED. H. O., FITTED FOR ROUND SHANK NEEDLES**

NO.	PLATE	NAME	EACH
*15495	—	Arm.....	\$6 00
15496	—	" 15495 with 435c, 448c, 15486 and 15498.....	6 70
2002	703	Arm Dowel Pin.....	02
138E	705	" Screw.....	07
15497	4917	" Shaft.....	1 50
15498	4917	" " Bushing.....	35
435c	4923	" " " Set Screw.....	06
15427	4917	" Side Cover.....	25
286B	706	" " " Thumb Screw.....	20
2007	703	" Spool Pin.....	02
8879	700	" " " Washer (cloth).....	01
15282	699	Balance Wheel, 2½ in. pulley.....	1 50
*2805	—	Bed.....	6 00
256B	700	Clamp Stop Motion Clamp Screw.....	50
248A	705	" " " Stop Screw.....	02
2020	700	" " " Washer.....	07
*15312	—	" " " Flanged Bushing.....	55
15313	1902	" " " " 15312 with two 462c.....	55
2022	703	Clamp Stop Motion Flanged Bushing Pin	01
462c	706	" " " " Set Screw.....	02
15314	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....	1 15
125011	4917	Crank Connecting Rod with 125012 and two 896E.....	95
*125012	—	Crank Connecting Rod Cap.....	—
896E	4923	" " " " Screw.....	06
375c	705	" " " Hinge Screw.....	20
1518E	706	" " " " Nut.....	06
*15406	—	Face Plate.....	90
*15407	—	" " 15406 with 15428.....	1 25
15432	4917	" " 15407 with 857B, 2827, 15410, 15412 and 50292B.....	1 85

NO.	PLATE	NAME	EACH
15408	—	Face Plate Tension Seat.....	\$ 30
15428	—	" " " " 15408 with 15395	35
55644	—	Face Plate complete, Nos. 15432 and 15471	2 50
190B	705	Face Plate Screw.....	05
2827	703	" " Thread Guard with 8505.....	02
8505	703	" " " " Rivet...per 100	20
2037	700	Feed Bar.....	55
315C	705	" " Screw Centre.....	06
1519J	706	" " " " Nut.....	05
15306	1902	" Cam with 1285C.....	35
1285C	706	" " Set Screw.....	06
2040	702	" Dog.....	35
191C	705	" " Screw.....	05
15319	699	" Forked Connection with 175J.....	85
175J	706	" " " Adjusting Screw	02
1381K	706	" " " Hinge Screw (eccentric).....	20
1520J	706	Feed Forked Connection Hinge Screw Nut	05
15182	1909	" " " Slide Block.....	30
15183	—	Feed Forked Connection Slide Block complete, Nos. 1085C and 15182.....	35
1085C	1909	Feed Forked Connection Slide Block Screw Stud.....	10
2816	699	Feed Lifting Rock Shaft.....	55
2817	—	Feed Lifting Rock Shaft complete, Nos. 2573 and 2816.....	1 15
2573	702	Feed Lifting Rock Shaft Crank with 157J and 1935.....	60
157J	705	Feed Lifting Rock Shaft Crank Clamping Screw.....	06
1935	706	Feed Lifting Rock Shaft Crank Roller and Stud.....	30
307C	705	Feed Lifting Rock Shaft Screw Centre...	10
1513J	706	" " " " " " Nut	07
2044	704	" Regulator.....	35
8217	4918	" " Friction Washer.....	01
50353E	4918	" " Hinge Screw.....	10
747B	705	" " " Thumb Screw.....	20
15297	699	" Rock Shaft.....	80
307C	705	" " " Screw Centre.....	10
1513J	706	" " " " " " Nut.....	07
50380C	6317	Machine Hinge Connection Set Screw....	05
15067	1902	Needle Bar.....	55
*15248	1909	" " Connecting Link with 930E...	80
15374	—	" " " " " 15248 with 2052.....	1 15

NO.	PLATE	NAME	EACH
930E	1909	Needle Bar Connecting Link Adjusting Screw.....	\$ .06
570C	706	Needle Bar Connecting Link Hinge Screw.....	10
1520J	706	" " " " "	
		Nut.....	.05
2052	704	Needle Bar Connecting Stud with 155C.....	.35
155C	705	" " " " Set Screw.....	.05
15068	711	" " Thread Guard.....	.01
233B	706	" " " " Screw.....	.02
15069	1909	" Clamp with 246A.....	.30
246A	706	" " Screw.....	.05
*4304	1902	Oscillating Rock Shaft with 4784.....	1.50
5747	—	" " " 4304 with 635C, 1513J and 56812.....	2.60
3052	1902	Oscillating Rock Shaft Hinge Pin.....	.80
56812	—	" " " " " 3052 with 1513J.....	.85
1513J	706	Oscillating Rock Shaft Hinge Pin Nut.....	.07
635C	706	" " " " " Screw Bearing.....	.10
1513J	706	Oscillating Rock Shaft Hinge Pin Screw Bearing Nut.....	.07
4784	1909	Oscillating Rock Shaft Oil Pad.....	.01
2056	699	" Shaft.....	.35
*15160	—	" " Crank for 15161.....	.35
15425	—	" " " " 15162.....	.35
*15161	—	Oscillating Shaft Crank complete, Nos. 462C, 1519E, 15160 and 15171.....	1.20
15162	1909	Oscillating Shaft Crank complete, Nos. 1519E, 15171, 15425 and two 462C.....	1.20
2049	703	Oscillating Shaft Crank Pin.....	.01
462C	706	" " " Set Screw.....	.02
15170	1909	" " " Slide Block.....	.55
229D	1909	" " " " " Cap Screw.....	.02
12424	1909	Oscillating Shaft Crank Slide Block Cap Screw Washer.....	.02
1035C	1909	Oscillating Shaft Crank Slide Block Screw Stud.....	.25
1519E	706	Oscillating Shaft Crank Slide Block Screw Stud Nut.....	.05
15171	1909	Oscillating Shaft Crank Slide Block com- plete, Nos. 229D, 1035C, 12424 and 15170	.80
2058	4910	Presser Bar.....	.50
15236	4906	" " Lifter.....	.30
15486	4923	" " " Hinge Stud.....	.25
448C	705	" " " " " Set Screw.	.05

NO.	PLATE	NAME	EACH
8399	700	Presser Bar Spring.....	\$ .07
2068	704	" " " Bracket with 453c...	.35
453c	705	" " " Set Screw....	.02
2070	703	" " " Washer.....	.01
15281	4909	" Foot.....	.35
15262	4909	" (rounded heel) for riding seams.....	.50
286B	706	Presser Foot Thumb Screw.....	.20
263J	705	Pressure Regulating Thumb Screw.....	.30
2073	702	Shuttle Bobbin.....	.07
2211	702	" " Retaining Spring.....	.05
2212	702	" " " Rivet ..... per 100	.35
*2213	—	Shuttle Body with 398E, 2082, 2084, 2211 and two 2212.....	.85
*2075	—	Shuttle Cover.....	.55
*44001	—	" " 2075 with 112D, 466H, 2078, 2080, 2086 and 2090.....	.85
2076	702	Shuttle Cover Hinge Pin.....	.01
2078	702	" Delivery Eye Thread Guard.....	.05
2080	702	" " " " Rivet	.01
2082	702	" Main Spring.....	.20
398E	702	" " " Screw.....	.02
2084	702	" " " Steady Pin.....	.01
466H	702	" Tension Regulating Screw.....	.06
2086	702	" " Spring.....	.05
2090	702	" " " Plate.....	.07
112D	702	" " " Screw.....	.02
2208	702	Shuttle complete, Nos. 2073, 2076, 2213 and 44001.....	1 .50
*2176	—	Shuttle Driver.....	.80
2092	702	" " 2176 with two 457c.....	.80
2049	703	" " Pin.....	.01
457c	705	" " Set Screw.....	.02
2095	701	" Race Back.....	.30
190c	705	" " " Screw.....	.05
2096	—	" " Body.....	.65
2093	701	Shuttle Race complete, Nos. 2095, 2096 and two 190c.....	1 .15
158D	705	Shuttle Race Screw.....	.05
2994	—	" " Slide.....	.35
2995	4910	Shuttle Race Slide complete, Nos. 2824, 2994 and two 50216J.....	.50
2824	704	Shuttle Race Slide Spring.....	.07
50216J	704	" " " " Screw.....	.02
2102	1909	Tension Disc.....	.07
1560B	706	" Regulating Thumb Nut.....	.06

NO.	PLATE	NAME	EACH
32572	4906	Tension Releasing Disc.....	\$ .07
15238	4906	" " Pin.....	.01
13710	4918	" Spring.....	.05
50291J	4918	" Stud.....	.20
15410	4918	" " Bushing.....	.20
50292B	4918	" " Set Screw.....	.02
15471	—	Tension complete, Nos. 1560B, 13710, 15238, 32572, 50291J, 55645 and two 2102.....	.55
15395	4918	Tension Thread Guard.....	.05
26075	704	Thread Cutter and Holder.....	.07
15273	4910	" Take-up Cam with 1293c.....	1.50
1293c	706	" " " Position Screw.....	.20
*15493	4917	" " Lever with 1822.....	.80
15494	—	" " " 15493 with 50527c	.90
50527c	4923	" " " Hinge Screw.....	.10
1822	706	" " " Roller and Stud..	.30
55645	4918	" " Spring.....	.05
15412	4918	" " " Regulator .....	.35
857B	4918	" " " " Set Screw	.02
2831	1965	Throat Plate, large needle hole, for 2040	.60
2832	—	" " small needle hole, for 2040	.60
691A	705	" " Screw .....	.06

## MACHINE No. 15-50

FAMILY, C. B., DROP FEED, H. O. WITH HAND ATTACHMENT

This Machine is the 15-30 with the addition of  
the following:

### HAND ATTACHMENT PARTS

NO.	PLATE	NAME	EACH
*94002	4915	Body.....	\$ .70
33647	4915	" Bracket.....	.25
183E	4916	" " Screw.....	.05
80023	4915	Crank Handle (wood).....	.06
94012	4915	" " Spindle.....	.10
8280	4916	" Hinge Pin.....	.01
8435	4915	" Lever.....	.30
8281	4916	" Lock Pin.....	.02
8282	4916	" " " Spring.....	.01
94005	—	Crank complete, Nos. 8435, 80023 and 94012.....	.60
94006	4916	Driver.....	.30
33643	—	" Finger.....	.20
94007	4916	" " 33643 with 8390, 8391 and 94009.....	.25

NO.	PLATE	NAME	EACH
80018	4616	Driver Finger Hinge Pin.....	\$ 01
94008	4916	" " Lock Pin.....	03
8388	4916	" " " Spring.....	01
94009	4916	" " Sheath (leather).....	01
8390	4916	" " Plate.....	01
8391	4916	" " Staple.....	01
8392	710	Gear with 8281 and 8282.....	55
94016	4925	" Cover.....	10
399A	706	" " Screw.....	02
659D	706	" Screw Stud.....	20
8394	710	Pinion.....	55
80028	4916	" Dowel Pin..... per 100	10
660D	706	" Screw Stud.....	20
94018	—	Hand Attachment complete, Nos. 137B, 659D, 660D, 8280, 8388, 8392, 8394, 33647, 80018, 80028, 94002, 94005 to 94008, 94016 and two each 183E and 399A.....	3 80
137B	4916	Hand Attachment Screw.....	06

## ACCESSORIES

NO.	PLATE	NAME	EACH
36569	4910	Oiler with 36571.....	\$ 10
36570	—	" 36569, filled with oil.....	20
36571	4910	" Spout, 1 3/4 in. long, with 36807.....	06
36807	6317	" " Washer (leather).....	01
120329	—	Machine Cover.....	1 50

## ATTACHMENT SET

FOR 15-50 MACHINE

NO.	PLATE	NAME	EACH
26319	5650	Binder.....	\$ 25
25527B	5635	Cloth Guide.....	20
287B	5635	" " Thumb Screw.....	20
25626	5650	Hemmer $\frac{3}{16}$ in. hem.....	20
25627	5650	" $\frac{1}{4}$ in. hem.....	20
25628	5650	" $\frac{3}{8}$ in. hem.....	20
25629	5650	" $\frac{5}{8}$ in. hem.....	20
—	—	Needles (six).....	—
25537	5635	Screw Driver (machine).....	20
25538	5635	" " (shuttle tension).....	07
2996	709	Shuttle Bobbin (five).....	07
36583	5637	Tucker.....	1 50

NO.	PLATE	NAME	EACH
120306	—	Attachment Set, Nos. 287B, 25527B, 25537, 25538, 25626 to 25629, 26319, 36583, five 2996 and six needles.....	\$4.80
35463	5647	Ruffler.....	.95
25623	—	Attachment Set complete, Nos. 35463 and 120306.....	6.00

## ATTACHMENT SET

FOR 15-30 AND 15-41 MACHINES

NO.	PLATE	NAME	EACH
36594	5636	Binder.....	\$ .80
25527B	5635	Cloth Guide.....	.20
287B	5635	" " Thumb Screw.....	.20
35931	5636	Hemmer (adjustable).....	1.50
—	—	Needles (six).....	—
25537	5635	Screw Driver (machine).....	.20
25538	5635	" " (shuttle tension).....	.07
2996	709	Shuttle Bobbin (five).....	.07
36583	5637	Tucker.....	1.50
120309	—	Attachment Set, Nos. 287B, 25527B, 25537, 25538, 35931, 36583, 36594, five 2996 and six needles.....	6.00
120290	8313	Ruffler.....	1.25
35918	—	Attachment Set complete, Nos. 120290 and 120309.....	7.50

## EMBROIDERY ATTACHMENT

FOR ONE THREAD

NO.	PLATE	NAME	EACH
26521	1018	Driving Lever with 26536.....	\$ .35
22232	1018	" " Friction Washer.....	.01
26784	1018	" " Hinge Stud.....	.07
26523	1018	" " Washer.....	.01
26524	1004	Frame with 26525.....	.80
26525	1004	" Block.....	.07
26527	1018	Looper.....	.55
468C	1018	" Set Screw.....	.02
26528	1018	Scroll with 468C.....	.35
26529	1018	" Carrier with 26531.....	.20
22232	1018	" " Friction Washer.....	.01
26530	1018	" " Hinge Stud.....	.05
26531	1018	" " Pin.....	.01
26532	1018	" Cover.....	.20
26533	1018	" Driving Lever with 26534.....	.25
26534	1018	" " " Stud.....	.05

NO.	PLATE	NAME	EACH
26535	1004	Spool Fin, for arm of machine .....	\$ .07
26536	1018	Thread Bracket.....	.05
9859	1018	" " Rivet (for repairs only) .....	
		..... per 100	.20
26537	1018	Thread Eyelet.....	.01
26785	1018	" Retaining Spring.....	.20
240D	1018	" " " Screw.....	.02
26538	1004	Embroidery Attachment complete, Nos. 240D, 26521, 26523, 26524, 26527 to 26530, 26532, 26533, 26535, 26537, 26784, 26785 and two 22232.....	3.00

## EMBROIDERY ATTACHMENT FOR TWO THREADS

NO.	PLATE	NAME	EACH
35483	933	Body.....	\$ .55
35484	933	" Block.....	.30
12152	933	" " Rivet..... per 100	.20
35485	935	Driving Lever.....	.30
35486	935	" " Arm (lower).....	.20
35487	935	" " " (upper).....	.20
35488	933	" " Guide.....	.20
35489	935	" " " Hinge Stud.....	.07
35490	935	" " " Spring.....	.07
35491	935	" " Hinge Stud.....	.20
35492	935	Thread Carrier (left).....	.35
35493	935	" " " Hinge Stud.....	.07
35494	935	" " (right).....	.35
50139B	935	" " " Hinge Screw.....	.06
35495	935	" " Friction Plate.....	.07
35496	933	Embroidery Attachment, Nos. 190B, 12152, 35483 to 35488, 35490 to 35495, 35498, 50139B and two 35489.....	3.00
190B	933	Embroidery Attachment Screw.....	.05
35497	936	Spool Bracket.....	.20
35498	936	" " Stud.....	.07
1422B	936	" " Tension Regulating Thumb Screw.....	.07
35499	936	Spool Bracket Tension Spring.....	.07
35500	936	" " " " Position Pin.....	.05
35500	936	Spool Bracket Thread Guide Pin.....	.05
35501	936	" " Wire.....	.07
35502	936	" " " Hinge Stud.....	.07
35503	936	" " " " " Washer..	.07

## EMBROIDERY ATTACHMENT

29

NO.	PLATE	NAME	EACH
35504	936	Spool Bracket complete, Nos. 1422B, 35497, 35499, 35502, 35503 and two each 35500 and 35501.....	\$ .80
35505	—	Embroidery Attachment complete, Nos. 35496 and 35504.....	3 .80

**BIAS GAUGE**

NO.	PLATE	NAME	EACH
25525	5635	Bias Gauge.....	\$ .20

**BRAIDER**

NO.	PLATE	NAME	EACH
25510	5647	Braider.....	\$ .30
289B	4906	" Thumb Screw.....	.10

**CORDER (Bow) FOR TOP CORDING**

NO.	PLATE	NAME	EACH
26398	1950	Corder Bow.....	\$ —
4604	4923	" " Rivet.....per 100	.20
25789	1950	" " Tip.....	.35
25794	1950	Presser Foot.....	1 .15
26399	1950	Corder Bow complete, Nos. 4604, 25789, 25794 and 26398.....	3 .35
190D	705	Corder Screw.....	.05

**DARNING FOOT (Spring)**

NO.	PLATE	NAME	EACH
86291	—	Darning Foot.....	\$ —
86292	—	" " Clamp, Nos. 86295 and 86296.....	—
*86295	—	Darning Foot Clamp Body.....	—
*86296	—	" " " Guide.....	—
SS476c	4922	" " " Thumb Screw.....	.10
66646	4922	" " " Spring.....	.06
36658	4922	" " " Rivet.....per 100	.80
86294	4922	Darning Foot (spring) complete, Nos. SS476c, 36658, 66646, 86291 and 86292	1 .00

**EDGE STITCHER**

NO.	PLATE	NAME	EACH
36865	4919	Edge Stitcher.....	\$ .80

## FELLER (Foot)

NO.	PLATE	NAME	EACH
36835	4922	Feller (foot) . . . . .	\$ 35

## HEMMERS

NO.	PLATE	NAME	EACH
25904	—	Hemmer (foot) $\frac{1}{16}$ in. hem, for silk ties, for 2040 and 2506 . . . . .	\$ 60
36333	4919	Hemmer (foot) $\frac{1}{16}$ in. hem, for chiffon and silk . . . . .	3 35
35996	4909	Hemmer (foot) $\frac{5}{64}$ in. hem . . . . .	50
35857	4909	" " $\frac{1}{8}$ in. hem . . . . .	55
25895	—	" " $\frac{1}{8}$ in. hem, for shirt work, for 2040 and 2506 . . . . .	60
35884	4919	Hemmer (foot) $\frac{3}{16}$ in. hem . . . . .	55
36469	—	" " for chiffon and silk, slotted for lace . . . . .	3 35
6267	4909	Hemmer Folder . . . . .	02
25888	4909	" Tongue . . . . .	01

NOTE: When ordering Nos. 6267 or 25888 give width of  
hem and No. of Hemmer for which it is required.

## HEMSTITCHER

NO.	PLATE	NAME	EACH
28915	4909	Hemstitcher . . . . .	\$ 80

## PRESSER FEET

### FOR 15-30 MACHINE

NO.	PLATE	NAME	EACH
15429	4922	Presser Foot, for stitching on edge and inserting cord . . . . .	\$ 80
28831	4922	Presser Foot, for darning . . . . .	60
36055	4922	" " with 665B and 36056, for blind stitch braiding, for soutache braid	2 30
36056	4922	Presser Foot Braid Guide . . . . .	80

NOTE When ordering Nos. 36055 or 36056 send  
sample of braid for which it is to be used.

665B	4919	Presser Foot Braid Guide Screw . . . . .	02
36058	4919	" " with 665B and 36059, for blind stitch cording, to turn small curves . . . . .	3 80

NO.	PLATE	NAME	EACH
36059	4919	Presser Foot Cord Guide.....	\$ 80

NOTE: When ordering Nos. 36058 or 36059 send sample of cord for which it is to be used.

665B	4919	Presser Foot Cord Guide Screw.....	02
2506	704	Feed Dog for 36058.....	60
2831	1965	Throat Plate, large needle hole, for 2506	60
36067	4919	Presser Foot, for braiding, for art work, for braid $\frac{1}{16}$ in. to $\frac{3}{16}$ in. wide.....	90

NOTE: When ordering No. 36067, state the size or send sample of the braid for which it is to be used.

## QUilters

NO.	PLATE	NAME	EACH
85301	5647	Quilter Bar.....	\$ 06
85302	5647	" Guide.....	03
25515	5647	Quilter complete, Nos. 85301 and 85302	07
35932	5636	Quilter.....	50

## RUFFLERS

NO.	PLATE	NAME	EACH
35463	5647	Ruffler.....	\$ 95
26155	—	" 35463 with 25632.....	1 15
25632	5649	" Shirring Plate.....	20
120290	8313	Ruffler.....	1 25
120292	—	" 120290 with 35938.....	1 50
35938	5638	" Shirring Plate.....	25

## TUBULAR TRIMMING ATTACHMENT

NO.	PLATE	NAME	EACH
35983	4922	Strip Wire.....	\$ 20
35984	4922	Presser Foot (strip folding) with tube...	4 25
25539	5635	Stiletto.....	07
35985	—	Tubular Trimming Attachment complete, for making $\frac{3}{32}$ in., $\frac{1}{8}$ in. and $\frac{5}{32}$ in. trimmings, Nos. 25539, 35983 and 35984	4 50

## TUCK FOLDER

### FOR 15-30 MACHINE

NO.	PLATE	NAME	EACH
225923	2928	Folder.....	\$ 60
171A	2929	" Adjusting Screw.....	.05
36090	2928	" Arm with 50068E.....	1 15

NO.	PLATE	NAME	EACH
50066E	2929	Folder Screw Stud.....	\$ 25
50067D	2929	" " " Cap Screw.....	.06
19044	2929	" " " " Spring Washer.....	.02
1704B	2929	Folder Screw Stud Thumb Nut.....	.06
202600	2929	" " " " Washer ..	.01
225926	2928	Space Gauge.....	.50
50068E	2929	" " Screw Stud .....	.02
1705B	2929	" " " " Thumb Nut .....	.05
202603B	2929	" " " " Washer ..	.01
36091	2928	Tuck Folder complete, for small pieces of goods, Nos. 171A, 1704B, 1705B, 19044, 36090, 50066E, 50067D, 202600, 202603B, 225923, 225926 and two 1483H.....	2 .30
1483H	2929	Tuck Folder Thumb Screw .....	.20
36092	4919	Presser Foot.....	.35

## UNDER BRAIDERS

NO.	PLATE	NAME	EACH
25636	5649	Under Braider.....	\$ .25
25637	5647	" " Foot.....	.25
35940	5638	Under Braider .....	.30

## BOBBIN WINDERS

### BOBBIN WINDER (Automatic)

FOR 15282

FOR 15-22 AND 15-43 MACHINES

NO.	PLATE	NAME	EACH
15376	4920	Adjusting Arm.....	\$ .25
50058B	6313	" " Screw.....	.05
15072	6313	Bobbin Position Pin.....	per 100 .20
15284	6312	Bracket (belt cover).....	.35
180B	6313	" Screw.....	.05
15413	4920	Frame.....	.35
50059B	6313	" Hinge Screw.....	.20
15286	6313	" Spring.....	.02
15287	6313	Friction Ring (rubber).....	.02
15288	6313	Pulley.....	.07
15300	4914	Spindle with 15072.....	.25
571c	6313	" Worm.....	.20
15378	4920	Stop Latch.....	.25
50230B	6313	" " Hinge Screw.....	.07
15291	6313	" " Spring.....	.01

## BOBBIN WINDERS

33

NO.	PLATE	NAME	EACH
15415	4920	Thread Guide.....	\$ 20
50061B	6313	" " Hinge Screw.....	10
15366	6313	" " Spring.....	02
15416	4920	Worm Wheel and Thread Guide Cam....	25
2749	6313	" " " " " Friction Washer.....	01
50B	6313	Worm Wheel and Thread Guide Cam Screw Stud.....	20
1528J	6313	Worm Wheel and Thread Guide Cam Screw Stud Nut.....	05
15417	—	Bobbin Winder complete, Nos. 50B, 571c, 1528J, 2749, 15284, 15286 to 15288, 15291, 15300, 15366, 15376, 15378, 15413, 15415, 15416, 50058B, 50059B, 50061B and 50230B.....	2 75

**BOBBIN WINDER (Automatic)**

FOR 15282

FOR 15-30, 15-41 AND 15-50 MACHINES

NO.	PLATE	NAME	EACH
15376	4920	Adjusting Arm.....	\$ 25
50058B	6313	" " Screw.....	05
15072	6313	Bobbin Position Pin.....per 100	20
15284	6312	Bracket (belt cover).....	35
180B	6313	" Screw.....	05
15413	4920	Frame.....	35
50059B	6313	" Hinge Screw.....	20
15286	6313	" Spring.....	02
15287	6313	Friction Ring (rubber).....	02
15288	6313	Pulley.....	07
15289	4913	Spindle with 15072.....	25
571c	6313	" Worm.....	20
15377	4920	Stop Latch.....	25
50230B	6313	" " Hinge Screw.....	07
15291	6313	" " Spring.....	01
15418	4920	Thread Guide.....	20
50061B	6313	" " Hinge Screw.....	10
15366	6313	" " Spring.....	02
15416	4920	Worm Wheel and Thread Guide Cam....	25
2749	6313	" " " " " Friction Washer.....	01
50B	6313	Worm Wheel and Thread Guide Cam Screw Stud.....	20
1528J	6313	Worm Wheel and Thread Guide Cam Screw Stud Nut.....	05

## BOBBIN WINDERS

NO.	PLATE	NAME	EACH
15419	4921	Bobbin Winder complete, Nos. 50B, 571c, 1528J, 2749, 15284, 15286 to 15289, 15291, 15366, 15376, 15377, 15413, 15416, 15418, 50058B, 50059B, 50061B and 50230B.....	\$2 65

**BOBBIN WINDER (Automatic)**

FOR 15282

FOR 15-30, 15-41 AND 15-50 MACHINES

OBSOLETE, USE 15419

NO.	PLATE	NAME	EACH
15376	4920	Adjusting Arm.....	\$ 25
50058B	6313	" " Screw.....	.05
15072	6313	Bobbin Position Pin.....	per 100 .20
15284	6312	Bracket (belt cover).....	.35
180B	6313	" Screw.....	.05
15285	6313	Frame.....	.35
15473	—	" 15285 with 571c, 15288 and 15289	.85
50059B	6313	" Hinge Screw.....	.20
15286	6313	" Spring.....	.02
15287	6313	Friction Ring (rubber).....	.02
15288	6313	Pulley.....	.07
15289	4913	Spindle with 15072.....	.25
571c	6313	" Worm.....	.20
15377	4920	Stop Latch.....	.25
50230B	6313	" " Hinge Screw.....	.07
15291	6313	" " Spring.....	.01
15364	4913	Thread Guide.....	.20
*2746	6313	" " Cam.....	.07
233B	6313	" " " Screw.....	.02
50061B	6313	" " Hinge Screw.....	.10
15366	6313	" " Spring.....	.02
2748	6313	Worm Wheel.....	.20
15403	—	" " 2748 with 233B and 2746 ..	.30
2749	6313	" " Friction Washer.....	.01
50B	6313	" " Screw Stud.....	.20
1528J	6313	" " " Nut.....	.05
15294	4913	Bobbin Winder complete, Nos. 50B, 1528J, 2749, 15284, 15286, 15287, 15291, 15364, 15366, 15376, 15377, 15403, 15473, 50058B, 50059B, 50061B and 50230B ..	2 65

**BOBBIN WINDER (Automatic)**

FOR 15282

FOR 15-22 AND 15-43 MACHINES

OBSOLETE, USE 15417

NO.	PLATE	NAME	EACH
15376	4920	Adjusting Arm.....	\$ 25
50058B	6313	" " Screw.....	.05
15072	6313	Bobbin Position Pin.....per 100	.20
15284	6312	Bracket (belt cover).....	.35
180B	6313	" Screw.....	.05
15285	6313	Frame.....	.35
50059B	6313	" Hinge Screw.....	.20
15286	6313	" Spring.....	.02
15287	6313	Friction Ring (rubber).....	.02
15288	6313	Pulley.....	.07
15300	4914	Spindle with 15072.....	.25
	571C	" Worm.....	.20
15378	4920	Stop Latch.....	.25
50230B	6313	" " Hinge Screw.....	.07
15291	6313	" " Spring.....	.01
15365	4914	Thread Guide.....	.20
*2746	6313	" " Cam.....	.07
233B	6313	" " " Screw.....	.02
50061B	6313	" " Hinge Screw.....	.10
15366	6313	" " Spring.....	.02
2748	6313	Worm Wheel.....	.20
15403	—	" " 2748 with 233B and 2746.....	.30
2749	6313	" " Friction Washer.....	.01
50B	6313	" " Screw Stud.....	.20
1528J	6313	" " " Nut.....	.05
15303	4914	Bobbin Winder complete, Nos. 50B, 571C, 1528J, 2749, 15284 to 15288, 15291, 15300, 15365, 15366, 15376, 15378, 15403, 50058B, 50059B, 50061B and 50230B.....	2 65

**BOBBIN WINDER (Automatic)**

FOR 2008

FOR 15-22 AND 15-43 MACHINES

OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ .20
2446	701	Bracket (belt cover).....	.35
190B	705	" Screw.....	.05

## BOBBIN WINDERS

NO.	PLATE	NAME	EACH
2447	701	Frame.....	\$ 20
48B	705	" Hinge Screw.....	20
2744	700	Pulley.....	20
2449	701	Spindle with 15072.....	20
2855	—	" 2449 with 2744.....	30
2840	702	Spool Stand Bed.....	07
2455	702	" " Thread Retaining Disc.....	02
15367	702	" " " " Spring.....	05
2457	702	" " " " Stud..	05
2839	702	Spool Stand complete, Nos. 2455, 2457, 2840 and 15367.....	25
205A	705	Spool Stand Screw.....	05
2451	702	Spring.....	05
2452	701	Stop Latch.....	20
24B	705	" " Hinge Screw.....	10
2444	701	Bobbin Winder, Nos. 24B, 48B, 2446, 2447, 2451, 2452 and 2855.....	1 25
2843	—	Bobbin Winder complete, Nos. 2444 and 2839.....	1 50

**BOBBIN WINDER (Automatic)**

FOR 2008

FOR 15-22 AND 15-43 MACHINES

**OBSOLETE**

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ 20
15172	1905	Bracket (belt cover).....	35
180B	6313	" Screw.....	05
2447	701	Frame.....	20
48B	705	" Hinge Screw.....	20
2744	700	Pulley.....	20
2449	701	Spindle with 15072.....	20
2855	—	" 2449 with 2744.....	30
2840	702	Spool Stand Bed.....	07
2455	702	" " Thread Retaining Disc.....	02
15367	702	" " " " Spring.....	05
2457	702	" " " " Stud..	05
2839	702	Spool Stand complete, Nos. 2455, 2457, 2840 and 15367.....	25
205A	705	Spool Stand Screw.....	05
2451	702	Spring.....	05
2452	701	Stop Latch.....	20
24B	705	" " Hinge Screw.....	10

## BOBBIN WINDERS

37

NO.	PLATE	NAME	EACH
15173	—	Bobbin Winder, Nos. 24B, 48B, 2447, 2451, 2452, 2855 and 15172.....	\$1 25
15174	—	Bobbin Winder complete, Nos. 2839 and 15173.....	1 50

**BOBBIN WINDER (Automatic)**

FOR 2804

FOR 15-22 AND 15-43 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin..... per 100	\$ 20
2838	701	Bracket (belt cover).....	35
190B	705	" Screw.....	05
2447	701	Frame.....	20
48B	705	" Hinge Screw.....	20
2744	700	Pulley.....	20
2449	701	Spindle with 15072.....	20
2855	—	" 2449 with 2744.....	30
2840	702	Spool Stand Bed.....	07
2455	702	" " Thread Retaining Disc.....	02
15367	702	" " " " Spring	05
2457	702	" " " " Stud..	05
2839	702	Spool Stand complete, Nos. 2455, 2457, 2840 and 15367.....	25
205A	705	Spool Stand Screw.....	05
2851	702	Spring.....	05
2452	701	Stop Latch.....	20
24B	705	" " Hinge Screw.....	10
2841	—	Bobbin Winder, Nos. 24B, 48B, 2447, 2452, 2838, 2851 and 2855.....	1 25
2842	—	Bobbin Winder complete, Nos. 2839 and 2841.....	1 50

**BOBBIN WINDER (Automatic)**

FOR 2804

FOR 15-22 AND 15-43 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin..... per 100	\$ 20
15175	1905	Bracket (belt cover).....	35
180B	6313	" Screw.....	05
2447	701	Frame.....	20
48B	705	" Hinge Screw.....	20

## BOBBIN WINDERS

NO.	PLATE	NAME	EACH
2744	700	Pulley.....	\$ 20
2449	701	Spindle with 15072.....	20
2855	—	" 2449 with 2744.....	30
2840	702	Spool Stand Bed.....	07
2455	702	" " Thread Retaining Disc.....	02
15367	702	" " " " Spring	05
2457	702	" " " " Stud..	05
2839	702	Spool Stand complete, Nos. 2455, 2457, 2840 and 15367.....	25
205A	705	Spool Stand Screw.....	05
2851	702	Spring.....	05
2452	701	Stop Latch.....	20
24B	705	" " Hinge Screw.....	10
15176	—	Bobbin Winder, Nos. 24B, 48B, 2447, 2452, 2851, 2855 and 15175.....	1 25
15177	—	Bobbin Winder complete, Nos. 2839 and 15176 .....	1 50

**BOBBIN WINDER (Eccentric)**

(HAMBURG)

FOR 15-22 AND 15-43 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
2466	700	Eccentric.....	\$ 25
286B	706	" Thumb Screw.....	20
2844	701	Frame.....	25
161B	705	" Screw.....	06
2460	700	Friction Ring (rubber).....	02
2461	700	Pulley.....	10
2845	701	Spindle, for bobbin.....	25
2846	700	" " spool.....	20
2847	—	" 2845 with 2846.....	35
2848	701	Bobbin Winder complete, Nos. 286B, 2460, 2461, 2466, 2844 and 2847.....	1 10

**BOBBIN WINDER (Automatic)**

FOR 2008

FOR 15-30 AND 15-41 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ 20
15062	708	Bracket (belt cover).....	35
190B	705	" Screw.....	05

NO.	PLATE	NAME	EACH
2738	708	Frame.....	\$ 35
48B	705	" Hinge Screw.....	20
2739	703	" Spring.....	05
2744	700	Pulley.....	20
2997	708	Spindle with 15072.....	25
571C	6313	" Worm.....	20
2431	709	Stop Latch.....	25
92B	706	" " Hinge Screw.....	07
2442	703	" " Spring.....	02
2745	709	Thread Guide.....	20
*2746	6313	" " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " Hinge Screw.....	07
2747	703	" " Spring.....	02
2748	6313	Worm Wheel.....	20
15403	—	" " 2748 with 233B and 2746..	30
2749	6313	" " Friction Washer.....	01
50B	6313	" " Screw Stud.....	20
1528J	6313	" " " Nut.....	05
15085	708	Bobbin Winder complete, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2739, 2744, 2745, 2747, 2749, 2997, 15062, 15403 and two 92B .....	2 65

**BOBBIN WINDER (Automatic)**

FOR 2008

FOR 15-30 AND 15-41 MACHINES

**OBSOLETE**

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ 20
15180	1905	Bracket (belt cover).....	35
180B	6313	" Screw.....	05
2738	708	Frame.....	35
48B	705	" Hinge Screw.....	20
2739	703	" Spring.....	05
2744	700	Pulley.....	20
2997	708	Spindle with 15072.....	25
571C	6313	" Worm.....	20
2431	709	Stop Latch.....	25
92B	706	" " Hinge Screw.....	07
2442	703	" " Spring.....	02
2745	709	Thread Guide.....	20
*2746	6313	" " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " Hinge Screw.....	07
2747	703	" " Spring.....	02

## BOBBIN WINDERS

NO.	PLATE	NAME	EACH
2748	6313	Worm Wheel.....	\$ 20
15403	—	" " 2748 with 233B and 2746...	30
2749	6313	" " Friction Washer.....	01
50B	6313	" " Screw Stud.....	20
1528J	6313	" " " " Nut.....	05
15181	—	Bobbin Winder complete, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2739, 2744, 2745, 2747, 2749, 2997, 15180, 15403 and two 92B.....	2 65

**BOBBIN WINDER (Automatic)**

FOR 2804

FOR 15-30 AND 15-41 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
2849	708	Bracket (belt cover).....	\$ 35
190B	705	" Screw.....	05
2738	708	Frame.....	35
48B	705	" Hinge Screw.....	20
15064	703	" Spring.....	05
32557	708	Pulley.....	20
2742	1902	Spindle.....	25
2859	—	" 2742 with 32557.....	35
571C	6313	" Worm.....	20
2431	709	Stop Latch.....	25
92B	706	" " Hinge Screw.....	07
2442	703	" " Spring.....	02
2745	709	Thread Guide.....	20
*2746	6313	" " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " Hinge Serew.....	07
2747	703	" " Spring.....	02
2748	6313	Worm Wheel.....	20
15403	—	" " 2748 with 233B and 2746...	30
2749	6313	" " Friction Washer.....	01
50B	6313	" " Screw Stud.....	20
1528J	6313	" " " " Nut.....	05
2850	—	Bobbin Winder complete, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2849, 2859, 15064, 15403 and two 92B.....	2 65

**BOBBIN WINDER (Automatic)**

FOR 2804

FOR 15-30 AND 15-41 MACHINES

OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ 20
2849	708	Bracket (belt cover).....	35
190B	705	" Screw.....	05
2738	708	Frame.....	35
48B	705	" Hinge Screw.....	20
15064	703	" Spring.....	05
32557	708	Pulley.....	20
2997	708	Spindle with 15072.....	25
571c	6313	" Worm.....	20
2431	709	Stop Latch.....	25
92B	706	" " Hinge Serew.....	07
2442	703	" " Spring.....	02
2745	709	Thread Guide.....	20
*2746	6313	" " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " Hinge Screw.....	07
2747	703	" " Spring.....	02
2748	6313	Worm Wheel.....	20
15403	—	" " 2748 with 233B and 2746....	30
2749	6313	" " Friction Washer.....	01
50B	6313	" " Screw Stud.....	20
1528J	6313	" " " Nut.....	05
15020	708	Bobbin Winder complete, Nos. 48B, 50B, 571c, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2849, 2997, 15064, 15403, 32557 and two 92B.....	2 65

**BOBBIN WINDER (Automatic)**

FOR 2804

FOR 15-30 AND 15-41 MACHINES

OBSOLETE

NO.	PLATE	NAME	EACH
15072	711	Bobbin Position Pin.....per 100	\$ 20
15178	1905	Bracket (belt cover).....	35
180B	6313	" Screw.....	05
2738	708	Frame.....	35
48B	705	" Hinge Screw.....	20
15064	703	" Spring.....	05
32557	708	Pulley.....	20
2997	708	Spindle with 15072.....	25
571c	6313	" Worm.....	20

## BOBBIN WINDERS

NO.	PLATE	NAME	EACH
2431	709	Stop Latch.....	\$ 25
92B	706	" " Hinge Screw.....	07
2442	703	" " Spring.....	02
2745	709	Thread Guide.....	20
*2746	6313	" " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " Hinge Screw.....	07
2747	703	" " Spring.....	02
2748	6313	Worm Wheel.....	20
15403	—	" " 2748 with 233B and 2746...	30
2749	6313	" " Friction Washer.....	01
50B	6313	" " Screw Stud.....	20
1528J	6313	" " " Nut.....	05
15179	—	Bobbin Winder complete, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2997, 15064, 15178, 15403, 32557 and two 92B.....	2 65

**BOBBIN WINDER (Eccentric)**

(HAMBURG)

## FOR 15-30 AND 15-41 MACHINES

## OBSOLETE

NO.	PLATE	NAME	EACH
2466	700	Eccentric.....	\$ 25
286B	706	" Thumb Screw.....	20
2844	708	Frame.....	25
161B	705	" Screw.....	06
2460	700	Friction Ring (rubber).....	02
2461	700	Pulley.....	10
2852	708	Spindle, for bobbin.....	25
2846	700	" " spool.....	20
2853	—	" 2852 with 2846.....	35
2854	708	Bobbin Winder complete, Nos. 286B, 2460, 2461, 2466, 2844 and 2853.....	1 10

**HAND ATTACHMENTS**

## HAND ATTACHMENT WITH

## BOBBIN WINDER

FOR 2008

## FOR 15-22 MACHINE

## OBSOLETE

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ 80
15155	1905	" Bracket with 15156 and two 145F..	1 15
*15156	—	" " Cap (belt cover).....	—

NO.	PLATE	NAME	EACH
145F	706	Body Bracket Cap Screw.....	\$ 06
183E	706	" " Screw.....	05
8380	710	Crank Handle (wood).....	05
8433	—	" " Spindle.....	20
8434	1902	" " " 8433 with 8382....	20
8382	703	" " " Washer.....	01
8280	711	" Hinge Pin.....	01
8435	1902	" Lever.....	30
8281	711	" Lock Pin.....	02
8282	711	" " " Spring.....	01
8436	1902	Crank complete, Nos. 8380, 8434 and 8435	55
8313	710	Driver.....	30
8284	711	" Finger.....	20
8285	711	" " Hinge Pin.....	01
8286	711	" " Lock Spring.....	02
233B	706	" " " " Screw.....	02
8392	710	Gear with 8281 and 8282.....	55
8393	710	" Cover.....	20
399A	706	" " Screw.....	02
659D	706	" Screw Stud.....	20
8394	710	Pinion.....	55
2532	711	" Dowel Pin..... per 100	20
660D	706	" Screw Stud.....	20
15072	711	Bobbin Position Pin..... per 100	20
15053	701	" Winder Frame.....	25
48B	705	" " " Hinge Screw.....	20
15056	703	" " " Spring.....	05
2049	703	" " " Stop Pin... .	01
15153	1902	" " Friction Ring (rubber)...	02
15154	1902	" " Pulley.....	25
15218	1902	" " Spindle with 15072.....	25
15219	1902	" " Stop Latch.....	25
92B	706	" " " " Hinge Screw.	07
2442	703	" " " " Spring.....	02
15205	—	Hand Attachment complete with Bobbin Winder, Nos. 48B, 92B, 233B, 659D, 660D, 2049, 2442, 2532, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15053, 15056, 15153 to 15155, 15218, 15219 and two each 183E and 399A....	6 00

## HAND ATTACHMENT WITH BOBBIN WINDER

FOR 2804

FOR 15-22 MACHINE

OBSOLETE

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ .80
2960	710	" Bracket with 2961 and two 145F....	1 15
*2961	710	" " Cap (belt cover).....	.60
145F	706	" " " Screw.....	.06
183E	706	" " Screw.....	.05
8380	710	Crank Handle (wood).....	.05
8433	—	" " Spindle.....	.20
8434	1902	" " " 8433 with 8382....	.20
8382	703	" " Washer.....	.01
8280	711	" Hinge Pin.....	.01
8435	1902	" Lever.....	.30
8281	711	" Lock Pin.....	.02
8282	711	" " Spring.....	.01
8436	1902	Crank complete, Nos. 8380, 8434 and 8435	.55
8313	710	Driver.....	.30
8284	711	" Finger.....	.20
8285	711	" " Hinge Pin.....	.01
8286	711	" " Lock Spring.....	.02
233B	706	" " " Screw.....	.02
8392	710	Gear with 8281 and 8282.....	.55
8393	710	" Cover.....	.20
399A	706	" " Screw.....	.02
659D	706	" Screw Stud.....	.20
8394	710	Pinion.....	.55
2532	711	" Dowel Pin..... per 100	.20
660D	706	" Screw Stud.....	.20
15072	711	Bobbin Position Pin..... per 100	.20
15053	701	" Winder Frame.....	.25
48B	705	" " " Hinge Screw.....	.20
15056	703	" " " Spring.....	.05
2049	703	" " " " Stop Pin...	.01
2460	700	" " Friction Ring (rubber)...	.02
2461	700	" " Pulley.....	.10
15054	701	" " Spindle with 15072.....	.25
15055	701	" " Stop Latch.....	.25
92B	706	" " " " Hinge Screw.	.07
2442	703	" " " " Spring.....	.02

NO.	PLATE	NAME	EACH
15057	—	Hand Attachment complete with Bobbin Winder, Nos. 48B, 92B, 233B, 659D, 660D, 2049, 2442, 2460, 2461, 2532, 2960, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15053 to 15056 and two each 183E and 399A.....	\$ 6 00

## HAND ATTACHMENT WITH BOBBIN WINDER

FOR 2008

FOR 15-30 MACHINE

OBSOLETE, USE 15247

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ .80
15155	1905	" Bracket with 15156 and two 145F..	1 15
*15156	—	" " Cap (belt cover).....	—
145F	706	" " " Screw.....	.06
183E	706	" " " Screw.....	.05
8380	710	Crank Handle (wood).....	.05
8433	—	" " Spindle.....	.20
8434	1902	" " " 8433 with 8382....	.20
8382	703	" " " Washer.....	.01
8280	711	" Hinge Pin.....	.01
8435	1902	" Lever.....	.30
8281	711	" Lock Pin.....	.02
8282	711	" " " Spring.....	.01
8436	1902	Crank complete, Nos. 8380, 8434 and 8435	.55
8313	710	Driver.....	.30
8284	711	" Finger.....	.20
8285	711	" " Hinge Pin.....	.01
8286	711	" " Lock Spring.....	.02
233B	706	" " " " Screw.....	.02
8392	710	Gear with 8281 and 8282.....	.55
8393	710	" Cover.....	.20
399A	706	" " Screw.....	.02
659D	706	" Screw Stud.....	.20
8394	710	Pinion.....	.55
2532	711	" Dowel Pin..... per 100	.20
660D	706	" Screw Stud.....	.20
15072	711	Bobbin Position Pin..... per 100	.20
2738	708	" Winder Frame.....	.35
48B	705	" " " Hinge Screw.....	.20
15064	703	" " " Spring.....	.05
2049	703	" " " " Stop Pin... ..	.01

## HAND ATTACHMENTS

NO.	PLATE	NAME	EACH
15153	1902	Bobbin Winder Friction Ring (rubber)...	\$ 02
15154	1902	" " Pulley.....	25
2997	708	" " Spindle with 15072.....	25
571c	6313	" " " Worm.....	20
15159	1902	" " Stop Latch.....	25
92B	706	" " " Hinge Screw.	07
2442	703	" " " Spring.....	02
2745	709	" " Thread Guide.....	20
*2746	6313	" " " Cam.....	07
233B	706	" " " Screw.....	02
92B	706	" " " H i n g e Screw.....	07
2747	703	Bobbin Winder Thread Guide Spring....	02
2748	6313	" " Worm Wheel.....	20
15403	—	" " " 2748 with 233B and 2746.....	30
2749	6313	Bobbin Winder Worm Wheel Friction Washer.....	01
50B	6313	Bobbin Winder Worm Wheel Screw Stud	20
1528J	6313	" " " " "	
		Nut.....	05
15157	—	Hand Attachment complete with Bobbin Winder, Nos. 48B, 50B, 233B, 571c, 659D, 660D, 1528J, 2049, 2442, 2532, 2738, 2745, 2747, 2749, 2997, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15064, 15153 to 15155, 15159, 15403 and two each 92B, 183E and 399A	7 20

### HAND ATTACHMENT WITH BOBBIN WINDER

FOR 2008  
FOR 15-30 MACHINE  
OBSOLETE

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ 80
15240	1905	" Bracket with 15241 and two 145F..	1 15
*15241	—	" " Cap (belt cover).....	60
145F	706	" " " Screw.....	06
183E	706	" " " Screw.....	05
8380	710	Crank Handle (wood).....	05
8433	—	" " Spindle.....	20
8434	1902	" " " 8433 with 8382....	20
8382	703	" " " Washer.....	01
8280	711	" Hinge Pin.....	01
15295	1902	" Lever.....	30

## HAND ATTACHMENTS

47

NO.	PLATE	NAME	EACH
8281	711	Crank Lock Pin.....	\$ .02
8282	711	" " " Spring.....	.01
15296	1902	Crank complete, Nos. 8380, 8434 and 15295	.55
8313	710	Driver.....	.30
8284	711	" Finger.....	.20
8285	711	" " Hinge Pin.....	.01
8286	711	" " Lock Spring.....	.02
233B	706	" " " Screw.....	.02
8392	710	Gear with 8281 and 8282.....	.55
8393	710	" Cover.....	.20
399A	706	" " Screw.....	.02
659D	706	Screw Stud.....	.20
8394	710	Pinion.....	.55
2532	711	" Dowel Pin..... per 100	.20
660D	706	" Screw Stud.....	.20
15072	711	Bobbin Position Pin..... per 100	.20
15242	1905	" Winder Bracket.....	.50
134D	4906	" " " Screw.....	.07
15243	1905	" " Frame.....	.50
48B	705	" " " Hinge Screw.....	.20
2460	700	" " Friction Ring (rubber)....	.02
2461	700	" " Pulley.....	.10
15244	4906	" " Spindle with 15072.....	.30
571C	6313	" " " Worm.....	.20
15245	4906	" " Stop Latch.....	.25
92B	706	" " " Hinge Screw.....	.07
2747	703	" " " Spring.....	.02
15246	4906	" " Thread Guide.....	.20
*2746	6313	" " " Cam.....	.07
233B	706	" " " " Screw.....	.02
92B	706	" " " H i n g e Screw.....	.07
2747	703	Bobbin Winder Thread Guide Spring....	.02
2748	6313	" " Worm Wheel.....	.20
15403	—	" " " " 2748 with 233B and 2746.....	.30
2749	6313	Bobbin Winder Worm Wheel Friction Washer.....	.01
50B	6313	Bobbin Winder Worm Wheel Screy Stud	.20
1528J	6313	" " " " " "	
		Nut.....	.05
15247	—	Hand Attachment complete with Bobbin Winder, Nos. 48B, 50B, 134D, 233B, 571C, 659D, 660D, 1528J, 2460, 2461, 2532, 2749, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 15240, 15242 to 15246, 15296, 15403 and two each 92B, 183E, 399A and 2747.....	7 .50

## HAND ATTACHMENT WITH BOBBIN WINDER

FOR 2804

FOR 15-30 MACHINE

OBSOLETE

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ 80
2960	710	" Bracket with 2961 and two 145F...	1 15
*2961	710	" " Cap (belt cover).....	60
145F	706	" " Screw.....	06
183E	706	" " Screw.....	05
8380	710	Crank Handle (wood).....	05
8433	—	" " Spindle.....	20
8434	1902	" " " 8433 with 8382...	20
8382	703	" " " Washer.....	01
8280	711	" Hinge Pin.....	01
8435	1902	" Lever.....	30
8281	711	" Lock Pin.....	02
8282	711	" " " Spring.....	01
8436	1902	Crank complete, Nos. 8380, 8434 and 8435	55
8313	710	Driver.....	30
8284	711	" Finger.....	20
8285	711	" " Hinge Pin.....	01
8286	711	" " Lock Spring.....	02
233B	706	" " " " Screw.....	02
8392	710	Gear with 8281 and 8282.....	55
8393	710	" Cover.....	20
399A	706	" " Screw.....	02
659D	706	" Screw Stud.....	20
8394	710	Pinion.....	55
2532	711	" Dowel Pin..... per 100	20
660D	706	" Screw Stud.....	20
15072	711	Bobbin Position Pin..... per 100	20
2738	708	" Winder Frame.....	35
48B	705	" " " " Hinge Screw.....	20
15064	703	" " " Spring.....	05
2049	703	" " " " Stop Pin...	01
2460	700	" " Friction Ring (rubber)...	02
2461	700	" " Pulley.....	10
2997	708	" " Spindle with 15072.....	25
571C	6313	" " " " Worm.....	20
2431	709	" " Stop Latch.....	25
92B	706	" " " " Hinge Screw.....	07
2442	703	" " " " Spring.....	02
2745	709	" " Thread Guide.....	20

## HAND ATTACHMENTS

49

NO.	PLATE	NAME	EACH
*2746	6313	Bobbin Winder Thread Guide Cam.....	\$ 07
233B	706	" " " " " Screw	02
92B	706	" " " " H i n g e	
		Screw.....	07
2747	703	Bobbin Winder Thread Guide Spring....	02
2748	6313	" " Worm Wheel.....	20
15403	—	" " " " 2748 with 233B and 2746.....	30
2749	6313	Bobbin Winder Worm Wheel Friction Washer.....	01
50B	6313	Bobbin Winder Worm Wheel Screw Stud	20
1528J	6313	" " " " "	
		Nut.....	05
2962	—	Hand Attachment complete with Bobbin Winder, Nos. 48B, 50B, 233B, 571C, 659D, 660D, 1528J, 2049, 2431, 2442, 2460, 2461, 2532, 2738, 2745, 2747, 2749, 2960, 2997, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15064, 15403 and two each 92B, 183E and 399A....	7 20

**HAND ATTACHMENT**

FOR 15282

**OBSOLETE**

NO.	PLATE	NAME	EACH
8377	710	Body.....	\$ 80
33647	1902	" Bracket.....	25
183E	706	" " Screw.....	05
8380	710	Crank Handle (wood).....	05
8433	—	" " Spindle.....	20
8434	1902	" " " 8433 with 8382....	20
8382	703	" " " Washer.....	01
8280	711	" Hinge Pin.....	01
8435	1902	" Lever.....	30
8281	711	" Lock Pin.....	02
8282	711	" " " Spring.....	01
8436	1902	Crank complete, Nos. 8380, 8434 and 8435	55
33642	1902	Driver.....	30
33650	—	" 33642 with 2532, 8386 to 8388, 8394 and 94007.....	1 30
33643	—	Driver Finger.....	20
94007	4916	" " 33643 with 8390, 8391 and 94009.....	25
8386	703	Driver Finger Hinge Pin.....	01
8387	711	" " Lock Pin.....	02
8388	711	" " " Spring.....	01

## HAND ATTACHMENTS

NO.	PLATE	NAME	EACH
94009	4916	Driver Finger Sheath (leather).....	\$ 01
8390	711	" " " Plate.....	01
8391	711	" " " Staple.....	01
8392	710	Gear with 8281 and 8282.....	55
8393	710	" Cover.....	20
399A	706	" " Screw.....	02
659D	706	" Screw Stud.....	20
8394	710	Pinion.....	55
2532	711	" Dowel Pin..... per 100	20
660D	706	" Screw Stud.....	20
33646	—	Hand Attachment complete, Nos. 137B, 659D, 660D, 8280, 8377, 8392, 8393, 8436, 33647, 33650 and two each 183E and 399A.....	3 80
137B	706	Hand Attachment Screw.....	06

**HAND ATTACHMENT**

FOR 15-50 MACHINE

OBSOLETE, USE 94018

NO.	PLATE	NAME	EACH
*94002	4915	Body.....	\$ 70
33647	4915	" Bracket.....	25
183E	4916	" " Screw.....	05
80023	4915	Crank Handle (wood).....	06
94012	4915	" " Spindle.....	10
8280	4916	" Hinge Pin.....	01
8435	4915	" Lever.....	30
8281	4916	" Lock Pin.....	02
8282	4916	" " Spring.....	01
94005	—	Crank complete, Nos. 8435, 80023 and 94012.....	60
94006	4916	Driver.....	30
33643	—	" Finger.....	20
94007	4916	" " 33643 with 8390, 8391 and 94009.....	25
80018	4916	Driver Finger Hinge Pin.....	01
94008	4916	" " Lock Pin.....	03
8388	4916	" " " Spring.....	01
94009	4916	" " Sheath (leather).....	01
8390	4916	" " " Plate.....	01
8391	4916	" " " Staple.....	01
94010	4915	Gear with 8281 and 8282.....	60
94011	4915	" Cover.....	10
211A	4916	" " Screw.....	02
SS380D	4916	" Screw Stud.....	20

## HAND ATTACHMENTS

51

NO.	PLATE	NAME	EACH
80027	4916	Pinion.....	\$ 60
80028	4916	" Dowel Pin.....per 100	10
SS381D	4916	" Screw Stud.....	20
94001	—	Hand Attachment complete, Nos. 137B, SS380D, SS381D, 8280, 8388, 33647, 80018, 80027, 80028, 94002, 94005 to 94008, 94010, 94011 and two each 183E and 211A.....	3 80
137B	4916	Hand Attachment Screw.....	06

**STAND****ROCKING TREADLE, BALL BEARING PITMAN, COVER SET**

NO.	PLATE	NAME	EACH
25442	6321	Band Wheel, 12½ in. diam., with 972C...	\$1 40
46515	6321	" " Crank.....	25
46624	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 46506 to 46510, 46515, 46655 and six 25362.....	2 00
46511	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 46624 and 46630.....	2 15
297C	3826	Band Wheel Crank Screw Centre.....	20
46629	—	" " " " 297C with 1507R.....	25
1507R	3826	Band Wheel Crank Screw Centre Nut....	07
972C	3826	" " Set Screw.....	10
82680	—	Belt, size $\frac{3}{16}$ in., length 64½ in., with 25027	30
46631	4925	Belt Guide.....	10
1288R	706	" " Screw.....	10
25027	1909	" Hook.....	01
46525	699	" Shifter.....	07
34R	705	" " Hinge Screw.....	10
25033	1909	" " Spring.....	02
46632	6430	Brace with three 46629.....	2 15
46638	6430	" Section (left) with 46629.....	85
46639	6430	" " (right) with two 46629....	1 55
138E	705	" " Screw.....	07
46640	6430	Brace (sectional) complete, Nos. 46638, 46639 and three 138E.....	2 65
748R	3826	Brace Screw.....	10
46633	—	Dress Guard.....	50
46634	6430	Dress Guard complete, Nos. 34R, 25033, 46525 and 46633.....	65
1059R	705	Dress Guard Bolt with 1510R.....	05
1510R	706	" " " Nut.....	02

NO.	PLATE	NAME	EACH
25444	6321	Leg with two each 25068 and 25069 . . . . .	\$ 2 70
25068	699	" Roller.....	07
25069	699	" " Pin.....	01
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.....per 100	1 20
46506	3826	" " Bearing Adjusting Screw Ring.....	25
46507	3826	Pitman Ball Bearing Adjusting Screw Ring Locking Washer (brass) ..per 100	35
46508	3826	Pitman Ball Bearing Ring.....	20
46509	3826	" " Case.....	35
46655	3826	" " Separator.....	07
46510	6321	" Rod with 25360.....	25
*25360	—	" " Ball.....	20
25371	3826	" " " Bushing.....	25
25361	3826	" " " Screw Bearing.....	20
46630	—	" " " " 25361 with 1670E.....	25
1670E	3826	Pitman Rod Ball Screw Bearing Nut.....	07
1520R	3826	" " Lock Nut.....	05
25406	6321	Treadle.....	95
297C	3826	" Screw Centre.....	20
46629	—	" " " 297C with 1507R...	25
1507R	3826	" " " Nut.....	07
25086	6321	Wrench for 1507, 1510 and 1670.....	20
25200	6321	" " 972.....	20
25281	—	Stand (iron work) complete, Nos. 1059R, 1288R, 25086, 25200, 25406, 25442, 46511, 46631, 46632, 46634, two 25444 and four 748R.....	—

## STAND

### ROCKING TREADLE, BALL BEARING PITMAN, CABINET TABLE

NO.	PLATE	NAME	EACH
25442	6321	Band Wheel, $12\frac{1}{2}$ in. diam., with 972C...	\$1 40
46515	6321	" " Crank.....	25
46624	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 46506 to 46510, 46515, 46655 and six 25362.....	2 00
46511	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 46624 and 46630.....	2 15
297C	3826	Band Wheel Crank Screw Centre.....	20
46629	—	" " " " 297C with 1507R.....	25

NO.	PLATE	NAME	EACH
1507R	3826	Band Wheel Crank Screw Centre Nut...	\$ 07
972c	3826	" " Set Screw.....	10
25488	—	Belt, size $\frac{3}{16}$ in., length $66\frac{1}{2}$ in., with 25027	30
83031	4925	Belt Guide.....	10
1288R	706	" " Screw.....	10
25027	1909	" Hook.....	01
46525	699	" Shifter.....	07
34R	705	" " Hinge Screw.....	10
25033	1909	" " Spring.....	02
82896	6321	Brace with three 46629.....	2 70
748R	3826	" Screw.....	10
46526	—	Dress Guard.....	55
25049	6321	Dress Guard complete, Nos. 34R, 25033, 46525 and 46526.....	65
504R	705	Dress Guard Bolt with 1510R.....	05
1510R	706	" " " Nut.....	02
25444	6321	Leg with two each 25068 and 25069.....	2 70
25068	699	" Roller.....	07
25069	699	" " Pin.....	01
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.....per 100	1 20
46506	3826	" " Bearing Adjusting Screw Ring.....	25
46507	3826	Pitman Ball Bearing Adjusting Screw Ring Locking Washer (brass)....per 100	35
46508	3826	Pitman Ball Bearing Ring.....	20
46509	3826	" " Case.....	35
46655	3826	" " Separator.....	07
46510	6321	" Rod with 25360.....	25
*25360	—	" " Ball.....	20
25371	3826	" " " Bushing.....	25
• 25361	3826	" " " Screw Bearing.....	20
46630	—	" " " " 25361 with 1670E.....	25
1670E	3826	Pitman Rod Ball Screw Bearing Nut.....	07
1520R	3826	" " Lock Nut.....	05
25406	6321	Treadle.....	95
297c	3826	" Screw Centre.....	20
46629	—	" " " 297c with 1507R...	25
1507R	3826	" " " Nut.....	07
25086	6321	Wrench for 1507, 1510 and 1670.....	20
25200	6321	" " 972.....	20
82953	—	Stand (iron work) complete, Nos. 504R, 1288R, 25049, 25086, 25200, 25406, 25442, 46511, 82896, 83031, two 25444 and four 748R.....	—

## CABINET TRIMMINGS TRIMMINGS FOR COVER SET

NO.	PLATE	NAME	EACH
56498	4924	Cover Cushion (felt).....	\$ 01
56494	4924	" Hook.....	07
28297	6316	" " Cup Catch (nickled).....	07
56251	6316	" Lock.....	20
28297	6316	" " Cup Catch (nickled).....	07
28076	2917	" " Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			
28233	712	Cover Lock Key .....	07
2833	6318	Drip Pan with four 1 in. wire nails .....	30
28079	712	End Leaf Hinge .....	05
25056	6430	" " Support.....	20
46671	4925	" " " Bracket, 4½ in. between screw holes, with three wood screws ¾ in. No. 7.....	20
28088	6413	Handle (wood).....	07
50550B	4923	" Bolt.....	10
NN 83J	6413	" " Nut.....	03
28229	6413	" Hinge Rivet.....	01
124307	4924	" Link.....	10
124310	—	" " 124307 with 28229 and 50550B.....	25
28231	6413	Handle Stud.....	10
124311	—	Handle complete, Nos. 28088, 28231 and two each NN83J and 124310.....	70
525B	705	Machine Hinge Bolt.....	25
1727E	4918	" " " Nut.....	05
2807	703	" " " Washer.....	01
8294	703	" " Connection.....	10
8295	703	" " " Hinge Pin...	01
8306	700	Machine Hinge, Nos. 525B, 8294 and 8295	30
8292	—	Machine Hinge complete, Nos. 1727E, 2807 and 8306.....	35
28242	6317	Machine Rest Cushion (leather) with 5604	01
5604	711	" " " Pin..... per 100	20
56429	2917	Partition Lock (revolving bolt, double) ..	07
56430	2917	" " (revolving bolt, single)....	07
28076	2917	" " Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			
28233	712	Partition Lock Key .....	07
25047	699	Skeleton Drawer Case Drawer Spring....	02
46612	699	" " " Support with two wood screws ½ in. No. 7 R. H. B.....	05

## TRIMMINGS FOR CABINET TABLE

NO.	PLATE	NAME	EACH
87605	6317	Centre Drawer Hinge Bracket with two wood screws $\frac{1}{2}$ in. No. 7.....	\$ 10
87606	6317	Centre Drawer Hinge Bracket Plate with two wood screws $\frac{1}{2}$ in. No. 7.....	07
56441	6316	Centre Drawer Lock with two wood screws $\frac{1}{2}$ in. No. 2.....	07
28076	2917	Centre Drawer Lock Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			
28233	712	Centre Drawer Lock Key.....	07
56260	6321	Counterbalance Spring.....	35
56261	6321	“ “ Adjusting Collar	25
50251E	6317	“ “ “ “ Bolt with 1734E.....	05
1734E	6317	Counterbalance Spring Adjusting Collar Bolt Nut.....	02
9281	6317	Counterbalance Spring Adjusting Collar Bolt Nut Washer.....	01
56262	6321	Counterbalance Spring Bracket (hinge) ..	50
28235	712	Hinge, round end, for machine platform flap.....	20
NOTE: When ordering No. 28235, state finish.			
28234	712	Hinge, round ends, for top leaf .....	25
NOTE: When ordering No. 28234, state finish.			
25152	1909	Machine Cushion (felt) .....	01
25070	703	“ “ Tack (rubber).....	01
56348	4924	“ Hinge Connection.....	20
2809	711	“ “ “ Hinge Pin...	01
15263	711	“ “ Plate.....	30
56349	—	Machine Hinge complete, Nos. 2809, 15263, 56348 and wood screw 1 in. No. 10.....	50
NOTE: When ordering No. 56349, state finish.			
56263	6321	Machine Lifting Plate.....	60
56319	—	“ “ “ 56263 with 28123 and 56262.....	1 15
28123	711	Machine Lifting Plate Hinge Pin.....	05
56264	6321	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 56319	1 80
56429	2917	Partition Lock (revolving bolt, double)...	07
56430	2917	“ “ (revolving bolt, single)....	07
28076	2917	“ “ Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			

NO.	PLATE	NAME	EACH
28233	712	Partition Lock Key.....	\$ 07
28125	712	Shield Supporting Bracket.....	07
25047	699	Skeleton Drawer Case Drawer Spring.....	02
46612	699	" " " Support with two wood screws $\frac{1}{2}$ in. No. 7 R. H. B.....	05

## TRIMMINGS FOR DRAWING ROOM CABINET

NO.	PLATE	NAME	EACH
28210	2917	Attachment Tray Pull (leather).....	\$ 02
28211	2917	" " " Washer.....	02
28205	2915	Band Wheel with 972c.....	1 20
28005	2915	" " Bracket with 302c and 1507R	90
28206	2915	" " Crank.....	30
28248	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 28206, 28247, 46506 to 46509, 46655, 56317 and six 25362.....	2 15
302c	706	Band Wheel Crank Screw Centre.....	10
1507R	3826	" " " " Nut....	07
972c	3826	" " Set Screw.....	10
28007	—	Belt, size $\frac{3}{16}$ in., length $65\frac{1}{2}$ in., with 25027	30
28012	2917	" Guide Screw Eye.....	01
25027	1909	" Hook.....	01
46525	699	" Shifter.....	07
124333	4925	" " Bracket.....	25
124334	—	Belt Shifter complete, Nos. 34R, 25033, 46525 and 124333.....	40
34R	705	Belt Shifter Hinge Screw.....	10
25033	1909	" " Spring.....	02
28016	712	Cabinet Case Roller (iron).....	06
28017	712	" " " Frame.....	20
28018	711	" " " Pin.....	01
28019	712	Cabinet Case Roller complete, Nos. 28016 to 28018.....	25
56260	6321	Counterbalance Spring.....	35
56261	6321	" " Adjusting Collar	25
50251E	6317	" " " "	
		Bolt with 1734E.....	05
1734E	6317	Counterbalance Spring Adjusting Collar Bolt Nut.....	02
9281	6317	Counterbalance Spring Adjusting Collar Bolt Nut Washer.....	01
56262	6321	Counterbalance Spring Bracket (hinge)...	50

## TRIMMINGS FOR DRAWING ROOM CABINET 57

NO.	PLATE	NAME	EACH
124315	4924	Door (left) Lock .....	\$ 07
28076	2917	" " " Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			
28233	712	Door (left) Lock Key.....	07
56356	4924	" " " Plate.....	10
15232	2915	Drip Pan.....	30
28253	712	Hinge, 1 in. x $1\frac{5}{16}$ in., for doors.....	07
NOTE: When ordering No. 28253, state finish.			
28235	712	Hinge, round end, for machine platform flap.....	20
NOTE: When ordering No. 28235, state finish.			
28234	712	Hinge, round ends, for top leaf .....	25
NOTE: When ordering No. 28234, state finish.			
28291	4924	Hinge for Shield.....	07
25152	1909	Machine Cushion (felt).....	01
56348	4924	" Hinge Connection.....	20
2809	711	" " " Hinge Pin...	01
15263	711	" " Plate.....	30
56349	—	Machine Hinge complete, Nos. 2809, 15263, 56348 and wood screw 1 in. No. 10.....	50
NOTE: When ordering No. 56349, state finish.			
124381	6432	Machine Lifting Plate .....	60
124382	—	" " " 124381 with 28123 and 56262.....	1 15
28123	711	Machine Lifting Plate Hinge Pin.....	05
124383	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124382	1 80
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.....per 100	1 20
46506	3826	" " Bearing Adjusting Screw Ring.....	25
46507	3826	Pitman Ball Bearing Adjusting Screw Ring Locking Washer (brass)...per 100	35
46508	3826	Pitman Ball Bearing Ring.....	20
46509	3826	" " Case.....	35
46655	3826	" " Separator.....	07
28247	2915	" Rod with 25360.....	25
*25360	—	" " Ball.....	20
25371	3826	" " " Bushing.....	25
56253	2917	" " " Screw Bearing.....	20
56317	—	" " " " 56253 with 1670E.....	25
1670E	3826	Pitman Rod Ball Screw Bearing Nut....	07
1520R	3826	" " Lock Nut.....	05

## 58 TRIMMINGS FOR DRAWING ROOM CABINET

NO.	PLATE	NAME	EACH
124351	4925	Shield Chain, 5½ in. long, with 124352 and wood screw ½ in. No. 5 R. H. B.	\$ 20
124352	4925	Shield Chain Hook.....	02
56496	4924	Spring Catch, for doors.....	06
56497	4924	" " Cup.....	06
28208	2915	Treadle.....	1 80
50574c	4923	" Screw Centre.....	20
124331	4925	" " " Bracket.....	30
124332	—	Treadle Screw Centre Bracket complete, Nos. 1507R, 50574c and 124331.....	55
1507R	3826	Treadle Screw Centre Nut.....	07
25086	6321	Wrench for 1507 and 1670.....	20
25200	6321	" " 972.....	20

TRIMMINGS FOR OPEN-SIDE  
DRAWING ROOM CABINET

NO.	PLATE	NAME	EACH
25442	6321	Band Wheel, 12½ in. diam., with 972c...	\$1 40
46515	6321	" " Crank.....	25
28260	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 28267, 46506 to 46509, 46515, 46655, 56317 and six 25362.....	2 15
56446	6322	Band Wheel Crank Frame with two 46629	2 30
28262	6322	" " " " Bracket with 28263 .....	80
28263	6317	Band Wheel Crank Frame Bracket Cushion (leather).....	01
649E	4906	Band Wheel Crank Frame Screw.....	07
297c	3826	" " " Screw Centre.....	20
46629	—	" " " " " 297c with 1507R.....	25
1507R	3826	Band Wheel Crank Screw Centre Nut....	07
972c	3826	" " Set Screw.....	10
25135	—	Belt, size $\frac{3}{16}$ in., length 67½ in., with 25027	30
28266	4910	" Guide.....	20
25027	1909	" Hook.....	01
46525	699	" Shifter.....	07
34R	705	" " Hinge Screw.....	10
25033	1909	" " Spring.....	02
28016	712	Cabinet Case Roller (iron).....	06
28017	712	" " " Frame.....	20
28018	711	" " " Pin.....	01
28019	712	Cabinet Case Roller complete, Nos. 28016 to 28018.....	25

## TRIMMINGS FOR OPEN-SIDE CABINET 59

NO.	PLATE	NAME	EACH
56260	6321	Counterbalance Spring.....	\$ 35
56261	6321	“ “ Adjusting Collar	25
50251E	6317	“ “ “ “	
		Bolt with 1734E.....	05
1734E	6317	Counterbalance Spring Adjusting Collar Bolt Nut.....	02
9281	6317	Counterbalance Spring Adjusting Collar Bolt Nut Washer.....	01
56262	6321	Counterbalance Spring Bracket (hinge)...	50
28278	—	Door Drawer Lock Plate (brass).....	07
28279	4270	“ “ “ “ (oxidized).....	07
28280	—	“ “ “ Hub Key (brass)	25
28281	4270	“ “ “ “ “ (oxi- dized).....	25
28283	4270	Door Hinge.....	30
NOTE: When ordering No. 28283, state finish.			
28284	4270	Door Lock with four round head wood screws $\frac{3}{4}$ in. No. 4.....	25
NOTE: When ordering No. 28284, state finish.			
28286	4270	Door Lock Key.....	07
NOTE: When ordering No. 28286, state finish.			
28288	4270	Door Lock Key Hole Escutcheon with two round head wood screws $\frac{3}{8}$ in. No. 2	07
NOTE: When ordering No. 28288, state finish.			
56254	4270	Door Lock Plate.....	06
56499	4924	“ Stop (felt).....	01
46526	—	Dress Guard.....	55
25049	6321	Dress Guard complete, Nos. 34R, 25033, 46525 and 46526.....	65
504R	705	Dress Guard Bolt with 1510R.....	05
1510R	706	“ “ “ Nut.....	02
28235	712	Hinge, round end, for machine platform flap.....	20
NOTE: When ordering No. 28235, state finish.			
28234	712	Hinge, round ends, for top leaf.....	25
NOTE: When ordering No. 28234, state finish.			
25152	1909	Machine Cushion (felt).....	01
56348	4924	“ Hinge Connection.....	20
2809	711	“ “ “ Hinge Pin...	01
15263	711	“ “ Plate.....	30
56349	—	Machine Hinge complete, Nos. 2809, 15263, 56348 and wood screw 1 in. No. 10.....	50
NOTE: When ordering No. 56349, state finish.			

## 60 TRIMMINGS FOR OPEN-SIDE CABINET

NO.	PLATE	NAME	EACH
124384	6432	Machine Lifting Plate.....	\$ 60
124385	—	" " " 124384 with 28123 and 56262.....	1 15
28123	711	Machine Lifting Plate Hinge Pin.....	.05
124386	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124385	1 80
25362	3826	Pitman Ball, size $\frac{3}{16}$ in.....per 100	1 20
46506	3826	" " Bearing Adjusting Screw Ring.....	.25
46507	3826	Pitman Ball Bearing Adjusting Screw Ring Locking Washer (brass) ..per 100	.35
46508	3826	Pitman Ball Bearing Ring.....	.20
46509	3826	" " Case.....	.35
46655	3826	" " Separator.....	.07
28267	6322	" Rod with 25360.....	.25
*25360	—	" " Ball.....	.20
25371	3826	" " " Bushing.....	.25
56253	2917	" " " Screw Bearing.....	.20
56317	—	" " " " 56253 with 1670E.....	.25
1670E	3826	Pitman Rod Ball Screw Bearing Nut.....	.07
1520R	3826	" " Lock Nut.....	.05
124351	4925	Shield Chain, $5\frac{1}{2}$ in. long, with 124352 and wood screw $\frac{1}{2}$ in. No. 5 R. H. B.	.20
124352	4925	Shield Chain Hook.....	.02
28290	4270	Top Leaf Support Cushion (rubber).....	.02
25406	6321	Treadle.....	.95
28268	4270	" Centre.....	.07
56450	6432	" " Bracket with 28268.....	.25
297c	3826	" Screw Centre.....	.20
46629	—	" " " 297c with 1507R.....	.25
1507R	3826	" " " Nut.....	.07
25086	6321	Wrench for 1507, 1510 and 1670.....	.20
25200	6321	" " 972.....	.20

## TRIMMINGS FOR PORTABLE CASE

NO.	PLATE	NAME	EACH
25070	703	Base Cushion Tack (rubber).....	\$ .01
124402	6432	" Till Lid.....	.25
124403	—	Base Till Lid complete, Nos. 124362, 124363, 124402 and two 124364.....	.35
124362	4924	Base Till Lid Latch.....	.02
124363	4924	" " " " Button.....	.06
124364	4924	" " " " " Washer.....	.02
56498	4924	Cover Cushion (felt).....	.01
56494	4924	" Hook.....	.07

## TRIMMINGS FOR PORTABLE CASE

61

NO.	PLATE	NAME	EACH
56495	4924	Cover Hook Plate.....	\$ 07
56251	6316	" Lock.....	20
28076	2917	" " Escutcheon.....	02
NOTE: When ordering No. 28076, state finish.			
28233	712	Cover Lock Key.....	07
87427	6413	" " Plate.....	07
87555	4925	" Re-enforcing Plate.....	07
15214	1962	Drip Pan.....	25
28088	6413	Handle (wood).....	07
50549B	4923	" Bolt.....	10
NN 83J	6413	" " Nut.....	03
28229	6413	" Hinge Rivet.....	01
124307	4924	" Link.....	10
124308	—	" " 124307 with 28229 and 50549B.....	25
28231	6413	Handle Stud.....	10
124309	—	Handle complete, Nos. 28088, 28231, 87555 and two each NN 83J and 124308	55
124387	4924	Machine Button.....	10
124388	—	" " 124387 with 56493.....	10
124389	—	" " 124388 with 732B, 22436R and 124390.....	65
56493	4924	Machine Button Cushion (leather).....	01
732B	4923	" " Thumb Screw.....	20
124390	4924	" " " " Bushing..	35
22436R	4924	" " " " Washer...	01
87721	4924	" Hinge Connection.....	10
8295	703	" " " " Hinge Pin...	01
87722	4924	" " Head.....	25
SS368J	6413	" " " Screw.....	10
87572	6413	" " " " Washer.....	03
87723	—	Machine Hinge complete, Nos. SS368J, 8295, 87572, 87721 and 87722.....	60
28242	6413	Machine Rest Cushion (leather) with 5604	01
5604	6413	" " " " Pin..... per 100	20

**OBSOLETE PARTS**

NO.	PLATE	NAME	EACH
*2801	—	Arm with 450C, 2006 and 2803, use 15318	\$ 6 00
*15318	—	" " " " " " 15496	6 00
2802	699	" Shaft for 2019 for 2828 for 15-22 Machine, for 2837 for 15-30 and 15-50 Machines, for 2896 for 15-41 Machine and for 2871 for 15-43 Machine .....	1 50

NO.	PLATE	NAME	EACH
15305	—	Arm Shaft for 2019 and 15306 for 15271 for 15-22 Machine, for 15272 for 15-30 Machine, for 15275 for 15-41 Machine and for 15273 for 15-43 Machine.....	\$1 50
15311	699	Arm Shaft for 15318 for 15306 and 15314, for 15271 for 15-22 Machine, for 15272 for 15-30 and 15-50 Machines, for 15275 for 15-41 Machine and for 15273 for 15-43 Machine.....	1 50
2006	700	Arm Shaft Bushing (back).....	25
450c	705	" " " " Set Screw....	02
*2803	—	" " " (front).....	25
8300	700	" Side Cover, use 15427.....	25
15514	6317	Apron Spring (Trimmings for Open-Side Drawing Room Cabinet).....	07
28277	6317	Apron Spring Screw Eye (Trimmings for Open-Side Drawing Room Cabinet)...	02
2008B	699	Balance Wheel, 2½ in. pulley.....	1 50
2804	699	" " 3 in. pulley.....	1 50
28261	6322	Band Wheel Crank Frame with two 46629 (Trimmings for Open-Side Drawing Room Cabinet).....	2 30
124356	—	Base Till Lid.....	25
56500	6432	Base Till Lid complete, Nos. 87581, 124301, 124302 and 124356 (Trimmings for Portable Case).....	35
87581	6413	Base Till Lid Catch Plate.....	07
87582	6413	" " " " Pin.....	03
124301	4924	" " " Knob (wood).....	02
124302	4923	" " " Rivet.....	01
25439	6321	Belt Guide for 82953.....	10
28011	2915	" " with 34R, 25033 and 28015 (Trimmings for Drawing Room Cabinet)	50
28126	4906	Belt Hole Bushing (oval, brass) 5/8 in. x 1 in. (Trimmings for Drawing Room Cabinet).....	07
28250	—	Belt Hole Bushing (oval, oxidized) 5/8 in. x 1 in. (Trimmings for Drawing Room Cabinet).....	07
28015	712	Belt Shifter for 28011.....	07
15283	6313	Bobbin Winder Adjusting Arm for 15294 and 15303.....	25
15414	4920	Bobbin Winder Pulley for 15417 and 15419, use 15288.....	10
15290	4913	Bobbin Winder Stop Latch for 15294....	25
15301	4914	" " " " " 15303....	25

NO.	PLATE	NAME	EACH
50060B	6313	Bobbin Winder Stop Latch Hinge Screw for 15294 and 15303.....	\$ 10
15292	711	Bobbin Winder Thread Guide for 15293..	20
15302	4906	" " " " " 15293..	20
15293	6313	" " " " Spring for 15292 and 15302.....	01
15424	4920	Bobbin Winder Worm Wheel and Thread Guide Cam Friction Washer for 15417 and 15419.....	01
56258	6317	Centre Drawer Stop Pin (Trimmings for Cabinet Table).....	02
87428	6316	Cover Hook (Trimmings for Cover Set and Portable Case).....	07
87372	6316	Cover Hook Cup Catch (Trimmings for Cover Set) .....	07
87431	6413	Cover Hook Plate (Trimmings for Porta- ble Case).....	10
*2021	—	Clamp Stop Motion Flanged Bushing....	55
15152	700	" " " " " 2021 with two 462c.....	55
2019B	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15152.....	1 15
2811	699	Crank Connecting Rod with 2812 and two 158E.....	95
*2812	—	Crank Connecting Rod Cap.....	—
158E	705	" " " " " Screw.....	05
28020	2915	Drawer Lock Bolt (Trimmings for Draw- ing Room Cabinet).....	60
28021	712	Drawer Lock Bolt Cam and Plate (Trim- mings for Drawing Room Cabinet)....	55
87363	712	Drawer Lock Key (Trimmings for Draw- ing Room Cabinet).....	07
25058	6430	End Leaf Support Bracket, 4 $\frac{1}{8}$ in. between screw holes, with three wood screws $\frac{3}{4}$ in. No. 7 (Trimmings for Cover Set).....	20
*2813	—	Face Plate.....	90
2814	699	" " 2813 with 2815.....	1 15
2815	1902	" " Tension Seat.....	30
15239	—	Face Plate complete, Nos. 248A, 1338D, 1560B, 2814, 2826, 2827, 2829, 2830, 8238, 15238, 32572 and two 2102, use 55644.....	2 30
15019	—	Face Plate complete, Nos. 248A, 413D, 1560B, 2814, 2826, 2827, 2829, 2830, 2923, 15070 and two 2921, use 15151	2 40

NO.	PLATE	NAME	EACH
15151	—	Face Plate complete, Nos. 248A, 413D, 1560B, 2814, 2826, 2827, 2829, 2830, 8238, 15150 and two 2102.....	\$2 40
2038	700	Feed Cam with 448c.....	35
448c	705	“ “ Set Screw.....	05
15466	—	“ Cover Plate with 15260.....	55
15259	4907	“ “ “ 15466 with 1423B, for art work, for 15-30 Machine.....	60
15260	4907	Feed Cover Plate Position Stud.....	07
1423B	4907	“ “ “ Screw.....	06
15298	4905	“ Dog (feeding surface same as 15279) for 15-22 Machine.....	35
15102	1908	Feed Dog, three teeth at right of needle, square corner, for 15-30 and 15-50 Machines.....	60
15226	1965	Feed Dog, for shirt work, beveled for hemmer, for 15-30 and 15-50 Machines	60
15249	4905	Feed Dog, three teeth at right of needle, square corner, for 15-30 and 15-50 Machines.....	80
15211	1965	Feed Dog (feeding surface same as 2506) 22 teeth (36 teeth to the inch) for 15-30, 15-41 and 15-50 Machines.....	60
15138	1908	Feed Dog, three teeth at right of needle, rounded corner, for 15-43 Machine....	35
2042B	699	Feed Forked Connection.....	80
378c	705	“ “ “ Hinge Screw....	20
74E	706	“ Regular Hinge Screw.....	10
2047B	699	“ Rock Shaft.....	55
2046B	—	Feed Rock Shaft complete, Nos. 2047B and 2048B.....	80
2048B	704	Feed Rock Shaft Crank with 465c.....	25
2049	703	“ “ “ Pin.....	01
465c	706	“ “ “ Set Screw.....	02
8332	4910	Hand Attachment Crank complete for 15247, Nos. 8279, 8380 and 8381, use 15296.....	55
8379	710	Hand Attachment Crank complete for 2962, 15057, 15157 and 15205, Nos. 8380, 8381 and 8383, use 8436.....	55
8316	—	Hand Attachment Crank Handle Spindle for 8381.....	20
8381	710	Hand Attachment Crank Handle Spindle 8316 with 8382, for 8332 and 8379....	20
8279	4910	Hand Attachment Crank Lever for 8332	30
8383	710	“ “ “ “ 8379, use 8435.....	30

NO.	PLATE	NAME	EACH
50289B	6413	Handle Bolt.....	\$ 10
87558	6413	" Link.....	10
87550	—	Handle complete, Nos. 28088, 28231, 87555 and two each NN83J, 28229, 50289B and 87558 (Trimmings for Portable Case).....	80
26152	4909	Hemmer (foot) $\frac{1}{8}$ in. hem, use 35857....	55
25883	4909	" " $\frac{5}{64}$ in. hem, use 35996....	50
28227	—	Knob (brass).....	25
28228	—	Knob (brass) complete, Nos. 1272E and 28227 (Trimmings for Cabinet Table and Drawing Room Cabinet).....	30
28221	6316	Knob (oxidized).....	25
28223	—	Knob (oxidized) complete, Nos. 1272E and 28221 (Trimmings for Cabinet Table and Drawing Room Cabinet)...	30
1272E	6316	Knob Screw.....	07
28029	712	Latch for 28037.....	10
56323	6429	" " 56326.....	20
28030	712	" Button (brass) for 28037.....	25
56324	6429	" " for 56326.....	25
28032	703	" " Hinge Pin for 28037.....	01
56438	6317	" " " " 56326 .....	01
28033	712	" Frame for 28037.....	25
56325	6429	" " " 56326.....	25
28034	711	" Hinge Pin.....	01
28200	711	" Spring.....	07
5604	711	" " Rivet.....per 100	20
28037	712	Latch (brass) complete, Nos. 5604, 28029, 28030, 28032 to 28034 and 28200 (Trimmings for Drawing Room Cabi- net) .....	60
56326	6429	Latch complete, Nos. 5604, 28034, 28200, 56323 to 56325 and 56438 (Trimmings for Drawing Room Cabinet).....	65
87342	6413	Machine Button with 84151 and wood screw 1 in. No. 9 R. H. B. (Trimmings for Portable Case).....	03
84151	6413	Machine Button Washer (leather).....	01
2993B	—	" Hinge Connection for 2992.....	20
2810B	—	" " Plate for 2992.....	30
2992B	—	Machine Hinge (nickelated) complete, Nos. 2809, 2810B, 2993B and two nickel- plated wood screws $\frac{3}{4}$ in. No. 10.....	50
15255	—	Machine Hinge Plate (brass) for 15256...	30

NO.	PLATE	NAME	EACH
15256	—	Machine Hinge (brass) complete for Cabinet Table, Nos. 2809, 15254, 15255 and two brass wood screws $\frac{3}{4}$ in. No. 10.....	\$ 50
15252	711	Machine Hinge Plate (oxidized) for 15253	30
15253	711	Machine Hinge (oxidized) complete for Cabinet Table, Nos. 2809, 15251, 15252 and two oxidized wood screws $\frac{3}{4}$ in. No. 10.....	50
15254	—	Machine Hinge Connection (brass) for 15256 and 15266.....	20
15251	711	Machine Hinge Connection (oxidized) for 15253 and 15264.....	20
15265	—	Machine Hinge Plate (brass) for 15266	30
15266	—	Machine Hinge (brass) complete, Nos. 2809, 15254, 15265 and brass wood screw $\frac{7}{8}$ in. No. 10 (Trimmings for Cabinet Table and Open-Side Drawing Room Cabinet).....	50
15264	711	Machine Hinge (oxidized) complete, Nos. 2809, 15251, 15263 and oxidized wood screw $\frac{7}{8}$ in. No. 10 (Trimmings for Cabinet Table and Open-Side Drawing Room Cabinet).....	50
87571	6413	Machine Hinge Head.....	25
87573	—	Machine Hinge complete, Nos. SS368J, 8294, 8295, 87571 and 87572 (Trimmings for Drawing Room Cabinet and Portable Case).....	60
56451	6432	Machine Lifting Plate for 56452.....	60
56452	—	“ “ “ 56451 with 28123 and 56262, for 56453.....	1 15
56453	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 56452 (Trimmings for Drawing Room Cabinet).....	1 80
124320	6432	Machine Lifting Plate for 124321.....	60
124321	—	“ “ “ 124320 with 28123 and 56262, for 124322.....	1 10
124322	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124321 (Trimmings for Open-Side Drawing Room Cabinet).....	1 75
2819	704	Needle Bar Connecting Link with 794E, use 15248 .....	80
794E	705	Needle Bar Connecting Link Adjusting Screw.....	07

## OBSOLETE PARTS

67

NO.	PLATE	NAME	EACH
2820	700	Oscillating Rock Shaft for 15-22, 15-30 and 15-50 Machines, obsolete, use 125013..	\$ .80
2821	704	Presser Bar Lifter.....	.30
1058C	705	" " " Screw.....	.20
1520E	706	" " " Nut.....	.05
15261	4907	" " Stop Collar with 237F, for art work, for 15-30 Machine.....	.25
237F	4907	Presser Bar Stop Collar Set Screw.....	.02
2071	704	" Foot, use 15281.....	.35
35600	4907	" " .....	.80
35601	4907	" " Body.....	.35
22232	4907	" " Friction Washer.....	.01
1292B	4907	" " Hinge Screw.....	.06
35602	4907	Presser Foot complete, for etching, for 15259 for 15-30 Machine, Nos. 190B, 1292B, 22232, 35600 and 35601.....	1 .15
190B	4907	Presser Foot Screw.....	.05
*56257	—	Rocking Frame.....	1 .20
*56255	—	" " 56257 with two each 28043 and 28045.....	1 .45
28041	2915	Rocking Frame 56255 with 434c and 28048 (Trimmings for Drawing Room Cabi- net).....	1 .85
28042	2915	Rocking Frame Bracket (Trimmings for Drawing Room Cabinet).....	.25
28043	2915	Rocking Frame Connecting Link for 56255	.06
28044	712	" " " " Bracket (Trimmings for Drawing Room Cabi- net).....	.06
2269	711	Rocking Frame Connecting Link Bracket Pin.....	.01
28045	2917	Rocking Frame Connecting Link Hinge Stud for 56255.....	.06
28046	2915	Rocking Frame Hinge Plate (Trimmings for Drawing Room Cabinet) .....	.20
28047	2915	Rocking Frame Spring (Trimmings for Drawing Room Cabinet).....	1 .15
28048	2915	Rocking Frame Spring Adjusting Block for 28041.....	.35
28049	711	Rocking Frame Spring Adjusting Block Pin.....	.02
434c	706	Rocking Frame Spring Adjusting Block Set Screw.....	.06
56442	—	Shield Chain, 6½ in. long, for 56443.....	.10

NO.	PLATE	NAME	EACH
56443	4925	Shield Chain 56442 with 640B, 56444 and wood screw $\frac{1}{2}$ in. No. 5 R. H. B. (Trim-mings for Drawing Room Cabinet and Open-Side Drawing Room Cabinet) . . .	\$ 20
56444	4924	Shield Chain Plate. . . . .	02
640B	4923	" " " Screw. . . . .	02
15003	—	Shuttle Bobbin Case Hinge for 15099, Nos. 2972 to 2974. . . . .	35
2972	709	Shuttle Bobbin Case Latch for 15003. . . . .	20
15099	—	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 15003, 15027 and 15098, use 15142. . . . .	1 15
15142	709	Shuttle Bobbin Case complete for 15100, Nos. 591F, 592E, 2523, 2975, 15027, 15098 and 15141, use 15277. . . . .	1 15
2526	709	Shuttle Tension Spring for 15142. . . . .	20
15098	709	" " " " 15099 a n d 15142. . . . .	20
240D	705	Shuttle Race Slide Spring Screw for 2995 and 15147. . . . .	02
725J	706	Shuttle Race Slide Spring Screw for 2995 and 15147. . . . .	02
2921	703	Tension Disc. . . . .	07
15070	703	" Releaser for 15019. . . . .	25
15150	1909	" " " 15151. . . . .	25
15237	—	" Releasing Disc, use 32572. . . . .	07
413D	705	" Screw Stud. . . . .	20
1338D	4906	" " " . . . . .	20
2923	703	" Spring. . . . .	07
8238	1909	" " . . . . .	07
2826	703	" Thread Guard. . . . .	07
2828	701	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-22 Machine. . . . .	80
2837	708	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-30 and 15-50 Machines. . . . .	80
2896	4910	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-41 Machine. . . . .	1 50
2871	4910	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-43 Machine. . . . .	1 50
743C	705	Thread Take-up Cam Position Screw. . . . .	07
448C	705	" " " Set Screw. . . . .	05
2316	700	" " Lever with 1822, for 15-22 and 15-43 Machines. . . . .	80
15071	1902	Thread Take-up Lever with 1822, for 15-30, 15-41 and 15-50 Machines. . . . .	80

## OBSOLETE PARTS

69

NO.	PLATE	NAME	EACH
79c	706	Thread Take-up Lever Hinge Screw.....	\$ 10
2829	703	" " Spring.....	05
2830	703	" " Regulator .....	35
248A	705	" " " Set Screw	02
15299	4905	Throat Plate for 15298.....	60
2986	704	" " 2506.....	60
15103	1908	" " 15102.....	60
15227	1965	" " 15226.....	60
15250	4905	" " 15249.....	60
15139	1908	" " 15138.....	60
15001	1908	" " art work, use 15259.....	35
28269	4910	Treadle Centre Bracket with 28268 (Trimmings for Open-Side Drawing Room Cabinet).....	25
56252	2915	Treadle Screw Centre Bracket with 46629 (Trimmings for Drawing Room Cabi- net).....	50

**NUMERICAL LIST OF PARTS  
FOR  
MACHINES**  
**Nos. 15-22, 15-30, 15-41,  
15-43 and 15-50**

## NUMERICAL LIST OF PARTS

NO.	PLATE	NAME	EACH
24B	705	Bobbin Winder Stop Latch Hinge Screw for 2444, 2841, 15173 and 15176, obsolete.....	\$ 10
34R	705	Belt Shifter Hinge Screw for 25049, 28011, 46634 and 124334 .....	10
48B	705	Bobbin Winder Frame Hinge Screw for 2144 2841, 2850, 2962, 15020, 15057, 15085, 15157, 15173, 15176, 15179, 15181, 15205 and 15247, obsolete.....	20
50B	6313	Bobbin Winder Worm Wheel Screw Stud for 2850, 2962, 15020, 15085, 15157, 15179, 15181, 15247, 15294 and 15303, obsolete .....	20
50B	6313	Bobbin Winder Worm Wheel and Thread Guide Cam Screw Stud for 15417 and 15419.....	20
74E	706	Feed Regulator Hinge Screw, obsolete...	10
79C	706	Thread Take-up Lever Hinge Screw, obsolete.....	10
NN83J	6413	Handle Bolt Nut for 87550, 124309 and 124311.....	03
92B	706	Bobbin Winder Stop Latch Hinge Screw for 2850, 2962, 15020, 15057, 15085, 15157, 15179, 15181, 15205 and 15247, obsolete.....	07
92B	706	Bobbin Winder Thread Guide Hinge Screw for 2850, 2962, 15020, 15085, 15157, 15179, 15181 and 15247, obsolete....	07
112D	702	Shuttle Tension Spring Screw for 44001..	02
134D	4906	Bobbin Winder Bracket Screw for 15247, obsolete.....	07
137B	4916	Hand Attachment Screw for 33646, 94001 and 94018.....	06
138E	705	Arm Screw.....	07
138E	705	Brace Section Screw for 46640.....	07
145F	706	Hand Attachment Body Bracket Cap Screw for 2960, 15155 and 15240, obsolete.....	06
145D	706	Shuttle Race Screw for 15-30, 15-41 and 15-50 Machines.....	06
155C	705	Needle Bar Connecting Stud Set Screw for 2052.....	05

NO.	PLATE	NAME	EACH
157J	705	Feed Lifting Rock Shaft Crank Clamping Screw for 2509 and 2573.....	\$ 06
158E	705	Crank Connecting Rod Cap Screw for 2811, obsolete.....	05
158D	705	Shuttle Race Screw for 15-22 and 15-43 Machines.....	05
161B	705	Bobbin Winder Frame Screw for 2848 and 2854, obsolete.....	06
171A	2929	Tuck Folder Adjusting Screw for 36091	05
175J	706	Feed Forked Connection Adjusting Screw for 15319.....	02
180B	6313	Bobbin Winder Bracket Screw for 15172, 15175, 15178, 15180 and 15284.....	05
183E	4916	Hand Attachment Body Bracket Screw for 2962, 15057, 15157, 15205, 15247, 33646, 94001 and 94018.....	05
190B	705	Bobbin Winder Bracket Screw for 2446, 2838, 2849 and 15062, obsolete.....	05
190D	705	Corder Screw for 26399.....	05
190B	933	Embroidery Attachment Screw for 35496	05
190B	705	Face Plate Screw.....	05
190B	4907	Presser Foot Screw for 35602, obsolete..	05
190C	705	Shuttle Race Back Screw for 2093.....	05
191C	705	Feed Dog Screw for 15-22 and 15-43 Machines.....	05
205A	705	Bobbin Winder Spool Stand Screw for 2839, obsolete.....	05
208E	706	Feed Dog Screw for 15-30, 15-41 and 15-50 Machines.....	02
211A	4916	Hand Attachment Gear Cover Screw for 94001, obsolete.....	02
229D	1909	Oscillating Shaft Crank Slide Block Cap Screw for 15171.....	02
233B	6313	Bobbin Winder Thread Guide Cam Screw for 15403, obsolete.....	02
233B	706	Hand Attachment Driver Finger Lock Spring Screw for 2962, 15057, 15157, 15205 and 15247, obsolete.....	02
233B	706	Needle Bar Thread Guard Screw for 15-41 and 15-43 Machines.....	02
237F	4907	Presser Bar Stop Collar Set Screw for 15261, obsolete.....	02
240D	705	Shuttle Race Slide Spring Screw for 2995 and 15147, obsolete.....	02
240D	1018	Embroidery Attachment Thread Retaining Spring Screw for 26538 .....	02
246A	706	Needle Clamp Screw for 15069.....	05

## NUMERICAL LIST OF PARTS

73

NO.	PLATE	NAME	EACH
248A	705	Clamp Stop Motion Clamp Stop Screw for 2019 and 15314.....	\$ 02
248A	705	Thread Take-up Spring Regulator Set Screw for 15019, 15151 and 15239, obsolete .....	02
251A	705	Needle Bar Thread Guard Screw for 15-22, 15-30 and 15-50 Machines....	02
256B	700	Clamp Stop Motion Clamp Screw for 2019 and 15314.....	50
263J	705	Pressure Regulating Thumb Screw.....	30
286B	706	Arm Side Cover Thumb Screw.....	20
286B	706	Bobbin Winder Eccentric Thumb Screw for 2848 and 2854, obsolete.....	20
286B	706	Presser Foot Thumb Screw.....	20
287B	5635	Cloth Guide Thumb Screw for 120306 and 120309.....	20
289B	4906	Braider Thumb Screw for 25510 .....	10
297C	3826	Band Wheel Crank Screw Centre for 46629	20
297C	3826	Treadle Screw Centre for 46629.....	20
302C	706	Band Wheel Crank Screw Centre for 28005	10
307C	705	Feed Lifting Rock Shaft Screw Centre...	10
307C	705	" Rock Shaft Screw Centre.....	10
307C	705	Oscillating Rock Shaft Screw Centre for 15-22, 15-30 and 15-50 Machines....	10
315C	705	Feed Bar Screw Centre.....	06
SS368J	6413	Machine Hinge Head Screw for 87573 and 87723.....	10
375C	705	Crank Connecting Rod Hinge Screw.....	20
378C	705	Feed Forked Connection Hinge Screw, obsolete.....	20
SS380D	4916	Hand Attachment Gear Screw Stud for 94001, obsolete.....	20
SS381D	4916	Hand Attachment Pinion Screw Stud for 94001, obsolete .....	20
398E	702	Shuttle Main Spring Screw for 2213....	02
399A	706	Hand Attachment Gear Cover Screw for 2962, 15057, 15157, 15205, 15247, 33646 and 94018 .....	02
413D	705	Tension Screw Stud for 15019 and 15151, obsolete.....	20
434C	706	Rocking Frame Spring Adjusting Block Set Screw for 28041, obsolete.....	06
435C	4923	Arm Shaft Bushing Set Screw for 15496	06
448C	705	Feed Cam Set Screw for 2038, obsolete..	05
448C	705	Presser Bar Lifter Hinge Stud Set Screw for 15496.....	05

NO.	PLATE	NAME	EACH
448C	705	Thread Take-up Cam Set Screw for 2828, 2837, 2871 and 2896, obsolete.....	\$ .05
450C	705	Arm Shaft Bushing (back) Set Screw for 2801 and 15318, obsolete.....	.02
453C	705	Presser Bar Spring Bracket Set Screw for 2068.....	.02
457C	705	Shuttle Driver Set Screw for 2092.....	.02
462C	706	Clamp Stop Motion Flanged Bushing Set Screw for 15152 and 15313.....	.02
462C	706	Oscillating Shaft Crank Set Screw for 2057, 2511, 15161, 15162, 15164 and 15165.....	.02
462C	706	Shuttle Driver Set Screw for 2441.....	.02
465C	706	Feed Rock Shaft Crank Set Screw for 2048, obsolete.....	.02
466H	702	Shuttle Tension Regulating Screw for 44001.....	.06
468C	1018	Embroidery Attachment Looper Set Screw for 26528.....	.02
SS476C	4922	Darning Foot Clamp Thumb Screw for 86294.....	.10
504R	705	Dress Guard Bolt with 1510R, for 82953 and Trimmings for Open-Side Drawing Room Cabinet .....	.05
525B	705	Machine Hinge Bolt for 8306.....	.25
552C	705	Needle Clamp Thumb Screw for 2054....	.20
570C	706	" Bar Connecting Link Hinge Screw	.10
571C	6313	Bobbin Winder Spindle Worm for 2850, 2962, 15020, 15085, 15157, 15179, 15181, 15247, 15303, 15417, 15419 and 15473	.20
591F	709	Shuttle Tension Regulating Screw for 15099, 15142 and 15277.....	.02
592E	709	Shuttle Bobbin Case Latch Stop Screw for 15099, 15142 and 15277.....	.02
635C	706	Oscillating Rock Shaft Hinge Pin Screw Bearing for 5747.....	.10
640B	4923	Shield Chain Plate Screw for 56443, obsolete.....	.02
648J	709	Shuttle Race Back Spring Screw for 2528	.10
649E	4906	Band Wheel Crank Frame Screw (Trimmings for Open-Side Drawing Room Cabinet).....	.07
659D	706	Hand Attachment Gear Screw Stud for 2962, 15057, 15157, 15205, 15247, 33646 and 94018.....	.20

## NUMERICAL LIST OF PARTS

75

NO.	PLATE	NAME	EACH
660D	706	Hand Attachment Pinion Screw Stud for 2962, 15057, 15157, 15205, 15247, 33646 and 94018.....	\$ 20
662D	706	Shuttle Race Cap Screw for 15420.....	02
665B	4919	Presser Foot Braid Guide Screw for 36055	02
665B	4919	“ “ Cord Guide Screw for 36058	02
691A	705	Throat Plate Screw.....	06
725J	706	Shuttle Race Slide Spring Screw for 2995 and 15147, obsolete.....	02
732B	4923	Machine Button Thumb Screw for 124389	20
743C	705	Thread Take-up Cam Position Screw, obsolete.....	07
747B	705	Feed Regulator Thumb Screw.....	20
748R	3826	Brace Screw for 25281 and 82953.....	10
794E	705	Needle Bar Connecting Link Adjusting Screw for 2819, obsolete.....	07
857B	4918	Thread Take-up Spring Regulator Set Screw for 15432.....	02
896E	4923	Crank Connecting Rod Cap Screw for 125011.....	06
930E	1909	Needle Bar Connecting Link Adjusting Screw for 15248.....	06
972C	3826	Band Wheel Set Screw for 25442 and 28205.....	10
1035C	1909	Oscillating Shaft Crank Slide Block Screw Stud for 15171.....	25
1058C	705	Presser Bar Lifter Screw, obsolete.....	20
1059R	705	Dress Guard Bolt with 1510R, for 25281	05
1085C	1909	Feed Forked Connection Slide Block Screw Stud for 15183.....	10
1085E	1909	Feed Forked Connection Roller Screw Stud for 1832.....	10
1272E	6316	Knob Screw for 28223 and 28228, obso- lete .....	07
1285C	706	Feed Cam Set Screw for 15306.....	06
1288R	706	Belt Guide Screw for 25281 and 82953...	10
1292B	4907	Presser Foot Hinge Screw for 35602, obsolete.....	06
1293C	706	Thread Take-up Cam Position Screw for 2828, 2837, 2871, 2896, 15271 to 15273 and 15275.....	20
1338D	4906	Tension Screw Stud for 15239, obsolete	20
1381C	706	Feed Forked Connection Hinge Screw (eccentric).....	20
1422B	936	Embroidery Attachment Spool Bracket Tension Regulating Thumb Screw for 35504.....	07

NO.	PLATE	NAME	EACH
1423B	4907	Feed Cover Plate Screw for 15259, obsolete.....	\$ 06
1483H	2929	Tuck Folder Thumb Screw for 36091....	20
1507R	3826	Band Wheel Crank Screw Centre Nut for 28005 and 46629.....	07
1507R	3826	Treadle Screw Centre Nut for 46629 and 124332.....	07
1510R	706	Dress Guard Bolt Nut for 504 and 1059	02
1513J	706	Feed Lifting Rock Shaft Screw Centre Nut	07
1513J	706	“ Rock Shaft Screw Centre Nut.....	07
1513J	706	Oscillating Rock Shaft Hinge Pin Nut for 56812.....	07
1513J	706	Oscillating Rock Shaft Hinge Pin Screw Bearing Nut for 5747.....	07
1513J	706	Oscillating Rock Shaft Screw Centre Nut for 15-22, 15-30 and 15-50 Machines	07
1518E	706	Crank Connecting Rod Hinge Screw Nut	06
1519E	706	Oscillating Shaft Crank Slide Block Screw Stud Nut for 15161, 15162, 15164 and 15165.....	05
1519J	706	Feed Bar Screw Centre Nut.....	05
1520E	706	“ Forked Connection Hinge Screw Nut	05
1520E	706	Needle Bar Connecting Link Hinge Screw Nut.....	05
1520E	706	Presser Bar Lifter Screw Nut, obsolete	05
1520R	3826	Pitman Rod Lock Nut for 28248, 28260 and 46624.....	05
1528J	6313	Bobbin Winder Worm Wheel Screw Stud Nut for 2850, 2962, 15020, 15085, 15157, 15179, 15181, 15247, 15294 and 15303, obsolete.....	05
1528J	6313	Bobbin Winder Worm Wheel and Thread Guide Cam Screw Stud Nut for 15417 and 15419.....	05
1560B	706	Tension Regulating Thumb Nut for 15019, 15151, 15239 and 15471.....	06
1670E	3826	Pitman Rod Ball Screw Bearing Nut for 46630 and 56317.....	07
1704B	2929	Tuck Folder Screw Stud Thumb Nut for 36091.....	06
1705B	2929	Tuck Folder Space Gauge Screw Stud Thumb Nut for 36091.....	05
1727E	4918	Machine Hinge Bolt Nut for 8292.....	05
1734E	6317	Counterbalance Spring Adjusting Collar Bolt Nut for 50251.....	02
1813	706	Feed Lifting Rock Shaft Crank Roller and Stud for 2509.....	30

## NUMERICAL LIST OF PARTS

77

NO.	PLATE	NAME	EACH
1813	706	Oscillating Shaft Crank Roller and Stud for 2163 and 2416.....	\$ 30
1822	706	Thread Take-up Lever Roller and Stud for 2316, 15071, 15491 and 15493.....	30
1832	706	Feed Forked Connection Roller with 1085E, for 15-22, 15-30 and 15-50 Machines.....	30
1935	706	Feed Lifting Rock Shaft Crank Roller and Stud for 2573.....	30
2002	703	Arm Dowel Pin.....	02
2006	700	" Shaft Bushing (back) for 2801 and 15318, obsolete.....	25
2007	703	Arm Spool Pin.....	02
2008B	699	Balance Wheel, 2½ in. pulley, obsolete..	1 50
2019B	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15152, obsolete.....	1 15
2020	700	Clamp Stop Motion Clamp Washer for 2019 and 15314.....	07
*2021	—	Clamp Stop Motion Flanged Bushing for 15152, obsolete.....	55
2022	703	Clamp Stop Motion Flanged Bushing Pin	01
2037	700	Feed Bar for 15-22 and 15-43 Machines..	55
2038	700	" Cam with 448C, obsolete.....	35
2040	702	" Dog for 15-22 and 15-43 Machines..	35
2042B	699	" Forked Connection, obsolete.....	80
2044	704	" Regulator.....	35
2046B	—	Feed Rock Shaft complete, Nos. 2047B and 2048B, obsolete.....	80
2047B	699	Feed Rock Shaft for 2046, obsolete.....	55
2048B	704	" " " Crank with 465C, for 2046, obsolete.....	25
2049	703	Bobbin Winder Frame Spring Stop Pin for 2962, 15057, 15157 and 15205, obsolete.....	01
2049	703	Feed Rock Shaft Crank Pin, obsolete...	01
2049	703	Oscillating Shaft Crank Pin.....	01
2049	703	Shuttle Driver Pin.....	01
2050	700	Needle Bar for 15-22, 15-30 and 15-50 Machines.....	55
2052	704	Needle Bar Connecting Stud with 155C, for 15374 .....	35
2054	703	Needle Clamp with 552C, for 15-22, 15-30 and 15-50 Machines.....	35
2056	699	Oscillating Shaft for 15-22 and 15-43 Machines.....	35
2057	702	Oscillating Shaft Crank 2163 with two 462C, for 15-22 Machine.....	80

NO.	PLATE	NAME	EACH
2058	4910	Presser Bar for 15-41 and 15-43 Machines	\$ 50
2068	704	" " Spring Bracket with 453c....	35
2070	703	" " " Washer.....	01
2071	704	" Foot, obsolete, use 15281.....	35
2073	702	Shuttle Bobbin for 2208.....	07
*2075	—	" Cover for 44001.....	55
2076	702	" " Hinge Pin for 2208.....	01
2078	702	" Delivery Eye Thread Guard for 44001.....	05
2080	702	Shuttle Delivery Eye Thread Guard Rivet for 44001.....	01
2082	702	Shuttle Main Spring for 2213.....	20
2084	702	" " " Steady Pin for 2213.	01
2086	702	" Tension Spring for 44001.....	05
2090	702	" " " Plate for 44001...	07
2092	702	" Driver 2176 with two 457c, for 15-22 and 15-43 Machines.....	80
2093	701	Shuttle Race complete for 15-22 and 15-43 Machines, Nos. 2095, 2096 and two 190c.....	1 15
2095	701	Shuttle Race Back for 2093.....	30
2096	—	" " Body for 2093.....	65
2102	1909	Tension Disc for 15151, 15239 and 15471.	07
*2163	—	Oscillating Shaft Crank with 1813, for 2057.....	80
*2176	—	Shuttler Driver for 2092.....	80
2208	702	Shuttle complete for 15-22 and 15-43 Machines, Nos. 2073, 2076, 2213 and 44001.....	1 50
2211	702	Shuttle Bobbin Retaining Spring for 2213	05
2212	702	" " " " Rivet for 2213.....per 100	35
*2213	—	Shuttle Body with 398E, 2082, 2084, 2211 and two 2212, for 2208.....	85
2269	711	Rocking Frame Connecting Link Bracket Pin (Trimmings for Drawing Room Cabinet) obsolete.....	01
2316	700	Thread Take-up Lever with 1822, for 15-22 and 15-43 Machines, obsolete	80
*2416	—	Oscillating Shaft Crank with 1813, for 2511.....	80
2431	709	Bobbin Winder Stop Latch for 2850, 2962, 15020, 15085, 15179 and 15181, obsolete	25
2441	708	Shuttle Driver 2542 with two 462c, for 15-30, 15-41 and 15-50 Machines....	1 15

## NUMERICAL LIST OF PARTS

79

NO.	PLATE	NAME	EACH
2442	703	Bobbin Winder Stop Latch Spring for 2850, 2962, 15020, 15057, 15085, 15157, 15179, 15181 and 15205, obsolete....	\$ 02
2444	701	Bobbin Winder for 2843, Nos. 24B, 48B, 2446, 2447, 2451, 2452 and 2855, obsolete.....	1 25
2446	701	Bobbin Winder Bracket (belt cover) for 2444, obsolete.....	35
2447	701	Bobbin Winder Frame for 2444, 2841, 15173 and 15176, obsolete.....	20
2449	701	Bobbin Winder Spindle with 15072, for 2855, obsolete.....	20
2451	702	Bobbin Winder Spring for 2444 and 15173, obsolete.....	05
2452	701	Bobbin Winder Stop Latch for 2444, 2841, 15173 and 15176, obsolete.....	20
2455	702	Bobbin Winder Spool Stand Thread Re- taining Disc for 2839, obsolete.....	02
2457	702	Bobbin Winder Spool Stand Thread Re- taining Disc Stud for 2839, obsolete....	05
2460	700	Bobbin Winder Friction Ring (rubber) for 2848, 2854, 2962, 15057 and 15247, obsolete.....	02
2461	700	Bobbin Winder Pulley for 2848, 2854, 2962, 15057 and 15247, obsolete.....	10
2466	700	Bobbin Winder Eccentric for 2848 and 2854, obsolete.....	25
2506	704	Feed Dog, for cloth, for 15-41 Machine, and for 36058 for 15-30 Machine .....	60
2509	709	Feed Lifting Rock Shaft Crank with 157J and 1813, for 2836.....	60
2510	708	Oscillating Shaft for 15-30, 15-41 and 15-50 Machines.....	35
2511	708	Oscillating Shaft Crank 2416 with two 462c, for 15-30 and 15-50 Machines...	80
2515	709	Shuttle Body for 15100.....	1 15
2523	709	" Bobbin Case Position Finger Rivet for 15099, 15142 and 15277....per 100	35
2526	709	Shuttle Tension Spring for 15142, obsolete	20
2528	708	Shuttle Race complete for 15-30, 15-41 and 15-50 Machines, Nos. 648J, 2531, 2533, 15420 and two 2532.....	2 30
2530	—	Shuttle Race Body for 15420.....	1 15
2531	708	" " Back for 2528.....	60
2532	711	Hand Attachment Pinion Dowel Pin for 2962, 15057, 15157, 15205, 15247 and 33650, obsolete.....per 100	20

NO.	PLATE	NAME	EACH
2532	711	Shuttle Race Back Position Pin for 2528 .....per 100	\$ 20
2533	708	Shuttle Race Back Spring for 2528.....	20
2535	708	" " Cap for 15420.....	25
*2542	—	" Driver for 2441.....	1 15
2573	702	Feed Lifting Rock Shaft Crank with 157J and 1935, for 2817.....	60
2738	708	Bobbin Winder Frame for 2850, 2962, 15020, 15085, 15157, 15179 and 15181, obsolete.....	35
2739	703	Bobbin Winder Frame Spring for 15085 and 15181, obsolete .....	05
2742	1902	Bobbin Winder Spindle for 2859, obsolete	25
2744	700	" " Pulley for 2855, 15085 and 15181, obsolete.....	20
2745	709	Bobbin Winder Thread Guide for 2850, 2962, 15020, 15085, 15157, 15179 and 15181, obsolete.....	20
*2746	6313	Bobbin Winder Thread Guide Cam for 15403, obsolete.....	07
2747	703	Bobbin Winder Stop Latch Spring for 15247, obsolete.....	02
2747	703	Bobbin Winder Thread Guide Spring for 2850, 2962, 15020, 15085, 15157, 15179, 15181 and 15247, obsolete.....	02
2748	6313	Bobbin Winder Worm Wheel for 15403, obsolete.....	20
2749	6313	Bobbin Winder Worm Wheel and Thread Guide Cam Friction Washer for 15417 and 15419.....	01
2749	6313	Bobbin Winder Worm Wheel Friction Washer for 2850, 2962, 15020, 15085, 15157, 15179, 15181, 15247, 15294 and 15303, obsolete.....	01
*2801	—	Arm with 450c, 2006 and 2803, obsolete, use 15318.....	6 00
2802	699	Arm Shaft for 2019 for 2828 for 15-22 Machine, for 2837 for 15-30 and 15-50 Machines, for 2896 for 15-41 Machine, and for 2871 for 15-43 Machine, obsolete	1 50
*2803	—	Arm Shaft Bushing (front) for 2801 and 15318, obsolete.....	25
2804	699	Balance Wheel, 3 in. pulley, obsolete....	1 50
*2805	—	Bed.....	6 00
2807	703	Machine Hinge Bolt Nut Washer for 8292	01

## NUMERICAL LIST OF PARTS

81

NO.	PLATE	NAME	EACH
2809	711	Machine Hinge Connection Hinge Pin for 2992, 15253, 15256, 15264, 15266 and 56349.....	\$ .01
2810B	—	Machine Hinge Plate for 2992, obsolete	30
2811	699	Crank Connecting Rod with 2812 and two 158E, obsolete.....	95
*2812	—	Crank Connecting Rod Cap for 2811, obsolete.....	—
*2813	—	Face Plate for 2814, obsolete.....	90
2814	699	“ “ 2813 with 2815, for 15019, 15151 and 15239, obsolete.....	1 15
*2815	1902	Face Plate Tension Seat for 2814, obsolete	30
2816	699	Feed Lifting Rock Shaft for 2817 and 2836.....	55
2817	—	Feed Lifting Rock Shaft complete for 15-22 and 15-43 Machines, Nos. 2573 and 2816.....	1 15
2819	704	Needle Bar Connecting Link with 794E, obsolete, use 15248.....	80
2820	700	Oscillating Rock Shaft for 15-22, 15-30 and 15-50 Machines, obsolete, use 125013.....	80
2821	704	Presser Bar Lifter, obsolete.....	30
2824	704	Shuttle Race Slide Spring for 2995 and 15147.....	07
2826	703	Tension Thread Guard for 15019, 15151 and 15239, obsolete.....	07
2827	703	Face Plate Thread Guard with 8505, for 15019, 15151, 15239 and 15432.....	02
2828	701	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-22 Machine, obsolete .....	80
2829	703	Thread Take-up Spring for 15019, 15151 and 15239, obsolete.....	05
2830	703	Thread Take-up Spring Regulator for 15019, 15151 and 15239, obsolete....	35
2831	1965	Throat Plate, large needle hole, for 2040 for 15-43 Machine, and for 2506 for 36058 and 15-41 Machine.....	60
2832	—	Throat Plate, small needle hole, for 2040 for 15-43 Machine and for 2506 for 15-41 Machine.....	60
2833	6318	Drip Pan with four 1 in. wire nails (Trimmings for Cover Set).....	30
2835	708	Feed Bar for 15-30, 15-41 and 15-50 Machines.....	60

NO.	PLATE	NAME	EACH
2836	—	Feed Lifting Rock Shaft complete for 15-30, 15-41 and 15-50 Machines, Nos. 2509 and 2816.....	\$1 15
2837	708	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-30 and 15-50 Machines, obsolete.....	.80
2838	701	Bobbin Winder Bracket (belt cover) for 2841, obsolete.....	.35
2839	702	Bobbin Winder Spool Stand complete for 2842, 2843, 15174 and 15177, Nos. 2455, 2457, 2840 and 15367, obsolete..	.25
2840	702	Bobbin Winder Spool Stand Bed for 2839, obsolete.....	.07
2841	—	Bobbin Winder for 2842, Nos. 24B, 48B, 2447, 2452, 2838, 2851 and 2855, obsolete.....	1 25
2842	—	Bobbin Winder (automatic) complete for 2804 for 15-22 and 15-43 Machines, Nos. 2839 and 2841, obsolete.....	1 50
2843	—	Bobbin Winder (automatic) complete for 2008 for 15-22 and 15-43 Machines, Nos. 2444 and 2839, obsolete.....	1 50
2844	701	Bobbin Winder Frame for 2848 and 2854, obsolete.....	.25
2845	701	Bobbin Winder Spindle, for bobbin, for 2847, obsolete.....	.25
2846	700	Bobbin Winder Spindle, for spool, for 2847 and 2853, obsolete.....	.20
2847	—	Bobbin Winder Spindle 2845 with 2846, for 2848, obsolete.....	.35
2848	701	Bobbin Winder (eccentric) complete (Hamburg) for 15-22 and 15-43 Machines, Nos. 286B, 2460, 2461, 2466, 2844 and 2847, obsolete.....	1 10
2849	708	Bobbin Winder Bracket (belt cover) for 2850 and 15020, obsolete .....	.35
2850	—	Bobbin Winder (automatic) complete for 2804 for 15-30 and 15-41 Machines, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2849, 2859, 15064, 15403 and two 92B, obsolete...	2 65
2851	702	Bobbin Winder Spring for 2841 and 15176, obsolete.....	.05
2852	708	Bobbin Winder Spindle, for bobbin, for 2853, obsolete.....	.25
2853	—	Bobbin Winder Spindle 2852 with 2846, for 2854, obsolete.....	.35

## NUMERICAL LIST OF PARTS

83

NO.	PLATE	NAME	EACH
2854	708	Bobbin Winder (eccentric) complete (Hamburg) for 15-30 and 15-41 Machines, Nos. 286B, 2460, 2461, 2466, 2844 and 2853, obsolete.....	\$1 10
2855	—	Bobbin Winder Spindle 2449 with 2744, for 2444, 2841, 15173 and 15176, obsolete.....	30
2859	—	Bobbin Winder Spindle 2742 with 32557, for 2850, obsolete.....	35
2871	4910	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-43 Machine, obsolete.....	1 50
2896	4910	Thread Take-up Cam with 448c and 1293c, for 2802 for 15-41 Machine, obsolete .....	1 50
2921	703	Tension Disc for 15019, obsolete.....	07
2923	703	" Spring for 15019, obsolete.....	07
2960	710	Hand Attachment Body Bracket with 2961 and two 145F, for 2962 and 15057, obsolete.....	1 15
*2961	710	Hand Attachment Body Bracket Cap (belt cover) for 2960, obsolete.....	60
2962	—	Hand Attachment complete with Bobbin Winder for 2804 for 15-30 Machine, Nos. 48B, 50B, 233B, 571C, 659D, 660D, 1528J, 2049, 2431, 2442, 2460, 2461, 2532, 2738, 2745, 2747, 2749, 2960, 2997, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15064, 15403 and two each 92B, 183E and 399A, obsolete	7 20
2972	709	Shuttle Bobbin Case Latch for 15003, obsolete.....	20
2973	709	Shuttle Bobbin Case Latch Lever for 15003 and 15141.....	20
2974	709	Shuttle Bobbin Case Latch Lever Fulcrum Pin for 15003 and 15141 ..per 100	20
2975	709	Shuttle Bobbin Case Latch Spring for 15099, 15142 and 15277.....	02
2986	704	Throat Plate for 2040 for 15-22 Machine, and obsolete for 2506 for 15-30 Machine	60
2992B	—	Machine Hinge (nickled) complete, Nos. 2809, 2810B, 2993B and two nickel-plated wood screws $\frac{3}{4}$ in. No. 10, obsolete.....	50
2993B	—	Machine Hinge Connection for 2992, obsolete.....	20
2994	—	Shuttle Race Slide for 2995.....	35

## NUMERICAL LIST OF PARTS

NO.	PLATE	NAME	EACH
2995	4910	Shuttle Race Slide complete for 15-22 and 15-43 Machines, Nos. 2824, 2994 and two 50216J.....	\$ 50
2996	709	Shuttle Bobbin for 15100, 120306 and 120309.....	.07
2997	708	Bobbin Winder Spindle with 15072, for 2962, 15020, 15085, 15157, 15179 and 15181, obsolete.....	.25
3052	1902	Oscillating Rock Shaft Hinge Pin for 56812.....	.80
*4304	1902	Oscillating Rock Shaft with 4784, for 5747	1 .50
4604	4923	Corder Bow Rivet for 26399.....per 100	.20
4641	1965	Feed Dog, four teeth at right of needle, square corner, for 15-41 Machine.....	.60
4645	—	Throat Plate, small needle hole, for 4641	.80
4737	1965	“ “ large needle hole, for 4641	.80
4784	1909	Oscillating Rock Shaft Oil Pad for 4304	.01
5604	711	Latch Spring Rivet for 28037 and 56326, obsolete.....per 100	.20
5604	711	Machine Rest Cushion Pin for 28242 .....per 100	.20
5747	—	Oscillating Rock Shaft 4304 with 635c, 1513J and 56812, for 15-41 and 15-43 Machines.....	2 .60
6267	4909	Hemmer Folder.....	.02
8217	4918	Feed Regulator Friction Washer.....	.01
8238	1909	Tension Spring for 15151 and 15239, obsolete.....	.07
8279	4910	Hand Attachment Crank Lever for 8332, obsolete.....	.30
8280	4916	Hand Attachment Crank Hinge Pin for 2962, 15057, 15157, 15205, 15247, 33646, 94001 and 94018.....	.01
8281	4916	Hand Attachment Crank Lock Pin for 8392 and 94010.....	.02
8282	4916	Hand Attachment Crank Lock Pin Spring for 8392 and 94010.....	.01
Nos. 8284 to 8286 FOR 2962, 15057, 15157, 15205 AND 15247, OBSOLETE			
8284	711	Hand Attachment Driver Finger.....	.20
8285	711	“ “ “ “ Hinge Pin.....	.01
8286	711	Hand Attachment Driver Finger Lock Spring.....	.02
8292	—	Machine Hinge complete, Nos. 1727E, 2807 and 8306 (Trimmings for Cover Set).....	.35

## NUMERICAL LIST OF PARTS

85

NO.	PLATE	NAME	EACH
8294	703	Machine Hinge Connection for 8306 and - 87573.....	\$ 10
8295	703	Machine Hinge Connection Hinge Pin for 8306, 87573 and 87723.....	01
8300	700	Arm Side Cover, obsolete, use 15427 ...	25
8306	700	Machine Hinge for 8292, Nos. 525B, 8294 and 8295.....	30
8313	710	Hand Attachment Driver for 2962, 15057, 15157, 15205 and 15247, obsolete.....	30
8316	—	Hand Attachment Crank Handle Spindle for 8381, obsolete.....	20
8332	4910	Hand Attachment Crank complete for 15247, Nos. 8279, 8380 and 8381, obsolete, use 15296.....	55
8377	710	Hand Attachment Body for 2962, 15057, 15157, 15205, 15247 and 33646, obsolete	80
8379	710	Hand Attachment Crank complete for 2962, 15057, 15157 and 15205, Nos. 8380, 8381 and 8383, obsolete, use 8436	55
8380	710	Hand Attachment Crank Handle (wood) for 8332, 8379, 8436 and 15296, obsolete	05
8381	710	Hand Attachment Crank Handle Spindle 8316 with 8382, for 8332 and 8379, obsolete.....	20
8382	703	Hand Attachment Crank Handle Spindle Washer for 8381 and 8434, obsolete...	01
8383	710	Hand Attachment Crank Lever for 8379, obsolete, use 8435.....	30
8386	703	Hand Attachment Driver Finger Hinge Pin for 33650, obsolete.....	01
8387	711	Hand Attachment Driver Finger Lock Pin for 33650, obsolete.....	02
8388	4916	Hand Attachment Driver Finger Lock Pin Spring for 33650, 94001 and 94018	01
8390	4916	Hand Attachment Driver Finger Sheath Plate for 94007.....	01
8391	4916	Hand Attachment Driver Finger Sheath Staple for 94007.....	01
8392	710	Hand Attachment Gear with 8281 and 8282, for 2962, 15057, 15157, 15205, 15247, 33646 and 94018.....	55
8393	710	Hand Attachment Gear Cover for 2962, 15057, 15157, 15205, 15247 and 33646, obsolete.....	20
8394	710	Hand Attachment Pinion for 2962, 15057, 15157, 15205, 15247, 33650 and 94018	55
8399	700	Presser Bar Spring.....	07

NO.	PLATE	NAME	EACH
8433	—	Hand Attachment Crank Handle Spindle for 8434, obsolete.....	\$ 20
8434	1902	Hand Attachment Crank Handle Spindle 8433 with 8382, for 8436 and 15296, obsolete.....	20
8435	4915	Hand Attachment Crank Lever for 8436 and 94005.....	30
8436	1902	Hand Attachment Crank complete for 2962, 15057, 15157, 15205 and 33646, Nos. 8380, 8434 and 8435, obsolete...	55
8505	703	Face Plate Thread Guard Rivet for 2827 .....per 100	20
8879	700	Arm Spool Pin Washer (cloth).....	01
9281	6317	Counterbalance Spring Adjusting Collar Bolt Nut Washer for 56264, 56453, 124322, 124383 and 124386.....	01
9859	1018	Embroidery Attachment Thread Bracket Rivet (for repairs only) for 26938..per 100	20
12152	933	Embroidery Attachment Body Block Rivet for 35496 ....., per 100	20
12424	1909	Oscillating Shaft Crank Slide Block Cap Screw Washer for 15171.....	02
13710	4918	Tension Spring for 15471.....	05
15001	1908	Throat Plate, for art work, obsolete, use 15259.....	35
15003	—	Shuttle Bobbin Case Hinge for 15099, Nos. 2972 to 2974, obsolete.....	35
15019	—	Face Plate complete, Nos. 248A, 413D, 1560B, 2814, 2826, 2827, 2829, 2830, 2923, 15070 and two 2921, obsolete, use 15151 .....	2 40
15020	708	Bobbin Winder (automatic) complete for 2804 for 15-30 and 15-41 Machines, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2849, 2997, 15064, 15403, 32557 and two 92B, obsolete.....	2 65
15027	709	Shuttle Bobbin Case Position Finger for 15099, 15142 and 15277 .....	07
15053	701	Bobbin Winder Frame for 15057 and 15205, obsolete.....	25
15054	701	Bobbin Winder Spindle with 15072, for 15057, obsolete.....	25
15055	701	Bobbin Winder Stop Latch for 15057, obsolete.....	25
15056	703	Bobbin Winder Frame Spring for 15057 and 15205, obsolete.....	05

## NUMERICAL LIST OF PARTS

87

NO.	PLATE	NAME	EACH
15057	—	Hand Attachment complete with Bobbin Winder for 2804 for 15-22 Machine, Nos. 48B, 92B, 233B, 659D, 660D, 2049, 2442, 2460, 2461, 2532, 2960, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15053 to 15056 and two each 183E and 399A, obsolete.....	\$6 00
15062	708	Bobbin Winder Bracket (belt cover) for 15085, obsolete.....	35
15064	703	Bobbin Winder Frame Spring for 2850, 2962, 15020, 15157 and 15179, obsolete	05
15067	1902	Needle Bar for 15-41 and 15-43 Machines	55
15068	711	" " Thread Guard.....	01
15069	1909	" Clamp with 246A, for 15-41 and 15-43 Machines.....	30
15070	703	Tension Releaser for 15019, obsolete.....	25
15071	1902	Thread Take-up Lever with 1822, for 15-30, 15-41 and 15-50 Machines, obsolete.....	80
15072	6313	Bobbin Winder Bobbin Position Pin for 2449, 2997, 15054, 15218, 15244, 15289 and 15300.....per 100	20
15085	708	Bobbin Winder (automatic) complete for 2008 for 15-30 and 15-41 Machines, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2739, 2744, 2745, 2747, 2749, 2997, 15062, 15403 and two 92B, obsolete	2 65
15098	709	Shuttle Tension Spring for 15099 and 15142, obsolete.....	20
15099	—	Shuttle Bobbin Case complete, Nos. 591F, 592E, 2523, 2975, 15003, 15027 and 15098, obsolete, use 15142.....	1 15
15100	709	Shuttle, 1½ in. diam., for 15-30, 15-41 and 15-50 Machines, Nos. 2515, 2996 and 15277.....	2 30
15102	1908	Feed Dog, three teeth at right of needle, square corner, for 15-30 and 15-50 Machines, obsolete.....	60
15103	1908	Throat Plate for 15102, obsolete.....	60
15138	1908	Feed Dog, three teeth at right of needle, rounded corner, for 15-43 Machine, obsolete.....	35
15139	1908	Throat Plate for 15138, obsolete.....	60
15140	709	Shuttle Bobbin Case Latch for 15141 .....	20
15141	—	" " " Hinge for 15142 and 15277, Nos. 2973, 2974 and 15140.....	35

NO.	PLATE	EACH	EACH
15142	709	Shuttle Bobbin Case complete for 15100, Nos. 591F, 592E, 2523, 2975, 15027, 15098 and 15141, obsolete, use 15277..	\$1 15
15147	700	Shuttle Race Slide complete for 15-30, 15-41 and 15-50 Machines, Nos. 2824, 15188 and two 50216J.....	50
15150	1909	Tension Releaser for 15151, obsolete....	25
15151	—	Face Plate complete, Nos. 248A, 413D, 1560B, 2814, 2826, 2827, 2829, 2830, 8238, 15150 and two 2102, obsolete...	2 40
15152	700	Clamp Stop Motion Flanged Bushing 2021 with two 462c, for 2019, obsolete.....	55
Nos. 15153 to 15155 FOR 15157 AND 15205, OBSOLETE			
15153	1902	Bobbin Winder Friction Ring (rubber)...	02
15154	1902	" " Pulley.....	25
15155	1905	Hand Attachment Body Bracket with 15156 and two 145F.....	1 15
*15156	—	Hand Attachment Body Bracket Cap (belt cover) for 15155, obsolete.....	—
15157	—	Hand Attachment complete with Bobbin Winder for 2008 for 15-30 Machine, Nos. 48B, 50B, 233B, 571C, 659D, 660D, 1528J, 2049, 2442, 2532, 2738 2745 2747, 2749, 2997, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15064, 15153 to 15155, 15159, 15403 and two each 92B, 183E and 399A, obsolete, use 15247...	7 20
15159	1902	Bobbin Winder Stop Latch for 15157, obsolete.....	25
*15160	—	Oscillating Shaft Crank for 15161.....	35
*15161	—	Oscillating Shaft Crank complete for 15-43 Machine, Nos. 462c, 1519E, 15160 and 15171.....	1 20
15162	1909	Oscillating Shaft Crank complete for 15-43 Machines, Nos. 1519E, 15171, 15425 and two 462c.....	1 20
*15163	—	Oscillating Shaft Crank for 15164.....	35
*15164	—	Oscillating Shaft Crank complete for 15-41 Machine, Nos. 462c, 1519E, 15163 and 15171.....	1 20
15165	1909	Oscillating Shaft Crank complete for 15-41 Machine, Nos. 1519E, 15171, 15426 and two 462c.....	1 20
15170	1909	Oscillating Shaft Crank Slide Block for 15171.....	55

## NUMERICAL LIST OF PARTS

89

NO.	PLATE	NAME	EACH
15171	1909	Oscillating Shaft Crank Slide Block complete for 15161, 15162, 15164 and 15165, Nos. 229D, 1035C, 12424 and 15170....	\$ 80
15172	1905	Bobbin Winder Bracket (belt cover) for 15173, obsolete.....	35
15173	—	Bobbin Winder for 15174, Nos. 24B, 48B, 2447, 2451, 2452, 2855 and 15172, obsolete.....	1 25
15174	—	Bobbin Winder (automatic) complete for 2008 for 15-22 and 15-43 Machines, Nos. 2839 and 15173, obsolete.....	1 50
15175	1905	Bobbin Winder Bracket (belt cover) for 15176, obsolete.....	35
15176	—	Bobbin Winder for 15177, Nos. 24B, 48B, 2447, 2452, 2851, 2855 and 15175, obsolete.....	1 25
15177	—	Bobbin Winder (automatic) complete for 2804 for 15-22 and 15-43 Machines, Nos. 2839 and 15176, obsolete .....	1 50
15178	1905	Bobbin Winder Bracket (belt cover) for 15179, obsolete.....	35
15179	—	Bobbin Winder (automatic) complete for 2804 for 15-30 and 15-41 Machines, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2745, 2747, 2749, 2997, 15064, 15178, 15403, 32557 and two 92B, obsolete.....	2 65
15180	1905	Bobbin Winder Bracket (belt cover) for 15181, obsolete.....	35
15181	—	Bobbin Winder (automatic) complete for 2008 for 15-30 and 15-41 Machines, Nos. 48B, 50B, 571C, 1528J, 2431, 2442, 2738, 2739, 2744, 2745, 2747, 2749, 2997, 15180, 15403 and two 92B, obsolete	2 65
15182	1909	Feed Forked Connection Slide Block for 15183.....	30
15183	—	Feed Forked Connection Slide Block complete for 15-41 and 15-43 Machines, Nos. 1085C and 15182.....	35
15188	—	Shuttle Race Slide for 15147.....	35
15205	—	Hand Attachment complete with Bobbin Winder for 2008 for 15-22 Machine, Nos. 48B, 92B, 233B, 659D, 660D, 2049, 2442, 2532, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 8436, 15053, 15056, 15153 to 15155, 15218, 15219 and two each 183E and 399A, obsolete.....	6 00

NO.	PLATE	NAME	EACH
15211	1965	Feed Dog (feeding surface same as 2506) 22 teeth (36 teeth to the inch) for 15-30, 15-41 and 15-50 Machines, obsolete....	\$ 60
15214	1962	Drip Pan (Trimmings for Portable Case)	25
15218	1902	Bobbin Winder Spindle with 15072, for 15205, obsolete.....	25
15219	1902	Bobbin Winder Stop Latch for 15205, obsolete.....	25
15226	1965	Feed Dog, for shirt work, beveled for hemmer, for 15-30 and 15-50 Machines, obsolete.....	60
15227	1965	Throat Plate for 15226, obsolete.....	60
15232	2915	Drip Pan (Trimmings for Drawing Room Cabinet).....	30
15236	4906	Presser Bar Lifter.....	30
15237	—	Tension Releasing Disc, obsolete, use 32572.....	07
15238	4906	Tension Releasing Pin for 15239 and 15471	01
15239	—	Face Plate complete, Nos. 248A, 1338D, 1560B, 2814, 2826, 2827, 2829, 2830, 8238, 15238, 32572 and two 2102, obsolete, use 55644.....	2 30
15240	1905	Hand Attachment Body Bracket with 15241 and two 145F, for 15247, obsolete	1 15
*15241	—	Hand Attachment Body Bracket Cap (belt cover) for 15240, obsolete.....	60
Nos. 15242 to 15246 FOR 15247, OBSOLETE			
15242	1905	Bobbin Winder Bracket.....	50
15243	1905	" " Frame.....	50
15244	4906	" " Spindle with 15072.....	30
15245	4906	" " Stop Latch.....	25
15246	4906	" " Thread Guide.....	20
15247	—	Hand Attachment complete with Bobbin Winder for 2008 for 15-30 Machine, Nos. 48B, 50B, 134D, 233B, 571C, 659D, 660D, 1528J, 2460, 2461, 2532, 2749, 8280, 8284 to 8286, 8313, 8377, 8392 to 8394, 15240, 15242 to 15246, 15296, 15403 and two each 92B, 183E, 399A and 2747, obsolete.....	7 50
*15248	1909	Needle Bar Connecting Link with 930E, for 15374.....	80
15249	4905	Feed Dog, three teeth at right of needle, square corner, for 15-30 and 15-50 Machines, obsolete.....	80
15250	4905	Throat Plate for 15249, obsolete.....	60

## NUMERICAL LIST OF PARTS

91

NO.	PLATE	NAME	EACH
15251	711	Machine Hinge Connection (oxidized) for 15253 and 15264, obsolete.....	\$ 20
15252	711	Machine Hinge Plate (oxidized) for 15253, obsolete.....	30
15253	711	Machine Hinge (oxidized) complete for Cabinet Table, Nos. 2809, 15251, 15252 and two oxidized wood screws $\frac{3}{4}$ in. No. 10, obsolete .....	50
15254	—	Machine Hinge Connection (brass) for 15256 and 15266, obsolete.....	20
15255	—	Machine Hinge Plate (brass) for 15256, obsolete.....	30
15256	—	Machine Hinge (brass) complete for Cabinet Table, Nos. 2809, 15254, 15255 and two brass wood screws $\frac{3}{4}$ in. No. 10, obsolete.....	50
15257	700	Presser Bar for 15-22, 15-30 and 15-50 Machines.....	50
15259	4907	Feed Cover Plate 15466 with 1423B, for art work, for 15-30 Machine, obsolete	60
15260	4907	Feed Cover Plate Position Stud for 15466, obsolete.....	07
15261	4907	Presser Bar Stop Collar with 237F, for art work, for 15-30 Machine, obsolete..	25
15262	4909	Presser Foot (rounded heel) for riding seams.....	50
15263	711	Machine Hinge Plate for 15264 and 56349	30
15264	711	Machine Hinge (oxidized) complete, Nos. 2809, 15251, 15263 and oxidized wood screw $\frac{7}{8}$ in. No. 10 (Trimmings for Cabinet Table and Open Side Drawing Room Cabinet) obsolete .....	50
15265	—	Machine Hinge Plate (brass) for 15266, obsolete.....	30
15266	—	Machine Hinge (brass) complete, Nos. 2809, 15254, 15265 and brass wood screw $\frac{7}{8}$ in. No. 10 (Trimmings for Cabinet Table and Open Side Drawing Room Cabinet) obsolete.....	50
15271	701	Thread Take-up Cam with 1293c, for 15-22 Machine.....	80
15272	4910	Thread Take-up Cam with 1293c, for 15-30 and 15-50 Machines.....	80
15273	4910	Thread Take-up Cam with 1293c, for 15-43 Machine.....	1 50
15275	4910	Thread Take-up Cam with 1293c, for 15-41 Machine.....	1 50

## NUMERICAL LIST OF PARTS

NO.	PLATE	NAME	EACH
15277	709	Shuttle Bobbin Case complete for 15100, Nos. 591F, 592E, 2523, 2975, 15027, 15141, 15278 and 62739.....	\$1 15
15278	709	Shuttle Tension Spring for 15277.....	20
15279	4905	Feed Dog, 12 teeth (14 teeth to the inch) three teeth at right of needle, square corner, for 15-30 and 15-50 Machines	80
15280	—	Throat Plate, medium needle hole, for 15279 and 15304.....	60
15281	4909	Presser Foot.....	35
15282	699	Balance Wheel, 2½ in. pulley.....	1 50
15283	6313	Bobbin Winder Adjusting Arm for 15294 and 15303, obsolete.....	25
15284	6312	Bobbin Winder Bracket (belt cover) for 15294, 15303, 15417 and 15419.....	35
15285	6313	Bobbin Winder Frame for 15303 and 15473, obsolete.....	35
15286	6313	Bobbin Winder Frame Spring for 15294, 15303, 15417 and 15419.....	02
15287	6313	Bobbin Winder Friction Ring (rubber) for 15294, 15303, 15417 and 15419....	02
15288	6313	Bobbin Winder Pulley for 15303, 15417, 15419 and 15473.....	07
15289	4913	Bobbin Winder Spindle with 15072, for 15419 and 15473.....	25
15290	4913	Bobbin Winder Stop Latch for 15294, obsolete.....	25
15291	6313	Bobbin Winder Stop Latch Spring for 15294, 15303, 15417 and 15419.....	01
15292	711	Bobbin Winder Thread Guide for 15293, obsolete.....	20
15293	6313	Bobbin Winder Thread Guide Spring for 15292 and 15302, obsolete.....	01
15294	4913	Bobbin Winder (automatic) complete for 15282 for 15-30, 15-41 and 15-50 Ma- chines, Nos. 50B, 1528J, 2749, 15284. 15286, 15287, 15291, 15364, 15366, 15376, 15377, 15403, 15473, 50058B, 50059B, 50061B and 50230B, obsolete, use 15419.....	2 65
15295	1902	Hand Attachment Crank Lever for 15296, obsolete.....	30
15296	1902	Hand Attachment Crank complete for 15247, Nos. 8380, 8434 and 15295, obsolete.....	55
15297	699	Feed Rock Shaft.....	80

## NUMERICAL LIST OF PARTS

93

NO.	PLATE	NAME	EACH
15298	4905	Feed Dog (feeding surface same as 15279) for 15-22 Machine, obsolete.....	\$ 35
15299	4905	Throat Plate for 15298, obsolete.....	60
15300	4914	Bobbin Winder Spindle with 15072, for 15303 and 15417.....	25
15301	4914	Bobbin Winder Stop Latch for 15303, obsolete.....	25
15302	4906	Bobbin Winder Thread Guide for 15293, obsolete.....	20
15303	4914	Bobbin Winder (automatic) complete for 15282 for 15-22 and 15-43 Machines, Nos. 50B, 571C, 1528J, 2749, 15284 to 15288, 15291, 15300, 15365, 15366, 15376, 15378, 15403, 50058B, 50059B, 50061B and 50230B, obsolete, use 15417	2 65
15304	4905	Feed Dog, 15 teeth (18 teeth to the inch) three teeth at right of needle, square corner, for 15-30 and 15-50 Machines	80
15305	—	Arm Shaft for 2019 and 15306, for 15271 for 15-22 Machine, for 15272 for 15-30 Machine, for 15275 for 15-41 Machine and for 15273 for 15-43 Machine, obsolete	1 50
15306	1902	Feed Cam with 1285C.....	35
15311	699	Arm Shaft for 15318 for 15306 and 15314, for 15271 for 15-22 Machine, for 15272 for 15-30 and 15-50 Machines, for 15275 for 15-41 Machine and for 15273 for 15-43 Machine, obsolete .....	1 50
*15312	—	Clamp Stop Motion Flanged Bushing for 15313.....	55
15313	1902	Clamp Stop Motion Flanged Bushing 15312 with two 462C, for 15314.....	55
15314	—	Clamp Stop Motion complete, Nos. 248A, 256B, 2020 and 15313.....	1 15
15316	4905	Throat Plate, large needle hole, for 15279 and 15304.....	60
15317	—	Throat Plate, small needle hole, for 15279 and 15304.....	60
*15318	—	Arm with 450C, 2006 and 2803, obsolete, use 15496.....	6 00
15319	699	Feed Forked Connection with 175J.....	85
15359	4912	" Cover Plate for 15-30 and 15-50 Machines.....	20
15364	4913	Bobbin Winder Thread Guide for 15294, obsolete.....	20
15365	4914	Bobbin Winder Thread Guide for 15303, obsolete.....	20

## NUMERICAL LIST OF PARTS

NO.	PLATE	NAME	EACH
15366	6313	Bobbin Winder Thread Guide Spring for 15294, 15303, 15417 and 15419.....	\$ 02
15367	702	Bobbin Winder Spool Stand Thread Retaining Disc Spring for 2839, obsolete	05
15374	—	Needle Bar Connecting Link 15248 with 2052.....	1 15
15376	4920	Bobbin Winder Adjusting Arm for 15294, 15303, 15417 and 15419.....	25
15377	4920	Bobbin Winder Stop Latch for 15294 and 15419.....	25
15378	4920	Bobbin Winder Stop Latch for 15303 and 15417.....	25
15395	4918	Tension Thread Guard for 15428.....	05
15403	—	Bobbin Winder Worm Wheel 2748 with 233B and 2746, for 2850, 2962, 15020, 15085, 15157, 15179, 15181, 15247, 15294 and 15303, obsolete.....	30
*15406	—	Face Plate for 15407.....	90
*15407	—	" " 15406 with 15428, for 15432..	1 25
15408	—	" " Tension Seat for 15428.....	30
15410	4918	Tension Stud Bushing for 15432.....	20
15412	4918	Thread Take-up Spring Regulator for 15432.....	35
15413	4920	Bobbin Winder Frame for 15417 and 15419.....	35
15414	4920	Bobbin Winder Pulley for 15417 and 15419, obsolete, use 15288.....	10
15415	4920	Bobbin Winder Thread Guide for 15417..	20
15416	4920	" " Worm Wheel and Thread Guide Cam for 15417 and 15419.....	25
15417	—	Bobbin Winder (automatic) complete for 15282 for 15-22 and 15-43 Machines, Nos. 50B, 571C, 1528J, 2749, 15284, 15286 to 15288, 15291, 15300, 15366, 15376, 15378, 15413, 15415, 15416, 50058B, 50059B, 50061B and 50230B..	2 75
15418	4920	Bobbin Winder Thread Guide for 15419	20
15419	4921	Bobbin Winder (automatic) complete for 15282 for 15-30, 15-41 and 15-50 Machines, Nos. 50B, 571C, 1528J, 2749, 15284, 15286 to 15289, 15291, 15366, 15376, 15377, 15413, 15416, 15418, 50058B, 50059B, 50061B and 50230B..	2 65
15420	—	Shuttle Race Body 2530 with 2535 and two 662B, for 2528.....	1 45

## NUMERICAL LIST OF PARTS

95

NO.	PLATE	NAME	EACH
15424	4920	Bobbin Winder Worm Wheel and Thread Guide Cam Friction Washer for 15417 and 15419, obsolete.....	\$ 01
15425	—	Oscillating Shaft Crank for 15162.....	35
15426	—	“ “ “ 15165.....	35
15427	4917	Arm Side Cover.....	25
15428	—	Face Plate Tension Seat 15408 with 15395, for 15407.....	35
15429	4922	Presser Foot, for stitching on edge and inserting cord, for 15-30 Machine.....	80
15432	4917	Face Plate 15407 with 857B, 2827, 15410, 15412 and 50292B, for 55644.....	1 85
15466	—	Feed Cover Plate with 15260, for 15259, obsolete.....	55
15471	—	Tension complete for 55644, Nos. 1560B, 13710, 15238, 32572, 50291J, 55645 and two 2102 .....	55
15473	—	Bobbin Winder Frame 15285 with 571c, 15288 and 15289, for 15294, obsolete	85
15486	4923	Presser Bar Lifter Hinge Stud for 15496..	25
*15491	4917	Thread Take-up Lever with 1822, for 15492.....	80
15492	—	Thread Take-up Lever 15491 with 50527c, for 15-30, 15-41 and 15-50 Machines	90
*15493	4917	Thread Take-up Lever with 1822, for 15494.....	80
15494	—	Thread Take-up Lever 15493 with 50527c, for 15-22 and 15-43 Machines.....	90
*15495	—	Arm for 15496.....	6 00
15496	—	“ 15495 with 435c, 448c, 15486 and 15498.....	6 70
15497	4917	Arm Shaft.....	1 50
15498	4917	“ “ Bushing for 15496.....	35
15514	6317	Apron Spring (Trimmings for Open-Side Drawing Room Cabinet) obsolete....	07
19044	2929	Tuck Folder Screw Stud Cap Screw Spring Washer for 36091.....	02
22232	1018	Embroidery Attachment Driving Lever Friction Washer for 26538.....	01
22232	1018	Embroidery Attachment Scroll Carrier Friction Washer for 26538 .....	01
22232	4907	Presser Foot Friction Washer for 35602, obsolete.....	01
22436R	4924	Machine Button Thumb Screw Washer for 124389.....	01
25027	1909	Belt Hook for 25135, 25488, 28007 and 82680.....	01

NO.	PLATE	NAME	EACH
25033	1909	Belt Shifter Spring for 25049, 28011, 46634 and 124334.....	\$ .02
25047	699	Skeleton Drawer Case Drawer Spring (Trimmings for Cabinet Table and Cover Set).....	.02
25049	6321	Dress Guard complete for 82953 and Trimmings for Open-Side Drawing Room Cabinet, Nos. 34R, 25033, 46525 and 46526.....	.65
25056	6430	End Leaf Support (Trimmings for Cover Set).....	.20
25058	6430	End Leaf Support Bracket, $4\frac{7}{8}$ in. be- tween screw holes, with three wood screws $\frac{3}{4}$ in. No. 7 (Trimmings for Cover Set) obsolete.....	.20
25068	699	Leg Roller for 25444.....	.07
25069	699	" " Pin for 25444.....	.01
25070	703	Machine Cushion Tack, rubber (Trim- mings for Cabinet Table) .....	.01
25070	703	Base Cushion Tack, rubber (Trim- mings for Portable Case) .....	.01
25086	6321	Wrench for 1507, 1510 and 1670, for 25281, 82953 and Trimmings for Draw- ing Room Cabinet and Open-Side Drawing Room Cabinet .....	.20
25135	—	Belt, size $\frac{3}{16}$ in., length $67\frac{1}{2}$ in., with 25027 (Trimmings for Open-Side Drawing Room Cabinet).....	.30
25152	1909	Machine Cushion, felt (Trimmings for Cabinet Table, Drawing Room Cabinet and Open-Side Drawing Room Cabinet)	.01
25200	6321	Wrench for 972, for 25281, 82953 and Trimmings for Drawing Room Cabinet and Open-Side Drawing Room Cabinet	.20
25281	—	Stand (iron work) rocking treadle, ball bearing pitman, cover set complete, Nos. 1059R, 1288R, 25086, 25200, 25406, 25442, 46511, 46631, 46632, 46634, two 25444 and four 748R.....	—
*25360	—	Pitman Rod Ball for 28247, 28267 and 46510.....	.20
25361	3826	Pitman Rod Ball Screw Bearing for 46630	.20
25362	3826	" Ball, size $\frac{3}{16}$ in., for 28248, 28260 and 46624..... per 100	1 .20
25371	3826	Pitman Rod Ball Bushing for 28248, 28260 and 46624.....	.25

## NUMERICAL LIST OF PARTS

97

NO.	PLATE	NAME	EACH
25406	6321	Treadle for 25281, 82953 and Trimmings for Open-Side Drawing Room Cabinet	\$ .95
25439	6321	Belt Guide for 82953, obsolete.....	10
25442	6321	Band Wheel, 12½ in. diam., with 972c, for 25281, 82953 and Trimmings for Open-Side Drawing Room Cabinet.....	1 .40
25444	6321	Leg with two each 25068 and 25069, for 25281 and 82953.....	2 .70
25488	—	Belt, size $\frac{3}{16}$ in., length 66½ in. with 25027, for 82953 .....	30
25510	5647	Braider.....	30
25515	5647	Quilter complete, Nos. 85301 and 85302	.07
25525	5635	Bias Gauge.....	.20
25527B	5635	Cloth Guide for 120306 and 120309.....	.20
25537	5635	Screw Driver (machine) for 120306 and 120309.....	.20
25538	5635	Screw Driver (shuttle tension) for 120306 and 120309.....	.07
25539	5635	Stiletto for 35985.....	.07
25623	—	Attachment Set complete for 15-50 Machine, Nos. 35463 and 120306.....	6 .00

## Nos. 25626 to 25629 FOR 120306

25626	5650	Hemmer, $\frac{3}{16}$ in. hem.....	.20
25627	5650	" $\frac{1}{4}$ in. hem.....	.20
25628	5650	" $\frac{3}{8}$ in. hem.....	.20
25629	5650	" $\frac{5}{8}$ in. hem.....	.20
25632	5649	Ruffler Shirring Plate for 26155.....	.20
25636	5649	Under Braider.....	.25
25637	5647	" " Foot.....	.25
25789	1950	Corder Bow Tip for 26399.....	.35
25794	1950	Presser Foot for 26399.....	1 .15
25883	4909	Hemmer (foot) $\frac{5}{8}$ in. hem, obsolete, use 35996.....	.50
25888	4909	Hemmer Tongue.....	.01
25895	—	" (foot) $\frac{1}{8}$ in. hem, for shirt work, for 2040 and 2506.....	.60
25904	—	Hemmer (foot) $\frac{1}{16}$ in. hem, for silk ties, for 2040 and 2506.....	.60
26075	704	Thread Cutter and Holder.....	.07
26152	4909	Hemmer (foot) $\frac{1}{8}$ in. hem, obsolete, use 35857.....	.55
26155	—	Ruffler 35463 with 25632.....	1 .15
26319	5650	Binder for 120306.....	.25
26398	1950	Corder Bow for 26399.....	—
26399	1950	Corder (bow) complete, for top cording, Nos. 4604, 25789, 25794 and 26398...	3 .35

NO.	PLATE	NAME	EACH
26521	1018	Embroidery Attachment Driving Lever with 26536, for 26538.....	\$ 35
26523	1018	Embroidery Attachment Driving Lever Washer for 26538.....	.01
26524	1004	Embroidery Attachment Frame with 26525, for 26538.....	.80
26525	1004	Embroidery Attachment Frame Block for 26524.....	.07
26527	1018	Embroidery Attachment Looper for 26538	.55
26528	1018	" " Scroll with 468c, for 26538.....	.35
26529	1018	Embroidery Attachment Scroll Carrier with 26531, for 26538.....	.20
26530	1018	Embroidery Attachment Scroll Carrier Hinge Stud for 26538.....	.05
26531	1018	Embroidery Attachment Scroll Carrier Pin for 26529.....	.01
26532	1018	Embroidery Attachment Scroll Cover for 26538.....	.20
26533	1018	Embroidery Attachment Scroll Driving Lever with 26534, for 26538.....	.25
26534	1018	Embroidery Attachment Scroll Driving Lever Stud for 26533.....	.05
26535	1004	Embroidery Attachment Spool Pin, for arm of machine, for 26538.....	.07
26536	1018	Embroidery Attachment Thread Bracket for 26521.....	.05
26537	1018	Embroidery Attachment Thread Eyelet for 26538.....	.01
26538	1004	Embroidery Attachment complete, for one thread, Nos. 240D, 26521, 26523, 26524, 26527 to 26530, 26532, 26533, 26535, 26537, 26784, 26785 and two 22232.....	3.00
26784	1018	Embroidery Attachment Driving Lever Hinge Stud for 26538.....	.07
26785	1018	Embroidery Attachment Thread Retaining Spring for 26538.....	.20
28005	2915	Band Wheel Bracket with 302C and 1507R (Trimmings for Drawing Room Cabinet).....	.90
28007	—	Belt, size $\frac{3}{16}$ in., length 65 $\frac{1}{2}$ in., with 25027 (Trimmings for Drawing Room Cabinet).....	.30
28011	2915	Belt Guide with 34R, 25033 and 28015 (Trimmings for Drawing Room Cabinet) obsolete.....	.50

## NUMERICAL LIST OF PARTS

99

NO.	PLATE	NAME	EACH
28012	2917	Belt Guide Screw Eye (Trimmings for Drawing Room Cabinet).....	\$ 01
28015	712	Belt Shifter for 28011, obsolete.....	07
		Nos. 28016 to 28018 FOR 28019	
28016	712	Cabinet Case Roller (iron).....	06
28017	712	“ “ “ Frame.....	20
28018	711	“ “ “ Pin.....	01
28019	712	Cabinet Case Roller complete, Nos. 28016 to 28018 (Trimmings for Drawing Room Cabinet and Open-Side Drawing Room Cabinet) .....	25
28020	2915	Drawer Lock Bolt (Trimmings for Drawing Room Cabinet) obsolete.....	60
28021	712	Drawer Lock Bolt Cam and Plate (Trimmings for Drawing Room Cabinet) obsolete.....	55
28029	712	Latch for 28037, obsolete.....	10
28030	712	“ Button (brass) for 28037, obsolete.	25
28032	703	“ “ Hinge Pin for 28037, obsolete.....	01
28033	712	Latch Frame for 28037, obsolete.....	25
28034	711	“ Hinge Pin for 28037 and 56326, obsolete.....	01
28037	712	Latch (brass) complete, Nos. 5604, 28029, 28030, 28032 to 28034 and 28200 (Trimmings for Drawing Room Cabinet) obsolete.....	60
28041	2915	Rocking Frame 56255 with 434c and 28048 (Trimmings for Drawing Room Cabinet) obsolete.....	1 85
28042	2915	Rocking Frame Bracket (Trimmings for Drawing Room Cabinet) obsolete....	25
28043	2915	Rocking Frame Connecting Link for 56255, obsolete.....	06
28044	712	Rocking Frame Connecting Link Bracket (Trimmings for Drawing Room Cabinet) obsolete.....	06
28045	2917	Rocking Frame Connecting Link Hinge Stud for 56255, obsolete.....	06
28046	2915	Rocking Frame Hinge Plate (Trimmings for Drawing Room Cabinet) obsolete	20
28047	2915	Rocking Frame Spring (Trimmings for Drawing Room Cabinet) obsolete....	1 15
28048	2915	Rocking Frame Spring Adjusting Block for 28041, obsolete.....	35

NO.	PLATE	NAME	EACH
28049	711	Rocking Frame Spring Adjusting Block Pin, obsolete.....	\$ 02
28076	2917	Centre Drawer Lock Escutcheon (Trimmings for Cabinet Table).....	02
28076	2917	Cover Lock Escutcheon (Trimmings for Cover Set and Portable Case).....	02
28076	2917	Door (left) Lock Escutcheon (Trimmings for Drawing Room Cabinet).....	02
28076	2917	Partition Lock Escutcheon (Trimmings for Cover Set and Cabinet Table)....	02
28079	712	End Leaf Hinge (Trimmings for Cover Set).....	05
28088	6413	Handle (wood) for 87550, 124309 and 124311.....	07
28123	711	Machine Lifting Plate Hinge Pin for 56319, 56452, 124321, 124382 and 124385.....	05
28125	712	Shield Supporting Bracket (Trimmings for Cabinet Table).....	07
28126	4906	Belt Hole Bushing (oval, brass) $\frac{5}{8}$ in. x 1 in. (Trimmings for Drawing Room Cabinet) obsolete.....	07
28200	711	Latch Spring for 28037 and 56326, obsolete	07
28205	2915	Band Wheel with 972c (Trimmings for Drawing Room Cabinet).....	1 20
28206	2915	Band Wheel Crank for 28248.....	30
28208	2915	Treadle (Trimmings for Drawing Room Cabinet).....	1 80
28210	2917	Attachment Tray Pull, leather (Trimmings for Drawing Room Cabinet)....	02
28211	2917	Attachment Tray Pull Washer (Trimmings for Drawing Room Cabinet)...	02
28221	6316	Knob (oxidized) for 28223, obsolete.....	25
28223	—	Knob (oxidized) complete, Nos. 1272E and 28221 (Trimmings for Cabinet Table and Drawing Room Cabinet) obsolete.....	30
28227	—	Knob (brass) for 28228, obsolete.....	25
28228	—	Knob (brass) complete, Nos. 1272E and 28227 (Trimmings for Cabinet Table and Drawing Room Cabinet) obsolete	30
28229	6413	Handle Hinge Rivet for 87550, 124308 and 124310.....	01
28231	6413	Handle Stud for 87550, 124309 and 124311	10
28233	712	Centre Drawer Lock Key (Trimmings for Cabinet Table).....	07

## NUMERICAL LIST OF PARTS

101

NO.	PLATE	NAME	EACH
28233	712	Cover Lock Key (Trimmings for Cover Set and Portable Case).....	\$ 07
28233	712	Door (left) Lock Key (Trimmings for Drawing Room Cabinet).....	07
28233	712	Partition Lock Key (Trimmings for Cover Set and Cabinet Table).....	07
28234	712	Hinge, round ends, for top leaf (Trimmings for Cabinet Table, Drawing Room Cabinet and Open-Side Drawing Room Cabinet).....	25
28235	712	Hinge, round end, for machine platform flap (Trimmings for Cabinet Table, Drawing Room Cabinet and Open-Side Drawing Room Cabinet) .....	20
28242	6413	Machine Rest Cushion (leather) with 5604 (Trimmings for Cover Set and Portable Case).....	01
28247	2915	Pitman Rod with 25360, for 28248.....	25
28248	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 28206, 28247, 46506 to 46509, 46655, 56317 and six 25362 (Trimmings for Drawing Room Cabinet).....	2 15
28250	—	Belt Hole Bushing (oval, oxidized) $\frac{5}{8}$ in. x 1 in. (Trimmings for Drawing Room Cabinet) obsolete.....	07
28253	712	Hinge, 1 in. x $1\frac{5}{16}$ in., for doors (Trimmings for Drawing Room Cabinet).....	07
Nos. 28260 to 28263 (TRIMMINGS FOR OPEN-SIDE DRAWING ROOM CABINET)			
28260	—	Band Wheel Crank and Pitman (ball bearing) complete, Nos. 1520R, 25371, 28267, 46506 to 46509, 46515, 46655, 56317 and six 25362.....	2 15
28261	6322	Band Wheel Crank Frame with two 46629, obsolete.....	2 30
28262	6322	Band Wheel Crank Frame Bracket with 28263.....	80
28263	6317	Band Wheel Crank Frame Bracket Cushion (leather) for 28262.....	01
Nos. 28266 to 28269 (TRIMMINGS FOR OPEN-SIDE DRAWING ROOM CABINET)			
28266	4910	Belt Guide.....	20
28267	6322	Pitman Rod with 25360, for 28260.....	25
28268	4270	Treadle Centre for 28269 and 56450.....	07
28269	4910	" " Bracket with 28268, obsolete.....	25

NO.	PLATE	NAME	EACH
Nos. 28277 to 28281 (TRIMMINGS FOR OPEN-SIDE DRAWING ROOM CABINET)			
28277	6317	Apron Spring Screw Eye, obsolete.....	\$ 02
28278	—	Door Drawer Lock Plate (brass).....	07
28279	4270	" " " " (oxidized).....	07
28280	—	" " " " Hub Key (brass).....	25
28281	4270	" " " " " (oxidized).....	25
28283	4270	" Hinge (Trimmings for Open-Side Drawing Room Cabinet).....	30
28284	4270	Door Lock with four round head wood screws $\frac{3}{4}$ in. No. 4 (Trimmings for Open-Side Drawing Room Cabinet)....	25
28286	4270	Door Lock Key (Trimmings for Open-Side Drawing Room Cabinet).....	07
28288	4270	Door Lock Key Hole Escutcheon with two round head wood screws $\frac{3}{8}$ in. No. 2 (Trimmings for Open-Side Drawing Room Cabinet).....	07
28290	4270	Top Leaf Support Cushion, rubber (Trimmings for Open-Side Drawing Room Cabinet).....	02
28291	4924	Hinge for Shield (Trimmings for Drawing Room Cabinet).....	07
28297	6316	Cover Hook Cup Catch, nickeled (Trimmings for Cover Set).....	07
28297	6316	Cover Lock Cup Catch, nickeled (Trimmings for Cover Set).....	07
28831	4922	Presser Foot, for darning, for 15-30 Machine.....	60
28915	4909	Hemstitcher.....	80
32557	708	Bobbin Winder Pulley for 2859, 15020 and 15179, obsolete.....	20
32572	4906	Tension Releasing Disc for 15239 and 15471.....	07
33642	1902	Hand Attachment Driver for 33650, obsolete.....	30
33643	—	Hand Attachment Driver Finger for 94007	20
33646	—	Hand Attachment complete for 15282, Nos. 137B, 659D, 660D, 8280, 8377, 8392, 8393, 8436, 33647, 33650 and two each 183E and 399A, obsolete.....	3 80
33647	4915	Hand Attachment Body Bracket for 33646, 94001 and 94018.....	25
33650	—	Hand Attachment Driver 33642 with 2532, 8386 to 8388, 8394 and 94007, for 33646, obsolete.....	1 30

## NUMERICAL LIST OF PARTS

103

NO.	PLATE	NAME	EACH
35463	5647	Ruffler for 25623 and 26155.....	\$ .95
Nos. 35483 to 35495 FOR 35496			
35483	933	Embroidery Attachment Body.....	.55
35484	933	“ “ “ Block.....	.30
35485	935	“ “ Driving Lever	.30
35486	935	“ “ “ “	
		Arm (lower).....	.20
35487	935	Embroidery Attachment Driving Lever Arm (upper).....	.20
35488	933	Embroidery Attachment Driving Lever Arm Guide.....	.20
35489	935	Embroidery Attachment Driving Lever Arm Hinge Stud.....	.07
35490	935	Embroidery Attachment Driving Lever Arm Spring.....	.07
35491	935	Embroidery Attachment Driving Lever Hinge Stud.....	.20
35492	935	Embroidery Attachment Thread Carrier (left).....	.35
35493	935	Embroidery Attachment Thread Carrier (left) Hinge Stud.....	.07
35494	935	Embroidery Attachment Thread Carrier (right).....	.35
35495	935	Embroidery Attachment Thread Carrier Friction Plate.....	.07
35496	933	Embroidery Attachment for 35505, Nos. 190B, 12152, 35483 to 35488, 35490 to 35495, 35498, 50139B and two 35489..	3 .00
35497	936	Embroidery Attachment Spool Bracket for 35504.....	.20
35498	936	Embroidery Attachment Spool Bracket Stud for 35496.....	.07
35499	936	Embroidery Attachment Spool Bracket Tension Spring for 35504.....	.07
35500	936	Embroidery Attachment Spool Bracket Tension Spring Position Pin for 35504	.05
35500	936	Embroidery Attachment Spool Bracket Thread Guide Pin for 35504.....	.05
35501	936	Embroidery Attachment Spool Bracket Wire for 35504.....	.07
35502	936	Embroidery Attachment Spool Bracket Wire Hinge Stud for 35504.....	.07
35503	936	Embroidery Attachment Spool Bracket Wire Hinge Stud Washer for 35504....	.07

NO.	PLATE	NAME	EACH
35504	936	Embroidery Attachment Spool Bracket complete for 35505, Nos. 1422B, 35497, 35499, 35502, 35503 and two each 35500 and 35501.....	\$ 80
35505	—	Embroidery Attachment complete, for two threads, Nos. 35496 and 35504.....	3 80
35600	4907	Presser Foot for 35602, obsolete.....	80
35601	4907	“ “ Body for 35602, obsolete....	35
35602	4907	Presser Foot complete, for etching, for 15259 for 15-30 Machine, Nos. 190B, 1292B, 22232, 35600 and 35601, obsolete	1 15
35857	4909	Hemmer (foot) $\frac{1}{8}$ in. hem.....	55
35884	4919	“ “ $\frac{3}{16}$ in. hem .....	55
35918	—	Attachment Set complete for 15-30 and 15-41 Machines, Nos. 120290 and 120309.....	7 50
35931	5636	Hemmer (adjustable) for 120309.....	1 50
35932	5636	Quilter.....	50
35938	5638	Ruffler Shirring Plate for 120292.....	25
35940	5638	Under Braider.....	30
35983	4922	Strip Wire for 35985.....	20
35984	4922	Presser Foot (strip folding) with tube, for 35985.....	4 25
35985	—	Tubular Trimming Attachment complete, for making $\frac{3}{32}$ in., $\frac{1}{8}$ in. and $\frac{5}{32}$ in. trimmings, Nos. 25539, 35983 and 35984	4 50
35996	4909	Hemmer (foot) $\frac{5}{64}$ in. hem .....	50
36055	4922	Presser Foot with 665B and 36056, for blind stitch braiding, for soutache braid, for 15-30 Machine.....	2 30
36056	4922	Presser Foot Braid Guide for 36055.....	80
36058	4919	“ “ with 665B and 36059, for blind stitch cording, to turn small curves, for 15-30 Machine.....	3 80
36059	4919	Presser Foot Cord Guide for 36058 .....	80
36067	4919	“ “ for braiding, for art work, for braid $\frac{1}{16}$ in. to $\frac{3}{16}$ in. wide, for 15-30 Machine.....	90
36090	2928	Tuck Folder Arm with 50068E, for 36091	1 15
36091	2928	Tuck Folder complete, for small pieces of goods, for 15-30 Machine, Nos. 171A, 1704B, 1705B, 19044, 36090, 50066E, 50067D, 202600, 202603B, 225923, 225926 and two 1483H.....	2 30
36092	4919	Presser Foot for 36091.....	35
36333	4919	Hemmer (foot) $\frac{1}{16}$ in. hem, for chiffon and silk.....	3 35

## NUMERICAL LIST OF PARTS

105

NO.	PLATE	NAME	EACH
36469	—	Hemmer (foot) for chiffon and silk, slotted for lace.....	\$3 35
36569	4910	Oiler with 36571, for 36570.....	10
36570	—	" 36569, filled with oil (Accessories) ..	20
36571	4910	" Spout, 1 3/4 in. long, with 36807, for 36569.....	06
36583	5637	Tucker for 120306 and 120309.....	1 50
36594	5636	Binder for 120309.....	80
36658	4922	Darning Foot Spring Rivet for 86294 .....	80
		per 100	
36807	6317	Oiler Spout Washer (leather) for 36571...	01
36835	4922	Feller (foot).....	35
36865	4919	Edge Stitcher.....	80
*44001	—	Shuttle Cover 2075 with 112D, 466H, 2078, 2080, 2086 and 2090, for 2208 .....	85
Nos. 46506 to 46509 FOR 28248, 28260 AND 46624			
46506	3826	Pitman Ball Bearing Adjusting Screw Ring	25
46507	3826	" " " " "	
		Locking Washer (brass)..... per 100	35
46508	3826	Pitman Ball Bearing Ring.....	20
46509	3826	" " Case.....	35
46510	6321	" Rod with 25360, for 46624.....	25
46511	—	Band Wheel Crank and Pitman (ball bearing) complete for 25281 and 82953, Nos. 46624 and 46630 .....	2 15
46515	6321	Band Wheel Crank for 28260 and 46624..	25
46525	699	Belt Shifter for 25049, 46634 and 124334	07
46526	—	Dress Guard for 25049.....	55
46612	699	Skeleton Drawer Case Support with two wood screws 1/2 in. No. 7 R. H. B. (Trimmings for Cabinet Table and Cover Set).....	05
46624	—	Band Wheel Crank and Pitman (ball bearing) complete for 46511, Nos. 1520R, 25371, 46506 to 46510, 46515, 46655 and six 25362.....	2 00
46629	—	Band Wheel Crank Screw Centre 297C, with 1507R, for 28261, 46632, 46639, 56446 and 82896.....	25
46629	—	Treadle Screw Centre 297C with 1507R, for 28261, 46632, 46638, 46639, 56252, 56446 and 82896.....	25
46630	—	Pitman Rod Ball Screw Bearing 25361 with 1670E, for 46511.....	25
46631	4925	Belt Guide for 25281.....	10
46632	6430	Brace with three 46629, for 25281 .....	2 15

NO.	PLATE	NAME	EACH
46633	—	Dress Guard for 46634.....	\$ .50
46634	6430	Dress Guard complete for 25281, Nos. 34R, 25033, 46525 and 46633.....	.65
46638	6430	Brace Section (left) with 46629, for 46640	.85
46639	6430	" " (right) with two 46629, for 46640.....	1.55
46640	6430	Brace (sectional) complete for 25281, Nos. 46638, 46639 and three 138E.....	2.65
46655	3826	Pitman Ball Separator for 28248, 28260 and 46624.....	.07
46671	4925	End Leaf Support Bracket, 4½ in. between screw holes, with three wood screws ¾ in. No. 7 (Trimmings for Cover Set).....	.20
50058B	6313	Bobbin Winder Adjusting Arm Screw for 15294, 15303, 15417 and 15419.....	.05
50059B	6313	Bobbin Winder Frame Hinge Screw for 15294, 15303, 15417 and 15419.....	.20
50060B	6313	Bobbin Winder Stop Latch Hinge Screw for 15294 and 15303, obsolete.....	.10
50061B	6313	Bobbin Winder Thread Guide Hinge Screw for 15294, 15303, 15417 and 15419....	.10
50066E	2929	Tuck Folder Screw Stud for 36091.....	.25
50067D	2929	" " " CapScrew for 36091	.06
50068E	2929	" " Space Gauge Screw Stud for 36090.....	.02
50139B	935	Embroidery Attachment Thread Carrier (right) Hinge Screw for 35496.....	.06
50216J	704	Shuttle Race Slide Spring Screw for 2995 and 15147.....	.02
50230B	6313	Bobbin Winder Stop Latch Hinge Screw for 15294, 15303, 15417 and 15419:...	.07
50251E	6317	Counterbalance Spring Adjusting Collar Bolt with 1734E, for 56264, 56453, 124322, 124383 and 124386.....	.05
50289B	6413	Handle Bolt for 87550, obsolete.....	.10
50291J	4918	Tension Stud for 15471.....	.20
50292B	4918	" " Set Screw for 15432.....	.02
50353E	4918	Feed Regulator Hinge Screw.....	.10
50380C	6317	Machine Hinge Connection Set Screw....	.05
50527C	4923	Thread Take-up Lever Hinge Screw for 15492 and 15494.....	.10
50549B	4923	Handle Bolt for 124308.....	.10
50550B	4923	" " " 124310.....	.10
50574C	4923	Treadle Screw Centre for 124332.....	.20
55644	—	Face Plate complete, Nos. 15432 and 15471	2.50
55645	4918	Thread Take-up Spring for 15471.....	.05

## NUMERICAL LIST OF PARTS

107

NO.	PLATE	NAME	EACH
56251	6316	Cover Lock (Trimmings for Cover Set and Portable Case).....	\$ 20
56252	2915	Treadle Screw Centre Bracket with 46629 (Trimmings for Drawing Room Cabinet) obsolete.....	50
56253	2917	Pitman Rod Ball Screw Bearing for 56317	20
56254	4270	Door Lock Plate (Trimmings for Open-Side Drawing Room Cabinet) .....	06
*56255	—	Rocking Frame 56257 with two each 28043 and 28045, for 28041, obsolete.....	1 45
*56257	—	Rocking Frame for 56255, obsolete.....	1 20
56258	6317	Centre Drawer Stop Pin (Trimmings for Cabinet Table) obsolete.....	02
56260	6321	Counterbalance Spring for 56264, 56453, 124322, 124383 and 124386.....	35
56261	6321	Counterbalance Spring Adjusting Collar for 56264, 56453, 124322, 124383 and 124386.....	25
56262	6321	Counterbalance Spring Bracket (hinge) for 56319, 56452, 124321, 124382 and 124385.....	50
56263	6321	Machine Lifting Plate for 56319.....	60
56264	6321	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 56319 (Trimmings for Cabinet Table).....	1 80
56317	—	Pitman Rod Ball Screw Bearing 56253 with 1670E, for 28248 and 28260.....	25
56319	—	Machine Lifting Plate 56263 with 28123 and 56262, for 56264.....	1 15
Nos. 56323 to 56325 FOR 56326, OBSOLETE			
56323	6429	Latch.....	20
56324	6429	" Button.....	25
56325	6429	" Frame.....	25
56326	6429	Latch complete, Nos. 5604, 28034, 28200, 56323 to 56325 and 56438 (Trimmings for Drawing Room Cabinet) obsolete..	65
56348	4924	Machine Hinge Connection for 56349....	20
56349	—	Machine Hinge complete, Nos. 2809, 15263, 56348 and wood screw 1 in. No. 10 (Trimmings for Cabinet Table, Drawing Room Cabinet and Open-Side Drawing Room Cabinet).....	50
56356	4924	Door (left) Lock Plate (Trimmings for Drawing Room Cabinet).....	10

NO.	PLATE	NAME	EACH
56429	2917	Partition Lock, revolving bolt, double (Trimmings for Cabinet Table and Cover Set).....	\$ 07
56430	2917	Partition Lock, revolving bolt, single (Trimmings for Cabinet Table and Cover Set).....	07
56438	6317	Latch Button Hinge Pin for 56326, obsolete.....	01
56441	6316	Centre Drawer Lock with two wood screws $\frac{1}{2}$ in. No. 2 (Trimmings for Cabinet Table).....	07
56442	—	Shield Chain, $6\frac{1}{2}$ in. long, for 56443, obsolete.....	10
56443	4925	Shield Chain 56442 with 640B, 56444 and wood screw $\frac{1}{2}$ in. No. 5 R. H. B. (Trimmings for Drawing Room Cabinet and Open-Side Drawing Room Cabinet) obsolete.....	20
56444	4924	Shield Chain Plate for 56443, obsolete...	02
56446	6322	Band Wheel Crank Frame with two 46629 (Trimmings for Open-Side Drawing Room Cabinet).....	2 30
56450	6432	Treadle Centre Bracket with 28268 (Trimmings for Open-Side Drawing Room Cabinet).....	25
56451	6432	Machine Lifting Plate for 56452, obsolete	60
56452	—	“ “ “ 56451 with 28123 and 56262, for 56453, obsolete.....	1 15
56453	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 56452 (Trimmings for Drawing Room Cabinet) obsolete.....	1 80
56493	4924	Machine Button Cushion (leather) for 124388.....	01
56494	4924	Cover Hook (Trimmings for Cover Set and Portable Case).....	07
56495	4924	Cover Hook Plate (Trimmings for Porta- ble Case).....	07
56496	4924	Spring Catch, for doors (Trimmings for Drawing Room Cabinet).....	06
56497	4924	Spring Catch Cup (Trimmings for Draw- ing Room Cabinet).....	06
56498	4924	Cover Cushion, felt (Trimmings for Cover Set and Portable Case).....	01
56499	4924	Door Stop, felt (Trimmings for Open-Side Drawing Room Cabinet) .....	01

## NUMERICAL LIST OF PARTS

109

NO.	PLATE	NAME	EACH
56500	6432	Base Till Lid complete, Nos. 87581, 124301, 124302 and 124356 (Trimmings for Portable Case) obsolete .....	\$ 35
56812	—	Oscillating Rock Shaft Hinge Pin 3052 with 1513J, for 5747.....	85
62739	—	Shuttle Bobbin Case for 15277.....	50
66646	4922	Darning Foot Spring for 86294.....	06
80018	4916	Hand Attachment Driver Finger Hinge Pin for 94001 and 94018.....	01
80023	4915	Hand Attachment Crank Handle (wood) for 94005.....	06
80027	4916	Hand Attachment Pinion for 94001, obsolete.....	60
80028	4916	Hand Attachment Pinion Dowel Pin for 94001 and 94018..... per 100	10
82680	—	Belt, size $\frac{3}{16}$ in., length 64½ in., with 25027, for 25281.....	30
82896	6321	Brace with three 46629, for 82953.....	2 70
82953	—	Stand (iron work) rocking treadle, ball bearing pitman, cabinet table, complete, Nos. 504R, 1288R, 25049, 25086, 25200, 25406, 25442, 46511, 82896, 83031, two 25444 and four 748R.....	—
83031	4925	Belt Guide for 82953.....	10
84151	6413	Machine Button Washer (leather) for 87342, obsolete.....	01
85301	5647	Quilter Bar for 25515.....	06
85302	5647	“ Guide for 25515.....	03
86291	—	Darning Foot for 86294.....	—
86292	—	“ “ Clamp for 86294, Nos. 86295 and 86296.....	—
86294	4922	Darning Foot (spring) complete, Nos. SS476C, 36658, 66646, 86291 and 86292	1 00
*86295	—	Darning Foot Clamp Body for 86292....	—
*86296	—	“ “ “ Guide for 86292....	—
87342	6413	Machine Button with 84151 and wood screw 1 in. No. 9 R. H. B. (Trimmings for Portable Case) obsolete.....	03
87363	712	Drawer Lock Key (Trimmings for Drawing Room Cabinet) obsolete.....	07
87372	6316	Cover Hook Cup Catch (Trimmings for Cover Set) obsolete.....	07
87427	6413	Cover Lock Plate (Trimmings for Portable Case).....	07
87428	6316	Cover Hook (Trimmings for Cover Set and Portable Case) obsolete.....	07

NO.	PLATE	NAME	EACH
87431	6413	Cover Hook Plate (Trimmings for Portable Case) obsolete.....	\$ 10
87550	—	Handle complete, Nos. 28088, 28231, 87555 and two each NN83J, 28229, 50289B and 87558 (Trimmings for Portable Case) obsolete.....	80
87555	4925	Cover Re-enforcing Plate for 87550 and 124309.....	07
87558	6413	Handle Link for 87550, obsolete.....	10
87571	6413	Machine Hinge Head for 87573, obsolete.	25
87572	6413	“ “ “ Screw Washer for 87573 and 87723.....	03
87573	—	Machine Hinge complete, Nos. SS368J, 8294, 8295, 87571 and 87572 (Trimmings for Drawing Room Cabinet and Portable Case) obsolete.....	60
87581	6413	Base Till Lid Catch Plate for 56500, obsolete.....	07
87582	6413	Base Till Lid Catch Plate Pin (Trimmings for Portable Case) obsolete.....	03
87605	6317	Centre Drawer Hinge Bracket with two wood screws $\frac{1}{2}$ in. No. 7 (Trimmings for Cabinet Table) .....	10
87606	6317	Centre Drawer Hinge Bracket Plate with two wood screws $\frac{1}{2}$ in. No. 7 (Trimmings for Cabinet Table) .....	07
87721	4924	Machine Hinge Connection for 87723....	10
87722	4924	“ “ Head for 87723.....	25
87723	—	Machine Hinge complete, Nos. SS368J, 8295, 87572, 87721 and 87722 (Trimmings for Portable Case).....	60
94001	—	Hand Attachment complete for 15-50 Machine, Nos. 137B, SS380D, SS381D, 8280, 8388, 33647, 80018, 80027, 80028, 94002, 94005 to 94008, 94010, 94011 and two each 183E and 211A, obsolete, use 94018.....	3 80
*94002	4915	Hand Attachment Body for 94001 and 94018.....	70
94005	—	Hand Attachment Crank complete for 94001 and 94018, Nos. 8435, 80023 and 94012.....	60
94006	4916	Hand Attachment Driver for 94001 and 94018.....	30
94007	4916	Hand Attachment Driver Finger 33643, with 8390, 8391 and 94009, for 33650, 94001 and 94018.....	25

## NUMERICAL LIST OF PARTS

111

NO.	PLATE	NAME	EACH
94008	4916	Hand Attachment Driver Finger Lock Pin for 94001 and 94018.....	\$ .03
94009	4916	Hand Attachment Driver Finger Sheath (leather) for 94007.....	.01
94010	4915	Hand Attachment Gear with 8281 and 8282, for 94001, obsolete .....	.60
94011	4915	Hand Attachment Gear Cover for 94001, obsolete.....	.10
94012	4915	Hand Attachment Crank Handle Spindle for 94005.....	.10
94016	4925	Hand Attachment Gear Cover for 94018	.10
94018	—	Hand Attachment complete for 15-50 Machine, Nos. 137B, 659D, 660D, 8280, 8388, 8392, 8394, 33647, 80018, 80028, 94002, 94005 to 94008, 94016 and two each 183E and 399A .....	3.80
120290	8313	Ruffler for 35918 and 120292.....	1.25
120292	—	“ 120290 with 35938.....	1.50
120306	—	Attachment Set for 25623, Nos. 287B, 25527B, 25537, 25538, 25626 to 25629, 36589, 36583, five 2996 and six needles	4.80
120309	—	Attachment Set for 35918, Nos. 287B, 25527B, 25537, 25538, 35931, 36583, 36594, five 2996 and six needles .....	6.00
120329	—	Machine Cover (Accessories).....	1.50
124301	4924	Base Till Lid Knob (wood) for 56500, obsolete.....	.02
124302	4923	Base Till Lid Knob Rivet for 56500, obsolete.....	.01
124307	4924	Handle Link for 124308 and 124310.....	.10
124308	—	“ “ 124307 with 28229 and 50549B, for 124309.....	.25
124309	—	Handle complete, Nos. 28088, 28231, 87555 and two each NN83J and 124308 (Trimmings for Portable Case).....	.55
124310	—	Handle Link 124307 with 28229 and 50550B, for 124311.....	.25
124311	—	Handle complete, Nos. 28088, 28231 and two each NN83J and 124310 (Trimmings for Cover Set).....	.70
124315	4924	Door (left) Lock (Trimmings for Drawing Room Cabinet).....	.07
124320	6432	Machine Lifting Plate for 124321, obsolete .....	.60
124321	—	“ “ “ 124320 with 28123 and 56262, for 124322, obsolete.....	1.10

NO.	PLATE	NAME	EACH
124322	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124321 (Trimmings for Open-Side Drawing Room Cabinet) obsolete.....	\$1 75
124331	4925	Treadle Screw Centre Bracket for 124332	30
124332	—	Treadle Screw Centre Bracket complete, Nos. 1507R, 50574C and 124331 (Trimmings for Drawing Room Cabinet)...	55
124333	4925	Belt Shifter Bracket for 124334.....	25
124334	—	Belt Shifter complete, Nos. 34R, 25033, 46525 and 124333 (Trimmings for Drawing Room Cabinet).....	40
124351	4925	Shield Chain, 5½ in. long, with 124352 and wood screw ½ in. No. 5 R. H. B. (Trimmings for Drawing Room Cabinet and Open-Side Drawing Room Cabinet)	20
124352	4925	Shield Chain Hook for 124351.....	02
124356	—	Base Till Lid for 56500.....	25
Nos. 124362 to 124364 FOR 124403			
124362	4924	Base Till Lid Latch.....	02
124363	4924	" " " " Button.....	06
124364	4924	" " " " Washer.....	02
124381	6432	Machine Lifting Plate for 124382.....	60
124382	—	" " " 124381 with 28123 and 56262, for 124383.....	1 15
124383	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124382 (Trimmings for Drawing Room Cabinet).....	1 80
124384	6432	Machine Lifting Plate for 124385.....	60
124385	—	" " " 124384 with 28123 and 56262, for 124386.....	1 15
124386	—	Machine Lifting Plate complete, Nos. 9281, 50251E, 56260, 56261 and 124385 (Trimmings for Open-Side Drawing Room Cabinet).....	1 80
124387	4924	Machine Button for 124388.....	10
124388	—	" " 124387 with 56493, for 124389.....	10
124389	—	Machine Button 124388 with 732B, 22436R and 124390 (Trimmings for Portable Case).....	65
124390	4924	Machine Button Thumb Screw Bushing for 124389.....	35
124402	6432	Base Till Lid for 124403.....	25

## NUMERICAL LIST OF PARTS


113

NO.	PLATE	NAME	EACH
124403	—	Base Till Lid complete, Nos. 124362, 124363, 124402 and two 124364 (Trim- mings for Portable Case).....	\$ 35
125011	4917	Crank Connecting Rod with 125012 and two 896E.....	95
125012	—	Crank Connecting Rod Cap for 125011..	—
125013	4917	Oscillating Rock Shaft for 15-22, 15-30 and 15-50 Machines.....	80
202600	2929	Tuck Folder Screw Stud Thumb Nut Washer for 36091.....	01
202603B	2929	Tuck Folder Space Gauge Screw Stud Thumb Nut Washer for 36091.....	01
225923	2928	Tuck Folder for 36091.....	60
225926	2928	“ “ Space Gauge for 36091.....	50


**ILLUSTRATIONS OF PARTS  
FOR  
MACHINES  
Nos. 15-22, 15-30, 15-41,  
15-43 and 15-50**

**PLATE 699—ONE-FOURTH SIZE**


2008



2804



15282



2802



15311




2047



15297



2814




46525



46612




2816




2811



2042



15319



25068



25069




2056



25047




# PLATE 700—ONE-HALF SIZE




**PLATE 701—ONE-HALF SIZE**

2444



2446

2838



2447



2449



2452



2093




2095



2828



15271




2844




2848



15053



15054




15055



# PLATE 702—FULL SIZE

2208




2082 2090 2076 2086 398




2073



2839



2455




15367



2840



2457



2040

2451




2851




2212




2573




2092



2057




# PLATE 703—FULL SIZE




**PLATE 704—FULL SIZE**

2506




2986




2071



2068



2044




2048



2819



2052



2821



50216




26075



2824



# PLATE 705—FULL SIZE



## PLATE 706—FULL SIZE

1288



137



145



183



175



208



92



74



1381



659



660



302



635



1293



570




434



233



399



246



1285



286



725



462



465



662




1519




1520



1510



1513



1515



1518




1813



1935



1832



1822



1560






PLATE 708—ONE-HALF SIZE




**PLATE 709—FULL SIZE**


15100




2515



15277



2996



15140



2973



2974



592




2523



2975




2509



2431



15142



15098



15027




591




15278



2745



648





2526




2972




PLATE 710—ONE-HALF SIZE




2960



8392




8393



8313



8379




# PLATE 711—FULL SIZE

15253


2809

15264

15252



15263



---15251

---15251

8284



8286



8285



2269



8387



8388



28049



28123



8282



8281




8390



8391



15292



8280




28200



28018



28034 5604




15068




# PLATE 712—ONE-HALF SIZE


28235




28073



28253



28125



28021




28015




28044




28121



28234




28024




28026




28079




87363




28019



28037




28020



28233



28030




28033


28017

PLATE 933—FULL SIZE

35496



35483



35484



35488



190




12152



# PLATE 935—FULL SIZE

35485



35486

35489

35487


35491



35492



35494



50139



35493



35490






PLATE 936—FULL SIZE




**PLATE 1004—FULL SIZE**

26535




26538




26525



26524




2653



# PLATE 1018—FULL SIZE

26521



26785



22232



26784



26537



240



26523



26527



468



26528



26529




26530



26532



26533



26534




9859



36611



36695



**PLATE 1902—ONE-HALF SIZE**


15067




3052



4304



15313




2815



15306



15071




15219



15154



15153



15159




2742



15218




15296



33642



33647




8434




PLATE 1905—ONE-HALF SIZE

15178



15180




15175




15172




15155



15240



15243



15242






PLATE 1908—FULL SIZE


15103




15102



15001



15139




15138




# PLATE 1909—FULL SIZE


15165



15162



15171



1035



15170



12424



229



15182




1085




25027



2102




15150



8238



15248



4784




930



15069




25033



25152



PLATE 1950—FULL SIZE



**PLATE 1962 - ONE-FOURTH SIZE**

15214



**PLATE 1965—FULL SIZE**






PLATE 2915—ONE-NINTH SIZE



**PLATE 2917—FULL SIZE**


56429



28012



56430



28076



28054



28045



28051



28052



28210



28211



56253



56441



2928—ONE-HALF SIZE




PLATE 2929—FULL SIZE

50066



19044



50067



202600



1704



171



50068



1705



202603



1483




36807




PLATE 3826—FULL SIZE


46509




46506



46508



46655



46507




25362



1520



1670



25371



25361



972




25127



296



748



297



1507






PLATE 4270—FULL SIZE

28283




28281




28279



28284



28286



28288



56254



28268




28290




**PLATE 4905—FULL SIZE**


15250



15249




15299




15298




15304



15316




15279




# PLATE 4906—FULL SIZE

15236




1338



15238




32572




289



134



15245



649




28299




15244




15246



28126




15302



# PLATE 4907—FULL SIZE


15259



35602



15261



35601



237



35600



1423



22232



15260



1292




190



# PLATE 4909—FULL SIZE

26152



25883



6267




15262



25888




28915




15281



35857



35996



**PLATE 4910—ONE-HALF SIZE**

**2995**



**2896**



**2871**



**2058**

—


**15272**



**8332**




**28235**



**8279**

**36569**



**36571**




**15273**



**15275**



**28266**



**28269**




PLATE 4912—FULL SIZE

15359






PLATE 4913—FULL SIZE

15294



15364



15289




15290




**PLATE 4914—FULL SIZE**

15303



15365



15300




15301




**PLATE 4915—ONE-HALF SIZE**


33647




94002



94011



94010



94012



80023




8435




**PLATE 4916—FULL SIZE**


94006



94007



80027



94009



8391



8390



8281



8282



94008



8388



80028



80018




8280



SS 381



SS 380



137



183




PLATE 4917—ONE-HALF SIZE


15497




125011



15432



125013



15498




15493



15427



15491



**PLATE 4918—FULL SIZE**


50291 50292



857



15395



13710




15410




50353



55645



15412



1727




8217




PLATE 4919—FULL SIZE

36865



36333



35884



36058



36059

36067




36092




PLATE 4920—FULL SIZE


15376




15378



15414



15415




15424




15377



15416



15418



15413





PLATE 4921—FULL SIZE

15419



**PLATE 4922—FULL SIZE**

86294



36658



15429



36056



36055

S.S. 476



66646



28831



35983



35984



36835



**PLATE 4923—FULL SIZE**

50574



50550



50549



50527



732



15486



124302 4604




**PLATE 4924—FULL SIZE**


56494



28291



56356



56495



124307



87721



56348



56496



87722



56499



124387



22436



124363



56493



124301



124362



124390



56498




**PLATE 4925—ONE-HALF SIZE**

124351 56443




46671



83031



124352



94016


87555



46631




124331



124333




**PLATE 5635—FULL SIZE**



287




25537




25525



28880



25539




25538




**PLATE 5636—FULL SIZE**


36517



36594



35931



35932






PLATE 5637—FULL SIZE



From the library of: Superior Sewing Machine & Supply LLC

**PLATE 5638—FULL SIZE**

**35938**



**35940**





PLATE 5647 - FULL SIZE

8941-12

25510




25515




25637



25635




35463



**PLATE 5649—FULL SIZE**

25636



25632






PLATE 5650—FULL SIZE

26319




25626




25627



25628




25629



**PLATE 6312—FULL SIZE**

15284




# PLATE 6313—FULL SIZE


50059



180



15285



50058



15283



15287



15288



571




15072



2749




2746



50



2748



1528



233



15293



50060



15291



50061



15286



15366




50230




**PLATE 6316 — FULL SIZE**

56251



28297




28221



1272




56441



28077



87428



87372




PLATE 6317—FULL SIZE

87605



87606




50251



1734



9281



87571



S.S.368



87572



50380



36807



26075



15514



28277



56258



28263



28242



56438



**PLATE 6318—ONE-FOURTH SIZE**






PLATE 6321 — ONE-NINTH SIZE



From the library of: Superior Sewing Machine & Supply LLC

PLATE 6322—ONE-NINTH SIZE



**PLATE 6413—FULL SIZE**


28088



28231



87558



28229




50289



NN 83




87428



87342



87431



28242



5604




87582




84151



87581



SS 368



87572




PLATE 6429—ONE-HALF SIZE

56326







PLATE 6430—ONE-NINTH SIZE




**PLATE 6432—ONE-FOURTH SIZE**

124381

56451

124384

124320



56500

124402

56450



PLATE 8313—FULL SIZE

120290

