
# Contents of accessory box



41 16 041-07 Accessory box with presser feet and accessories



41 11 383-01 Standard presser foot mounted on the machine



41 14 512-01 Utility stitch and pattern presser foot



41 11 389-01 Raised seam presser foot, three grooves

40 15 427-01 Raised seam cord guide for use with or without



41 12 988-01 Presser foot for light fabrics



41 11 650-01 Buttonhole foot



41 12 897-01 Darning foot



41 13 901-01 Roller presser foot




cord

41 14 228-01 Blindstitching presser foot



41 12 989-01 Zipper foot

# Standard accessories



41 17 389-01

41 12 989-01


# Contents of accessory box




Stitch programmers

A. 41 15 830-01	B. 41 15 831-01
C. 41 15 832-01	D. 41 15 833-01
E 41 12 034 01	E 41 15 095 A1

G. 41 15 836-01 H. 41 15 837-01



41 16 045-01 Holder for programmers



41 12 699-01 Large screwdriver



41 11 732-01 Button reed




40 15 555-01 Brush





40 15 399-01 Buttonhole knife (seam ripper)



41 16 414-01 Needle case with needles System 705H



41 11 866-01 Glide plate






40 11 770-01 (USA) 41 14 401-01 (other countries) Bobbins, six



41 11 399-01 Attachment screw



### Needle assortment

Only use needles of System 130/705H.

40 16 086-01. Needle No. 60. 40 16 089-01. Needle No. 70, 40 16 092-01. Needle No. 80,

40 16 099-01. Needle No. 100. 40 16 102-01. Needle No. 110. 40 16 106-01.

Needle No. 120.

40 15 819-01. Needle case containing 1 No. 70, 2 No. 80, 1 No. 90, 1 twin needle No. 80 with 2 mm needle gap.

40 16 119-01. Needle case containing 1 No. 80, 3 No. 90, 1 No. 100.

41 10 714-01. Needle case containing 3 No. 80, 2 No. 90.

41 14 518-01. Needle case containing 2 No. 70, 6 No. 80, 2 No. 90,

41 14 703-01. Needle case containing needles with rounded tip, 2 No. 70, 3 No. 80.

41 16 284-01. Needle case containing stretch needles, 5 No. 90.

41 16 285-01. Needle case containing jeans needles, 2 No. 90, 2 No. 100, 1 No. 110.

41 16 285-02. Needle case containing jeans needles, 5 No. 90.

41 16 414-01. Needle case containing 1 No. 70, 2 No. 80, 1 No. 90, 1 twin needle No. 80 with 2 mm needle gap, 2 stretch needles, 1 No. 75, 1 No. 90, 2 jeans needles,

1 No. 90, 1 No. 100.



41 14 235-01. Twin needle No. 80, 2 mm needle gap. 41 14 235-02. Twin needle No. 80, 3 mm needle gap.

41 14 235-03. Twin needle No. 80, 4 mm needle gap.

41 11 621-01. Twin needle No. 90, 3 mm needle gap. 41 11 621-02. Twin needle No. 90, 4 mm needle gap.

41 11 621-03. Twin needle No. 90, 2 mm needle gap.

For parallel seams and raised seams.

Maximum stitch width setting, 2.5 resp. 1.5 and 0.


41 11 622-01. Triplet needle No. 90, 3 mm needle gap.


41 11 622-02. Triplet needle No. 80, 2.5 mm needle gap. Maximum stitch width setting, 1.5.


40 15 600-01. Thread reel pin. To be used when necessary for a third thread reel.

The above-mentioned needles are suitable for our sewing machines. However, all types are not available on all markets


Read more about needles on pages 10, 11 and the next page.









41 12 683-01. Cutting needle No. 100 for sewing in leather or thick skin.




41 12 684-01. Wing needle produces a hemstitch effect. Can be used for zig-zag and pattern stitching.




41 14 541-01. Finger guard.




41 12 685-01, No. 80. 41 12 685-02, No. 90. 41 12 685-03, No. 100. Slotted needles for people with impaired vision. The needle eye is supplied with a slot. When threading, pass the thread along the needle, until the thread glides into the slot.




41 11 384-01. Presser foot for 2 mm hemming. To be sewn with straight stitch or zig-zag. Stitch length 1.5, stitch width 1.5.




41 11 385-01. Presser foot for 5 mm hemming. To be sewn with straight stitch, zig-zag or a decorative stitch.




 $41\ 11\ 386\text{-}01.$  Presser foot for 3 mm scalloped hem. To be sewn with zig-zag, stitch length 4.5, stitch width 3.75 and tight thread tension. Suitable for soft fabrics.




41 11 387-01. Presser foot for 2 mm rolled hem. To be sewn with zig-zag, stitch length 3, stitch width 3.5. Suitable for light fabrics.




41 14 538-01. Presser foot with five holes for decorative stitching over yarn or for satin-stitching, 41 16 287-01. Thread the needle threader from underneath the presser foot and draw the threads down through the holes.




40 93 022-01. Piping attachment. Insert the cord between the layers of the material.




40 93 005-01. Presser foot for attaching braiding, which is inserted through a guide and attached with a straight stitch in the middle of the braiding.




41 14 381-01. Presser foot for gathering. The fabric is gathered as it is sewn—the longer the stitch length, the fuller the gathering. The gathered fabric can be sewn simultaneously to another ungathered fabric.




40 15 237-01. Presser foot for sewing on large buttons and buttons with high edges.



41 13 931-01. Marker presser foot. By using this foot you can transfer markings from paper patterns to fabric, sew Point de Paris hemstitch and "miniature rugs".




41 12 745-01. Piping presser foot for fastening edging tape with a flat and a round part (piping). Only the round part will be visible when the tape is in place.




41 11 395-01. Decorative stitch presser foot. Made of metal, grooved underneath to make room for close seams.




41 11 882-01. Bias binder for edging with bias tape. Can be used for 8, 10, 12 and 15 mm folded tape and for 22-24 mm unfolded tape. The stitch distance can be varied.




40 93 020-01. Ruffler. Can be set for gathering and pleating at every, every 6th or every 12th stitch.




40 15 813-01. Attachment for circular sewing. Stretch the fabric over an embroidery hoop, place a thumbtack in the middle as a pivot and attach the guide over the pivot thumbtack.



41 13 458-01, 30 mm (1 1/8"). 41 13 458-01, 45 mm (1 3/4"). Weaver's reed for rug sewing. Wind the yarn over the reed and sew in place, with straight stitch.




40 15 367-01. Hemstitcher. Put the fork between two layers of material, which are sewn together with long straight stitches. (Note: In parts of USA, "hemstitching" may not mean the same as described here.)



41 14 294-01. Dual feeder. To be used for materials which are easily displaced, e.g. plastic, velvet, etc. Useful also for checked and striped fabrics.







40 15 395-01. Presser foot for narrow stitches. zippers, welts or welting.




40 93 015-01. Presser foot, extra narrow, for special straight stitching.



41 11 394-01. Presser foot for extra fine straight stitching in light fabrics.



41 14 540-01 Presser foot with side slit.



41 15 625-01. Stitch plate with round needle hole, for straight stitching in very loose or light fabrics.



41 15 868-01. Plate for darning and embroidering with straight stitching especially in light fabrics.



For making closing bars around holes, for example evelets in belts, the feed dog is covered by a plate. Available for different hole-diameters.

41 15 855-01. Plate for eyelets 4 mm. 41 15 855-02. Plate for eyelets 6 mm.



41 15 849-01. Darning foot.



40 93 028-01 40 93 029-01 40 93 030-01

Frames for darning and embroidery 40 15 398-01 5.5 cm diameter (2 1/8") 40 93 028-01 10 cm diameter (4") 40 93 029-01 15 cm diameter (6") 40 93 030-01 20 cm diameter (8")



41 14 243-01. Glide plate for 41 12 989-01 Zipper foot.



41 14 244-01. Glide plate for 41 11 650-01 Buttonhole foot.