

Spare Parts,  
Attachments  
and  
Accessories  
for

---

**Husqvarna**

DOMESTIC SEWING MACHINE  
CLASS 21 E



HUSQVARNA VAPENFABRIKS AB, HUSKVARNA, SWEDEN



Arm and bottom plate with exterior details

Husqvarna special parts:

41 10 150 Cover plate, small, for  
41 11 205

41 11 205 Bottom plate, complete

40 11 538 Rubber ring for 40 11 692

40 11 629 Arm sleeve, upper part

40 11 649 Fixing pivot for 40 12 493

40 11 686 Locking spring for cover

40 11 692 Arm sleeve, lower part,  
complete

40 11 724 Cover plate, large, for  
41 11 205

40 11 768 Rubber foot for 41 11 205

40 11 769 Washer for 40 11 768


Husqvarna standard parts:

20 65 268 Screw, front, for 40 11 692

20 65 347 Screw for 41 11 205

20 70 786 Screw, back, for 40 11 692

23 04 141 Screw for 40 11 686



23 04 201 Screw for 41 10 150 and 40 11 724      23 04 221 Screw for 40 11 692  
28 01 231 Washer for 23 04 221

Face plate, motor case, belt guard and cover plate

Husqvarna special parts:

40 03 041 Felt washer for 40 11 855

41 10 512 Thread guide for bobbin winding

41 10 526 Oil pipe for lubrication of 40 12 576

41 11 203 Motor case

41 11 210 Belt guard, complete

40 11 592 Locking spring for 40 13 016

40 11 854 Cover plate, front

40 11 855 Cover plate arm, complete

40 11 856 Cover plate, back


40 11 858 Spool pin

40 11 872 Hinge for 40 13 016

40 11 954 Plate spring

40 12 494 Rubber pivot for 40 11 855

40 13 016 Face plate, complete



21 25 298 Screw for 40 11 872      23 04 201 Screw for 40 11 954  
21 25 326 Screw for 41 11 203      25 85 180 Nut for 20 90 135  
23 04 141 Screw for 40 11 592      28 70 031 Screw rivet for 41 10 512

Husqvarna standard parts:

20 70 219 Screw for 41 11 203

20 70 255 Screw for 40 11 855

20 70 775 Screw for 41 11 210

20 90 135 Screw for 41 11 210



40 11 696



41 11 559



40 10 740



40 09 302



41 10 607



40 12 545



40 11 919



40 11 558



40 11 689



40 12 544



20 74 286



41 11 555


41 10 155

SINGLE HOLE 41 11 413


*Husqvarna standard parts:*

20 71 234 Screw for 40 12 544

20 74 286 Screw for 41 11 555




40 12 108



20 70 170

40 12 578



40 12 576



41 10 692

40 09 171

40 12 109

41 10 719

40 11 619 Needle bar, complete

40 11 620 Needle bar

40 11 637 Needle bar connecting rod, complete

40 11 641 Crank rod pin with 20 56 737

40 12 108 Screw for 41 10 749

40 12 109 Screw for 40 11 619

40 12 576 Frame

40 12 577 Shaft

40 12 578 Thread take-up lever

40 12 582 Slide, complete

40 13 342 Needle bar crank

*Husqvarna standard parts:*

20 56 251 Screw for lower bearing 40 11 637

20 56 737 Screw for 40 11 641

20 70 170 Screw for 40 12 578

20 90 127 Screw for 40 12 576

21 25 394 Screw for 41 10 518

28 16 191 Washer for 41 10 518



40 13 342



20 56 737

40 11 641

40 11 637

20 56 251

**Needle bar and thread take-up lever movement***Husqvarna special parts:*

40 09 171 Flat-head screw for top bearing in 40 11 637

41 10 518 Bolt for 40 13 342

41 10 692 Crank stud, complete

41 10 719 Thread guide

41 10 749 Needle clamp with

40 12 108

**Presser bar movement and thread release device***Husqvarna special parts:*

- 41 10 379 Link for 41 11 459  
 41 10 509 Presser bar spring  
 41 11 459 Presser bar guide, complete with release  
 40 11 693 Thread release yoke  
 40 11 782 Presser bar lifter  
 40 11 783 Pivot pin for 40 11 783  
 40 12 111 Screw for attachments  
 40 12 610 Eccentric pivot for 40 11 693  
 40 13 317 Presser bar guide  
 40 13 318 Spring for 41 11 459  
 40 13 319 Lock washer for 41 11 459  
 40 13 320 Set screw for 41 11 459  
 40 13 327 Presser bar  
 40 15 229 Zigzag presser foot with link


*Husqvarna standard parts:*

- 20 56 223 Screw for 40 11 783  
 20 91 475 Screw for 41 11 459


28 80 190 Elastic tubular pin for 40 13 319      28 95 190 C-washer for 40 13 320  
 28 95 235 C-washer for 41 11 459

**Thread tension device***Husqvarna special parts:*

- 41 10 530 Thread release pin  
 41 10 791 Housing  
 41 10 792 Adjusting ring  
 40 12 463 Thread tension device, complete  
 40 12 464 Knob  
 40 12 465 Screw  
 40 12 467 Shaft  
 40 12 469 Interior thread tension washer  
 40 12 470 Washer  
 40 12 471 Exterior thread tension washer  
 40 12 472 Thread tension spring  
 40 12 473 Thread regulating spring  
 40 12 474 Frictional washer  
 40 12 475 Frictional spring  
 40 12 478 Cover for knob

*Husqvarna standard parts:*

- 20 90 162 Screw for 40 12 463  
 20 95 227 Screw for 40 12 467


**Zig-zag mechanism**

Husqvarna special parts:

- 41 10 152 Eccentric pivot for 40 12 597
- 41 11 219 Screw for 40 12 451
- 40 11 694 Spring washer for 40 12 517
- 40 11 835 Draw rod, complete
- 40 12 451 Washer for 40 12 597
- 40 12 509 Spring for 40 12 597
- 40 12 517 Regulator shaft
- 40 12 542 Scale for stitch width
- 40 12 597 Needle bar frame
- 40 12 598 Shaft for 40 12 597
- 40 13 057 Link
- 40 13 093 Crank, complete

Husqvarna standard parts:

- 20 91 316 Screw
- 21 25 298 Screw for 40 12 509
- 21 25 304 Screw for 40 13 093
- 28 01 248 Washer for 40 11 835
- 28 95 190 C-Washer for 40 13 057 and 40 13 093
- 28 95 220 C-Washer for 40 12 517 and 40 12 598

41 10 952 Cam set C<sup>1</sup>

- 41 10 953 Cam set D, special
- 41 10 954 Cam set E, special
- 40 11 808 Worm screw with 20 91 316 for 41 11 340
- 40 12 513 Regulator knob, complete, for stitch width
- 40 12 515 Step for buttonhole sewing
- 40 12 516 Spring for 40 12 513
- 40 12 588 Guide plate, complete with shaft
- 40 12 589 Shaft for 40 12 588
- 40 25 266 Check ring with 20 91 248 for 41 11 340

Husqvarna standard parts:

- 20 70 216 Screw for 40 12 513
- 20 91 248 Screw for 40 25 266
- 20 91 316 Screw for 40 11 808
- 20 91 382 Screw for 40 12 513
- 21 25 466 Screw for 41 10 588
- 25 05 180 Nut for 40 12 588
- 28 04 280 Spring washer for 40 12 588
- 28 16 200 Washer for 41 10 588
- 28 95 250 C-washer for 41 10 588

**Zigzag mechanism**

Husqvarna special parts:

- 41 10 588 Shaft for 41 10 589


- 40 10 589 Worm wheel
- 41 10 592 Washer for 41 10 589
- 41 10 950 Cam set A<sup>1</sup>
- 41 10 951 Cam set B<sup>1</sup>



### Zig-zag mechanism

*Husqvarna special parts:*


- 41 10 587 Locking pin
  - 41 11 464 Spring for 40 13 083
  - 40 11 725 Spring for starting position
  - 40 11 804 Spring for 40 13 064
  - 40 11 812 Bearing for 40 12 477
  - 40 11 819 Link for setting the starting position, complete
  - 40 11 821 Stop washer for 40 11 822-01
  - 40 11 822-01 Regulator knob
  - 40 11 827 Pattern selector
  - 40 11 909 Cam guide
  - 40 11 910 Distance sleeve with 20 91 246 for 40 11 909
  - 40 11 913 Spring for 40 11 909
  - 40 11 926 Stop for 40 12 477
  - 40 11 960 Spring washer for 20 56 247
  - 40 12 477 Guide, complete
  - 40 12 541 Starting position scale
  - 40 13 064 Shaft for 40 11 822-01
  - 40 13 083 Shaft, complete, cam guide
- Husqvarna standard parts:*
- 20 56 247 Screw for 40 11 812



### Arm shaft and rotating shuttle transmission

*Husqvarna special parts:*

- 41 10 508 Bushing, back, for 41 11 537
- 41 11 338 Sprocket, lower, with 20 56 273 and 20 56 841
- 41 11 340 Arm shaft, upper
- 41 11 537 Arm shaft, lower
- 40 11 774 Chain belt
- 40 11 896 Arrest ring with 20 91 316 for 41 11 340
- 40 11 956 Cog wheel, complete
- 40 11 991 Balance wheel
- 40 12 547 Oil felt
- 40 12 580 Washer for 41 11 340
- 40 12 700 Sprocket, upper, with 20 90 152
- 40 13 042 Arrest ring with 20 90 152 for 41 11 537
- 40 13 096 Washer for 40 11 777



*Husqvarna standard parts:*

- 20 56 273 Screw for 41 11 334
- 20 56 281 Screw for 40 11 991
- 20 56 841 Screw for 41 11 338

- 20 90 152 Screw for 41 10 508, 40 11 956, 40 12 700 and 40 13 042.
- 20 91 316 Screw for 40 11 896
- 28 25 350 Cylindrical pin for 40 11 991



Shuttle, shuttle shaft, shuttle cover and driver

Husqvarna special parts:

41 10 371 Dust shield




- 40 12 569 Bushing for 40 11 777  
40 11 530 Bobbin case  
40 11 535 Latch for 40 11 530  
40 11 536 Spring for 40 11 530  
40 11 539 Spacing washer, 0,1 mm  
40 11 539-01 Spacing washer, 0,5 mm  
40 11 770 Bobbin  
40 11 777 Shaft for rotating shuttle  
40 11 778 Washer for 40 11 777  
40 11 781 Thread tension spring  
40 12 569 Bushing for 40 11 777

- 40 11 515 Gear wheel with 20 90 135 for 40 11 777  
40 11 517 Holder for 41 10 697  
40 11 520 Rotating shuttle complete with 40 11 530 and 40 11 770  
40 11 521 Rotating shuttle  
40 11 526 Driver  
40 11 530 Bobbin case  
40 11 535 Latch for 40 11 530  
40 11 536 Spring for 40 11 530  
40 11 539 Spacing washer, 0,1 mm  
40 11 539-01 Spacing washer, 0,5 mm  
40 11 770 Bobbin  
40 11 777 Shaft for rotating shuttle  
40 11 778 Washer for 40 11 777  
40 11 781 Thread tension spring  
40 12 569 Bushing for 40 11 777

Husqvarna standard parts:

- 20 61 321 Screw for 40 11 526  
20 74 260 Screw for 40 11 781  
20 90 135 Screw for 40 11 515  
20 90 152 Screw for 40 12 569  
20 91 316 Screw for 40 11 517  
22 88 125 Screw for 40 11 781  
23 04 141 Screw for 41 10 371



Feed dog length movement

Husqvarna special parts:

40 11 612 Link

40 11 698 Crank for 40 11 868

- 40 11 741 Oil wick for 40 11 862 and 40 12 595  
40 11 742 Oil wick, front, for rocker arm

- 40 11 751 Grub screw, front, for 40 11 868  
40 11 862 Stitch regulator fork  
40 11 868 Shaft for feed dog length movement  
40 11 895 Shaft for 40 11 862  
40 12 585 Eccentric  
40 12 595 Crank rod  
40 12 713 Oil wick, back, for rocker arm  
40 12 716 Grub screw, back, for 40 11 868

Husqvarna standard parts:

- 20 90 152 Screw for 40 11 868 and 40 12 585  
21 25 318 Screw for 40 11 698  
25 04 273 Nut for 40 12 716  
28 20 016 Safety ring for 40 12 585  
28 95 220 C-washer for 40 11 895

**Stitch regulator***Husqvarna special parts:*


- 40 09 285** Block  
**41 10 728** Guide sleeve  
**41 10 729** Guide, complete, for  
 stitch regulator  
**41 10 730** Guide  
**41 10 731** Screw for 41 10 729  
**41 10 732** Knob  
**41 10 734** Stitch regulator guide,  
 complete  
**41 11 209** Control arm, complete,  
 for 41 10 734  
**41 11 212** Nut for 41 10 729  
**41 11 460** Lock for 41 10 729  
**40 12 548** Knob, complete, for stitch  
 regulator  
**40 12 555** Adjusting ring for  
 41 10 729  
**40 12 556** Spring ring for 41 10 729  
**40 12 572** Spring ring for 40 12 548  
**40 12 574** Washer for 41 10 728

*Husqvarna standard parts:*

- 28 20 018** Safety ring for  
 41 10 729

**Feed dog height movement and feed  
 dog lowering***Husqvarna special parts:*


- 41 10 165** Clamp for 41 10 177  
**41 10 177** Oil wick for feed dog arm  
**41 10 798** Shaft for 41 10 799  
**41 10 799** Rocker bar, complete, with  
 feed dog arm  
**41 11 553** Feed dog  
**40 11 599** Crank for 41 10 799  
**40 11 602** Guide plate  
**40 11 609** Spring for 40 12 568  
**40 11 751** Grub screw, front, for  
 41 10 799  
**40 11 754** Arrest peg for 40 60 055  
**40 12 566** Piston for 40 11 602  
**40 12 567** Spring for 40 12 566  
**40 12 568** Lever for feed dog lowering  
**40 12 571** Knob for feed dog lowering  
**40 60 055** Grub screw, back, for  
 41 10 799

*Husqvarna standard parts:*

- 20 59 245** Screw for 41 11 553  
**20 90 162** Screw for 41 10 798

- 21 25 379** Screw for 40 11 602  
**21 25 386** Screw for 40 11 599  
**21 25 394** Screw for 40 11 754

- 28 01 256** Washer for 21 25 386  
**28 20 011** Safety ring for 40 12 571  
**28 95 220** C-washer for 41 10 798

**Reduction gear****Husqvarna special parts:****40 10 646** Shoulder screw for


40 11 880

**40 11 660** V-belt, long**40 11 661** V-belt, short**40 11 665** Holder for 40 11 666**40 11 666** Oil felt**40 11 669** Bearing for 40 11 881**40 11 671** Cog wheel for 40 11 882**40 11 672** Pulley with cog wheel**40 11 673** Pulley with 20 90 127 and  
20 95 227**40 11 676** Cog wheel, upper**40 11 680** Spring for 40 11 676**40 11 773** Washer, internal, for

40 11 676

**40 11 880** Reduction gear, complete**40 11 881** Mounting plate for

40 11 880

**40 11 882** Bobbin spindle, complete**40 11 885** Shaft, upper, for 40 11 880**40 11 886** Gear selector for 40 11 885**50 11 887** Gear selector for 40 11 992**40 11 888** Spring for 40 11 885**40 11 894** Spring for 40 11 881  
(belt tension)**40 11 992** Control knob**40 12 704** Guide plate**40 12 705** Lock washer for 40 11 880**40 12 710** Oil felt**Husqvarna standard parts:****20 56 277** Screw for 40 12 704**20 90 127** Screw for 40 11 673**20 95 227** Screw for 40 11 673**21 25 222** Screw for 40 11 887**21 25 295** Screw for 40 11 669**25 01 277** Nut for 40 11 885**28 01 530** Washer for 40 11 672**28 16 191** Washer, outer**28 80 150** Elastic tubular pin for  
40 11 671**28 95 205** C-washer for 40 11 885**Sewing light and motor****Husqvarna special parts:****41 10 382** Spring for cord**41 10 660** Shoulder screw for

41 10 959

**40 10 716** Spring washer for

41 10 660


**41 10 832** Lamp guard**41 10 959** Clamp for 41 11 151**41 10 960-06** Motor, complete, with  
foot control (41 11 004,  
41 11 058 and 41 11 102)**41 11 004** Motor, type KSH 270**41 11 058** Terminal board**41 11 102** Foot control**41 11 152** Lamp socket, complete,  
with cord**41 11 237** Spring for cord**41 11 427** Support for 41 11 001**41 11 428** Support for 41 11 001**41 11 429** Screw for 41 11 058**40 25 724** Bulb: 130 and 230 V**Husqvarna standard parts:****20 70 170** Screw for 41 10 832**21 25 237** Screw for 41 11 058**21 25 306** Screw for holder

**Extension plate***Husqvarna special parts:*

- 40 11 624** Spring for 40 11 784  
**40 11 644** Rubber support  
**40 11 748** Spring for 40 12 495  
**40 11 784** Latch  
**40 11 785** Handle for 40 11 784  
**40 12 493** Extension plate, complete  
**40 12 494** Rubber stud  
**40 12 495** Support  
**40 12 496** Foot for 40 12 495  
**40 12 496-01** Foot for 40 12 495  
**40 12 496-02** Foot for 40 12 495



**40 12 496**  
**40 12 496-01**  
**40 12 496-02**


**40 12 495****40 11 748****40 12 494****28 25 281****40 11 644****40 11 624****40 11 784****40 12 493***Husqvarna standard parts:*

- 28 25 281** Cylindrical pin for  
40 12 495  
**28 95 205** C-washer fro 40 11 784

**28 95 205****28 25 281****Box for accessories with contents  
and case**

- 40 03 046** Screwdriver  
**41 10 422** Box for accessories  
**41 10 470** Oil can with ampule  
**41 10 471** Oil, plastic container  
**41 10 525** Mat for 42 70 052  
**41 10 900** Plastic bag for camsets  
B<sup>1</sup> and C<sup>1</sup>  
**40 11 729** Bobbin, plastic  
**40 11 770** Bobbin, steel  
**40 15 399** Buttonhole knife  
**40 15 406** Screwdriver  
**40 15 555** Cleaning brush  
**40 15 819** Packet of needles,  
system 705  
**42 70 052** Case

**41 10 525****42 70 052****40 03 046****40 15 406****41 10 471****41 10 470****40 11 729****40 11 770****40 15 399****40 15 555****40 15 819****41 10 422**



40 03 002



40 03 005



40 03 013



40 03 017



40 03 019



40 03 022




40 15 100



40 15 240



40 03 038

41 11 622, 41 11 621-01  
41 11 622-01, 41 11 621-02

41 11 621



40 15 426



40 15 367



40 15 432



40 15 433



40 15 600

**Special attachments**40 03 002 Hemmer  $\frac{3}{32}$ " straight seam40 03 003 Hemmer  $\frac{1}{8}$ " straight seam

40 03 005 Braider

40 03 013 Presser foot, wide

40 03 017 Presser foot for rug sewing

40 03 019 Gathering foot

**Standard attachments**

40 03 029 Embroidery hoop, 6"

40 03 035 Hemmor for  $\frac{3}{16}$ " hem

41 11 483 Presser foot for zipper fasteners, adjustable

40 12 111 Attachment screw

40 15 229 Jointed presser foot (attached to the machine) for straight and zigzag stitching

40 15 236 Hemmer for roll seam

40 15 237 Button foot

40 15 420 Edge guide

40 15 423 Throat plate for  $\frac{1}{8}$ " eyelet

40 15 427 Raised-seam attachment

40 15 428 Buttonhole foot

40 15 460 Darning foot

40 15 801 Pattern stitching presser foot

40 15 818 Blindstitching guide

40 15 823 Twin-needle foot with 3 grooves



40 09 001

40 03 022 Piping attachment

40 03 028 Embroidery frame, dia. 4"

40 03 030 Embroidery frame, dia. 8"

40 03 038 Pricker

40 09 001 Weaver's reed

41 11 621-01 Twin-needle,  $\frac{1}{8}$ "

3 mm Nr. 90

40 11 621-01 Twin-needle,  $\frac{5}{32}$ "

4 mm Nr. 90

41 11 622 Triple-needle,  $\frac{3}{32}$ "

2.5 mm Nr. 80

41 11 622-01 Triple-needle,  $\frac{7}{64}$ "

3 mm Nr. 90

40 15 100 Jointed presser foot for straight stitching

40 15 240 Hemmer for scalloping

40 15 367 Hemstitcher

40 15 426 Twin-needle foot with 1 groove

40 15 432 Throat plate for  $\frac{3}{16}$ " eyelets40 15 433 Throat plate for  $\frac{7}{32}$ " eyelets

40 15 600 Spool pin for sewing with 3 threads

40 15 806 Throat plate with round needle hole



## Parts for terminal Board

- 244 74 Nut for 248 96  
 248 96 Screw for 21 32 35  
 10 16 80 Support  
 21 32 35 Cord clamp at terminal board  
 21 32 41 Socket for plug pin, complete  
 21 32 42 Connecting strip  
 21 39 04 Washer, under 10 16 80  
 21 39 12 Cord with wall plug for terminal board mark 40  
 21 39 95 Terminal board, only  
 21 39 97 Screw for 21 32 41  
 21 40 48 Connecting screw  
 21 84 48 Screw for 10 16 80

21 40 48

21 39 12

40 16 524

21 32 42



248 96




21 39 97



21 84 48



21 39 04



21 39 95

244 74



21 32 41



21 32 35




10 16 80

41 11 058


## Parts for motor KSH 270

- 247 73 Rivet for 284 64  
 255 40 Bearing bushing  
 284 64 Spring for 10 18 07  
 297 42 Spring for 297 46  
 297 46 Carbon brush  
 297 94 Felt ring  
 303 01 Screw for 21 02 72  
 303 14 Screw for 10 14 87  
 10 14 87 Brush holder  
 10 14 89 Cover for 10 14 87  
 10 18 06 Lock washer  
 10 18 07 Bearing holder  
 10 18 14 Washer, outer, oil slinger  
 10 19 21 Screw for 21 01 09 and 21 09 10  
 21 01 09 Bearing end plate, commutator side  
 21 01 10 Bearing end plate, driving side  
 21 02 69 Screw for 21 02 70  
 21 02 70 Belt pulley  
 21 02 72 Condenser holder  
 21 03 54 Washer, inner, oil slinger  
 21 05 99 Screw for 21 32 39





*Spare Parts, Attachments and Accessories for  
Husqvarna Domestic Sewing Machine Class 21 E*


**Parts for foot Control FR 340**

186 31 Spring washer for 10 23 96  
197 29 Screw for 21 20 99

**248 96 Screw for 21 20 72**

297 40 Connecting screw  
10 05 11 C-washer

<b>10 16 80</b>	<b>Support</b>
<b>10 23 96</b>	<b>Screw for 21 20 96</b>
<b>21 19 66</b>	<b>Set screw with contact</b>
<b>21 20 44</b>	<b>Spring washer for 248 96</b>
<b>21 20 59</b>	<b>Contact holder</b>
<b>21 20 64</b>	<b>Shaft</b>
<b>21 20 70</b>	<b>Base plate for foot control, blue-green</b>
<b>21 20 71</b>	<b>Cover for foot control, blue-green</b>
<b>21 20 72</b>	<b>Resistance</b>
<b>21 20 93</b>	<b>Stop lever</b>
<b>21 20 94</b>	<b>Contact roller, complete</b>
<b>21 20 95</b>	<b>Switch guide</b>
<b>21 20 96</b>	<b>Spring for 21 20 94</b>
<b>21 20 97</b>	<b>Spring</b>
<b>21 20 99</b>	<b>Bottom plate, complete</b>
<b>21 21 50</b>	<b>Locking spring for 21 20 64</b>
<b>21 21 53</b>	<b>Contact spring, complete</b>
<b>21 26 05</b>	<b>Guard sleeve, black</b>
<b>21 28 03</b>	<b>Cord with plug, black</b>
<b>21 30 66</b>	<b>Interference suppressor, complete</b>
<b>21 32 26</b>	<b>Condenser</b>
<b>21 37 44</b>	<b>Washer</b>
<b>21 84 48</b>	<b>Screw for 10 16 80</b>



## Service Bulletin


At the request of many dealers we give you a summary of the changes made on cam stacks for Class 21 and 51.

The left row below illustrates our old cam stacks and the right one the cam stacks now in use. A comparison between the two rows shows that the only difference is a minor re-grouping of the patterns, which took place in connection with the introduction of the utility cam stack A1.


The old cam stacks are no longer available, which means that a customer with an old Class 21 who would like a cam stack with blindstitch, should buy an A1 (40 10 950). Some of the patterns will, of course, be doubled but on the other hand, she will have all the utility stitches on the same cam stack.

**OLD CAM STACKS**


**A**  
40 15 526




**B**  
40 15 527




**C**  
40 15 528



**D**  
40 15 529




**E**  
40 15 530




**NEW CAM STACKS**


**A<sub>1</sub>**  
41 10 950




**B<sub>1</sub>**  
41 10 951




**C<sub>1</sub>**  
41 10 952



**D<sub>1</sub>**  
41 10 953



**E**  
41 10 954



BLIND HEM FOR JERSEY OR STRETCH MATERIALS

BLIND HEM FOR REGULAR MATERIALS

ELASTIC THREE-STEP STITCH FOR MENDING & OVERCASTING OF AND SEWING ELASTIC BANDS

ZIG-ZAG STITCH FOR BUTTON HOLES, SEWING ON BUTTONS, MAKING EYELETS, MONOGRAMMING, OVERCASTING, ETC.