## Husqvarna Dual Feeder for Husqvarna and Viking sewing machines

Helps provide smoother and more even feeding up to a stitchlength of 6 mm of both upper and lower layers of fabric and helps keep them together. An excellent aid when sewing some of the newer materials which might have a tendency to adhere to the underside of a presser foot. You may wish to try it when sewing with foamed fabrics, imitation leather, plastics, some stretch fabrics, knitted materials, fabrics requiring accurate pattern alignment, shiny synthetic fabrics, etc.

## How to attach

Make sure that the black lever arm (A) is pushed in. Bring the machine needle to its upper position and remove the presser foot from the "ankle" bracket. Tilt the dual feeder rearwards and insert it under the presser bar. The transverse pin (B) should then be snapped onto the "ankle" bracket the same as when fitting ordinary snap-on presser foot in place.

By pressing it from the rear, snap the jaw at the top of the bracket lever arm onto the horizontal projection of the needle clamp.

Press the top rear of the DUAL FEEDER forward so that it snaps onto the vertical presser bar.

## How to remove

- To remove the dual feeder, press the top downwards and to the rear.
- Lift the black jaw from the needle clamp projection.
- Then pull the Dual feeder presser foot downward and forward to unsnap it from the "ankle" bracket.

