

HOW TO USE THE NECCHI ZIG-ZAG WELTING FOOT NO. 894

For use with NECCHI "Z"or "A" SUPERNOVA, to sew purchased (or self-made) 1 Welting (covered cord) to one or two pieces of fabric, used on pillow covers, slip covers, bed spreads, draperies, etc.

MACHINE SETTING: (For st

(For straight stitching)

CAM:

No cam in machine.

PRESSER FOOT:

Remove regular presser foot and attach NECCHI Welting

Foot No. 894 to presser bar,

NEEDLE POSITION:

At left.

ZIG-ZAG WIDTH LEVER:

At "0".

STITCH LENGTH:

Between "2" and "3".

NEEDLE:

No. 14.

THREADS:

Necchi-Elna 3 ply sewing thread No. 50 (Needle and Bobbin).

TENSIONS:

Normal sewing tension.

PROCEDURE:

1. Place welting on fabric (with right side of fabric facing you) so that corded portion of welting is toward your left and raw edges of welting line up with the raw edge of the fabric (FIG,1).

Lower the welting foot so that the grooved portion of it covers the corded portion of the welting, then sew the welting with a straight stitch to the lst piece of the fabric for the desired length.

2. Place 2nd layer of fabric (with right side down) over the 1st layer of fabric ("right" sides together) so that all raw edges at your right are even (FIG.2).

Lower the welting foot over the corded portion and sew the 2nd straight stitch.

3. Set zig-zag lever of the machine to widest stitch (between "4" and "5") and adjust stitch length knob to "1", then zig-zag all raw edges together (FIG. 3).

This zig-zag stitch(overcasting) will prevent all raw edges from unravelling.