SINGER 28W

PRICE LIST

0 F

PARTS



MACHINES

OF.

CLASS 28 w

INDEX

| | PAGI |
|-------------------------|------|
| Accessories | 33 |
| Bobbin Winder | 3 |
| Feed Dogs | 3 |
| KNEE LIFTER PARTS | 36-3 |
| Lap Seam Fellers | 15 |
| " " Gude | 5(|
| Machine No. 28 w 1 | 7 |
| " | 10 |
| | 25 |
| ·' · · · · · 28 w 104 | 3 |
| Needle Holders | 40 |
| Numerical List of Parts | 59 |
| Obsolete Parts | 58 |
| Presser Feet | 4 |
| " Folders | 5 |
| Shirt Facing Folders | 5: |
| STRIP REELS | ភ |
| Thread Unwinder | 37 |
| Throat Plates | 4.7 |
| Lyner Driver | 56 |

Instructions for Ordering

In ordering from this list, use \mbox{ONLY} the \mbox{PART} number in the \mbox{FIRST} column.

The number stamped on a Sewing Machine Part is the number of the Single Part only, except when the part includes Set Screws, Clamping Screws, Studs and Rollers Spun on, Small Wires riveted, or Parts soldered together, etc., which it is necessary to furnish in combination.

Every combination of parts sent out has its specific number which, although not stamped on Parts (except in above cases) must be used when ordering the combination.

Each number always indicates the SAME PART in whatever list it appears, or for whatever Machine.

The letters after some of the numbers indicate the style of finish only, as follows:

- A. Hardened, Polished and Plated.
- B. Polished and Plated.
- C. Hardened only,
- D. Polished only.
- E. Soft, not polished.
- F. Hardened and Polished.
- H. Blued.

These letters MUST BE USED when they appear in the list and AFTER the number, as in the list.

In this series

200001 to 201500 are Screw Numbers.

201501 to 201800 are Nut Numbers

201801 to 202000 are Roller Numbers.

202001 and upward are numbers of Machine Parts.


The figures in the second column refer only to the plate in which the illustration of the part is shown and are NOT TO BE USED in ordering.

Two or more numbers over a cut indicate that the difference between such parts is not visible in an illustration.

Parts marked with an asterisk (*) are furnished only when repairs are made at the factory.

LIST OF PARTS COMPLETE

FOR



MACHINE No. 28 w 1

DROP FEED

For Shirts, Underwear, Wrappers, Etc.

In gauges from \(^3\) inch. to 2\(^1\) inches.

| No. | Plate | Name | Each |
|----------|-------|-----------------------------------|--------|
| *204161 | | Arm | . \$ — |
| *204412 | | " 204161 with 200439c, 202036 and | 1 |
| | | 204705 | |
| 204163 | 12305 | Arm Cap | 10 |
| 200278 n | 12311 | " " Serew | . 05 |
| 202248n | 12307 | " " " Washer | . 05 |
| 204235 | | " Position Pin (2) | . 02 |
| 200963E | 12311 | " Screw (3) | . 06 |
| 202005 | 12308 | " " Washer (3) | . 01 |
| 203202 | 12346 | " Shaft | . 1.75 |
| 204705 | 12334 | " " Bushing (front) | . 35 |
| 200439c | 12311 | " " Position Screw | . 05 |
| 204440 | 12346 | " " Connection with four 2000541 | -; |
| | | (9) | 7.5 |

| No. | Plate | Name | Ea | ch | No. | Plate | Name | Each |
|-----------------|-------|--|-----|-------|----------|------------|---|-------|
| 200054E | 12307 | Arm Shaft Connection Screw | \$ | 03 | 201525€ | 12310 | Feed Bar Hinge Screw Nut | \$ 03 |
| 202299 | | " " Oil Packing (wick) (2) | • | 01 | == | 12386 | " " Spring | 04 |
| | | Balance Wheel, 54 in. diam. (belt groove | | 0.1 | | 12306 | " " Hook | 04 |
| 204805 | 14049 | 3 in. diam.), with 200328c and 200335c. | 1 | 00 | | 12362 | 6 Dog, for 211880 | 75 |
| naaacn. | 10211 | | 1. | 07 | | 12125 | " " 211015 | 75 |
| 20006211 | 12311 | Balance Wheel Adjusting Screw | | | | 12126 | " " 211894 | 75 |
| 2003280 | 12311 | A COMMINION TO THE TAXABLE PARTY OF THE PART | | 04 | | 12127 | 211897 | 1 00 |
| 200335c | 12311 | Det Marie IIIIIII | | 04 | | 12127 | " " 211900 | 1 00 |
| *213138 | | Bed | | | 211902 | | 211956 | 1 00 |
| *212892 | | " 213138 with 200840a, 202062, 202299, | | | 211957 | 11929 | " " 211913 | 1 00 |
| | | 203248, 243124, two each 200362c and | | | 211914 | 12363 | | 1 00 |
| | | 200516E | | | 212082 | 11931 | ₩ 1 × 1 × 1 × 1 × 1 × 1 × 1 × 1 × 1 × 1 | 75 |
| 202258 | 12345 | Bed Hinge Connection (2) | | 08 | 221316 | 11936 | BBINIT | 02 |
| 200570e | 12311 | " " Screw (4) | | 05 | 200106в | 12311 | | 02 |
| 203329 | 11904 | " Slide (back) | | 30 | 203233 | 12305 | " Driving Cam with 200382c and | 50 |
| 203301 | 12334 | " " (front), for gauges from 3 to | | | | | 2004370 | 90 |
| | | 1 inch | | 35 | 204192 | 11925 | Feed Driving Cam Fork Lever with | o E |
| 213750 | 11925 | Bed Slide (front), for gauges from L_{32}^{4} | | | | | 204195 and 204293 | 85 |
| | | to 24 inches | | 35 | 204193 | 12334 | Feed Driving Cam Fork Lever Connec- | 95 |
| 203208 | 12312 | Bobbin | | 05 | | | tion with 200668c and 201525E | 35 |
| 203210 | 12312 | " Case Base with 202056, 203211 to | | | 204194 | 12306 | Feed Driving Cam Fork Lever Connec- | 45 |
| | | 203213 and 203216 | | 55 | | | tion Clamp with 200031c | 45 |
| 203211 | 12312 | Bobbin Case Base Latch | | 05 | 200031c | 12311 | Feed Driving Cam Fork Lever Connec- | 0.4 |
| *202056 | 12312 | " " " Pin | | | | | tion Clamp Pinch Screw | 04 |
| 203212 | 12312 | " " " Plunger | | 02 | 200668c | 12310 | Feed Driving Cam Fork Lever Connec- | 0.0 |
| 203213 | 12312 | " " Spring | | 0.1 | | | tion Clamp Screw Stud | 06 |
| 203209 | 12312 | " Cap with 200984F, 203214, | | | 201525E | 12310 | Feed Driving Cam Fork Lever Connec- | |
| | | 203215 and two 200594F | | 25 | | | tion Clamp Screw Stud Nut | 03 |
| 203214 | 12312 | Bobbin Case Tension Spring | | 10 | 200002 E | 12310 | Feed Driving Cam Fork Lever Connec- | = |
| $200984 { m F}$ | 12312 | " " " Regulating | | | | | tion Hinge Screw | 07 |
| | | Screw | | 0.1 | 201522 г | 12310 | Feed Driving Cam Fork Lever Connec- | |
| $200594 { m F}$ | 12312 | Bobbin Case Tension Spring Screw | | 02 | | | tion Hinge Screw Nut | 03 |
| 203215 | 12312 | " "Thread Guide | | 05 | *204195 | | Feed Driving Cam Fork Lever Shaft | |
| 200594€ | 12312 | " " " Screw | | 02 | 204197 | 12306 | " " " " " " (t ₀)- | |
| 203216 | 12312 | " Washer (cloth)Per 100 | | 25 | | | lar with 200113F | |
| 203217 | 12312 | Bobbin Case complete, Nos. 203209 and | | | 200113r | 12308 | Feed Driving Cam Fork Lever Shaft Col- | |
| | | 203210 | | 80 | | | lar Set Screw | 03 |
| 204533 | 12346 | Face Plate with 2003660, 201730, two | | | 204293 | 12308 | Feed Driving Cam Fork Lever Shaft | |
| | | each 200368n, 202090, 204281 and three | | | | | Position Pin | 1.0 |
| | | 200397u | 1 | 10 | 204196 | ± 2307 | Feed Driving Cam Fork Lever Shaft | |
| 200053c | 12311 | Face Plate Screw | | 0.1 | | | Sleeve (split) | 25 |
| 204730 | 12386 | " "Thread Guide | | 0.3 | 200043c | 12311 | Feed Driving Cam Fork Lever Shaft | |
| 200397н | | " " Set Serew | | 02 | | | Sleeve Set Screw | 04 |
| 204874 | | Face Plate complete, Nos. 200135c, | | | 901594€ | 12210 | Feed Driving Cam Fork Lever Shaft | |
| | | 200319c, 200577tt, 204277 to 204280, | | | 20110210 | 12.11 | Sleeve Set Screw Nut | |
| | | 204533, 204555, two each 200309E, 204059 | | | 004100 | (000) | Feed Driving Cam Fork Lever complete, | |
| | | and 204272 | | 50 | 204198 | 12004 | Nos. 204192 and 204194 | |
| 203303 | 12334 | | | 50 | | | | |
| 203309 | | " 203303 with 200214E, 201525E | | | 200437c | 12311 | | |
| -0.2 | | and 204200 | | 0.0 | 200382e | 11902 | | |
| 200214E | 12310 | Feed Bar Hinge Screw | | 12 | 204199 | 12346 | | 35 |
| | | From the library of Su | ını | _ri∩r | | hine | & Supply LLC | |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|---------------------|-----------------------|--|---------|---------------------|--------|---|--------|
| 206554 | | Feed Driving Rock Shaft 204199 with | | 202622 | 12306 | Feed Regulating Handle Shaft Sleeve | |
| | | 200002r, 201522r and 204193 | \$ 80 | 2000 | (20) | Washer | \$ 01 |
| 202305c | 12307 | Feed Driving Rock Shaft Center (2) | 06 | 202036 | 12310 | Feed Regulating Handle Stop Pin | 0.1 |
| 2000 13 c | 12311 | " " " " Set | | 204214 | | Feed Regulating Handle complete, Nos. | |
| | | Screw (2) | 0.1 | | | 200291E, 204207, 204211 and 204212 | 95 |
| 204200 | 12305 | THE THIRD TOWN THREE CLARK WHILE | | *203239 | | Hook (sewing) | |
| | | - $.204189$ (on left side) and two 200383 c | 35 | 203240 | 12312 | " 203239 with 200600F, 200616F and | |
| 200383c | 12314 | Feed Driving Rock Shaft Crank Set | | | | 203251 | 2 - 20 |
| | | Serew | 02 | 203290 | 12312 | Hook and Bobbin Case complete, Nos. | |
| 203235 | 12308 | | 75 | | | 203217 and 203240 | 3 00 |
| 204202 | 12308 | 1. O. R. (2011) [5000] 5.41 | 75 | 203241 | 12312 | Hook Bevel Gear Socket, 24 teeth | 85 |
| 2000271; | 12310 | " " " Pinch Screw | 0.1 | 213630 | 12342 | " " " Oil Guard (left) | |
| 202126 | 12308 | " Position Pin | 0.1 | | | (back) | 20 |
| 2000456 | 12310 | " " Screw | 03 | 213367 | 12342 | Hook Bevel Gear Socket Oil Guard (left) | |
| 203305 | 12334 | " Rock Shaft | 30 | | | (front) | 20 |
| 203315 | 12334 | 200.00 W 1 (I) | | 213633 | 12342 | Hook Bevel Gear Socket Oil Guard | |
| 000005 | | 203238 | 65 | | | (right) (back) | 20 |
| 202305c | 12307 | Feed Lifting Rock Shaft Center (2) | 06 | 213368 | 12342 | Hook Bevel Gear Socket Oil Guard | |
| 200043c | 12311 | Set | | | | (right) (front) | 20 |
| 0000=0 | | Screw (2) | 0.1 | $200099 \mathrm{H}$ | 12350 | Hook Bevel Gear Socket Oil Guard | |
| 202276 | 12308 | Feed Lifting Rock Shaft Slide Block | 15 | | | Screw (4) | 02 |
| 203238 | 12308 | | | 200555 п | 12312 | Hook Bevel Gear Socket Screw | 05 |
| 9000 (9) | 10010 | 202276 with 2002430 and 2015340 | 35 | 203242 | 11007 | " " Pinion, 24 teeth, with two | |
| 200243E | 12340 | The state of the s | | | | 200383c (2) | 1 00 |
| 00.079.0 | 10000 | Hinge Screw | 08 | 2 00383e | 12311 | Hook Bevel Pinion Set Screw | 02 |
| 201531E | 12308 | Feed Lifting Rock Shaft Slide Block | | 213136 | 12346 | " Counter Shaft | 45 |
| 90 000 | 10000 | Hinge Screw Nut | 03 | 203244 | 11007 | " " Collar with two | |
| 204206 | 12306 | Feed Regulating Handle | 10 | | | 200393c | 20 |
| 204207 | 12334 | 204500 W 14 U | | 200393c | 11007 | Hook Counter Shaft Collar Set Screw | 02 |
| | | 200098F, 202622, 204208 to 204210 and | | 203245 | 11007 | " " " Driving Gear, 44 | |
| 90.1900 | 1000= | 204213 | 55 | | | teeth, with 200362c and 200439c | 1 00 |
| 204208 | 12307 | Feed Regulating Handle Adjustable Stop | 05 | 213154 | 12305 | Hook Counter Shaft Driving Gear 203245 | |
| 200098F | 12307 | | | | | with 200045c and 203235 | 1.80 |
| 90.1900 | 10007 | Serew | 03 | 200439c | 12311 | Hook Counter Shaft Driving Gear Posi- | |
| 204209 204210 | 12307 | Feed Regulating Handle Position Pin | 01 | | | tion Screw | 05 |
| 204210 | $\frac{12306}{12306}$ | " " Shaft" " Crank with | 20 | 200362c | 12311 | Hook Counter Shaft Driving Gear Set | |
| 204211 | 12500 | | 0.0 | | | Serew | 03 |
| 204212 | 12307 | 200078c | 20 | 203246 | 11007 | Hook Counter Shaft Gear, 22 teeth, with | |
| 2011212 | 12001 | | | | | two 200383c | 75 |
| $200271 \mathrm{E}$ | 12311 | Link | 15 | 200383c | 12311 | Hook Counter Shaft Gear Set Screw | 02 |
| 2002(II). | 12-111 | Feed Regulating Handle Shaft Crank | n.e | 202299 | | " " Oil Packing (wick) | 01 |
| 200291E | 19907 | Link Hinge Screw (lower) | 05 | 200840E | 12311 | <i>u u u u u</i> | |
| 2002016 | 12001 | Feed Regulating Handle Shaft Crank | 0.5 | | | Stop Screw | 10 |
| 2000780 | 12307 | Link Hinge Screw (upper) | 05 | 213132 | 12346 | Hook Driving Shaft | 1. 60 |
| 2000100 | 1)*/ [| Feed Regulating Handle Shaft Crank Set | 0.0 | 203248 | 12334 | " " Bearing with 202299 | 20 |
| 204213 | 12307 | Serew Landle Shaft St | 03 | 202299 | 1 4001 | " " " Oil Packing | 20 |
| 201210 | 1 4-11/1 | Feed Regulating Handle Shaft Sleeve (split) | 1.5 | 2012200 | | (wick) | 01 |
| 900929 | 10044 | (split) | 15 | 000100 | 10900 | | VI |
| 200362c | 12311 | Feed Regulating Handle Shaft Sleeve | 2.0 | 202126 | 12308 | Hook Driving Shaft Bearing Position | Δ4 |
| | | Set Serew | orior C | owing Mas | hina | Pin | 01 |
| | | From the library of: Supe | 51101 5 | ewing wat | פוווונ | a Supply LLC | |

| No. | Plate | Name | Each | No. | Plate | Name E | Each |
|-----------|----------|--|-------|-------------------|---------|---|----------|
| 200516E | 12311 | Hook Driving Shaft Bearing Screw | \$ 08 | | 12308 | Needle Bar Connecting Stud Pinch | |
| 213124 | -12350 | " " Bushing (eccentric) | 25 | | 12,1111 | Screw \$ | 6 03 |
| 202299 | | " " " Oil Packing | | 204326 | | Needle Bar Packing Cord (2)Per 100 | 25 |
| | | (wiek) | 0.1 | | 12310 | " " Screw Bushing (lower) | 05 |
| 200362c | 12311 | | 03 | 200000415 | | Title Patring (10 at 1) | |
| 213141 | 12350 | " " Collar with two | (1.) | an | 12310 | ταρην τη | 05 |
| | | 200393c | 20 | 231385 | 11935 | " Holder, in 3 in. gauge, with 201030r | 4 50 |
| 200393c | 11007 | Hook Driving Shaft Collar Set Screw | | | | | 1 50 |
| 203251 | 12312 | " Gib | 02 | 201000 | 11935 | Needle Holder, in gauges from 35 to 24 | |
| 200600r | 12312 | " " Hinge Screw | 40 | | | in., in steps of $_{3}$ 5 in., with 201030 ϵ and | |
| 200616je | 12312 | | 02 | | | two 200141F | 1.75 |
| 203542 | 11230 | KIND OF THE THE TANK A | 02 | 201030₽ | 11935 | Needle Holder Screw | 02 |
| 200012 | 1.12.00 | " Saddle (left) with 200840E and two | | 200141⊬ | 11935 | " Set Screw | 02 |
| 90.95 4.1 | 11000 | 202299 | 1 50 | 204201 | 12334 | Presser Bar (hollow), with 200074F | 80 |
| 203541 | 11230 | Hook Saddle (right) with 202299 | 1 25 | 201252 | 12308 | " " Lifter | 20 |
| 202299 | | On Cacking (wick) | 01 | 200550c | 12311 | " " " Hinge Screw | 08 |
| 200006E | 11007 | " " Screw (4) | 07 | 204253 | 12308 | " Lifting Bracket with 200086c | 40 |
| 225585E | 12319 | " " Washer (4) | 02 | 200086c | 12308 | " " " Pinch Screw | 03 |
| 203254 | 12312 | " Washer | 20 | 204254 | 12307 | " " " Position Guide | 30 |
| 203544 | 11230 | Hook Saddle (left) complete, Nos. | | 2003626 | 12311 | u u u u u | |
| | | 20055511, 203241, 203254, 203290 and | | | | Set Screw | 03 |
| | | 203542 | 5 50 | 204327 | 12206 | Presser Bar Packing Washer (felt) | |
| 203543 | 11230 | Hook Saddle (right) complete, Nos. | | ~ 'C 1+1 Z I | 1 _ 11 | Per 100 | 25 |
| | | 200555н. 203241, 203254, 203290 and | | 200504E | 12310 | Presser Bar Screw Bushing (lower) | 05 |
| | | 203541 | 5 25 | 201255 | 12310 | " "Spring | 10 |
| 203545 | 11230 | Hook Saddle Combination (left and right) | | 204255 200491B | | Manda | 10 |
| | | complete, Nos. 203543 and 203514 | f1 00 | 2004818 | 12305 | THUMIN THE CHICAGO | 25 |
| 202445 | 11125 | Knee Lifter Connection Lever with | | | 1.1000 | regulating) | 25 |
| | | 202446 | 07 | 229107 | 14932 | Presser Foot, 46 needle hole, for needle | |
| 227311 | | | ", | | | sizes 5 to 7, in 7 in gauge | 85 |
| | | with 200224n, 200262n, 227302 and | | 229108 | 13073 | Presser Foot, 46 needle hole, for needle | |
| | | 227308 | - /. | | | sizes 5 to 7, in gauges from 34 to 1 in., | |
| 200224 n | 19906 | Knee Lifter Connection Lever Hinge | 50 | | | in steps of all inch | 95 |
| 20022111 | 1 201011 | | 4.3 | 229110 | 13073 | Presser Foot, 46 needle hole, for needle | |
| 997900 | 11105 | Screw | 12 | | | sizes 5 to 7, in gauges from 1_3 , to 1_2^4 | |
| 227308 | 11120 | Knee Lifter Connection Lever Lifting | | | | in., in steps of $\frac{1}{2}$ inch | 1 25 |
| 000000 | 10001 | Rod with 202302 | 05 | 229117 | 13075 | Presser Foot, 46 needle hole, for needle | |
| 202302 | 12321 | Knee Lifter Connection Lever Lifting | | | | sizes 5 to 7, in gauges from 13% to 21 | |
| | | Rod Cotter Pin | 0.1 | | | in., in steps of & inch | 1 50 |
| 202446 | 12306 | Knee Lifter Connection Lever Pin | 03 | 20007 fr | 12308 | Presser Foot Screw | 03 |
| 227302 | 11125 | " " Lifting Lever | 10 | 212920 | | Take-up Cam with 200335c and 200430c. | 1 35 |
| 200262ц | 12306 | " " " Hinge Screw | 10 | 203268 | 12334 | " 212920 with 200383c, 200658c | |
| 231390 | 11904 | Needle Bar (hollow) | 80 | | | and 201519c | 1 50 |
| 204248 | 12307 | " " Connecting Link | 35 | 203172 | 12307 | Take up Cam Friction Washer | 05 |
| 200658c | 12307 | " " " " Hinge Screw | | 2004300 | 12311 | " " Position Screw | 0.8 |
| | | Stud | 10 | 200383c | 12311 | " " " Check Serew | 02 |
| 201519e | 12307 | Needle Bar Connecting Link Hinge | | 200335c | 12311 | " Set Screw | 04 |
| | | Screw Stud Nut | 02 | 204553 | 12386 | " Lever with 204265 | 75 |
| 201249 | 12308 | Needle Bar Connecting Stud with | | 206601 | 12089 | " " 204553 with 204263 | 90 |
| | | 200072c and 202277 | 40 | | | " " Bearing with 204264 | 15 |
| 202277 | | Needle Bar Connecting Stud Oil Packing | | 201263 | 12310 | " " Position Pin | |
| | | (1-1-1-1 | 0.1 | 201264 | 12306 | | 01 05 |
| | | From the library of: | Sup | erior Sewing Ma | achin | e & Supply LLCC | 05 |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|------------------------------|--------------|---|---|------------|-------|---|-------|
| 204265 | | Take up Lever Oil Guard | \$ 05 | 20 1058 B | 12309 | Thread Retainer Stud | \$ 07 |
| 201816 | 12307 | " " Roller | 12 | 20036811 | 12209 | " Set Serew | 0.02 |
| 204554 | 12386 | Take-up Lever complete, Nos. 200042F. | | 204059 | 12309 | Thread Retainer complete, Nos. 202091, | |
| | | 201816 and 206601 | 1 00 | | | 202092 and 204058B | 15 |
| 202402 | 12309 | Tension Disc | 05 | 211880 | 12362 | Throat Plate, 50 needle hole, for needle | |
| 202090 | 12309 | " " Position Pin | 10 | | | sizes 3 to 5, in gauges from $\frac{3}{4}$ to $1\frac{1}{10}$ | |
| 204555 | 11935 | " Release Lever | 10 | | | in, in steps of $\frac{1}{3}$ in, for 211883 | 1.50 |
| 200309E | 10483 | " Serew | 04 | 211015 | 12125 | Throat Plate, 50 needle hole, for needle | |
| 202075 | 12309 | " " Plunger | 03 | | | sizes 3 to 5, in gauges 1,3, 14, 1,5 and | |
| 215609 | | " " Slide | 18 | | | 1 3 in., for 211886 | 1.50 |
| 204268 | 12310 | " " 215609 with 201269 | 20 | 211894 | 12126 | Throat Plate, 50 needle hole, for needle | |
| 204269 | 12308 | " " Spring | 02 | | | sizes 3 to 5, in gauges $1\frac{1}{4}$ and $1\frac{9}{23}$ in., | |
| 202407 | 12309 | " Spring | 05 | | | for 211896 | 1 50 |
| 200632B | 12309 | " Stud | 20 | 221347 | 11936 | Throat Plate, 50 needle bole, for needle | |
| 20039711 | 12309 | " " Set Screw | 02 | | | sizes 3 to 5, in gauges 1% and 111 in., | |
| 201572B | 12309 | " Thumb Nut | 04 | | | for 221346 | 1.50 |
| 204271 | 12309 | " Washer | 05 | 211897 | 12127 | Throat Plate, 50 needle hole, for needle | |
| 204272 | 12309 | | 011 | | | sizes 3 to 5, in gauges from $1\frac{3}{8}$ to $1\frac{11}{16}$ | |
| | | 202075, 202407, 204271 and two 202402 | 50 | | | in, in steps of 1 in. for 211907 | 2 00 |
| 204273 | 12308 | Thread Controller Adjusting Collar with | •, | 211900 | 12127 | Throat Plate, 50 needle hole, for needle | |
| | | 200684n (for Presser Bar) | 15 | | | sizes 3 to 5, in gauges 133, 13, 143 | |
| 20068411 | 12308 | Thread Controller Adjusting Collar | • • • | | | and 14% in., for 211902 | 2 00 |
| | | Screw | 04 | 211956 | 11929 | Throat Plate, 50 needle hole, for needle | |
| 204274 | 12309 | Thread Controller Plate | 12 | | | sizes 3 to 5, in gauges 1ξ , $1\frac{1}{6}$ and 2 | |
| 20057711 | 12311 | " " Serew | 02 | | | in., for 211957 | 2 00 |
| 202098 | 12309 | " Roller | 05 | 211913 | 12363 | Throat Plate, 50 needle hole, for needle | |
| 204275 | 12309 | " " " Guard | 10 | | | sizes 3 to 5, in gauges $24., 24., 23.$ | |
| 202084 | 12309 | " " " Washer | 01 | | | and 25 in., for 211914 | 2-00 |
| 200300€ | 12309 | " " Screw | 0.1 | 212081 | 11931 | Throat Plate, 46 needle hole, for needle | |
| 204276 | 12309 | " " Spring(Per 100 \$1.25) | 03 | | | sizes 5 to 7, in gauges $2\frac{3}{10}$, $2\frac{7}{5}$, and | |
| 204333 | 12309 | " " Guard | 0.8 | | | 21 in., for 212082 | 2 00 |
| 200581н | 12309 | " " " Serew | 02 | 2001616 | 12319 | Throat Plate Clamp Screw | 04 |
| 201277 | 12309 | " " Stop | 15 | 505085 | 12308 | " " Position Pin | 0.1 |
| 204278 | 12309 | " " " Driving Gear | 10 | 20057711 | 12311 | " "Serew | 02 |
| 200319c | 12309 | | • | | | | |
| | 1 2 11 11 12 | Hinge Screw | 0.4 | | | | |
| 2001350 | 12309 | Thread Controller Spring Stop Screw | 03 | | | | |
| 204279 | 12309 | " " Stud with 204925 | 10 | | | | |
| 200366н | 11902 | " " Set Screw, | 02 | | | | |
| 204925 | 12306 | " " " Washer | 01 | | | | |
| 205987 | 12309 | Thread Controller complete, Nos. 200300c. | ,,, | | | | |
| | . 2., .,. | 20058111, 202084, 202098, 204274, 204275 | | | | | |
| | | and 204333 | 42 | | | | |
| 204280 | 12309 | Thread Controller and Spring complete. | | | | | |
| and the second of the second | | Nos. 204276 and 205987 | 45 | | | | |
| 203343 | 12386 | Thread Guide | 10 | | | | |
| 204556 | 12386 | tt tt | 05 | | | | |
| 204281 | 12309 | " Retainer Guide Wire | 01 | | | | |
| 202091 | 12309 | " " Sleeve | 05 | | | | |
| 202092 | 12309 | | | | | | |
| 22 | 1 200000 | " Spring From the library of: Su | nario | r Sawing M | lachi | na & Sunnly II C | |

Name

Bobbin Case \$

" " " Pin

" " Plunger

" " Spring

" " Lever

" " " Eccentric

" " " Position Pin...

" " " Fulcrum

" "Latch 10

Each

0.1

40

LIST OF PARTS COMPLETE

FOR

MACHINE No. 28 w 4

DROP FEED. ALTERNATING PRESSERS.

| | DROP | FEED. ALTERNATING PRESSERS. | | 200066Б | 11235 | " " " Serow | 40 |
|---------------------|-------|---|------------|---------------------|-----------|--|----------|
| | | | | 203478 | 11235 | " " " Serew " " Slide Stud | 03 10 |
| | | For Tailoring. | | 203214 | 12312 | " " Tension Spring | 10 |
| | | In gauges from 3 to 2 inches. | | $200984 \mathrm{F}$ | 12312 | " " " Regulating | |
| | | | | | | Screw | 04 |
| No. | Plate | Name | Each | 200594r | 12312 | Bobbin Case Tension Spring Screw | 02 |
| *204471 | | Arm | \$ | 203216 | 12312 | " Washer (cloth)Per 100 | 25 |
| *204417 | | " 204471 with 200439c, 202036 and | | 203500 | 11255 | Bobbin Case complete, Nos. 200594F, | |
| | | 204705 | | | | 200984F, 202056, 203244, 203246, 203473, | 1 11/1 |
| 204163 | 12305 | Arm Cap | 10 | 213716 | 11901 | 203474, 203498 and 203648 | 1 00 |
| 200278n | 12311 | " " Serew | 05 | 210110 | 11.707 | two each 200368n, 202090, 204281 and | |
| 202248n | 12307 | " " " Washer | 05 | | | three 20039711 | 1 10 |
| 204235 | | " Position Pin (2) | 02 | 200053c | 12311 | Face Plate Screw | 0.1 |
| 200963 E | 12311 | " Screw (3) | 06 | 204730 | 12386 | " " Thread Guide | 03 |
| 202005 | 12308 | " " Washer (3) | 01 | 2003971 | 12309 | " " Sef Screw | 02 |
| 213001 | 11901 | " Shaft | 1 85 | 213747 | 11904 | Face Plate complete, Nos. 2005774, | |
| 204705 | 12334 | " " Bushing (front) | 35 | | | 202088, 203766, 204280, 213746, two | |
| 200439c | 12311 | " " Position Screw | 05 | | | each 200309E, 204059 and 204272 | 3 50 |
| 204440 | 12346 | " " Connection with four 200054E | cr | 203303 | 12334 | Feed Bar with 204189 | 50 |
| | | (2) | 75 | 203309 | 15 | 203303 with 200214E, 201525E | .,,,, |
| $200054 \mathrm{E}$ | 12307 | Arm Shaft Connection Serew | 03 | 2 | | and 201200 | 1 00 |
| 202299 | | " " Oil Packing (wick) (2) | 01 | 2002147 | 12310 | Feed Bar Hinge Screw | 12 |
| 201805 | 12346 | Balance Wheel, 51 in. diam. (belt | Ŀ, | 201525s | 12310 | " " " " Nut | 03 |
| | | groove 3 in, diam.), with 200328c and | 1 00 | 214424 | 12386 | " " Spring | 0.5 |
| | | 200335c | | 204189 | 12306 | " " " Hook | 01 |
| 2 00062H | | Balance Wheel Adjusting Screw | 07 | 211886 | 12125 | " Dog. for 212071 | 75 |
| 200328c | 12311 | " " Position Serew | 04 - 04 | 211896 | 12126 | " " 211966 | 75 |
| 200335c | 12311 | " Set Serew | | 211899 | 12127 | " " 211968 | 1 00 |
| *213138 | | Bed | | 211902 | 12127 | " " 212074 | 1.00 |
| *212892 | | " 213138 with 200840E, 202062, 202299, | | 211914 | 12363 | " " 211970 | 1 00 |
| | | 203248, 213124, two each 200362c and | | 200106E | 12311 | " " Screw (2) | 02 |
| | | 200516E | | 203233 | 12305 | " Driving Cam with 200382c and | |
| 202258 | 12345 | Bed Hinge Connection (2) | | | | 200437e | 50 |
| 200570н | 12311 | *************************************** | | 204192 | 11925 | Feed Driving Cam Fork Lever with | |
| 203329 | 11904 | " Slide (back) for many from 3 to | - | | | 204195 and 204293 | 85 |
| 203301 | 12334 | " " (front), for gauges from 3 to | | 204193 | 1933.1 | Feed Driving Cam Fork Lever Connec- | |
| | | 1 inch | | ~··*** | . 2-7-1-1 | tion with 200668c and 201525E | 35 |
| 213750 | 11925 | | | 204194 | 19202 | | ***1 |
| | | 2 inches | | | | Feed Driving Cam Fork Lever Connec- | |
| 203470 | 12368 | Bobbin From the library of: Su | perior | Sewing N | /lach | ine & Supply LLC | 45 |
| | | · · · · · · · · · · · · · · · · · · · | - | | | • • • | |

No.

*203498

203648

*202056

203473

203474

203499

203476

204243

203506 - 11235

Plate

12368

12368

12368

.

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|--------------------|----------|--|--------------|----------------------|---------|--|---|
| 200031c | 12311 | Feed Driving Cam Fork Lever Connec- | | 2002 #31: | 12310 | Feed Lifting Rock Shaft Slide Block | |
| | . – | tion Clamp Pinch Screw | \$ 04 | | | | \$ 0S |
| 200668c | 12310 | Feed Driving Cam Fork Lever Connec- | * . | 201531E | 12308 | Feed Lifting Rock Shaft Slide Block | , |
| | | tion Clamp Serew Stud | 0.6 | | | Hinge Screw Nuf | 03 |
| 201525E | 19910 | Feed Driving Cam Fork Lever Connec- | .,,, | 204206 | 12306 | Feed Regulating Handle | 10 |
| 201102011 | 12010 | tion Clamp Screw Stud Nut | 03 | 204207 | 12334 | " " 204206 with | • |
| 200002E | 19910 | Feed Driving Cam Fork Lever Connec- | (7.) | 507501 | 1 2.1 1 | 200098F, 202622, 204208 to 204210 and | |
| ZIMMEZE, | 12010 | * * | 0.7 | | | | - - |
| 004500 | 10010 | tion Hinge Screw | 07 | 00.1000 | 1000- | 204213 | 55 |
| 201522E | 12310 | Feed Driving Cam Fork Lever Connec- | | 201208 | 12307 | Feed Regulating Handle Adjustable Stop | 05 |
| | | tion Hinge Screw Nut | 03 | 200098₽ | 12307 | | |
| *204195 | | Feed Driving Cam Fork Lever Shaft | | | | Serew | 03 |
| 204197 | 12306 | " " " (Tol- | | 204209 | 12307 | Feed Regulating Handle Position Pin | 0.1 |
| | | lar with 200113# | 15 | 204210 | 12306 | " " Shaft | 20 |
| 200113 F | 12308 | Feed Driving Cam Fork Lever Shaft Col- | | 204211 | 12306 | " " Crank with | |
| | | lar Set Screw | 027 | | | 200078c | 20 |
| 204293 | 12308 | Feed Driving Cam Fork Lever Shaft | | 204212 | 12307 | Feed Regulating Handle Shaft Crank | |
| | | Position Pin | () [| | | Link | 15 |
| 204196 | 12307 | Feed Driving Cam Fork Lever Shaft | | $200271 \mathrm{e}$ | 12311 | Feed Regulating Handle Shaft Crank | |
| | | Sleeve (split) | 25 | | | Link Hinge Serew (lower) | 05 |
| 200043c | 12311 | Feed Driving Cam Fork Lever Shaft | | 200291E | 12307 | Feed Regulating Handle Shaft Crank | , |
| | | Sleeve Set Screw | 0.1 | | | Link Hinge Screw (upper) | 0.5 |
| 201524E | 12310 | Feed Driving Cam Fork Lever Shaft | | 200078c | 12307 | Feed Regulating Handle Shaft Crank | |
| | | Sleeve Set Screw Nut | 03 | | | Set Screw | 03 |
| 204198 | 12334 | Feed Driving Cam Fork Lever complete, | | 204213 | 12307 | Feed Regulating Handle Shaft Sleeve | |
| 2 | 12.,,,,, | Nos. 204192 and 204194 | 1.30 | | | (split) | 15 |
| 200437c | 12311 | Feed Driving Cam Position Screw | 06 | 200362c | 19911 | Feed Regulating Handle Shaft Sleeve | |
| | 11902 | " " Set Screw | 02 | 2 | 12/11 | Set Serew | 03 |
| 200382c | | " " Rock Shaft | 35 | 202622 | 19206 | Feed Regulating Handle Shaft Sleeve | 17.1 |
| 204199 | 12346 | " " 204199 with 2000020; | | 20/2002 | (,()() | | 0.1 |
| 206554 | | | | | | Washer | |
| | | 201522E and 204193 | 80 | 202036 | | Feed Regulating Handle Stop Pin | 0.1 |
| 202305c | 12307 | Feed Driving Rock Shaft Center (2) | | 204214 | | Feed Regulating Handle complete, Nos. | |
| 200043c | 12311 | 24.6 24.14.34 | | | | 200291E, 204207, 204211 and 204212 | 95 |
| | | (2) | 0.4 | *203511 | | Hook (sewing) | |
| 204200 | 12305 | Feed Driving Rock Shaft Crank with | | 203512 | 11235 | " 203511 with 203513 and two 200616r | 2 - 20 |
| | | 204189 (on left side) and two 200383c | 35 | 203514 | 11235 | Hook and Bobbin Case complete, Nos. | |
| 200383c | 12311 | Feed Driving Rock Shaft Crank Set | | | | 203500 and 203512 | 3 00 |
| | | Screw | 02 | 213810 | 12368 | Hook Beyel Gear Socket, 21 teeth | 85 |
| 203225 | 12308 | Feed Lifting Cam with 202126 | 75 | 2005550 | 12312 | " " Serew | 05 |
| 201202 | 12308 | " "Fork with 200027E | 75 | 203242 | 11007 | Pinion, 24 teeth, with two | **** |
| $200027\mathrm{E}$ | 12310 | " " " Pinch Screw | 04 | 2000212 | 11000 | 200383c (2) | 1 00 |
| 202126 | 1.2308 | " " Position Pin | 0.1 | | | | |
| 200045c | 12310 | " " Screw | 03 | | | Hook Bevel Pinion Set Screw | 02 |
| 203305 | 12334 | " " Rock Shaft | 30 | 213136 | 12346 | " Counter Shaft | 15 |
| 203315 | 12334 | " " " 203305 with 203238 | 65 | 203214 | 11007 | " Coffar with two | |
| 202305c | 12307 | " " " Center (2) | 06 | | | 2003936 | 20 |
| 200043c | 12311 | " " " " Set Screw | | 200393c | 11007 | Hook Counter Shaft Collar Set Screw | 02 |
| | | (2) | 0.4 | 203245 | 11007 | " " " Driving Gear, 44 | |
| 202276 | 12308 | Feed Lifting Rock Shaft Slide Block | | | | teeth, with 200362c and 200439c | 1 00 |
| 203238 | 12308 | " " " " " " " | 1 | 213154 | 12305 | Hook Counter Shaft Driving Gear 203215 | |
| <u> </u> | 12000 | 202276 with 200243E and 201531E | 35 | _, | | with 200045c and 203235 | 1.80 |
| | | Eropo the library of Con- | - mi - m - C | Saudia a N | 100b | | |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|----------------------|-------|--|---------|------------|---------|--|----------|
| 200439c | 12311 | Hook Counter Shaft Driving Gear Posi- | d• 43." | 227308 | 11125 | | Laci |
| 2003626 | 19911 | tion Screw Hook Counter Shatt Driving Gear Set | \$ 05 | | | Rod with 202302 | \$ - 05 |
| | 1 11 | Screw | 03 | 202302 | 12321 | Knee Lifter Connection Lever Lifting | |
| 203246 | 11007 | Hook Counter Shaft Gear, 22 feeth, with | 17.1 | | | Rod Cotter Pin | 01 |
| | | two 200383c | 75 | 202446 | 12306 | Knee Lifter Connection Lever Pin | 0.3 |
| 200383c | 12311 | Hook Counter Shaft Gear Set Screw | 02 | 227302 | 11125 | " Lifting Lever | 10 |
| 202299 | | " " " Oil Packing (wick) | 01 | 20026211 | 12306 | " " " " Hinge Screw | 10 |
| $200840 \mathrm{g}$ | 12311 | | *** | 201475 | 12376 | Lifting Lever with 200122n | 1 00 |
| | | Stop Screw | 10 | 208389 | | " " 204475 with 200935F, | |
| 213132 | 12346 | Hook Driving Shaft | 1 60 | 2111001 | 1.1000 | 201534E, 201478 and 206659 | 2 10 |
| 203248 | 12334 | " " Bearing with 202299 | 20 | 213004 | 11902 | Lifting Lever Driving Crank | 80 |
| 202299 | | " " " Oil Packing | | 201478 | 12376 | LAHER | 40 |
| | | (wiek) | 0.1 | 2001221 | 10483 | r3(0) | |
| 202126 | 12308 | Hook Driving Shaft Bearing Position | | Non ton | 1.1000 | Screw Distington Design | 0.3 |
| | | Pin | 0.1 | 200400c | 11902 | Lifting Lever Driving Crank Position | |
| 2005166 | 12311 | Hook Driving Shaft Bearing Screw | 0.8 | 200387c | 100=0 | Serew Naising Charles Desiring | 0.1 |
| 213124 | 12350 | " " Bushing (eccentric). | 25 | 2009846 | 12010 | Lifting Lever Driving Crank Position | (1) |
| 202299 | | " " Oil Packing | | 201479 | 11009 | Screw Set Serew | 02 |
| | | (wiek) | 0.1 | 2011117 | 11.1112 | Serew Set Serew Packing (brass) | o.t |
| 200362c | 12311 | Hook Driving Shaft Bushing Set Screw. | 03 | 2001816 | 19976 | Lifting Lever Stop Screw | 04 03 |
| 213141 | 12350 | " " Collar with two | | 204480 | 10483 | " " Stud Lifting Bracket with | 11.1 |
| | | 200393c | 20 | 201100 | 1 | 200086c and 200181b | 75 |
| 200393c | 11007 | Hook Driving Shaft Collar Set Screw | 02 | 208390 | | Lifting Lever Stud Lifting Bracket | (,) |
| 203513 | 11235 | " Gib | 45 | • | | 204480 with 208389 | 2 85 |
| 200616 F | 12312 | " " Screw | 02 | 200086c | 12308 | Lifting Lever Stud Lifting Bracket Pinch | 2, |
| 213682 | 11925 | " Saddle (left), with 2000665, 200840E | | | | Serew | 03 |
| | | and 202299 | 1 85 | 229654 | 11060 | Lifting Presser Foot, 46 needle hole. | , |
| 213681 | 11925 | Hook Saddle (right), with 200066b | 1 60 | 22,,,,,,,, | 11 | for needle sizes 5 to 7, in gauges 3. | |
| 2000061: | 11007 | " " Screw (1) | 07 | | | 18, 18 and 18 in., for 229655 | 2 00 |
| 202622 | 12306 | " " " Washer (1) | | 902209 | 11020 | | ., (71) |
| 213036 | 12368 | " Washer | 20 | 206683 | 11960 | Lifting Presser Foot, 46 needle hole, | |
| 203516 | 11235 | " 213036 with 203476 and two | | | | for needle sizes 5 to 7, in gauges from | |
| | | 201213 | 50 | | | $\frac{7}{5}$ to $\frac{11}{4}$ in., in steps of $\frac{1}{35}$ in., for | 0.00 |
| 203651 | 11925 | Hook Saddle (left) complete, Nos. | | | | 206685 | 3 00 |
| | | 200555n, 203478, 203499, 203506, 203514. | | 229659 | 11961 | Lifting Presser Foot, 46 needle hole, | |
| | | 203516, 243682 and 213810 | 7 25 | | | for needle sizes 5 to 7, in gauges from | |
| 202655 | 11925 | Hook Saddle (right) complete, Nos. | | | | 1.9. to 1.3 in., in steps of 4 in., for | 0.55 |
| | | 200555n, 203478, 203499, 203506, 203514, | | | | 229660 | 5 (5 |
| | | 203516, 213681 and 243840 | 7 (10) | 206687 | 11962 | Lifting Presser Foot, 46 needle hole, | |
| 203656 | | Hook Saddle Combination complete, Nos. | | | | for needle sizes 5 to 7, in gauges from | |
| | | 203654 and 203655 | 14 25 | | | 13 to 21 in., in steps of 4. in., for | |
| 202445 | 11125 | Knee Lifter Connection Lever with | | | • | 206689 | 4 00 |
| | | 202446 | 07 | 200074F | 12308 | Lifting Presser Foot Screw | 03 |
| 227314 | | Knee Lifter Connection Lever 202445 | | 231390 | 11904 | Needle Bar (hollow) | 80 |
| _41011 | | with 2002240, 2002620, 227302 and | | 204484 | 10483 | " " Connecting Link with | |
| | | 227308 | 50 | | | 200188c | 50 |
| 300904. | 19962 | | | 200188c | 12376 | Needle Bar Connecting Link Pinch Screw | 02 |
| 20022411 | 12500 | Knee Lifter Connection Lever Hinge | 12 | 201219 | 12308 | " " Stud with 200072c | |
| | | Screw | 13 | | | and 202277 | 40 |


Parts for Machine No. 28 w 4

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|--------------------------|-----------------------|---|-------|----------------------|--------|--|-------|
| 202277 | | Needle Bar Connecting Stud Oil Packing | | 204268 | 12310 | Tension Release Slide 215609 with 204269 | \$ 20 |
| | | (wick) | \$ 01 | 204269 | 12308 | " " " Spring | 02 |
| 200072c | 12308 | Needle Bar Connecting Stud Pinch Screw | 03 | 202407 | 12309 | " Spring | 05 |
| 204326 | | " Packing Cord (2)Per 100 | 25 | 200632в | 12309 | " Stud | 20 |
| 200504n | 12310 | " Screw Bushing (lower) | 05 | $200397 \mathrm{H}$ | 12309 | " " Set Screw | 02 |
| 200503B | 12310 | " " " " (прег) | 05 | $201572\mathrm{B}$ | 12309 | " Thumb Nut | 04 |
| 231385 | 11935 | Needle Holder, in 4 in. gauge, with | | 204271 | 12309 | " Washer | 05 |
| 231386 | 11925 | 201030F and two 200141F | 1 50 | 204272 | 12309 | Tension complete, Nos. 200632B, 201572B, 202075, 202407, 204271 and two 202402 | 50 |
| | 1 1 | in, in steps of 4. in, with 2010301 and | | 204274 | | Thread Controller Plate | 12 |
| | | two 2001ths | 1 75 | 200577n | 12311 | " " Screw | 02 |
| 201030F | 11935 | Needle Holder Screw | 02 | 202098 | 12309 | " Roller | 05 |
| 200141F | 11935 | " Set Screw | 02 | 204275 | 12309 | " " Guard | 10 |
| 204251 | 12334 | Presser Bar (hollow), with 200074F | 80 | 202084 | 12309 | " " " Washer | 0.1 |
| | 12308 | " " Lifter | 20 | | | | 0.1 |
| $\frac{204252}{200550c}$ | 12311 | " " Hinge Screw | | 200300c | 12309 | 38.1CW | 03 |
| | $\frac{12311}{11902}$ | | 08 | 204276 | 12309 | mpringrici in prizo | 08 |
| 201481 | 11502 | Throng Throws Tolerion | 0.5 | 201333 | 12309 | " " Guard " " Screw | 02 |
| | 1,111,11 | Guide | 35 | 20058111 | 12309 | | 03 |
| 2003627 | 12311 | Presser Bar Lifting Bracket Position | | 202087 | 11935 | Stop | |
| | 10000 | Guide Set Screw | 03 | 202088 | 10483 | 5(00 W101 204525). | [1] |
| 204327 | 12306 | Presser Bar Packing Washer (felt) | | 2003661 | 11902 | K11.1 - K10.11.1W | 02 |
| | | Per 100 | 25 | 204925 | 12306 | Washer | 0.1 |
| 200501E | 12310 | Presser Bar Screw Bushing (lower) | 05 | 205987 | 12309 | Thread Controller complete, Nos. | |
| 201482 | 11902 | " "Spring | 15 | | | 200300c, 200581n, 202081, 202098, | |
| 200491 n | 12305 | " "Thumb Screw (pressure | | | | 204274, 204275 and 204333 | 42 |
| | | regulating) | 25 | 204280 | 12309 | Thread Controller and Spring complete, | |
| 201506B | 12376 | Presser Bar Thumb Screw Check Nut | 06 | | | Nos. 204276 and 205987 | 45 |
| 213925 | 11904 | Take-up Cam with 200347c, 200383c, | | 203313 | 12386 | Thread Guide | 10 |
| | | 200387c, 200400c, 200430c and 204479 | 1.75 | 204556 | 12386 | " | 05 |
| 203172 | 12307 | Take-up Cam Friction Washer | 05 | 204284 | 12309 | " Retainer Guide Wire | 01 |
| 200430σ | 12311 | " " Position Screw | 08 | 202091 | 12309 | " " Sleeve | 05 |
| 200383c | 12311 | " " " Check Screw | 02 | 202092 | 12309 | " "Spring | 0.1 |
| 200347c | 12321 | " Set Serew | 03 | | | , . | |
| 213005 | 11901 | Take up Cam complete, Nos. 204484, | e. | 204058R | 12309 | KHUU | 07 |
| | | 213004 and 213925 | 3 00 | 20036811 | 12309 | " " Set Serew | 02 |
| 204553 | 42386 | Take up Lever with 204265 | 75 | 204059 | 12309 | Thread Retainer complete, Nos. 202091, | |
| 206601 | | " 204553 with 204263 | 90 | | | 202092 and 204058B | 15 |
| 204263 | 12310 | " " Bearing with 204264 | 15 | 212071 | 12137 | Throat Plate, 46 needle hole, for needle | |
| 204264 | 12306 | " " " Position Pin | 0.1 | | | sizes 5 to 7, in gauges from 1 to 1 3 in., | |
| 200042 F | 12311 | " " " Screw | 0.5 | | | in steps of do in, for 211886 | 1.50 |
| 204265 | | " " Oil Guard | 0.5 | 0.11022 | 11927 | Throat Plate, 46 needle hole, for needle | |
| 201816 | 12307 | " " Roller | 12 | 211966 | 11927 | | |
| 204554 | 12386 | Take-up Lever complete, Nos. 200042F, | | | | sizes 5 to 7, in gauges 1\ and 1^9_{12} in | 1 50 |
| | | 201816 and 206601 | 1.00 | | | for 211896 | 1 50 |
| 202402 | 12309 | Tension Disc | 05 | 211968 | 11927 | Throat Plate, 46 needle hole, for needle | |
| 202090 | 12309 | " " Position Pin | 0.1 | | | sizes 5 to 7, in gauges from 13 to 114 | |
| 203766 | 11935 | " Release Lever | 10 | | | in, in steps of $\frac{1}{2}$, in, for 211899 | 2 00 |
| 200309r: | 10483 | " " Screw | 0.4 | 212071 | -12137 | Throat Plate, 46 needle hole, for needle | |
| 202075 | 12309 | " " Plunger | 03 | | | sizes 5 to 7, in gauges 133 , 13 , 135 and | |
| 215609 | | " " Slide | 18 | | | 1‡3 in., for 211902 | 2 00 |

| No. | Plate | Name | Each |
|---------------------|-------|---|-------|
| 211970 | 11926 | Throat Plate, 16 needle hole, for needle | |
| | | sizes 5 to 7, in gauges 14, 113, 144, 144 | |
| | | and 2 in., for 211911\$ | 2 00 |
| 200161 p | 12319 | Throat Plate Clamp Screw | - 0.4 |
| 202062 | 12308 | " Position Pin | 0.1 |
| 200577н | 12311 | " Serew | 02 |
| 206660 | | Vibrating Presser Bar | 45 |
| 206659 | 12376 | " " 206660 with | 100 |
| | | 204193 and two 200138p | 60 |
| 200935 _F | 11935 | Vibrating Presser Bar Hinge Screw | 06 |
| 201534E | 11902 | " " Nut. | |
| 229838 | | | 03 |
| | 12376 | Position Stop | 50 |
| 200053c | 12311 | • | |
| | | ,Screw | 0.4 |
| 201493 | 12376 | Vibrating Presser Bar Spring | 10 |
| 200138 D | 11902 | " Screw | 02 |
| 229655 | 11960 | " Foot, for 229654 | 2 00 |
| 206685 | 11960 | | 2 00 |
| 229660 | 11961 | | 3 75 |
| 206689 | 11962 | | 3 75 |
| 200098 F | 12307 | " " Serew | 03 |
| 203357 | 11902 | " " Washer | . 01 |

LIST OF PARTS COMPLETE

FOR



MACHINE No. 28 w 100

DROP FEED.

For Shirts, Underwear, Wrappers, Etc.

In gauges from $\frac{3}{4}$ to $2\frac{1}{4}$ inches.

| No. | Plate | Name | Each |
|---------------------|-------|---|------|
| *204290 | | Arm | \$ - |
| *204413 | | " 204290 with 200439c, 202036 and | |
| | | 204705 | |
| 204163 | 42305 | Arm Cap | 10 |
| 200278 n | 12314 | " " Serew | 05 |
| $202248 \mathrm{H}$ | 12307 | " " " Washer | 05 |
| 204235 | | " Position Pin (2) | 02 |
| 200963E | 12314 | " Serew (3) | 06 |
| 202005 | 12308 | " " Washer (3) | 0.1 |
| 213622 | 12346 | " Shaft | 2 00 |
| 204705 | 12334 | " " Bushing (front) | 35 |
| 200439c | 12311 | " " Position Screw | 05 |
| 204440 | 12346 | " " Connection with four 200054ϵ | |
| | | (2) | 75 |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|----------------------|---------|--|--------|----------------------|----------|--|-------|
| $200054 \mathrm{E}$ | 12307 | Arm Shaft Connection Screw | \$ 03 | 201525к | 12310 | Feed Bar Hinge Screw Nut | \$ 03 |
| 202299 | | " " Oil Packing (wick) (2) | 01 | 214424 | 12386 | " " Spring | 0.4 |
| 204805 | 12346 | Balance Wheel, 51 in, diam, thelt groove | | 204189 | 12306 | " " " Hook | 0.1 |
| | | 3 in. diam.), with 200328c and 200335c | 1 00 | 211883 | 12362 | " Dog, for 211880 | 75 |
| 20006211 | 12311 | Balance Wheel Adjusting Screw | 07 | 211886 | 12125 | " " 211015 | 75 |
| 200328c | 12311 | " " Position Screw | 04 | 211896 | 12126 | 211894 | 75 |
| 200335c | 12311 | " Set Screw | 0.4 | 211907 | 12127 | " " 211897 | 1 00 |
| *213634 | | Bed | | 211902 | 12127 | 211900 | 1 00 |
| *213684 | | " 213634 with 200840E, 202062, 202299, | | 211957 | 11929 | " " <u>211956</u> | 1 00 |
| | | 203248, 213124, two each 200362c and | | 211914 | 12363 | | 1 00 |
| | | 200516F | | 212082 | 11931 | " " 212081 | 1 00 |
| 202258 | 12345 | Bed Hinge Connection (2) | 08 | 221346 | 11936 | " " 221347 | 75 |
| 200570s | 12311 | " " " Serew (1) | 0.5 | 200106E | 12311 | " " Screw (2) | 02 |
| 203329 | 11904 | " Slide (back) | 30 | 203233 | 12305 | " Driving Cam with 200382c and | 17.2 |
| 203301 | 12334 | " (front), for gauges from 7 to | | 200200 | [2500 | 200437c | 50 |
| 2000001 | 12.,.,1 | 1 inch | 35 | 90.1109 | 1.10.9.5 | Feed Driving Cam Fork Lever with | ,,,,, |
| 213750 | 11925 | Bed Slide (front), for gauges from 12. | **** | 204192 | 11925 | 204195 and 204293 | 85 |
| 210100 | 11.75.7 | to 21 inches | 35 | 964109 | 12334 | Feed Driving Cam Fork Lever Connec- | 0.0 |
| 203208 | 12312 | Bobbin | | 204193 | 12001 | tion with 200668c and 201525c | ., - |
| 203210 | 12312 | " Case Base with 207056, 203241 to | | 20.110.1 | 19900 | | 35 |
| 2001210 | 12.712 | 203213 and 203216 | 55 | 204194 | 13500 | Feed Driving Cam Fork Lever Connec- | 4.5 |
| 203211 | 12312 | Bobbin Case Base Latch | | | | tion Clamp with 200031c | 45 |
| *202056 | 12312 | " " Pin | | 200031c | 123 F1 | Feed Driving Cam Fork Lever Connec- | 0.4 |
| 203212 | 12312 | " Plunger | 02 | | | tion Clamp Pinch Screw | 0.4 |
| 203212 | 12312 | " " Spring | 01 | 200668c | 12310 | Feed Driving Cam Fork Lever Connec- | |
| 203213 | 12312 | " Cap with 200984F, 203214, | 0.1 | | | tion Clamp Screw Stud | 06 |
| 200200 | 12.012 | 203215 and two 200591F | 25 | 2015256 | 12310 | Feed Driving Cam Fork Lever Connec- | ()() |
| 909914 | 12312 | Bobbin Case Tension Spring | 10 | | | tion Clamp Screw Stud Nut | 03 |
| 203211 | | " " Regulating | | $200002_{ m E}$ | 12310 | Feed Driving Cam Fork Lever Connec- | |
| 200981r | 12312 | 1(1 pg (11(111)pg | 0.1 | | | tion Hinge Serew | 07 |
| NAME O L. | ingra | Screw | | 201522ы | 12310 | Feed Driving Cam Fork Lever Connec- | |
| 200594r | 12312 | · | | | | tion Hinge Screw Nut | 03 |
| 203215 | 12312 | " " " Thread Guide | | *204195 | | Feed Driving Cam Fork Lever Shaft | * |
| 200594F | 12312 | | | 204197 | 12306 | (Or | |
| 203216 | 12312 | | | | | lar with 200113F | 15 |
| 203217 | 12312 | Bobbin Case complete, Nos. 203209 and | | 200113ε | 12308 | Feed Driving Cam Fork Lever Shaft Col- | |
| | | 203210 | | | | lar Set Screw | 03 |
| 204533 | 12346 | Face Plate with 200366n, 204730, two | | 204293 | -12308 | Feed Driving Cam Fork Lever Shaft | |
| | | each 20036811, 202090, 201281 and three | | | | Position Pin | 0.1 |
| | 40044 | 20039711 | | 204196 | 12307 | Feed Driving Cam Fork Lever Shaft | |
| 200053c | 12311 | Face Plate Screw | | | | Sleeve (split) | 25 |
| 201730 | 12386 | | | 200043c | 19211 | Feed Driving Cam Fork Lever Shaft | |
| 200397 u | 12309 | | | 2000.40 | 12,771 | Sleeve Set Serew | 0.4 |
| 204874 | 12346 | Face Plate complete, Nos. 200135c. | | 004504 | 40040 | | |
| | | 200319c, 200577ti. 201277 to 201280, | | 201524E | 12310 | Feed Driving Cam Fork Lever Shaft | |
| | | 204533, 204555, two each 200309F, 204059 | | | | Sleeve Set Screw Nut | 03 |
| 12.072.00.00 | | and 201272 | | 204198 | 12334 | Feed Driving Cam Fork Lever complete. | |
| 203303 | 12334 | Feed Bar with 201189 | | | | Nos. 204192 and 204194 | 1 30 |
| 203309 | | " " 203303 with 200211F, 201525F | | 200437c | 12311 | Feed Driving Cam Position Screw | 96 |
| | | and 204200 | | 200382e | 11902 | " " Set Screw | 02 |
| $200214\mathrm{E}$ | -12310 | Feed Bar Hinge Screw | 12 | 204294 | 12346 | " | 35 |
| | | From the library of: Su | perior | Sewing M | achii | ne & Supply LLC | |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|--------------------|-------|---|-------|--------------------------|-----------|--|-------|
| 206555 | | Feed Driving Rock Shaft 204294 with | | 202622 | 12306 | Feed Regulating Handle Shaft Sleeve | |
| | | 200002E, 201522E and 201193 | \$ 80 | | | Washer | \$ 01 |
| 202305c | 12307 | Feed Driving Rock Shaft Center (2) | 06 | 202036 | 12310 | Feed Regulating Handle Stop Pin | 04 |
| 200043c | 12311 | set | | 204214 | | Feed Regulating Handle complete, Nos. | |
| | | Screw (2) | 0.1 | | | 200291E, 204207, 204211 and 204212 | 95 |
| 204200 | 12305 | Feed Driving Rock Shaft Crank with | | *203239 | | Hook (sewing) | |
| | | 204189 (on left side) and two $200383c$ | 35 | 203240 | 12312 | " 203239 with 200600F, 200616F and | |
| 200383c | 12311 | Feed Driving Rock Shaft Crank Set | | | | 203254 | 2 20 |
| | | Serew | 02 | 203290 | 12312 | Hook and Bobbin Case complete, Nos. | |
| 203235 | 12308 | Feed Lifting Cam with 202126 | 75 | | | 203247 and 203240 | 3 00 |
| 204202 | 12308 | " "Fork with 200027r: | 75 | 203241 | 12312 | Hook Beyel Gear Socket, 24 feeth | 85 |
| $200027\mathrm{E}$ | 12310 | " " " Pinch Screw | 0.1 | 213630 | 12342 | " " " " Oil Guard (left) | |
| 202126 | 12308 | " " " Position Pin | 0.1 | | | (back) | 20 |
| 2000450 | 12310 | " Screw | 03 | 213367 | 12342 | Hook Beyel Gear Socket Oil Guard (left) | |
| 203305 | 12334 | " " Rock Shaft | 30 | | | (front) | 20 |
| 203315 | 12334 | " " " 203305 with | | 213633 | 12342 | Hook Beyel Gear Socket Oil Guard | |
| | | 203238 | 65 | | | (right) (back) | 20 |
| 202305c | 12307 | Feed Lifting Rock Shaft Center (2) | 06 | 213368 | 12312 | Hook Bevel Gear Socket Oil Guard | |
| 200043c | 12311 | " " Set | | 2 | | (right) (front) | 20 |
| | | Screw (2) | 0.1 | 20009911 | 12350 | Hook Beyel Gear Socket Oil Guard | |
| 202276 | 12308 | Feed Lifting Rock Shaft Slide Block | 15 | | | Screw (4) | 02 |
| 203238 | 12308 | 14 45 45 55 56 | | 20055511 | 12312 | Hook Beyel Gear Socket Screw | 05 |
| | | 202276 with 200243E and 204531E | 35 | 203242 | 11007 | " Pinion, 21 feeth, with two | |
| 200 2 43 i: | 12310 | Feed Lifting Rock Shaft Slide Block | | | | 2003836 (2) | 1.00 |
| B.000 10011 | 12010 | Hinge Serew | 08 | 200283c | 12311 | Hook Bevel Pinion Set Screw | 02 |
| 201531E | 12308 | Feed Lifting Rock Shaft Slide Block | | 213136 | 12346 | " Counter Shaft | 15 |
| 2 | 1 27 | Hinge Screw Nut | 03 | 203244 | 11007 | " " Collar with two | |
| 204206 | 12306 | Feed Regulating Handle | 10 | 2000211 | | 200393c | 20 |
| 204207 | 12334 | " " 201206 with | , | 2003936 | 11007 | Hook Counter Shaft Collar Set Screw | 02 |
| 2121 | 121 | 200098F, 202622, 204208 to 201210 and | | 203245 | 11007 | " " Driving Gear, 44 | |
| | | 201213 | 55 | 2002 10 | | teeth, with 200362c and 200439c | 1 00 |
| 204208 | 12307 | Feed Regulating Handle Adjustable Stop | 05 | 213154 | 19205 | Hook Counter Shaft Driving Gear 203245 | |
| 200098F | 12307 | 1 | | _10101 | 12 | with 200045c and 203235 | |
| 2000.001 | 12001 | Serew | 03 | 200439c | 19211 | Hook Counter Shaft Driving Gear Posi- | |
| 204209 | 12307 | Feed Regulating Handle Position Pin | 0.1 | 2004111 | 12011 | tion Screw | 05 |
| 204210 | 12304 | " " Shaft | 20 | 200362c | 19914 | Hook Counter Shaft Driving Gear Set | |
| 204211 | 12306 | " " Crank with | | J.1111111 ₂ C | 12.911 | Serew | 45.11 |
| الشاالم | 12300 | 200078c | 20 | 203246 | 11007 | Hook Counter Shaft Gear, 22 teeth, with | |
| 204212 | 19307 | Feed Regulating Handle Shaft Crank | -17 | 2002 (0 | 11,,,,,,, | two 200383c | |
| 2012 | 12001 | Link | 15 | 200383c | 19211 | Hook Counter Shaft Gear Set Screw | |
| 9009710 | 19911 | Feed Regulating Handle Shaft Crank | , | 202299 | 12011 | " " Oil Packing (wick) | |
| 2002 (FF. | 12011 | Link Hinge Screw (lower) | 05 | 2008 10 E | 19211 | • • | |
| 9009016 | 19207 | Feed Regulating Handle Shaft Crank | 17.7 | 7(10) (10) | 12011 | Stop Screw | 10 |
| 2002 # FF. | 12007 | Link Hinge Screw (upper) | 05 | 213139 | 12346 | | 1.75 |
| 20007Sc | 19207 | Feed Regulating Handle Shaft Crank Set | 11 | 203248 | 12334 | " " " Bearing with 202299 | |
| 2000 (3) | 12501 | | 03 | 202299 | 1 2-141 1 | " " " Oil Packing | |
| 904919 | 1998" | Screw Feed Regulating Handle Shaft Sleeve | 11.1 | 20122111 | | (wick) | |
| 204213 | 12011 | | 15 | 202126 | 12308 | the state of the s | |
| | 4000 | (split) | 10 | 202120 | 12000 | Pin | |
| 200362c | 12311 | Feed Regulating Handle Shaft Sleeve | 0.0 | | | | |
| | | From the library of: | Supe | erior Sewing M | achir | Hook Driving Shaft Bearing Screw | , 110 |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|---------------------|-----------------------|--|-----------------|--------------------------------|-----------------------|---|------------|
| 213124 | 12350 | Hook Driving Shaft Bushing (eccentric) | \$ 25 | 200072e | 12308 | Needle Bar Connecting Stud Pinch | |
| 202299 | | " " " Oil Packing | | | | Screw | \$ 03 |
| | | (wick) | 01 | 204326 | | Needle Bar Packing Cord (2)Per 100 | 1.5 |
| 200362c | 12311 | Hook Driving Shaft Bushing Set Screw | 03 | $20050{\rm Hz}$ | 13310 | " Screw Bushing (lower) | 05 |
| 213141 | 12350 | " " Collar with two | | 200503p | 12310 | " (upper) | 05 |
| | | $200393c \dots \dots \dots$ | 20 | 231385 | 11935 | " Holder, in T in gauge, with | |
| 200393c | 11007 | Hook Driving Shaft Collar Set Screw | 02 | | | 201030F and two 200111F | 1 50 |
| 203251 | 12312 | " Gib | 40 | 231386 | 11935 | Needle Holder, in gauges from \mathbb{S}_{+} to $2\frac{1}{4}$ | |
| 200600F | 12312 | " " Hinge Screw | 02 | | | in., in steps of β_{γ} in., with 201030 κ and | |
| 200616F | 12312 | " " Screw | 02 | | | two 200141F | 1.75 |
| 203542 | 11230 | " Saddle (left) with 200840E and two | | 201030 _F | 11935 | Needle Holder Serew | 02 |
| | | 202299 | | 200141F | 11935 | " Set Screw | 02 |
| 203541 | 11230 | Hook Saddle (right) with 202299 | 1 25 | 204251 | 12334 | Presser Bar (hollow), with 2000741 | 80 |
| 202299 | 11007 | " " Oil Packing (wick) | 01 | 201252 | 12308 | " " Lifter | 20 |
| 200006E | 11007 | " " Screw (1) | $\frac{07}{02}$ | 200550c | 12311 | | 08 10 |
| 225585E 203254 | $\frac{12319}{12312}$ | " Washer | 20 | 204253 20 0 086c | $\frac{12308}{12308}$ | " " Lifting Bracket with 200086c | 03 |
| 203544 | 11230 | Hook Saddle (left) complete, Nos. | | 204254 | 12307 | " " " Position Guide | |
| 200044 | 11200 | 200555n, 203241, 203254, 203290 and | • | 2003626 | 12311 | Tosition stance | .,,,, |
| | | 203542 | 5 50 | 2000000 | 1 | Set Serew | 03 |
| 203543 | 11230 | Hook Saddle (right) complete, Nos. | ,, | 204327 | 12306 | Presser Bar Packing Washer (felt) | |
| 2 | | 200555H, 203241, 203254, 203290 and | | <i>a</i> | | Per 100 | 25 |
| | | 203541 | 5 25 | 200504⊬ | 12310 | Presser Bar Screw Bushing (lower) | 05 |
| 203545 | 11230 | Hook Saddle Combination (left and right) | | 204255 | 12310 | " " Spring | 10 |
| | | complete, Nos. 203543 and 203544 | 11 00 | 2004944; | 12305 | " " Thumb Screw (pressure | |
| 202445 | 11125 | Knee Lifter Connection Lever with | | | | regulating) | 25 |
| | | 202446 | 07 | 229107 | H932 | Presser Foot, 46 needle hole, for needle | |
| 227312 | | Knee Lifter Connection Lever 202445 | | | | sizes 5 to 7, in 7 in, gauge | 85 |
| | | with 20022411, 20026211, 227303 and | | 229108 | 13073 | Presser Foot, 46 needle hole, for needle | |
| | | 227308 | 50 | | | sizes 5 to 7, in gauges from 3; to 1 in., | |
| 20022411 | 12306 | Knee Lifter Connection Lever Hinge | | | | in steps of #winch | 95 |
| | | Screw | 12 | 229110 | 13073 | Presser Foot, 46 needle hole, for needle | |
| 227308 | 11125 | | . | | | sizes 5 to 7, in gauges from 1.5 , to $1\frac{1}{2}$ | |
| | | Rod with 202302 | 305 | | | in, in steps of 4. inch | 1 25 |
| 202302 | 12321 | Knee Lifter Connection Lever Lifting | | 229117 | 13075 | Presser Foot, 46 needle hole, for needle | |
| | | Rod Cotter Pin | 01 | | | sizes 5 to 7, in gauges from 145 to 24 | |
| 202446 | 12306 | Knee Lifter Connection Lever Pin | $\frac{03}{12}$ | | 40000 | in., in steps of $\frac{1}{2}$ inch | |
| 227303 | 11125 | " " Lifting Lever | 10 | 200071r | 12308 | Presser Foot Screw | 03 1 35 |
| 200262н | 12306 | | 80 | 212920 203268 | 12334 | Take-up Cam with 200335c and 200430c " 212920 with 200383c, 200658c | 1 -000 |
| 231390 | 11904 | Needle Bar (hollow) | | 200200 | 12004 | and 201519c | 1.50 |
| 204248 | 12307 | " " Connecting Link | 35 | 203172 | 12207 | Take-up Cam Friction Washer | 05 |
| 200658c | 12307 | " " " " Hinge Screw | | 200430c | 12311 | " Position Screw | 08 |
| | | Stud | 10 | 200383c | 12311 | " " " Check Screw | 02 |
| $-201519\mathbf{c}$ | 12307 | Needle Bar Connecting Link Hinge | | 200335c | 12311 | " Set Screw | 04 |
| | | Screw Stud Nut | 03 | 204553 | 12386 | " Lever with 204265 | 75 |
| 204249 | 12308 | Needle Bar Connecting Stud with | | 206601 | | " " 204553 with 204263 | 90 |
| | | 200072c and 202277 | 40 | 204263 | 12310 | " "Bearing with 204264 | 15 |
| 202277 | | Needle Bar Connecting Stud Oil Packing | | 204264 | 12306 | " " " Position Pin | 0.1 |
| | | | | | | | |

| No. | Plate | Name | Ea | ch | No. | Plate | Name Each |
|----------------------|----------|---|----|-----|----------|----------|--|
| 204265 | | Take-up Lever Oil Guard | \$ | 05 | 204058B | 12309 | Thread Retainer Stud |
| 201816 | 12307 | " " Roller | | 12 | 20036811 | 12309 | " Set Screw 02 |
| 204554 | 12386 | Take-up Lever complete, Nos. 200042F. | | | 204059 | 12309 | Thread Retainer complete, Nos. 202091, |
| | | 201816 and 206601 | 1 | 00 | | | 202092 and 201058B |
| 202402 | 12309 | Tension Disc | | 05 | 211880 | 12362 | Throat Plate, 50 needle hole, for needle |
| 202090 | 12309 | " Position Pin | | 01 | | | sizes 3 to 5, in gauges from 7 to 15. |
| 204555 | 11935 | " Release Lever | | 10 | | | in in the contract of the cont |
| 200309E | 10483 | " " Screw | | 0.1 | 211015 | 19195 | Throat Plate, 50 needle hole, for needle |
| 202075 | 12309 | " " Plunger | | 03 | 211(11) | 12120 | |
| 215609 | | " "Slide | | | | | sizes 3 to 5, in gauges 4.4. 13, 145 and |
| 204268 | 12310 | " " 215609 with 204269, | | 18 | 211801 | 19196 | 1 % in., for 211886 |
| 204269 | 12308 | 210000 WITH 204200; | | 20 | 211894 | 1-1-9 | Throat Plate, 50 needle hole, for needle |
| | | Spring | | 02 | | | sizes 3 to 5, in gauges 1; and 1% in., |
| 202407 | 12309 | 11/11/11/5 | | 05 | 201017 | 1.1600.0 | for 211896 |
| 200632B | 12309 | *************************************** | | 20 | 221347 | 11956 | Throat Plate, 50 needle hole, for needle |
| 20039711 | 12309 | " Set Screw | | 02 | | | sizes 3 to 5, in gauges 1% and 1½ in |
| 201572B | 12309 | " Thumb Nut | | 0.1 | | | for 221316 |
| 204271 | 12309 | " Washer | | 05 | 211897 | 12127 | Throat Plate, 50 needle hole, for needle |
| 204272 | 12309 | Tension complete, Nos. 200632B, 201572B. | | | | | sizes 3 to 5, in gauges from 1_8^3 to 1_7^{11} |
| | | 202075, 202407, 204271 and two 202102 | | 50 | | | in., in steps of 3. in., for 211907 2 00 |
| 204273 | 12308 | Thread Controller Adjusting Collar with | | | 211900 | 12127 | Throat Plate, 50 needle hole, for needle |
| | | 200684u (for Presser Bar) | | 15 | | | sizes 3 to 5, in gauges 143, 14, 144 |
| 200684н | 12308 | Thread Controller Adjusting Collar | | | | | and 143 in., for 211902 2 00 |
| | | Screw | | 0.1 | 211956 | 11929 | Throat Plate, 50 needle hole, for needle |
| 204274 | 12309 | Thread Controller Plate | | 12 | | | sizes 3 to 5, in gauges $1\overline{s}$, $1\frac{1}{10}$ and 2 |
| 200577H | 12311 | " Serew | | 02 | | | in., for 211957 2 00 |
| 202098 | 12309 | " " Roller | | 05 | 211913 | 12363 | Throat Plate, 50 needle hole, for needle |
| 204275 | 12309 | " " Guard | | 10 | | | sizes 3 to 5, in gauges $2\frac{1}{2\pi}$, $2\frac{1}{4\pi}$, $2\frac{\pi}{2\pi}$ |
| 202084 | 12309 | " " " Washer | | 01 | | | and $2\frac{1}{2}$ in., for 241914 $2 00$ |
| 200300c | 12309 | " " Serew | | 04 | 212081 | 11931 | Throat Plate, 46 needle hole for needle |
| 204276 | 12309 | " Spring(Per 100 \$1,25) | | 03 | | | sizes 5 to 7, in gauges $2\frac{\pi}{16}$, $2\frac{\pi}{16}$ and |
| 204333 | 12309 | " " " Guard | | 08 | | | 21 in., for 212082 2 00 |
| $200581 \mathrm{n}$ | 12309 | " " Screw | | 02 | 200161p | 12319 | Throat Plate Clamp Screw 04 |
| 204277 | 12309 | " " Stop | | 15 | 202062 | 12308 | " Position Pin 01 |
| 204278 | 12309 | " " " Driving Gear | | 10 | 20057711 | 12311 | " Screw 02 |
| 200319c | 12309 | 11 (1 (1 (1 (1 (1 (1 (1 (1 (1 (1 (1 (1 (| | | | | |
| | | Hinge Screw | | 0.1 | | | |
| 200135c | 12309 | Thread Controller Spring Stop Screw | | 03 | | | |
| 204279 | 12309 | " " Stud with 204925 | | 10 | | | |
| 2003661 | 11902 | " " Set Serew. | | 02 | | | |
| 204925 | 12306 | " " Washer | | 01 | | | |
| 205987 | 12309 | Thread Controller complete, Nos. 200200c. | | | | | |
| | | 200581u, 202084, 202098, 204274, 201275 | | | | | |
| | | and 204333 | | 42 | | | |
| 204280 | 12309 | Thread Controller and Spring complete. | | | | | |
| | | Nos. 204276 and 205987 | | 45 | | | |
| 203313 | 12386 | Thread Guide | | 10 | | | |
| 204556 | 12386 | 46 44 | | 05 | | | |
| 204281 | 12309 | " Retainer Guide Wire | | 01 | | | |
| 202091 | 12309 | " " Sleeve | | 05 | | | |
| 202092 | 12309 | " " Spring | | 01 | | | |
| 20021000 | 1 200000 | E (1 12 C O | | • | | | 0.0 |

MACHINE No. 28 w 104

DROP FEED. ALTERNATING PRESSERS

For Tailoring.

In gauges from 3 to 2 inches.

The same as Machine No. 28 w 4 with the following exceptions:

| No. | Plate | Name | Each |
|---------|-------|--|------|
| *204497 | | Arm, in place of 204471 | \$ - |
| *204421 | | " 204497 with 200439c, 202036 and | |
| | | 201705, in place of 204117 | - |
| 213010 | 11901 | Arm Shaft, in place of 213001 | 2-00 |
| *213634 | | Bed, in place of 213138 | |
| *213681 | | " 213634 with 200840F, 202062, 202299. | |
| | | $= 203248, \ 213424, \ { m two-each} \ 200362c$ and | |
| | | 200516E, in place of 212892 | - |
| 201294 | 12346 | Feed Driving Rock Shaft, in place of | |
| | | 201199 | 35 |
| 206555 | | Feed Driving Rock Shaft 204294 with | |
| | | $= 200002 \mathrm{E}, \ 201522 \mathrm{E}$ and 204193, in place of | |
| | | 206554 | 80 |
| 213139 | 12346 | Hook Driving Shaft, in place of 213132 | 1.75 |
| 227312 | | Knee Lifter Connection Lever 202145 | |
| | | with 200224n, 200262n, 227303 and | |
| | | 227308, in place of 227311 | 50 |
| 227303 | 11125 | Knee Lifter Lifting Lever, in place of | |
| | | 227302 | 12 |

ACCESSORIES

FOR MACHINE NO. 28 W 1

| | , | OR MACHINE NO. 28 W 1 | |
|----------------------|-------|---|-------|
| No. | Plate | Name | Each |
| 2001578 | 14530 | Attachment Screw | \$ 05 |
| 203208 | 12312 | Bobbin (10) | 0.5 |
| 225497 | 12345 | " Case Screw Driver | 10 |
| 12×3 | - | Needles, six each, sizes 3 and 4. Per doz. | 20 |
| 225191 | | Drip Pan with four wood screws ½ in., No. 5 | 30 |
| 2007480 | 12319 | Machine Clamp Screw | 10 |
| 22558511 | 12319 | " " Washer | 02 |
| 201582в | | " " Wing Nut | 0.2 |
| 227488 | 12345 | Machine Clamp complete, Nos. 2007484, 201582n and 225585n | 90 |
| 11400 | 12345 | Machine Rest Pin (wood) | 04 |
| 36578 | 12345 | Oiler with 36579 | 10 |
| 36579 | 12345 | " Spout, 3 in, long | 0.6 |
| 225498 | 12345 | Screw Driver, 71 in, long | 15 |
| 225554 | 12345 | Wrench (steel) | 10 |
| | | VING AUTOMATIC RIGHT HAND | |
| 202470 | 12320 | Bobbin Winder Base | 15 |
| 202471 | 12320 | " " Frame | 15 |
| $200221 \mathrm{E}$ | 12319 | " " " Hinge Screw | 12 |
| 202472 | 12319 | " " " Spring | 05 |
| 200161E | 12319 | " " " Serew | 0.4 |
| 202473 | 12320 | " Pulley with 200380c | 20 |
| 200380c | 12319 | " " Set Serew | 02 |
| 202474 | 12320 | " "Spindle | 15 |
| 227522 | 12319 | " " Stop Latch | 10 |
| 2000566 | 12319 | " " Screw | 03 |
| 202477 | 12319 | " " " Thumb Lever | 15 |
| 200299н | 12319 | | |
| | | Hinge Serew | 05 |
| 200299н | 12319 | Bobbin Winder Stop Latch Thumb Lever Joint Screw | 05 |
| 201537н | 12319 | Bobbin Winder Stop Latch Thumb Lever Joint Screw Nut | 03 |
| 202478 | 12319 | Bobbin Winder Stop Latch Trip Lever | 10 |
| 20029911 | 12319 | " " " " " " " " " " " " " " " " " " " | 10 |

| No. | Plate | Name | Each | No. | Plate | Name | Each |
|---------------|--------|--|---------|-------------------|-----------------------|--|-----------------|
| 227523 | 12320 | Bobbin Winder complete, Nos. 2000560, | | *227785 | | Knee Litter Rock Lever Rod Cap or Oil | |
| | | 200161E, 200221E, 201537H, 202470 to | | | | Guard | |
| | | 202471, 202477, 202478, 227522, three 200299n and two round head wood | | 2005290 | . – | Knee Lifter Rock Lever Rod Set Screw | Uõ |
| | | screws 14 in. No. 11 | : 1 35 | | | r Knee Lifter Parts are listed with parts— nachine head.) | |
| 202480 | 12320 | Bobbin Winder Speel Holder Base with | , | | | months in the | |
| | | 200355н and 202484 | 15 | | | THREAD UNWINDER | |
| 202481 | 12320 | Bobbin Winder Spool Holder Base Spool | | 202486 | | Spool Pin | 03 |
| | | Pin | 05 | 202487 | | " Rest | 25 |
| 202482 | 12319 | Robbin Winder Spool Holder Tension | 02 | 202488 | 10278 | " 202487 with 200363c, 200383c | 2., |
| 200011E | 19916 | Disc (lower or upper) | 1/2 | | | and two 202486 | 35 |
| EU0011B | 12.11. | Disc Screw | 05 | 202489 | 10278 | Spool Rest Rod | 05 |
| 200355н | 12319 | Bobbin Winder Spool Holder Tension | | 200383c | 12311 | " " Set Serew | 02 |
| | | Disc Screw Set Screw | 03 | 200383c | 12311 | " " Set Screw | 02 |
| 202483 | 12319 | Bobbin Winder Spool Holder Tension | | 202490 202491 | $\frac{10278}{10278}$ | " Stand with 200383c" " Washer (steel) | $\frac{20}{02}$ |
| | | Disc Spring (brass) | 0.1 | 202492 | 10278 | " Weight with 202493 | 25 |
| 202484 | 12319 | Bobbin Winder Spool Holder Tension Disc Thread Guide | 0.1 | 202493 | | " Center with 202793 and 203163 | 10 |
| 202485 | 12320 | Bobbin Winder Spool Holder complete. | | 203163 | | " " " Bushing | 03 |
| | | Nos. 200011E, 202480, 202481, 202483, | | 202793 | 10278 | " "Thread Guide | 05 |
| | | two 202482 and one wood serew 1 in. | | 202794 200363e | $\frac{10278}{11935}$ | Thread Eyelet Rod | $\frac{15}{03}$ |
| | | No. 13u Some Helden annu | 35 | 202795 | 10278 | Thread Unwinder complete, Nos. 202488 | , |
| 227524 | * | Bobbin Winder and Spool Holder com- plete, Nos. 202485 and 227523 | 1 65 | | | to 202490, 202794, two each 202491, | |
| | | prett, 1808. 2021 by that 2210 by 11111 | • | | | 202492 and three wood screws 1 in. | |
| | | KNEE LIFTER | | | | No. 13 | 1 25 |
| 227781 | 11195 | Knee Lifter Rock Lever with 200522c | | | _ | COD MARQUINE NO. CO.W.4 | |
| | | and 200529c | 35 | | | OR MACHINE NO. 28 W 4 | |
| 227782 | | Knee Lifter Rock Lever 227781 with | | Same | as for | No. 28 w 4 with the following exceptions: | |
| | | two each 202451 and 202452 | | 203470 | 12268 | Bobbin (10), in place of 203208 | 06 |
| 227783 | 11125 | Knee Lifter Rock Lever 227782 with | | 6 x 3 | | Needles, four each, sizes 5, 6 and 7, in | , |
| | | 202985 and 227784 | | | | place of 12 n 3, six each, sizes 3 and 4. | |
| 202453 | 11125 | Knee Lifter Rock Lever Knee Plate with | | | | Per doz. | 20 |
| | | 200526c Distance Proceedings | | | | | |
| 202985 | | Knee Lifter Rock Lever Knee Plate 202453 with 202455 | 4.5 ** | | FO | OR MACHINE NO. 28 W 100 | |
| 909455 | 11195 | Knee Lifter Rock Lever Knee Plate Arm | | Same | as for | No. 28 w f with the following exceptions: | |
| 202455 | 11120 | (short) | 1.0 | 225181 | | Drip Pan with four wood screws ! in. | |
| 2005296 | 12319 | Knee Lifter Rock Lever Knee Plate Arm | | 220101 | | No. 5, in place of 225191 | 35 |
| 2,,,,,,,,,,,, | 12,71. | Set Screw | 06 | | | 200000000000000000000000000000000000000 | , |
| 200526c | 12321 | | | | | KNEE LIFTER | |
| | | Screw | | 227781 | 11195 | Knee Lifter Rock Lever with 200522c | |
| 202451 | 11125 | Knee Lifter Rock Lever Lug with two | | | 11760 | and 200529c | 35 |
| | | wood serews % in. No. 13H | | 227782 | | Knee Lifter Rock Lever 227781 with two | |
| 202452 | 12319 | | | | | each 202451 and 202452 | 50 |
| 227784 | 11125 | | uG | 227787 | | Knee Lifter Rock Lever 227782 with | 0.0 |
| | | with 227785 | | Sawina | 1 Ma | 202203 and 227784, in place of 227783 | 90 |
| | | From the library of: S | uperior | OEMII IG | j ivia | onine & Supply LLC | |

| No. | Plate | Name | Each |
|-----------------|---|---|------|
| 202453 | 11125 | Knee Lifter Rock Lever Knee Plate with 200526c | s 17 |
| 202203 | *************************************** | Knee Lifter Rock Lever Knee Plate 202453 with 202454 | 30 |
| 202454 | 11125 | Knee Lifter Rock Lever Knee Plate | 10 |
| 200522c | 12319 | Arm (long) | 12 |
| DO OND DO | 12010 | Arm Set Screw | 0.6 |
| 200526c | 12321 | Knee Lifter Rock Lever Knee Plate Set | |
| | | Screw | 05 |
| 202451 | 11125 | Knee Lifter Rock Lever Lug with two | |
| | | wood screws 3 in. No. 13H | 05 |
| 202452 | 12319 | Knee Lifter Rock Lever Lug Hinge Pin | 02 |
| 2 27784 | 11125 | " " " Rod. 3 in. long, | 06 |
| * 227785 | | Knee Lifter Rock Lever Rod Cap or Oil Guard | - |
| 200529c | 12319 | Knee Lifter Rock Lever Rod Set Screw | 05 |
| | (Other | Knee Lifter Parts are listed with parts | |
| | of m | achine head.) | |
| | FO | R MACHINE NO. 28 W 104 | |
| Same | as for | No. 28 w.1 with the following exceptions | : |
| 203470 | 12368 | Bobbin (10), in place of 203208 | 0.6 |
| 225181 | | Drip Pan with four wood screws ½ in. | 35 |
| 227787 | | No. 5, in place of 225191 | 90 |
| 6 N 3 | | Needles, four each, sizes 5, 6 and 7, in place of 12 n 3, 6 each, sizes 3 and 4 | |
| | | Per doz. | 20 |

FEED DOGS

| No. | Plate | | N | ame | | | E.a | ach |
|----------------|-------|---------|---------|---------|---------|---------------------------------------|-----|-----|
| 211769 | 11928 | Feed 1 | og, for | 211033 | and 21 | 1034 | \$ | 75 |
| 211770 | 11928 | ** | ** | 211033 | and 2 | 11034 | | 75 |
| 211882 | 12362 | ** | | 211880, | 211881. | 221342 and | | |
| | | 22134 | | | | | | 85 |
| 211883 | 12362 | Feed De | og, for | 211880, | 211881, | 221342 and | | |
| | | 2213- | 14 | | | | | 75 |
| 211886 | 12125 | Feed 1 | og, for | 211015, | 211016 | and 212070 | | |
| | | to 21 | 2072 | | | | ٠ | 75 |
| 211889 | 12125 | Feed I | og, for | 211887, | 211888 | and 211936 | | 85 |
| 211892 | 12126 | " | | 211890 | and 2 | 11891 | | 75 |
| 21189 3 | 12126 | f+ | ** | 211890 | and 2 | 11891 | | 75 |
| 211896 | 12126 | " | | 211894, | 211895 | , 211965 and | | |
| | | 21190 | ii | | | | | 7.5 |
| 211899 | 12127 | Feed 1 | og, for | 211967, | 211968 | , 212097 and | | |
| | | | | | | | | 0.0 |
| 211902 | 12127 | | - | | | and 21 20 73 | | |
| | | | | | | | | 0.0 |
| 211907 | 12127 | | | | | 1898 | 1 | 0.0 |
| 211914 | 12363 | " | | | | , 211970 and | | |
| | | | | | | | | 0.0 |
| 211954 | 11930 | | | | | | - | 0.0 |
| 211955 | 11929 | | | | | | | 0.0 |
| 211957 | 11929 | ** | | 211956 | | · · · · · · · · · · · · · · · · · · · | 1 | 0.0 |
| 211986 | 11930 | ** | | 211987 | | | | 85 |
| 212080 | 11931 | 4.4 | | 212081 | | 12094 | | 00 |
| 212082 | 11931 | ** | | 212081 | and 2 | 12094 | 1 | 0.0 |
| 221346 | 11936 | 4.4 | | 221347 | | | | 75 |
| 230983 | 11928 | *** | 14 14 | 221343 | and 2 | 30971 | | 60 |

NEEDLE HOLDERS

| No. | Plate | Name | Each |
|--------|-------|---|------|
| 231385 | 11935 | Needle Holder, in 7 in gauge, with 201030r and two 200141r\$ | 1 50 |
| 231386 | 11935 | Needle Holder, in gauges from 12 to 24 in., in steps of 25 in., with 2010/300 and | |
| | | two 200141F | 1 75 |

PRESSER FEET

FOR MACHINES NOS. 28 W 1 AND 28 W 100

| No. | Plate | Name | Each |
|--------|---------|---|--------------|
| 229107 | 11932 | Presser Foot, 46 needle hole, for needle | |
| | | sizes 5 to 7, in $\frac{\pi}{4}$ in, gauge | \$ 85 |
| 229108 | 13073 | Presser Foot, 46 needle hole, for needle | |
| | | sizes 5 to 7, in gauges from 35 to 1 | |
| | | in,, in steps of $\frac{1}{2^n}$ inch | 95 |
| 229110 | 13073 | Presser Foot, 46 needle hole, for needle | |
| | | sizes 5 to 7, in gauges from $1\frac{1}{22}$ to $1\frac{1}{2}$ | |
| | | in., in steps of $\frac{1}{32}$ inch | 1 25 |
| 229117 | 13075 | Presser Foot, 46 needle hole, for needle | |
| | | sizes 5 to 7, in gauges from $1\frac{17}{99}$ to 21 | |
| | | in,, in steps of 🚉 inch | 1.50 |
| 230795 | 11902 | Presser Foot Hinge Pin | 0.1 |
| 229203 | | " " Plate, for 229201 | 1 75 |
| 229205 | | | t 75 |
| 229207 | | | 1.75 |
| 229209 | | " " 229210 | 1 75 |
| 229213 | | | 1 75 |
| 229227 | | | 1 75 |
| 229229 | | 22,12,011 | 1 75 |
| 229271 | | 2010 (B | 1 75 |
| 229273 | | 227214 | 1 75 |
| 229317 | | ΔΔNο10 | 1 75 1 75 |
| 229319 | - | <u> </u> | 1 75 60 |
| 202923 | 4.00.00 | DHAID | 60 |
| 229204 | 13087 | Presser Foot (hinged) complete, 46 needle hole, for needle sizes 5 to 7, in | |
| | | in. gauge, Nos. 202923, 229203 and | |
| | | 230795 | 2 50 |
| | (0.007 | | 2 00 |
| 229206 | 13087 | Presser Foot (hinged) complete, 46 needle hole, for needle sizes 5 to 7, | |
| | | in gauges from \$\frac{25}{2}\$ to \$\frac{15}{2}\$ in., in steps | |
| | | of $\frac{1}{3}$ in. Nos. 202923, 229205 and | |
| | | 230795 | 2 50 |
| 900000 | 13088 | Presser Foot (hinged) complete, 46 | |
| 229208 | 19099 | needle hole, for needle sizes 5 to 7, | |
| | | in gauges 31 , 1 , 135 and $1\frac{1}{16}$ in. Nos. | |
| | | 202923, 229207 and 230795 | 2 50 |
| 229210 | 13088 | Presser Foot (hinged) complete, 46 | - ~, |
| 220210 | 1.5088 | needle hole, for needle sizes 5 to 7, | |
| | | in gauges from 1.3 to 11 in., in steps of | |
| | | J. in., Nos. 202923, 229209 and 230795 | 2 50 |
| | | (* 111., 1877), 202020, 220200 (HM 2001)00 | J. 199 |

| No. | Plate | Name | Each | FOR | MAC | HINES NOS. 28 W 4 AND 28 W 10 | 04 |
|----------------|--------|--|--------|--------|-------|---|-------------------|
| 229214 | 13089 | Presser Foot (hinged) complete, 46 | | No. | Plate | Name | Each |
| | | needle hole, for needle sizes 5 to 7, in gauges from $1\frac{a_2}{a_2}$ to $1\frac{a_3}{a_3}$ in., in steps of $\frac{1}{a_2}$ in., Nos. 202923, 229213 and 230795 | : 2 50 | 206682 | | Lifting Presser Foot, 35 needle hole, for needle sizes 12 to 14, in 3 in. gauge, for 229649 | 3 2 50 |
| 2 29228 | 11932 | Presser Foot (hinged) complete, 38 needle hole, for needle sizes 9 to 12, in ⁹ in, gauge, Nos. 202923, 229227 and 230795 | 2 50 | 206683 | 11960 | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from 3 to 14 in., in steps of $\frac{3}{22}$ in., for 206685 and 229649 | 3 00 |
| 229230 | 11932 | Presser Foot (hinged) complete, 38 needle hole, for needle sizes 9 to 12, in gauges from 1 \(^{9}_{32}\) to 1\(^{1}_{2}\) in., in steps | 2 00 | 206684 | | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from \mathfrak{T} to $\mathfrak{1}^1_4$ in., in steps of \mathfrak{I}^1_{32} in., for 206685 | 3 50 |
| 229272 | 11022 | of 3d in., Nos. 202923, 229229 and 230795 | 2 50 | 206686 | 11961 | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from $\mathbb{1}_{39}^{a_0}$ to $\mathbb{1}_{33}^{a_0}$ in., in steps of $\mathbb{I}_{2}^{a_0}$ in., for | |
| | 11.700 | needle hole, for needle sizes 5 to 7, in gauges $1\frac{15}{45}$, $1\frac{1}{2}$, $1\frac{1}{45}$ and $1\frac{1}{26}$ in. Nos. 202923, 229271 and 230795 | 2 50 | 206687 | 11962 | 229660 | 4 0 0 |
| 229274 | 11933 | Presser Foot (hinged) complete, 46 needle hole, for needle sizes 5 to 7, in gauges from 143 to 13 in., in steps of 33 in., Nos. 202923, 229273 and 230795 | 2 50 | 206688 | 11962 | 14 to 24 in., in steps of 42 in., for 206689 Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from 13 | 4 00 |
| 229318 | 11933 | Presser Foot (hinged) complete, 38 needle hole, for needle sizes 9 to 12, in gauges from \$\frac{25}{2}\$ to 1\frac{1}{16}\$ in., in steps of | 2 00 | 229648 | 11934 | to 24 in., in steps of $\frac{1}{32}$ in., for 206689 Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in 3 in. gauge, for 229649 | 4 50 1 2 50 |
| 229320 | 11932 | Presser Foot (hinged) complete, 28 needle hole, for needle sizes 9 to 12, | 2 50 | 229654 | | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges 3, 35. 13 and 35 in., for 229655 | 3 00 |
| | | in gauges from $1\frac{1}{30}$ to $1\frac{1}{4}$ in., in steps of $\frac{1}{30}$ in., Nos. 202923, 229319 and 230795 | 2 50 | 229659 | 11961 | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from $1\frac{a_1}{a_2}$ to $1\frac{a_3}{a_3}$ in., in steps of $\frac{1}{a_2}$ in., for 229660 | 3 75 |
| | | | | 229888 | 11934 | Lifting Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges 3, 35, 13 and 33 in., for 229655 | 3 00 |
| | | | | 206685 | 11960 | Vibrating Presser Foot, for 206683 and 206684 | 2 00 |
| | | | | 206689 | | Vibrating Presser Foot, for 206687 and 206688 | 3 75 |
| | | | | 229649 | | Vibrating Presser Foot, for 206682, 206683 and 229648 | 1 50 |
| | | | | 229655 | 11960 | Vibrating Presser Foot, for 229654 and 229888 | 2 00 |
| | | | | 229660 | 11961 | Vibrating Presser Foot, for 206686 and 229659 | 3 75 |

THROAT PLATES

FOR MACHINES NOS. 28 W 1 AND 28 W 100

Adapted for Hook Saddle Complete, No. 203545.

| No. | Plate | Name | Εa | ach |
|-----------|-------------|---|----|------------|
| 2110 | 15 12125 | Throat Plate, 50 needle hole, for needle | | |
| | | sizes 3 to 5, in gauges from 4 to $1\frac{3}{16}$ | | |
| | | in., in steps of $\frac{1}{30}$ in., for 211886\$ | 1 | 50 |
| 2110 | 16 12125 | Throat Plate, 46 needle hole, for needle | | |
| | | sizes 5 to 7, in gauges from 1 to 13 | | |
| | | in., in steps of $\frac{1}{2}$ in., for 211886 | 1 | 50 |
| 2110 | 33 11928 | Throat Plate, 50 needle hole, for needle | | |
| | | sizes 3 to 5, in gauges 7, 85, 17, 81 and | | |
| | | ξ in., for 211769 and 211770 | 1 | 50 |
| 2110 | 34 11928 | Throat Plate, 46 needle hole, for needle | | |
| | | sizes 5 to 7, in gauges 4, 44, 15, 44 and | - | F 0 |
| 2118 | 80 12362 | 7 in., for 211769 and 211770 | ı | 50 |
| 2118 | 80 12/16/2 | Throat Plate, 50 needle hole, for needle | | |
| | | sizes 3 to 5, in gauges from 7 to 14, | | |
| | • | in., in steps of $\frac{1}{32}$ in., for 211882 and | 1 | 50 |
| 2118 | 81 12362 | 211883 | r | |
| 4110 | OE 12004 | sizes 5 to 7, in gauges from $\frac{7}{5}$ to $1\frac{1}{16}$ | | |
| | | in_{s} in steps of $\frac{1}{2}$ in, for 211882 and | | ٠ |
| | | 211883 | 1 | 50 |
| 2213 | 42 12362 | Throat Plate, 40 needle hole, for needle | | •,,,, |
| ا ۱۰ سوسد | 12 12.002 | sizes 7 to 9, in gauges from ξ to 1_{18} | | |
| | | in., in steps of $\frac{1}{2}$ in., for 211882 and | | |
| | | 211883 | 1 | 50 |
| 2118 | 87 12125 | | | |
| | | sizes 3 to 5, in gauges from 1 to 1.8 | | |
| | | in., in steps of 45 in., for 211889 | 1 | 50 |
| 2118 | 88 12125 | • | | _ |
| | | sizes 5 to 7, in gauges from 1 to 1.3. | | |
| | | in., in steps of $\frac{1}{32}$ in., for 211889 | 1 | 50 |
| 2118 | 90 12126 | Throat Plate, 50 needle hole, for needle | | |
| | | sizes 3 to 5, in gauges from 12 to 11 | | |
| | | in., in steps of $\frac{1}{22}$ in., for 211892 and | | |
| | | 211893 | 1 | 50 |
| 2118 | 691 - 12126 | Throat Plate, 46 needle hole, for needle | | |
| | | sizes 5 to 7, in gauges from 15 to 11 | | |
| | | in., in steps of $\frac{1}{32}$ in., for 211892 and | | |
| | | 211893 | 1 | 50 |
| 2118 | 894 F2126 | | | |
| | | sizes 3 to 5, in gauges 11 and $1\frac{6}{32}$ in | | _ |
| | | for 211896 | | 50 |

Throat Plates

| 40 | | inroat Plates | | | | |
|--------|-------|--|-------------------|---------------|---------|--|
| No. | Plate | Name | Eacl | No. | Plate | Name Each |
| 211895 | | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges 1\(\frac{1}{2}\) and 1\(\frac{9}{2}\) in., for 211896 | -1-5 | 221347 | 11936 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges 1% and 1% in., for 221346 |
| 211897 | 12127 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 13 to 114 in., in steps of 42 in., for 211907 | 2 0 | (| | |
| 211898 | 12127 | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges from 13 to 115 in., in steps of 3.5 in., for 211907 | 2 0 | ſ | | |
| 211900 | 12127 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 1½ to 1½ in., in steps of ½ in., for 211902 | 2 0 | e | | |
| 211901 | 12127 | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges from 1½ to 118 in., in steps of ½ in., for 211902 | 2 0 | c | | |
| 211913 | 12363 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 145 to 2½ in., in steps of 75 in., for 241914 and 241954 | 2 0 | 0 | | |
| 221341 | 12363 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 1\frac{15}{2} to 2\frac{1}{4} in., in steps of \frac{1}{2} in., for 211914 | 2 0 | 0 | | |
| 211936 | 12125 | Throat Plate, 40 needle hole, for needle sizes 7 to 9, in gauges from 1 to $1\frac{9}{32}$ in., in steps of $\frac{1}{32}$ in., for 211889 | 1 5 | 0 | | |
| 211956 | 11929 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges 17, 115 and 2 in., for 211955 and 211957 | 2 0 | e FOR | MAC | HINES NOS. 28 W 4 AND 28 W 104 |
| 211987 | 11930 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 1.3 to 1.5 at these | 1.5 | | Adapted | for Hook Saddle Complete, No. 203656. |
| 212081 | 11931 | in., in steps of 4_3 in., for 211986 Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges $2\frac{\pi}{10}$, $2\frac{\pi}{20}$ and $2\frac{\pi}{4}$ | 1.5 | 211965 | 11927 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges 14 and 1 3 in., for 211896 |
| 212094 | 11931 | in., for 212080 and 212082 | 2 0 | 211966 | 11927 | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges 11 and 1.2 in., for 211896 |
| 212097 | 11930 | in., for 212080 and 212082 | $\frac{2}{2} = 0$ | 211967 | 11927 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 1% to 114 |
| 040000 | 14000 | sizes 3 to 5, in gauges from 13 to 113 in., in steps of 22 in., for 211899 Throat Plate, 46 needle hole, for needle | 2 0 | 0 211968 | 11927 | in., in steps of 45 in., for 211899 2 00 Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges from 13 to 144 |
| 212098 | 11930 | sizes 5 to 7, in gauges from $1\frac{9}{8}$ to $1\frac{11}{8}$ in., in steps of $\frac{1}{8}$ in., for 211899 | 2 0 | 0 211969 | 11926 | in., in steps of $\frac{1}{2}$ in., for 211899 2 00 Throat Plate, 50 needle hole, for needle |
| 221343 | 11928 | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in 3 in. gauge, for 230983 | 1 2 | 5 211970 | 11996 | sizes 3 to 5, in gauges 17, 133, 145, 134 and 2 in., for 211911 |
| 230971 | 11928 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in § in. gauge, for 230983 | | 5 | | sizes 5 to 7, in gauges 13, 133, 113, 133 and 2 in., for 211914 |
| | | From the library of: S | upe | endi Sewing i | viacili | THE & Supply LLC |

| No. | Plate | Name | Eacl |
|----------------|-------|--|------|
| 212070 | 12137 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 4 to 1% in., in steps of 3. in., for 211886 | 1 50 |
| 212071 | 12137 | Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges from 1 to 1 \(\frac{3}{3}\), in., in steps of \(\frac{1}{3}\); in., for 211886 | 1 50 |
| 212072 | 12137 | Throat Plate. 40 needle hole, for needle sizes 7 to 9, in gauges from 1 to $1\frac{1}{16}$ in., in steps of $\frac{1}{2}$ in., for 211886 | 1 50 |
| 212073 | 12137 | Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from 1½ to 113 | |
| 212074 | 12137 | in, in steps of 4. in, for 211902 Throat Plate, 46 needle hole, for needle sizes 5 to 7, in gauges from 1½ to 113 | 2.30 |
| 212075 | 12137 | in., in steps of $\frac{1}{12}$ in., for 211902 Throat Plate, 40 needle hole, for needle sizes 7 to 9, in gauges from $\frac{1}{12}$ to $\frac{1}{13}$ | 2 00 |
| 2 21344 | 11926 | in., in steps of $\frac{1}{2}$, in., for 211902 Throat Plate, 50 needle hole, for needle sizes 3 to 5, in gauges from $\frac{3}{4}$ to $\frac{1}{4}$. | 2 00 |
| | | in., in steps of ½, in., for 211882 and 211883 | 1 50 |

LAP SEAM FELLERS

| which | n ordering Lap Seam Fellers, give letter refers to material to be used, in addi- number. |
|--------|--|
| F | Silks, fine muslins, etc., where there are no seams. |
| 1. | Fine shirts, underwear, corsets, etc. |
| M | General shirt and corset work, etc. |
| МН | Heavy corset and other medium heavy material, |
| H | Heavy shirt work, light overalls, etc. |
| XH | Overall and duck work. |
| XXH | Heavy duck and canvas work. |
| HXXX | Horse blankets, etc. |
| HXXXXX | Extra heavy material with seams. |

| No. | Plate | Name | Each |
|--------|-------|--|--------|
| 230043 | 11963 | Lap Seam Feller on Shank (right hand). For ^a to 1 in, gauge machines. For H. XH, XXH or XXXH material. Has no yielding spring | 3 40 |
| 230044 | 11849 | Lap Seam Feller on Shank (left hand). For ^a to 1 in, gauge machines. For II, XII, XXII or XXXII material. Has no yielding spring | 3 40 |
| 230045 | 11849 | Lap Seam Feller on Shank (left hand). For ? to 1! in, gauge machines. For M. MH, H, XH, XXH, XXXH or XXXXH material. Has no yielding spring | 3 40 |
| 230046 | 11963 | Lap Seam Feller on Shank (right hand). For \(^3\) to \(^1\) in, gauge machines. For \(^3\), MH, H, XH, XXH, XXXH or XXXXH material. Has no yielding spring. | 3 40 |
| 230047 | 11851 | Lap Seam Feller on Shank (left hand). For general work. For 7 to 1 in. gauge machines. For F. L. M. MH or H material. Has yielding spring | 3 40 |
| 230048 | 11851 | Lap Seam Feller on Shank (right hand). For general work. For 7 to 1 in. gauge machines. For F. L. M. MH or H material. Has yielding spring | . 3 40 |
| 230055 | 11851 | Lap Seam Feller on Shank (left hand). For general work. For 7 to 1 in. gauge machines. For XII, XXII or XXXII material. Has yielding spring | 3 40 |

| No. | Plate | Name | Eacl |
|--------|-------|---|------|
| 230056 | 11961 | Lap Seam Feller on Shank (right hand). For general work. For ? to 1 in. gauge machines. For XII, XXII or XXXII material. Has yielding spring | |

PRESSER FOLDERS

| No. | Plate | Name | Each |
|----------------|-------|---|--------------|
| 230129 | 11965 | Strip Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from $\frac{\pi}{4}$ to $1\frac{1}{4}$ in., in steps of $\frac{\pi}{4}$, in., folds and lays a strip | 3 50 |
| 230137 | 11965 | Strip Presser Foot, 16 needle hole, for needle sizes 5 to 7, in gauges from $\frac{\pi}{4}$ to 1_{\pm}^{4} in., in steps of $\frac{\pi}{4}$, in., folds and lays a strip and inserts a puckering | |
| 230138 | 14965 | string at one operation Strip Presser Foot, 46 needle hole, for needle sizes 5 to 7, in gauges from 7 to 11 in., in steps of 45 in., folds and | |
| 22 1345 | | lays a strip Strip Presser Poot, 46 needle hole, for needle sizes 5 to 7, in gauges from 1.2, to 21 in., in steps of 21 in., folds and lays a strip | 3 50 4 50 |

LAP SEAM GUIDE

Note: State gauge of Machine, weight of material to be used and if seams are to be crossed.

Each

Name

| | | | | 140. | Flate | Wallie |
|---------------------------------|---------------------------|---|------------------|----------------|--------------|---|
| 5 | HIR | RT FACING FOLDERS | | 231243 | | Shirt Facing Folder Arm Bracket com- plete, Nos. 2002688, 2015314, 226467, 230016, 230025, two each 2001578, 2001618 and 2015398 |
| N. a | Dista | A1 | Eacl | 231256 | | Shirt Facing Folder Arm Bracket com- |
| No. 230020 | Plate 11910 | Name Shirt Facing Folder (upper) with 230026, folds both edges of the upper strip | Eacr | 2.11 2.111 | | plete, Nos. 200268B, 201531E, 226467, 230016, 230102, two each 200157B, 200164B and 201539E |
| 231281 | 11910 | under | 1.77 | 23128 2 | | Shirt Facing Folder and Bracket complete, for folds from 3 to 31 in., Nos. |
| 230016 | 14530 | upper strip under | 5 7. | 231283 | | 230018, 230020 and 231241 |
| 200157B 201539r | 14530 11935 | 200174b, 200336b and 201537b | 1 00 01 | 231284 | | 230018, 230020 and 231242 |
| *230026 | | Nut | 0 7: | 231287 | | plete, for folds from 145 to 242 in., Nos. 230018, 230020 and 231243 11 50 Shirt Facing Folder and Bracket com- |
| 230017 230024 230025 | 1 1530 1 1530 14530 | " " Lever | 77 77 | | | plete, for folds from 1 to 143 in., Nos. 230018, 231242 and 231281 12 50 |
| $\frac{230102}{200336}_{\rm D}$ | $\frac{11910}{14530}$ | " " " " Adjust- | ĩ. | 231285 | | Shirt Facing Folder and Bracket complete, for folds 2\frac{1}{2} in, and wider, Nos. 230018, 230020 and 231256 |
| 201537E | 12319 | ing Screw | 0 ; | 201286 | - | Shirt Facing Folder and Bracket complete, for folds from \$ to \$1 in., Nos. |
| | | Shirt Facing Folder Bracket Lever Hinge Screw | 1€ | 231288 | | 230018, 231241 and 231281 |
| 201531E 226467 | | Shirt Facing Folder Bracket Lever Hinge Serew Nut | 0.7 | 231289 | | Nos. 230018, 231243 and 231281 12 50 Shirt Facing Folder and Bracket com- |
| 2001740 | | Screw Spring Washer Shirt Facing Folder Bracket Lever Stop | 05 | | | plete, for folds 2\frac{1}{2}\text{ in, and wider, Nos} \\ 230018, 231256 and 231284 \tag{12.50} \\ \text{12.50} \\ \text{23.0018} \text{ Policy Folder and Disablet con} \end{cases} |
| 200164B | | Shirt Facing Folder Bracket Lover Screw | 0; 0 <u>;</u> | 231290 | | Shirt Facing Folder and Bracket com- plete, for folds from \(\frac{2}{3}\) to \(\frac{21}{3}\) in. Nos. 230021, 231241 and 231281 13 00 |
| 230018 | | Strip Folder (lower) with 230029, folds both edges of the under strip over Strip Folder (lower) with 230031 and | 4 5€ | 231291 | | Shirt Facing Folder and Bracket complete, for folds from 4 to 1¼ in., Nos. |
| Z.M.V.Z.Y | 11.1. | 230032, folds both edges of the under strip over | 5 00 | 231292 | | 230021, 231242 and 231281 |
| *230031 *230032 | | Strip Folder Cloth Guide | 11 | 231293 | | Nos. 230021, 231243 and 231281 13 00 Shirt Facing Folder and Bracket com- |
| 230029 2 31241 | 11910 | Shirt Facing Folder Arm Bracket complete, Nos. 200268r. 201531r. 226467, 230016, 230017, two each 200157r. | | 2.7.2 | | plete, for folds 244 in, and wider, Nos. 230021 231256 and 231281 13 00 |
| 231242 | | 200164n and 201539n Shirt Facing Folder Arm Bracket com- plete, Nos. 200268n, 201531n, 226467, 230016, 230024, two each 200157n, | 2 2. | | | |
| | | From the library of: Supe | rior Se | ewing M | achir | ne & Supply LLC |

No.

Plate

225980

STRIP REELS Suspended under the Bench with Latch which permits the Reels to be brought forward for placing the Roll of Strip into position. No. Plate Name Each 226198Strip Reel Disc (9 in. diam.), with 225980 and three 225667 \$ 30 Strip Reel Disc Base 225980225667 11862 Rivet 0.1 22720411863 Rod 10 227205 11862 Clamp with two 200530c 20 200530c - 12321Strip Reel Disc Rod Clamp Set Screw 05 227116 11862.. Collar 06 " 227116 with 227210 11862 200731i: and 227327 20 200731E11862Strip Reel Disc Rod Collar Wing Screw 12 " " Tension Spring 22732711862 (spiral) 02Strip Reel Supporting Rod 227214 1186325 22721511863 ** Bracket (right), with two wood screws 1 in., No. No. 13 10 227203 11862 Strip Reel Supporting Rod Latch Bracket with two wood screws 1 in. No. 13 15 227223 11862 Strip Reel Supporting Rod Latch Bracket Spring (spiral) 05 11862 Strip Reel Supporting Rod Latch 227224 Bracket Spring Collar with 200380c... 10 200380c 12319 Strip Reel Supporting Rod Latch Bracket Spring Collar Set Screw 02200530c - 12321Strip Reel Supporting Rod Set Screw... 05 22720711863 Strip Reel complete, Nos. 227203 to 227205, 227214, 227215, 227223, 227224, two 227210 and four 226198 2 50 STRIP REELS Attached to the top of the Arm. 226199 Strip Reel Disc (6 in. diam.), with 225980 and three 225667 25

-- Strip Real Disc (9 in, diam.), with 225980

-- Strip Reel Disc Base

and three 225667

| No. | Plate | Name | Each |
|---------------------|-------|--|-------|
| 225667 | 11862 | Strip Reel Disc Base Rivet | \$ 01 |
| 227113 | 11863 | " " " Rod (lower), with Strip | |
| | | Guide | 20 |
| 227115 | 11863 | Strip Reel Disc Rod (upper), with Strip | |
| | | Guide | 20 |
| 227116 | 11862 | Strip Reel Disc Rod Collar | 06 |
| 227210 | 11862 | " " " 227116 with | |
| | | 200731E and 227327 | 20 |
| 200731ε | 11862 | Strip Reel Disc Rod Collar Wing Screw | 12 |
| $200530 {\rm E}$ | 12321 | " " " Set Screw | 65 |
| 227327 | 11862 | " " " Tension Spring | |
| | | (spiral) | 02 |
| 227108 | 11863 | Strip Reel Support with two 200530c | 60 |
| 200017E | 11862 | " " Serew | 90 |
| 227212 | 11863 | Double Strip Reel complete, Nos 200017E. | |
| | | 227108, 227113, 227115, two each 226198, | |
| | | 226199 and 227210 | 2 50 |

UNDER DRIVER


Ball Bearing, Right Hand, Round Belt, Two Speed.


| No. | Plate | Name | Eacl |
|---------|--------|---|------|
| 227370 | 11126 | Cone Pulley (grooved), two speed, 4% in. | |
| | | and 5½ in belt diams, with 227550\$ | 1 30 |
| 25362 | 12321 | Cone Pulley Ball, size % inch | 0; |
| 204100 | 12321 | " " " Bearing Cup | 1. |
| 204101 | 12321 | " " " Cap | 0; |
| 204102 | 12321 | " " Retaining Spring | 0: |
| 227553 | 12322 | Cone Pulley Ball Cup complete, Nos. | |
| | | 204100 to 204102 and thirteen 25362 | 41 |
| 202459 | 11126 | Driving Pulley, 71 in. diam., with 202400 | |
| | | and 204105 | - · |
| 202460 | 11126 | Driving Pulley Friction Ring (leather) | 01 |
| 204105 | 12321 | " Stop Pin | 0.1 |
| 227743 | | " " Shaft (hollow), with | |
| | | 204109, 204110, 204112 and two 204111. | 60 |
| 202461 | 11126 | Driving Pulley Shaft 227743 with 204107. | |
| | | 204108 and eleven 25303 | 1 00 |
| 25303 | 12321 | Driving Pulley Shaft Ball, size \ inch | 03 |
| 204107 | 12321 | " " " " " Cup, | 18 |
| 204108 | 12321 | " " Cap | 05 |
| 204109 | | " " " Oil Plug | 04 |
| 204110 | | *************************************** | 02 |
| 204111 | | Pin | |
| | | (leather) | 01 |
| 204112 | 12322 | Driving Pulley Shaft Oiling Wick | 0.1 |
| 200524c | 12321 | " Set Screw | 06 |
| 201113 | 12321 | " "Thimble | 10 |
| 227734 | 11126 | Frame with 200524c | 80 |
| 202463 | 11126 | Lever (compression) with 204117, two | |
| | | each 200524c and 202845 | 15 |
| 227735 | 11126 | Lever Brake with 200524c, 204122 and | |
| | | two 200374c | 35 |
| 227736 | 11126 | Lever Brake 227735 with 200082b and | |
| | | 227707 | 60 |
| 227737 | 11126 | Lever Brake Belt Guard | 90 |
| 2000826 | 12321 | " " Serew | 03 |
| 204122 | 12322 | " Leather | 0.5 |
| 200374c | 12321 | " Set Screw | 02 |
| 200524c | 12321 | " Set Serew | 06 |
| 204123 | 12322 | " Spring | 05 |
| 204117 | 12321 | " Compression Plate | 10 |
| 202845 | 12321 | 6 Rivet | 01 |
| 202343 | 11126 | " " Shaft with 202302 | 20 |
| -0-191 | 11(20) | ************************************** | 0 |

| No. | Plate | Name | Each |
|--------------------|--------|---|-------|
| 202302 | 12321 | Lever Compression Shaft Cotter Pin | \$ 01 |
| 200524c | 12321 | " Set Serew | 06 |
| 27070 | 11126 | Shaft Pulley (sectional grooved), 10 in. | |
| | | diam., $1 \frac{a}{16}$ in, bore, with two $597c$ | 45 |
| 597c | 11862 | Shaft Pulley Clamping Screw | 08 |
| 227976 | 11126 | Treadle with 200540p | 45 |
| 227977 | 11126 | " 227976 with 227978 | 60 |
| 227978 | 11126 | " Adjustable Connecting Slide | 15 |
| $200540\mathrm{p}$ | 11862 | "Set | |
| | | Serew | 10 |
| 202468 | 11126 | Treadle Pitman Rod (lower or upper) | 05 |
| 204126 | 12321 | " " " Clamp with two | |
| | | 200530c | 20 |
| 200530c | 12321 | Treadle Pitman Rod Clamp Set Screw | 05 |
| 227980 | 11126 | Treadle Pitman complete, Nos. 204126 | |
| | | and two 202168 | 30 |
| 204127 | -11126 | Treadle Stand (left), with two wood | |
| | | serews 1 in. No. 13 | 08 |
| 204128 | 11126 | Treadle Stand (right), with two wood | |
| | | serews 1 in. No. 43 | 08 |
| 227981 | | Treadle and Stand complete, Nos. 204127, | |
| | | 204128 and 227977 | 75 |
| 227982 | | Treadle and Pitman complete, Nos. | |
| | | 227980 and 227981 | 90 |
| 227740 | | Transmitter complete, Nos. 202459, | |
| | | 202461, 202463, 202464, 204413, 204423, | |
| | | 227370, 227734, 227736 and three wood | |
| | | serews 1 ³ in. No. 15 | 3 00 |
| 227985 | | | |
| | | sure, right hand, two speed complete, | |
| | | Nos. 27070, 227740 and 227982 | (00 |
| | | | |

OBSOLETE PARTS

| No. | Plate | Name | Each |
|---------|--------|---|-----------|
| *213605 | | reed thirting claim took there where | |
| | | Block | \$ - |
| *213604 | | Tive Parring valle Fork 13 ver conte | |
| | | Block with 200116c | |
| 213606 | 13041 | Feed Driving Cam Fork Lever Slide Block 213604 with 213605 | 36 |
| 000050 | 1.1007 | | • > 1. |
| 203250 | 11007 | Hook Driving Shaft Collar with two | 20 |
| | | 200393e | 20 |
| 204870 | 12346 | Needle Bar (hollow) | 80 |
| 203705 | 12364 | " Holder, in a in gauge, with | |
| | | 200068n and two 200141F | 1 50 |
| 203706 | 12350 | Needle Holder, in gauges from 👸 to 113 | |
| | | in., in steps of \pm in., with 200068 π | |
| | | and two 200141F | 1.75 |
| 203707 | 12364 | Needle Holder, in gauges from 2 to $2\frac{1}{4}$ | |
| | | in., in steps of $\frac{1}{10}$ in., with 20006811 | |
| | | and two 200141F | 2^{-00} |
| 215612 | | Vibrating Presser Bar | 15 |
| 204489 | 13041 | " " 215612 with 204493 | |
| | | and two 200138b, for Machines Nos. | |
| | | 28 w 4 and 28 w 104 | 60 |
| 215628 | | Vibrating Presser Bar | 15 |
| 204488 | 13041 | " " 215618 with 201493 | |
| | | and two 200138b, for Machines Nos. | |
| | | 28 w 4 and 28 w 104 | 60 |
| 204492 | 13041 | Vibrating Presser Bar Position Guide, | |
| | | for Machines Nos. 28 w 4 and 28 w 104 | 30 |













PLATE 11126-ONE-SIXTH SIZE






























































































PLATE 12306-FULL SIZE
























































PLATE 12376-FULL SIZE

