

## **Leak Testing**

Last Updated: January 13 2025



**Leak Found** 

**Leak Fixed** 

- 1. Make soapy water using soap WITHOUT oils or animal fat. If soap with fat or oils is used, it could create a fire hazard
- 2. Soak a clean cloth in the soapy water and wring it out on the piping joint. Or pour the soapy water directly on the piping joint.
- 3. If there is an air or oxygen leak, the soap will start to bubble up.
- 4. If there is a leak, tighten the union and do the soapy water test again until no more bubbles form.