SoundSphere Pro X User Manual


SoundSphere Pro X

Table of Contents

1. Introduction
2. Getting Started
3. Product Overview
4. Technical Specifications
5. Setup and Pairing
6. Basic Operation
7. Active Noise Cancellation
8. Touch Controls
9. Audio Features
10. Voice Assistant Integration
11. Mobile App
12. Battery and Charging
13. Care and Maintenance
14. Troubleshooting
15. Warranty Information
16. Contact Support

Introduction

Thank you for purchasing the SoundSphere Pro X wireless noise-cancelling headphones by AudioLux. Engineered for audiophiles and designed for everyday use, these premium headphones combine cutting-edge active noise cancellation technology with high-fidelity sound reproduction to deliver an unparalleled listening experience. This user manual will guide you through the setup, operation, and maintenance of your new headphones to ensure you get the most out of your audio journey.

Getting Started

Package Contents

- SoundSphere Pro X wireless headphones
- Premium carrying case
- USB-C charging cable
- 3.5mm audio cable
- Airplane adapter
- Quick start guide
- This user manual

Before First Use

1. Remove the headphones from the packaging
2. Fully charge the headphones before initial use (approximately 2 hours)

3. Download the AudioLux Connect app from the App Store or Google Play Store
4. Remove any protective films from the headphones

Product Overview


SoundSphere Pro X Components

1. Adjustable headband
2. Memory foam ear cushions with protein leather covering
3. Touch control panel (right ear cup)
4. USB-C charging port
5. 3.5mm audio jack
6. Power/Bluetooth button
7. ANC mode button
8. LED indicators
9. Microphone array (8 microphones)
10. 40mm beryllium drivers (internal)

Technical Specifications

Feature	Specification
Driver	40mm beryllium dynamic drivers
Frequency Response	5Hz - 40kHz (Hi-Res Audio certified)
Noise Cancellation	Hybrid ANC with 3 modes (Max, Adaptive, Transparency)
Battery Life	40 hours (ANC on), 60 hours (ANC off)
Quick Charge	5 minutes charge for 5 hours playback
Bluetooth	Bluetooth 5.3, multipoint connection (2 devices)
Audio Codecs	SBC, AAC, aptX, aptX HD, LDAC
Microphones	8 microphones (4 for ANC, 4 for calls with beamforming)
Controls	Touch controls, voice assistant compatible (Google, Alexa, Siri)
Materials	Aluminum frame, protein leather, memory foam cushions
Weight	285g
Water Resistance	IPX4 splash resistant

Setup and Pairing

Initial Setup

1. Ensure your headphones are charged
2. Press and hold the Power/Bluetooth button for 3 seconds to turn on the headphones
3. When powering on for the first time, the headphones will automatically enter pairing mode
4. The LED indicator will flash blue rapidly to indicate pairing mode

Pairing with a Smartphone

1. On your smartphone, go to Settings > Bluetooth and ensure Bluetooth is turned on
2. Look for "SoundSphere Pro X" in the list of available devices
3. Tap to connect
4. Once connected, the LED indicator will show a solid blue light
5. A voice prompt will confirm "Connected"

Multipoint Connection

The SoundSphere Pro X can connect to two devices simultaneously.

To set up multipoint connection:

1. Pair with your first device as described above
2. Once connected, press and hold the Power/Bluetooth button for 5 seconds to re-enter pairing mode
3. Pair with your second device
4. Both devices are now connected to your headphones

To switch between connected devices:

1. Pause audio on the current device
2. Play audio on the second device

Wired Connection

For high-resolution audio or when battery power is unavailable:

1. Connect the included 3.5mm audio cable to the headphone jack
2. Connect the other end to your audio source
3. The headphones will work in passive mode without power, but ANC and touch controls require battery power

Basic Operation

Power On/Off

- **Power On**: Press and hold the Power/Bluetooth button for 3 seconds
- **Power Off**: Press and hold the Power/Bluetooth button for 3 seconds

Volume Control

- **Increase Volume**: Swipe up on the right ear cup touch panel
- **Decrease Volume**: Swipe down on the right ear cup touch panel

Playback Control

- **Play/Pause**: Double-tap the right ear cup touch panel
- **Next Track**: Swipe forward on the right ear cup touch panel
- **Previous Track**: Swipe backward on the right ear cup touch panel

Call Management

- **Answer Call**: Double-tap the right ear cup when a call is incoming
- **End Call**: Double-tap the right ear cup during a call
- **Reject Call**: Press and hold the right ear cup touch panel for 2 seconds when a call is incoming
- **Mute/Unmute**: Triple-tap the right ear cup during a call

Active Noise Cancellation

The SoundSphere Pro X features advanced hybrid active noise cancellation with three distinct modes to suit different environments.

ANC Modes

- **Max Mode**: Maximum noise cancellation for loud environments like airplanes or busy offices
- **Adaptive Mode**: Automatically adjusts noise cancellation level based on your environment
- **Transparency Mode**: Allows ambient sound to pass through, ideal for conversations or awareness of surroundings


Switching Between Modes

1. Press the ANC mode button once to cycle between modes
2. A voice prompt will announce the current mode
3. Alternatively, use the AudioLux Connect app for more customization options

Adaptive ANC Technology

The SoundSphere Pro X uses 8 strategically placed microphones to analyze and cancel ambient noise:

- External microphones detect incoming noise
- Internal microphones monitor the sound reaching your ears
- Advanced DSP algorithms create inverse sound waves to cancel noise
- Real-time adjustment based on environmental changes and fit


ANC Technology Diagram

Touch Controls

The right ear cup features a touch-sensitive panel for intuitive control of your audio experience.

Touch Gestures

- **Tap twice**: Play/pause music or answer/end calls
- **Swipe forward**: Skip to next track
- **Swipe backward**: Return to previous track
- **Swipe up**: Increase volume
- **Swipe down**: Decrease volume
- **Press and hold (2 seconds)**: Activate voice assistant
- **Cover entire ear cup with palm**: Quick conversation mode (temporarily enables transparency mode and lowers volume)

Customizing Touch Controls

Touch controls can be customized through the AudioLux Connect app:

1. Open the AudioLux Connect app
2. Go to "Device Settings" > "Controls"
3. Select the gesture you want to customize
4. Choose your preferred function from the available options
5. Tap "Save" to apply changes

Audio Features

Sound Profiles

The SoundSphere Pro X offers multiple sound profiles to enhance your listening experience:

- **Balanced** (default): Accurate, neutral sound reproduction
- **Bass Boost**: Enhanced low frequencies for bass-heavy music
- **Vocal Clarity**: Enhanced mid-range for podcasts and vocals
- **Spacious**: Wider soundstage for an immersive experience
- **Custom EQ**: Create your own sound profile with the 10-band equalizer in the app

To change sound profiles:

1. Open the AudioLux Connect app
2. Go to "Sound" > "Sound Profiles"
3. Select your preferred profile or create a custom one

Hi-Res Audio

The SoundSphere Pro X is Hi-Res Audio certified, capable of reproducing frequencies up to 40kHz:

- For optimal Hi-Res Audio performance, use the included 3.5mm cable with a compatible Hi-Res Audio source
- When using Bluetooth, enable LDAC or aptX HD codec in the AudioLux Connect app for the highest wireless audio quality

Spatial Audio

Experience immersive 360° sound with the spatial audio feature:

1. Open the AudioLux Connect app
2. Go to "Sound" > "Spatial Audio"
3. Toggle the feature on
4. Select your preferred spatial audio mode (Movie, Music, or Game)

Voice Assistant Integration

The SoundSphere Pro X works seamlessly with popular voice assistants.

Activating Voice Assistant

- Press and hold the right ear cup touch panel for 2 seconds
- Wait for the confirmation tone before speaking your command

Compatible Voice Assistants

- Apple Siri (iOS devices)
- Google Assistant (Android devices)
- Amazon Alexa (requires Alexa app installation)

Setting Up Amazon Alexa

1. Open the AudioLux Connect app
2. Go to "Voice Assistant" > "Amazon Alexa"
3. Follow the on-screen instructions to link your Amazon account
4. Once set up, you can activate Alexa by pressing and holding the touch panel

Mobile App


The AudioLux Connect app enhances your SoundSphere Pro X experience with additional features and customization options.

App Features

- Firmware updates
- Battery status monitoring
- Custom EQ settings
- ANC customization
- Touch control customization
- Find My Headphones
- Sound profile selection
- Voice assistant preferences
- Auto-pause settings
- Spatial audio configuration

Downloading the App

1. Search for "AudioLux Connect" in the App Store (iOS) or Google Play Store (Android)
2. Download and install the app
3. Open the app and follow the setup instructions
4. Ensure your headphones are powered on and nearby during setup

 App Interface

Battery and Charging

Battery Life

- Up to 40 hours with ANC enabled
- Up to 60 hours with ANC disabled
- Actual battery life may vary depending on volume level and usage

Charging Instructions

1. Connect the USB-C end of the charging cable to the headphones
2. Connect the other end to a USB power source
3. The LED indicator will glow red during charging
4. When fully charged, the LED will turn green

Quick Charge

A 5-minute charge provides up to 5 hours of playback time when battery is low.

Battery Status

- Check battery status via the AudioLux Connect app
- Press the Power button briefly when headphones are on to hear a voice prompt with the current battery level
- LED indicator will flash red when battery is low


Care and Maintenance

Cleaning

- Wipe the headphones with a soft, slightly damp cloth
- For ear cushions, use a dry cloth with a small amount of mild soap if necessary
- Allow to dry completely before use
- Do not use alcohol, solvents, or harsh cleaning agents

Storage

1. Turn off the headphones when not in use
2. Fold the headphones as shown in the diagram below
3. Store in the provided carrying case
4. Keep in a cool, dry place away from direct sunlight


Folding Instructions

Ear Cushion Replacement

Ear cushions should be replaced every 12-18 months depending on usage:

1. Gently grip the edge of the ear cushion
2. Pull outward to detach from the ear cup
3. Align the new ear cushion with the ear cup
4. Press firmly around the edges until it snaps into place

Replacement ear cushions can be purchased from audiolux.com or authorized retailers.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Headphones won't turn on	Battery depleted	Charge the headphones for at least 10 minutes
No sound	Volume too low, incorrect source, or connection issue	Check volume, ensure correct audio source is selected, reconnect Bluetooth
Can't pair with device	Bluetooth issue or headphones not in pairing mode	Restart both devices, ensure headphones are in pairing mode
Poor sound quality	Codec issue or interference	Check codec settings in app, move away from sources of interference
ANC not working effectively	Poor fit or firmware issue	Ensure proper fit, update firmware via app
Touch controls unresponsive	System error	Restart headphones, ensure hands are dry
Battery draining quickly	ANC always on or high volume	Use ANC only when needed, lower volume
Intermittent connection	Interference or distance issue	Stay within 30ft/10m of device, avoid obstacles

Factory Reset

If you experience persistent issues, perform a factory reset:

1. Turn off the headphones
2. Press and hold both the Power/Bluetooth button and ANC mode button for 10 seconds
3. The LED will flash purple three times
4. The headphones will power off and reset to factory settings
5. You will need to pair your devices again

Firmware Updates

Keeping your firmware updated ensures optimal performance and access to the latest features.

To update firmware:

1. Open the AudioLux Connect app
2. Go to "Device Settings" > "Firmware Update"
3. If an update is available, tap "Download and Install"
4. Keep the headphones connected to your device during the update
5. Do not turn off the headphones during the update process

Warranty Information

The SoundSphere Pro X comes with a 2-year limited warranty covering defects in materials and workmanship under normal use. For warranty service, contact AudioLux customer support with your proof of purchase.

What's Covered

- Manufacturing defects
- Battery performance issues
- Electronic component failures
- Material defects

What's Not Covered

- Normal wear and tear
- Water damage beyond IPX4 rating
- Accidental damage
- Unauthorized repairs or modifications

Contact Support

- Customer Service: 1-800-AUDIOLUX (1-800-283-4658)
- Email: support@audiolux.com
- Website: www.audiolux.com/support
- Live Chat: Available 24/7 through the AudioLux Connect app

For tutorials, tips, and additional information, visit our website or access the Help section in the AudioLux Connect app.

© 2025 AudioLux, Inc. All rights reserved. SoundSphere Pro X™ is a registered trademark of AudioLux, Inc.