AYE
TECH HUB

• PLUMBING ENGINEERING • LESSON 01

# Introduction to Plumbing Systems

Beginner to Advanced — From Water Supply to Sewage

Lesson 01 of 30 | Plumbing Engineering Programme | AYE Tech Hub

**Awet G. Nway**

Founder, AYE Tech Hub | MEP & Plumbing Engineering Expert

- What plumbing is — scope, importance, and the two main systems
- Water supply system: pressure, distribution, storage and cold/hot water
- Drainage system: DWV (Drain-Waste-Vent) explained clearly
- All major pipe materials — PVC, CPVC, PEX, copper, steel — compared
- Plumbing codes and standards: IPC, UPC, BS EN, ISO — what applies where
- Career pathways in plumbing engineering — salaries and certifications
- The 30-lesson curriculum roadmap: beginner to professional plumber/engineer

# What Is Plumbing Engineering?

Plumbing is the system of pipes, fixtures, valves, and fittings that distribute potable (drinking) water throughout a building and remove wastewater safely. It is one of the oldest and most critical engineering disciplines — access to clean water and proper sanitation has saved more lives than any medical intervention in human history. The World Health Organization estimates that improved sanitation alone prevents over one million deaths per year from waterborne diseases.

Modern plumbing engineering covers two distinct but connected systems: the **water supply system** (clean water in, under pressure) and the **drainage system** (waste water out, by gravity). A plumbing engineer designs both systems to work safely, efficiently, and in compliance with national and international standards.

**Building Plumbing — Two Independent Systems Working Together**




*Fig 1 — Blue = cold supply (pressure), Red = hot supply, Brown = drain/waste (gravity), Green dashed = vent*

## The Two Main Plumbing Systems

| System | Purpose | Driving Force | Typical Pressure/Slope | Key Components |
|---|---|---|---|---|
| Water Supply System | Delivers clean potable water to all fixtures: taps, showers, toilets, appliances | Mains water pressure (or pump) | 1–4 bar (100–400 kPa) at fixtures | Rising main, cold water storage tank, boiler, distribution pipework, stop valves |
| Drainage System (DWV) | Removes wastewater and sewage from all fixtures and carries it to the sewer or septic tank | Gravity (pipes sloped downward) | 1:40 minimum fall (25mm per metre for 40mm pipe) | Soil pipe, waste pipes, traps, inspection chambers, vent stacks |
| Hot Water System | Heats cold supply water and distributes it to fixtures. Part of supply system but separately designed | Pump (if pressurised) or gravity (vented) | Boiler: 60°C minimum (prevent Legionella) | Boiler/water heater, hot water cylinder, expansion vessel, circulating pump, thermostat |

## Why Plumbing Engineering Matters — The Health Connection

Cholera, typhoid, dysentery, and hepatitis A are waterborne diseases that killed millions every century before modern sanitation. In 1854, physician John Snow traced a London cholera outbreak to a single contaminated water pump — a discovery that founded epidemiology AND proved that clean water distribution and waste separation could save entire cities. Today, approximately 2.2 billion people globally still lack access to safely managed drinking water. Plumbing engineers are directly solving one of humanity's greatest remaining public health challenges.

## The Water Supply System — Clean Water In

The water supply system begins at the point where the public mains water supply enters the building (the **service pipe**) and ends at each fixture outlet — taps, showers, appliances. Every component must be designed to maintain adequate pressure and flow rate at all fixtures simultaneously, without cross-contamination between hot and cold circuits or between drinking water and non-potable supplies.

| Supply Component | Function | Key Specification |
|---|---|---|
| Service pipe (rising main) | Brings mains water from street into the building. Fitted with a stopcock just inside the building entrance. | Min. 22mm (¾") for residential; 28–54mm+ for commercial. Buried min. 750mm deep to prevent freezing. |
| Cold water storage cistern | Stores cold water above roof level in indirect systems. Protects supply if mains pressure drops. | Typically 100–300 litres for a house. Must be covered, insulated, and screened against vermin and light (prevents algae). |
| Ball valve (float valve) | Automatically refills cistern when water level drops below set point. Closes when full. | BS 1212 compliant; type AA or AB air gap required to prevent backflow into mains supply. |
| Stop valve (stopcock) | Manually isolates water supply section for maintenance or emergency. Every fixture must have an isolating valve. | Quarter-turn ball valves preferred over gate valves for reliability. Label all stopcocks clearly. |
| Pressure reducing valve (PRV) | Reduces mains pressure to safe level for building distribution. Prevents damage to fittings and appliances. | Set to 3 bar (300 kPa) for residential. Required where mains exceeds 4 bar. |
| Check valve (non-return valve) | Prevents backflow — contaminated water flowing back into the clean supply. Critical at hose union taps, mixer showers. | Double check valve assembly required by Water Regulations at any potential contamination point. |
| Hot water cylinder | Stores hot water heated by boiler, immersion heater, or solar panels. Primary store for the hot water system. | Min. 60°C storage temperature (kills Legionella). Typically 150–250 litres for a family home. |

***BACKFLOW PREVENTION — Water Regulations in most countries make it illegal to connect any fitting that could allow contaminated water to flow back into the mains supply. Hose pipes, irrigation systems, toilet cisterns, and mixer taps are all potential backflow risks. Always specify the correct air gap or check valve as required by the relevant standard (Water Supply Regulations 1999 in the UK; Uniform Plumbing Code in the USA).***

## The Drainage System — Waste Water Out

The drainage system must remove wastewater reliably, silently, and without allowing sewer gases to enter the building. Unlike supply pipes (which use pressure), drain pipes use **gravity** — they must always slope downward toward the sewer. Getting the slope right is critical: too shallow and solids settle and block the pipe;

too steep and water runs ahead of solids, leaving them behind.

**DWV System — Drain, Waste and Vent: How They Work Together**




*Fig 2 — DWV works as a system: without proper venting, drains gurgle, slow down, and allow sewer gases into the building*

| Component | Function | Key Rule |
|---|---|---|
| Trap (U-bend) | Water-filled seal beneath every fixture that blocks sewer gases from entering the building through the drain opening. | Minimum 50mm water seal depth. Must be maintained — "trap drying" occurs if fixture unused for weeks. Fit anti-siphon traps where risk of siphoning. |
| Waste pipe | Carries wastewater from individual fixtures (basins, baths, showers) to the soil stack or drain. | Slope: 18–90mm per metre (1:60 to 1:11). 40mm minimum diameter for basins; 50mm for baths and showers. |
| Soil pipe (soil stack) | Large vertical pipe carrying toilet waste (soil) down through the building to the underground drain. Also collects waste from other fixtures on each floor. | 100mm (4") diameter minimum. Must extend above roof level as a vent. No bends sharper than 45° at base. |
| Underground drain | Carries combined waste and soil flow from the building to the sewer or septic tank. Set in concrete bedding. | Minimum 100mm (4") diameter. Slope: 1:40 to 1:60 (25–17mm per metre). Inspection chamber every 45m and at every change of direction. |
| Inspection chamber (manhole) | Provides access to the drain for clearing blockages and carrying out CCTV inspection. | Required at every junction, change of direction >30°, and every 45m on straight runs. Cover to BS EN 124 load rating. |
| Vent pipe / stack vent | Allows air into the drain to replace air displaced by flowing water, preventing trap siphoning. Also allows sewer gases to disperse to atmosphere. | Must terminate minimum 900mm above any openable window within 3m. No vent outlet near air intake. |

## The Golden Rule of Drainage — Gradient Matters

| Pipe Size | Minimum Fall | Maximum Fall | Flow Velocity Target |
|---|---|---|---|
| 40mm (basin waste) | 1:50 (20mm/m) | 1:12 (83mm/m) | 0.7–1.0 m/s (self-cleansing velocity) |
| 50mm (bath/shower) | 1:60 (17mm/m) | 1:15 (67mm/m) | 0.7–1.0 m/s |
| 75mm (combined waste) | 1:60 (17mm/m) | 1:20 (50mm/m) | 0.7–1.0 m/s |
| 100mm (soil/underground) | 1:40 (25mm/m) | 1:80 (12mm/m) | 0.75–1.0 m/s |

| | | | |
|---|---|---|---|
| 150mm (main sewer drain) | 1:60 (17mm/m) | 1:150 (7mm/m) | 0.75 m/s minimum |

## Pipe Materials — Choosing the Right Pipe for the Job

Selecting the correct pipe material is one of the most important decisions in plumbing design. The wrong choice can lead to premature failure, contamination of drinking water, or excessive installation cost. Each material has specific advantages, limitations, and approved applications defined by national standards.




*Fig 3 — Circles shown to scale relative to each other. Larger pipe = lower velocity, less noise, less friction loss.*

| Material | Max Temp | Pressure | Lifespan | Best Use | Avoid |
|---|---|---|---|---|---|
| Copper (Type L) | 110°C | High | 50+ yrs | Hot & cold supply, reliable for all applications, soldered joints | Where highly acidic water exists (corrodes copper) |
| PEX (cross-linked polyethylene) | 95°C | High | 50 yrs | Hot & cold supply, underfloor heating, flexible routing around obstacles | Exposed UV sunlight — degrades plastic; cannot be solvent welded |
| uPVC / PVC-U | 60°C | Medium | 50+ yrs | Cold water supply, drainage, underground sewer pipes | Hot water supply — softens and deforms above 60°C |
| CPVC (chlorinated PVC) | 93°C | Medium-High | 50 yrs | Hot & cold supply where copper cost is prohibitive, chemical resistance | Petroleum-based solvents; some fire suppression systems |
| HDPE (high-density polyethylene) | 60°C | High | 50+ yrs | Underground water mains, sewer pipes, corrosive environments | High-temperature systems; requires heat-fusion joining equipment |
| Galvanised steel | 120°C | Very high | 25–40 yrs | Industrial systems, fire sprinkler pipes, high-pressure gas (NEVER for water) | Drinking water — corrodes internally, stains water brown over time |
| Stainless steel | 120°C | Very high | 50+ yrs | Food processing, hospitals, marine environments, chemical plants | Cost-sensitive projects — most expensive pipe material |

| | | | | | |
|---|---|---|---|---|---|
| Cast iron / ductile iron | 250°C | Very high | 100+ yrs | Underground mains, large-diameter sewers, water distribution networks | Residential plumbing — too heavy and expensive for small diameter |

***PEX vs COPPER — The most common debate in modern residential plumbing. Copper is more durable, has better fire resistance, and is fully recyclable. PEX is cheaper, faster to install, flexible (fewer fittings needed), freeze-resistant (can expand slightly without bursting), and does not corrode. Most modern residential builds use PEX for distribution and copper only where exposed pipework is visible or higher temperatures are required.***

## Plumbing Standards and Codes — What Governs the Design

Plumbing is one of the most heavily regulated engineering disciplines because incorrect installation directly endangers public health. Every country has a plumbing code that specifies minimum pipe sizes, materials, installation methods, fixture requirements, and testing procedures. Plumbing work is subject to inspection and sign-off by local building authorities in most jurisdictions — unlicensed plumbing work is illegal and potentially void any building insurance.

| Standard / Code | Country / Region | Covers | Key Requirements |
|---|---|---|---|
| International Plumbing Code (IPC) | USA and 50+ countries | Complete plumbing design for all building types | Fixture unit method for pipe sizing; backflow requirements; water heater pressure relief |
| Uniform Plumbing Code (UPC) | Western USA (California, Oregon) | Alternative to IPC — stricter in some areas | Higher minimum pipe sizes in some applications; specific trap requirements |
| BS EN 806 (UK) | United Kingdom | Hot and cold water supply in buildings | Minimum pressure at outlets; pipe sizing by demand units; Legionella risk assessment |
| Water Supply (Water Fittings) Regulations 1999 | England & Wales | Legal requirements for all water fittings | Backflow prevention categories 1–5; material standards; notification for notifiable work |
| ISO 3822 series | International | Acoustics — noise from plumbing | Sound insulation requirements for pipes carrying water — important for multi-storey buildings |
| ASHRAE 90.1 — Plumbing sections | USA (commercial buildings) | Plumbing energy efficiency | Hot water system insulation; heat trap requirements; solar water heating integration |
| Ethiopian Building Code Standard (EBCS) | Ethiopia | General building services | Based on international standards; local authority approval required for all plumbing work |

## Career Pathways in Plumbing Engineering

| Role | Education | Salary Range (USD/yr) | Key Responsibilities |
|---|---|---|---|
| Plumber (Domestic) | Vocational training + apprenticeship (2–4 yrs) | $40,000 – $75,000 | Install and repair residential plumbing; fault-finding; maintenance |
| Plumber (Commercial) | Vocational + commercial licence | $55,000 – $90,000 | Install plumbing in offices, hospitals, factories; read drawings; pressure test |
| Plumbing Supervisor | Vocational + 5+ yrs experience | $65,000 – $100,000 | Manage plumbing crews; materials procurement; quality inspection on site |
| MEP Engineer (Plumbing) | Engineering degree + experience | $75,000 – $120,000 | Design plumbing systems for buildings; produce drawings; specify materials; coordinate with architects |
| Senior MEP Engineer | Engineering degree + 10+ yrs | $100,000 – $150,000 | Lead design on complex projects; check and approve junior designs; client-facing role |
| Water/Sanitation Consultant | Engineering + specialist | $90,000 – $180,000+ | Infrastructure projects; NGO/government water supply and sanitation programmes; international work |

### Your 30-Lesson Plumbing Engineering Roadmap

| Level | Lessons | Topics Covered |
|---|---|---|
| Beginner (Lessons 1–10) | PLUMB-001 to PLUMB-010 | Introduction, tools & safety, pipe materials, fittings & joints, water supply systems, hot water systems, drainage fundamentals, DWV design, fixture installation, bathroom layout |
| Intermediate (Lessons 11–20) | PLUMB-011 to PLUMB-020 | Kitchen plumbing, pipe sizing fundamentals, water pressure & flow, valves & controls, water heaters (gas/electric/solar), pump systems, irrigation & garden plumbing, plumbing drawings & symbols, soil & vent system design, water regulations |
| Advanced (Lessons 21–30) | PLUMB-021 to PLUMB-030 | Commercial plumbing systems, industrial plumbing, water treatment systems, sewage & waste systems, stormwater management, plumbing for MEP projects (Revit MEP integration), troubleshooting & fault diagnosis, maintenance & inspection, green plumbing & water conservation, professional plumbing workflow & project delivery |

### Key Takeaways — PLUMB-001: Introduction to Plumbing Systems

• **Plumbing engineering covers two systems:** the pressurised water supply (clean water in) and the gravity drainage system (waste water out). Both must be designed together but kept completely separate.

• **The DWV system** (Drain-Waste-Vent) requires all three components to work correctly. Without proper venting, drains slow, gurgle, and allow sewer gas into the building.

• **Pipe gradient is critical in drainage:** 1:40 to 1:60 fall for 100mm underground drains. Too shallow = blockages; too steep = water runs ahead of solids.

• **Every fixture needs a trap** — a water-filled seal that blocks sewer gases. Traps must be maintained; unused fixtures can lose their seal.

• **Pipe material selection depends on:** temperature, pressure, corrosion risk, and local standards. PEX dominates modern residential; copper for exposed work; uPVC/HDPE for drainage.

• **Backflow prevention is a legal requirement** in most countries — contaminated water must never be able to flow back into the potable supply.

• **Next lesson — PLUMB-002:** Plumbing Tools and Safety — the complete toolkit for a plumber, PPE requirements, and safe working practices for plumbing installation.