WorkingBand

properties

name

(tline)

(frequency)

TransmissionLine

methods

...
propagation_constant()
...

Frequency

properties

start
stop
npoints
f
f_scaled
unit