



2026 R1

© 2026 Synopsys, Inc and/or ANSYS, Inc. All rights reserved.
Unauthorized use, distribution, or duplication is prohibited.

Ansys Quick Start Installation Guide



Release 2026 R1
000403

ANSYS, Inc. and
ANSYS Europe,
Ltd. are UL
registered ISO
9001:2015
companies.

Installation made easy.

Copyright © 2026 Synopsys, Inc. and ANSYS, Inc. This Synopsys product and all associated documentation are proprietary to ANSYS, Inc. and Synopsys, Inc. and may only be used pursuant to the terms and conditions of a written license agreement. All other use, reproduction, modification or distribution of the Synopsys product or the associated documentation is strictly prohibited.

Table of Contents

..... 1

Important Notices

- If you want to run multiple releases of Ansys, Inc. software, you **MUST** install them chronologically (for example, Release 2021 R1 followed by Release 2021 R2). If you install an earlier release after installing Release 2026 R1, you will encounter licensing issues that may prevent you from running any products/releases. If you need to install an earlier release after you have already installed Release 2026 R1, you **MUST** uninstall Release 2026 R1, then re-install the releases in order.
- To run Ansys, Inc. release 2026 R1 software, you must have the 2026 R1 version of the License Manager installed.

Overview

The intent of this Quick Start Installation Guide is to give you a very simple overview of the steps required to install Ansys, Inc. products. This information applies to all Ansys 2026 R1 products that can be installed with the installation launcher. Ansys 2026 R1 will be used throughout this guide to refer to all Ansys 2026 R1 products.

This document assumes that you are installing products to run as a client. If you want to install the Ansys, Inc. License Manager, refer to the *Quick Start Licensing Guide* or the *Ansys, Inc. Licensing Guide*.

Ansys, Inc. Release 2026 R1 can be installed without removing previous releases, provided that you specify the same root installation directory (C:\Program Files\ANSYS Inc by default) to create the correct side-by-side installations. If you do want to remove the previous release(s), we recommend that you complete the Release 2026 R1 installation and verify that it is running correctly before uninstalling the previous release(s).

Some products have post-installation steps in addition to those steps documented here. You should review the *Ansys, Inc. Installation Guide* for your platform before using the products and ensure that you have completed all necessary post-installation procedures.

I. How do I get the files?

To download the installation files from our website, you will need to have a current technical support agreement.

Depending on the product/platform combination(s) you choose, you may need to download multiple files.

1. From the Ansys customer site, www.ansys.com/customercommunity, click **Downloads > Current Release**.
2. Select your installation operating system (**Windows x64** or **Linux x64**).
3. Select the type of files you wish to download:

Primary Packages: Individual full packages for the primary Ansys products.

ISO Images: ISO images for the DVD installation.

4. Click the appropriate download option.

-
5. Select your desired download directory and click **Save**.
 6. Repeat this process for each download file.
 7. To download **Add-On Packages, Tools** or **Documentation**, click the + to the right of the appropriate product group title to display the download options and download as required.
 8. After all downloads have been completed, uncompress each package using standard uncompression utilities for your specific platform. We strongly recommend that you extract the files into new, temporary directories.
 9. Run `setup.exe` on Windows (you must "Run as Administrator") or `/<mount_dir>/INSTALL` on Linux to begin the installation.

II. I am an existing customer upgrading from an earlier release to Release 2026 R1 and I already have a valid license key. How do I install the latest products?

If you are an existing customer with a valid license key, you will not receive a new one until your existing key expires. When you receive your Ansys 2026 R1 package, follow the steps below to install Release 2026 R1:

1. Run the Release 2026 R1 product installation setup program.
2. Choose **Install Ansys Products** from the Installation Launcher.
3. Accept the licensing agreement and click **Next**.
4. Specify the installation directory and click **Next**.
5. Select the products you want to install. You may have to specify additional information, depending on which CAD products you choose.
6. Review the date verification and the installation summary page and click **Next**.
7. After all files have been extracted and configuration steps are complete, click **Next**.
8. Client licensing configuration begins:
 - a. If you already have a valid key and valid license server specifications, click **Exit**.
 - b. If you do not have a license server specified, the application prompts you to specify your server information.
9. Exit out of all windows, including the Installation Launcher.
10. You can now run the Ansys, Inc. products that you installed.

III. I am an existing customer upgrading from an earlier release to Release 2026 R1 or a new customer installing Ansys, Inc. products for the first time and I received a license key with my Release 2026 R1 package.

1. Provide the license key to your license administrator for installation on the license server machine. You will not be able to run any products until the license key is installed on the license server machine(s) specified in Step 9, below.
2. Run the Release 2026 R1 product installation setup program.
3. Choose **Install Ansys Products** from the Installation Launcher.
4. Accept the licensing agreement and click **Next**.
5. Specify the installation directory and click **Next**.
6. Select the products you want to install. You may have to specify additional information, depending on which CAD products you choose.
7. Review the date verification and the installation summary page and click **Next**.
8. After all files have been extracted and configuration steps are complete, click **Next**.
9. Client licensing configuration begins:
 - a. If you already have a valid license server specification, click **Exit**.
 - b. If you do not have a license server specified, the application prompts you to specify your server information.
10. Exit out of all windows, including the Installation Launcher.
11. You can now run the Ansys, Inc. products that you installed.

IV. I am a new customer installing Ansys, Inc. products for the first time and I do not have a valid license key.

1. Ansys, Inc. must provide you with a valid license key. Your license administrator needs to run the **Register License Server Information** option of the server **ANSLIC_ADMIN** utility to generate the `licserver.info` file. Return the `licserver.info` file to your Ansys, Inc. sales representative so that a license key can be generated for you.
2. Download the packages and run the Release 2026 R1 product installation setup program as described above in **Section I. How do I get the files?**
3. Choose **Install Ansys Products** from the Installation Launcher.
4. Accept the licensing agreement and click **Next**.
5. Specify the installation directory and click **Next**.
6. Select the products you want to install. You may have to specify additional information, depending on which CAD products you choose.

-
7. Review the date verification and the installation summary page and click **Next**.
 8. After all files have been extracted and configuration steps are complete, click **Next**.
 9. Client licensing configuration begins:
 - a. If you already have a valid license server specification, click **Exit**.
 - b. If you do not have a license server specified, the application prompts you to specify your server information.
 10. Exit out of all windows, including the Installation Launcher.
 11. When your license administrator receives the new license key from Ansys, Inc., they must install it on the license server machine(s) specified in Step 9. You will not be able to run Ansys, Inc. products until then.

V. Finding more information

For more information on installing Ansys 2026 R1 (including network and silent installations), as well as setting up the licensing, you can refer to the following documents:

Ansys Quick Start Licensing Guide

Ansys, Inc. Licensing Guide

Ansys, Inc. Installation Guide for Windows

Ansys, Inc. Installation Guide for Linux

See the "Troubleshooting" section of these documents if you encounter any problems or error messages.