

下降沿计数

这里的下降沿计数其实本质上就是当前值和上一次的值分别和参考值进行比较




图 5 计数值加 1 触发条件

```
1 | AD_100x = Ad_Read(0x03) * 100 / 51;  
2 | if ((AD_100x <= AD_Para_10x * 10) && (AD_Old_100x >= AD_Para_10x * 10))  
3 |     Count_Down++;  
4 | AD_Old_100x = AD_100x;
```