General

Global

Pressing the **Global View** gives an overall view of the Mixer.

Select channel

Pressing a **Select** button will focus on a channel:

– In F1 mode the meters will only show the meter for the channel that is selected.

– In F2 mode all channels meters are shown.

Track

Global

Compressor / Gate On/Off switches. Rotaries don't do anything but there are different metering modes.

– F1: **Compressor**
  Buttons: Compressor On / Off

– F2: **Gate**
  Buttons: Gate On / Off
  Meters: Gate Meters

– F3: **Compressor Meters**
  Meters: Gate Meters

Select channel

– F1: **Compressor**
  Rotaries: Ratio, Threshold, Release, HPF, LPF
  Buttons: On / Off, Peak, Fast Attack, Filters > Sidechain, Sidechain Key

– F2: **Gate**
  Rotaries: Range, Threshold, Release, Hold, HPF, LPF
  Buttons: On / Off, Expander, Fast Attack, Filters > Sidechain, Sidechain Key

Pan

Global

Pan / Width control for all channels.

– F1: **Pan**
Rotaries: Pan

– F2: **Width**
Rotaries: Width

Select channel

– F1: **Pan & Width**
Rotaries: Pan, Width

EQ

Global

Rotaries don’t do anything in Bank 1.

– F1: **EQ**
  Buttons: EQ On / Off

– F2: **Gain**
  Buttons: EQ On / Off
  Rotaries: Input Gain

Select channel

– **All modes**:
  Rotaries: Input Gain, HPF Freq, LPF Freq
  Buttons: EQ On, Bell (LF and HF), HPF On, LPF On, E Mode

– F1: **EQ Gain**
  Rotaries: EQ Gain

– F2: **EQ Frequency**
  Rotaries: EQ Frequency
  Faders: EQ Gain

– F3: **EQ Q Width**
  Rotaries: EQ Frequency / EQ Q Width
  Faders: EQ Gain

Send

Global

F-Keys select control of Sends 1-8 across all channels.

– F1: **All channels, Send 1**
  Rotaries: FX1 Send Amount
  Buttons: FX1 On / Off

– F2: **All channels, Send 2**
  Rotaries: FX2 Send Amount
  Buttons: FX2 On / Off

– F3: **All channels, Send 3**
  Rotaries: FX3 Send Amount
  Buttons: FX3 On / Off

– F4: **All channels, Send 4**
  Rotaries: FX4 Send Amount
  Buttons: FX4 On / Off

– F5: **All channels, Send 5**
  Rotaries: FX5 Send Amount
  Buttons: FX5 On / Off

– F6: **All channels, Send 6**
  Rotaries: FX6 Send Amount
  Buttons: FX6 On / Off

– F7: **All channels, Send 7**
    Rotaries: FX7 Send Amount
    Buttons: FX7 On / Off

– F8: **All channels, Send 8**
    Rotaries: FX8 Send Amount
    Buttons: FX8 On / Off

Select channel

F-Keys select control of Sends 1-8 across selected channel.

– **All modes**:
    Rotaries: FX Send Amount 1-8

– F1: **Send**
    Buttons: Send On 1-8

– F2: **Pre**
    Faders: Pre Fader 1-8

Plug-In

Global

– F1: **Insert**
Rotaries: Input Gain
Buttons: Insert Bypass

– F2: **Insert**
Rotaries: Input Gain
Buttons: Insert Pre/Post

– F3: **Returns**
Rotaries: Returns Pan 1-8
Faders: Returns Level 1-8

– F4: **Master**
Rotaries: Peak Indicator Meter
Meters: Master VU

Select channel

– F1: **Insert Control**
Rotaries: Insert Rotaries 1-4
Buttons: Insert Bypass, Insert Buttons 1-4

– F2: **Insert Metering**
Rotaries: Insert FX Peak Meter
Buttons: Insert Bypass, Invert Phase, Insert Pre/Post, Dynamics Post EQ