


Mounting Holes


Reset & Boot

ESP32-S3 's CHIP_PU pin can enable the chip when it is high and reset the chip when it is low


add pull down resistors on gpios that glitch to a high value




GPIO0 and GPIO46 control the boot mode after the reset is released. Download Boot (USB): GPIO0 = 0 and GPIO46 = 0 SPI Boot (executing flash): GPIO0 = 1 and GPIO46 = Any




Hold bootloader button and press Reset button to program ESP




Header Pins



Termination Resistor



add jumper cap to short these two for EOL 120 ohm termination.



LEDs

CTL0603FRD1T-CT

 \mathbb{Z}

CTL0603FRD1T-CT_ U8

 \mathbb{Z}

CTL0603FRD1T-CT L

