

RINON ULLOA YAZMIN ELIZABETH

Lab - NETCONF w/Python: Device Configuration

Objectives

Part 1: Retrieve the IOS XE VM's Existing Running Configuration


Part 2: Update the Device's Configuration


Background / Scenario

In this lab, you will learn how to use the NETCONF ncclient to retrieve the device's configuration, and update and create a new interface configuration. You will also learn why the transactional support of NETCONF is important for getting consistent network changes.

Required Resources

- Access to a router with the IOS XE operating system version 16.6 or higher
- Python 3.x environment





Instructions

Part 1: Retrieve the IOS XE VM's Existing Running Configuration

In this part, you will use the ncclient module to retrieve the device's running configuration. The data are returned back in XML form. In the following steps, this data will be transformed into a more human readable format

Step 1: Use ncclient to retrieve the device's running configuration.

The ncclient module provides a "manager" class with "connect()" function to setup the remote NETCONF connection. After a successful connection, the returned object represents the NETCONF connection to the remote device.

- a. In Python IDLE, create a new Python script file:
- b. In the new Python script file editor, import the "manager" class from the ncclient module:

```
from ncclient import manager
```

c. Using the manager.connect() function, set up an m connection object to the IOS XE device.

```
m = manager.connect(
    host="192.168.56.101",
    port=830,
    username="cisco",
    password="cisco123!",
    hostkey_verify=False
)
```


The parameters of the manager.connect() function are:

 host – This is the address (host or IP) of the remote device (Adjust the IP address to match the router's current address.).

- port This is the remote port of the SSH service.
- username This is the remote SSH username (In this lab, use "cisco" because that was set up in the IOS XE VM.).
- password This is the remote SSH password (In this lab, use "cisco123!" because that was set up in the IOS XE VM.).
- hostkey_verify Use this to verify the SSH fingerprint (In this lab, it is safe to set to False; however, in production environments you should always verify the SSH fingerprints.).
- d. After a successful NETCONF connection, use the "get_config()" function of the "m" NETCONF session object to retrieve and print the device's running configuration. The get_config() function expects a "source" string parameter that defines the source NETCONF data-store.

```
netconf_reply = m.get_config(source="running")
print(netconf reply)
```


e. Execute the Python script and explore the output.




Step 2: Use CodeBeautfiy.com to evaluate the response.

Code Beautify maintains a website for viewing code in a more human readable format. The XML viewer URL is https://codebeautify.org/xmlviewer

f. Copy the XML from IDLE to XML Viewer.



g. Click Tree View or Beautify / Format to render the raw XML output into a more human readable format.



- To simplify the view, close the XML elements that are under the rpc-reply/data structure.
- . Note that the opened rpc-reply/data/native element contains an attribute xmlns that points to "Cisco-IOS-XE-native" YANG model. That means this part of the configuration is Cisco Native for IOS XE.

j. Also note that there are two "interfaces" elements. The one with xmlns is pointing to the "http://openconfig.net/yang/interfaces" YANG model, while the other is pointing to the "ietf-interfaces" YANG model.

Both are used to describe the configuration of the interfaces. The difference is that the openconfig.net YANG model does support sub-interfaces, while the ietf-interfaces YANG model does not.

Step 3: Use toprettyxml() function to prettify the output.


- a. Python has built in support to work with XML files. The "xml.dom.minidom" module can be used to prettify the output with the toprettyxml() function.
- b. Import the "xml.dom.minidom" module:

```
import xml.dom.minidom
```

c. Replace the simple print function "print (netconf_reply)" with a version that prints prettified XML output:

```
print( xml.dom.minidom.parseString(netconf reply.xml).toprettyxml() )
```

d. Execute the updated Python script and explore the output.




Step 4: Use filters to retrieve a configuration defined by a specific YANG model.

- a. NETCONF has support to return only data that are defined in a filter element.
- b. Create the following netconf_filter variable containing an XML NETCONF filter element that is designed to retrieve only data that is defined by the Cisco IOS XE Native YANG model:

c. Include the netconf filter variable in the get_config() call using the "filter" parameter:

```
netconf_reply = m.get_config(source="running", filter=netconf_filter)
print(xml.dom.minidom.parseString(netconf_reply.xml).toprettyxml())
```

e. Execute the updated Python script and explore the output



Las lineas de este punto c y b del apartado 4 marcan un error debido a que los link's ya no estan disponibles.

Part 2: Update the Device's Configuration

Step 1: Create a new Python script file.

- a. In IDLE, create a new Python script file.
- b. Import the required modules and set up the NETCONF session:

Step 2: Change the hostname.


- f. In order to update an existing setting in the configuration, you can extract the setting location from the configuration retrieved in Step 1.
- g. The configuration update is always enclosed in a "config" XML element. This element includes a tree of XML elements that require updates.
- h. Create a netconf_data variable that holds a configuration update for the hostname element as defined in the Cisco IOS XE Native YANG Model:

- i. Edit the existing device configuration with the "edit_config()" function of the "m" NETCONF session object. The edit config() function expects two parameters:
 - target This is the target netconf data-store to be updated.
 - config This is the configuration update.

The <code>edit_config()</code> function returns an XML object containing information about the success of the change. After editing the configuration, print the returned value:

```
netconf_reply = m.edit_config(target="running", config=netconf_data)
print(xml.dom.minidom.parseString(netconf reply.xml).toprettyxml())
```

- Before executing the new Python script, check the current hostname by connecting to the console of the IOS XE VM.
- k. Execute the Python script and explore the output.
- I. After executing the Python script, if the reply contained the <ok/> element, verify whether the current hostname has been changed by connecting to the console of the IOS XE VM.



Step 3: Create a loopback interface


m. Update the **netconf_data** variable to hold a configuration update that creates a new loopback **100** interface with the IP address 100.100.100.100/24:

```
netconf data = """
<config>
 <native xmlns="http://cisco.com/ns/yang/Cisco-IOS-XE-native">
  <interface>
   <Loopback>
    <name>100</name>
    <description>TEST1</description>
    <ip>>
     <address>
      cprimary>
       <address>100.100.100</address>
       <mask>255.255.255.0</mask>
      </primary>
     </address>
    </ip>
   </Loopback>
  </interface>
 </native>
</config>
```

n. Add the new loopback 100 interface by editing the existing device configuration using the "edit config()" function:

```
netconf_reply = m.edit_config(target="running", config=netconf_data)
print(xml.dom.minidom.parseString(netconf reply.xml).toprettyxml())
```

- o. Before executing the updated Python script, check the existing loopback interface by connecting to the console of the IOS XE VM using the **show ip int brief** and **show int desc** commands.
- p. Execute the Python script and explore the output
- q. After executing the Python script, if the reply contained the <ok/> element, verify whether the current loopback interfaces have changed by connecting to the console of the IOS XE VM.




Step 4: Attempt to create a new loopback interface with a conflicting IP address.

a. Update the **netconf_data** variable to hold a configuration update that creates a new loopback **111** interface with the same IP address as on loopback 100: 100.100.100.100/32:

b. Attempt to add the new loopback 111 interface by editing the existing device configuration using the "edit config()" function:

```
netconf_reply = m.edit_config(target="running", config=netconf_data)
print(xml.dom.minidom.parseString(netconf reply.xml).toprettyxml())
```

- c. Before executing the updated Python script, check the existing loopback interface by connecting to the console of the IOS XE VM using the **show ip int brief** and **show int desc** commands.
- d. Execute the Python script and explore the output.
 - The device has refused one or more configuration settings. With NETCONF, thanks to the transactional behavior, no partial configuration change has been applied but the whole transaction was canceled.
- e. After executing the Python script, verify that no configuration changes, not even partial, have been applied.



Como Podemos observer nonguna de las lineas que da algun link funciona, arroja errores esto debido a que los links ya no estan disponibles.