Power Module

Docking and Landing Module

| | RESET | MAX | MAX | MAX | MAX | TOGGLE | AUTOLAND | INVOQUE | |
|--|------------------|----------|-----------------------|-------------------|--------------------|------------------------|--------------------------|---------|--|
| Shields and Countermeasures Module | LAUCH | MIN | MIN | MIN | MIN | REQUEST LANDING | CAMERA | | |
| | | ТОР | LEFT | RIGHT | ВОТТОМ | ВАСК | DEPLOY | RESET | |
| Movement Module | G-LOCK SAFETY | E.S.P. | VTOL | CRUISE CONTROL | ACTIVE PING | SCANNING MODE | ACTIVATE SCANNING | | |
| Mining Module | MINING | FIRE | SWITCH | | 2 | 3 | JETTINSON CARGO | | |
| Camera Module | 7 | 8 | 9 | 4 | 5 | 6 | | 2 | |
| | 3 | RESET | CICLE | CICLE | FREE LOCK | VJ0Y FPS | EXIT REMOTE TORRET | E.S.P. | |
| | MOVEMENT TYPE | RECENTER | GIRO STABILIZATION | INSTAND ZOOM | CHANGE POSITION | STAGGERED /COMBINED | ON OFF | Torr | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |
| | | | | | | | | | |