# Duo Multicultural Arts Center (DMAC)

# **General and Technical Information**

Cari Gorostiza Theatre 62 East 4th Street New York, NY, 10003

Primary Contact
Michelangelo Alasa
+1 (201) 320-6455 (Mobile)
duotheatre@gmail.com



# **Table of Contents**

Table of Contents	2
General Information	3
Address	3
<u>Theatre</u>	3
Mailing	3
Access	
Staff and Contacts	3
Emergency Contacts:	3
Facility	4
Seating	4
Carpentry	4
Stage Dimensions	4
Flooring	4
<u>Draperies</u>	5
Lineset	5
Support Areas	
Load In	5
Lighting	5
Console	5
Dimmers	5
Circuits	
Networking	6
House Lights	6
Work Lights	6
Company Switch	6
Lighting Positions	6
Instrument Inventory	6
Cable	6
Sound	6
Video	7
Props	7
Chairs	
Dance Floor	<del> </del>
Tech Tables	<del></del>
Dressing Areas	<del></del>
Appendix	8
Lighting Plot	<u></u>

## **General Information**

#### **Address**

#### **Theatre**

62 East 4th Street, New York, NY, 10003 Floor 2

#### Mailing

PO Box 1200 Cooper Station, New York, 10276 ATTN: DUO Theatre

#### **Access**

**Please note:** There are 1.5 flights of stairs between the audience/front entrance and the theatre. Our building is over 125 years old and is not ADA compliant.

#### **Staff and Contacts**

**Michelangelo Alasa**, Artistic Director cell: +1 (201) 320-6455 (Mobile) email: duotheatre@gmail.com

### **Emergency Contacts:**

All Emergencies 911

Police and Fire Non Emergency: 311

NYPD 6th Precinct 321 East 5 Street

FDNY Engine 33/Ladder 9 42 Great Jones St

# **Facility**

## Seating

DMAC currently utilizes folding chairs for audience seating. 74 are available. The floor is sloped at 5° allowing for comfortable viewing angles from all positions. The "pit" when bare is ~23' X ~30'.

# Carpentry

## **Stage Dimensions**

Width 22'-10" wall to wall

Proscenium ~20" width from wall either side

11" deep

#### Note: The Cari Gorostiza theatre has a considerable apron (12'-10")

Stage Depth 12'-10" downstage edge to plaster line

16'-9" stage left upstage wall to plaster line 19'-9" stage right upstage wall to plaster line

**Grid Height** 10'-9" apron grid

11' stage grid

See attached Lighting Plot for details on grid layout. Note that the stage grid extends beyond the rear of the stage into the dressing areas.

**Stage Height** 2'-4" (From first row of audience)

## Flooring

- Sprung dance floor with Marley top surface available
- No Screwing and Stapling, Gaffing allowed
- Stage flooring is original to building, wood; Apron surface is 1" ply.
- Deck can be painted when used exposed, Renter is obligated to paint flat black at end of rental or provide 2 gallons paint.

## **Draperies**

2, black, width of stage available

#### Lineset

No system

#### **Support Areas**

Dressing area is directly behind stage

#### Load In

All equipment is to be loaded in via the front door. The tightest point is the staircase up to the theater level, which is 42" between railings (46" wall to wall). Additional stage access is available via the fire door in the dressing area with a 50" opening. This method is not recommended for loading due to significant challenges navigating the fire escape or otherwise hoisting objects to the second level.

# Lighting

#### Console

ETC Express 24/48

## **Dimmers**

24 channels available via 12 Lighting Methods Inc. L86 Dimmer Modules (dmx controlled). Located in FOH/Electrical Closet

#### Circuits

50 stage-pin runs from FOH/Electrical Closet to stage & ladders.

- 6 available at stage left ladder
- 6 available at stage right ladder
- 10 available above apron grid stage left wall
- 10 available above apron grid stage right wall
- 17 available above gird stage left

## Networking

None. (One DMX cable run between Console and Dimmerpack)

## **House Lights**

House lighting is provided by 2 hanging pendant lamps per side (4 total) located near walls. Dimmable, controlled via switch near lighting desk (NOT DMX).

## **Work Lights**

Two sets available.

- Incandescents sit within proscenium lighting stage, operated via switch hidden in proscenium stage right
- LED flood lights hang on stage grid as well as ladders, lighting stage and apron, operated via switch at floor of proscenium stage right

## **Company Switch**

60 Amp 240V switch with Cam-Lok tails located in FOH/Electrical Closet

## **Lighting Positions**

All lighting positions are 2" OD schedule 40 pipe

## **Instrument Inventory**

- 17 Generic Par Fixtures
  - o Shutters and hoods are available
- 15 ETC Source 4 50° conventionals
- 3 Leko style Generic mini profile fixtures

#### Cable

Various length stage-pin cable available.

## Sound

None.

## Video

Please inquire about your needs

## **Props**

#### Chairs

75 chairs (inclusive of those used for audience seating)

#### **Dance Floor**

Marley

#### **Tech Tables**

1 folding table

# **Dressing Areas**

Two dressing areas are available at the rear of the stage behind a false wall. The area at stage-level seats 4. The additional area abuts down a set of 3 steps and seats 7. There are no restrooms or facilities available in the dressing area. A door to the rear courtyard of the building is present.

# **Appendix**

# **Lighting Plot**

Available as an LXPlan .1xxplot scaled file. Inquire for raw files

