RENAT

Library version: RENAT 0.1.14

Library scope: global **Named arguments:** supported

Introduction

Document for RENAT framework

All in one pdf renat.pdf

Libraries

RENAT includes following libraries:

Common:

Common library of RENAT

VChannel:

Library controls connection to targets (servers, routers, ...)

<u>Logger</u>:

Library provides enhanced loggging keywords

Optical:

Library provides keywords to control L1 switches, includes mod calient mod, mod ntm mod

Router:

Library provides keywords to control routers, includes <code>mod_juniper</code> mod , <code>mod_cisco</code> mod and <code>mod_gr</code> mod

Tester:

Library provides keywords to control testers, includes mod ixnet, mod ixload, mod ixbps and mod avaproxy

WebApp:

Common library for web application includes 2 child libraries: Samurai and Arbor

Hypervisor:

Library provides keywords to control Hypervisor includes mod vmware

LabKeyword:

Common lab keywords

Others

Changes:

Changes information

Choose each libraries for detail infomration and samples about keywords.

Shortcuts

Keywords

Reyword Arguments Documentation

Altogether 0 keywords.

Generated by Libdoc on 2019-03-31 15:26:47.



Common

Library version: RENAT 0.1.14
Library scope: global
Named arguments: supported

Introduction

Common library for RENAT

It loads config files and create necessary varibles. The file should be the 1st library included from any test case.

Table of Contents

- Configuration file
- Variables
- Shortcuts
- Keywords

Configuration file

Global configuration

There are 2 important configuration files. The global configuration files (aka master files) include device information, authentication etc that are used for all the test cases in the suite. The local configuration file local.yaml includes information about nodes, tester ports etc. that are used in a specific test case.

At the beginning, the module makes a local copy the master files and initialize necessary variables.

The RENAT framework utilized the YAML format for its configurations file.

The master files folder is defined by renat-master-folder in \$RENAT_PATH/config/config.yaml. Usually, users do not need to modify the master files. The most common case is when new device is deployed, the device.yaml need to be update so that device could be used in the test cases.

1. device.yaml: contains global device information

Each device information is store under device block and has the following format:

```
<node_name>
type: <device type>
description: <any useful description>
ip: <the IPv4 address of the device
```

Where <node_name> is the name of the device. It could be the name of a switch, router or a web appliance box and should be uniq between the devices. <description> is any useful information and <ip> is the IP that RENAT uses to access the device.

<type> is important because it will be used as a key of the access_template in template file. Usually users do not need to invent a new type but should use the existed type. When a new platform need to be supported, a new type will be introduced with the correspon template and authentication information.

Examples

```
device:
  apollo:
    type: ssh-host
    description: main server
    ip: 10.128.3.101
  artermis:
    type: ssh-host
    description: second server
    ip: 10.128.3.91
  vmx11:
    type: juniper
    description: r1
    ip: 10.128.64.11
  vmx12:
    type: juniper
    description: r2
    ip: 10.128.64.12
```

2. template.yaml: contains device template information

The template file contains information about how to access to the device and how it should polling information (SNMP only for now). Each template has the following format:

Note: Becareful about the prompt field. Usually RENAT will wait until it could see the prompt in its output. A wrong prompt will halt the system until it is timed out.

Examples:

```
access-template:
# template for an oridnary UNIX server access by SSH
ssh-host:
access: ssh
auth: public-key
```

```
profile: default
    prompt: \$
    append:
    init: unalias -a
  # template for a Juniper router
  iuniper:
    access: telnet
    auth: plain-text
    profile: default
    prompt: "(#|>) '
    append: ' | no-more'
  # template for a Cisco router
  cisco:
    access: ssh
    auth: plain-text
    profile: default
    prompt: "\@.*(#|>) '
    append:
 # template for a Juniper router access through a SmartCS console server
 jump-smartcs:
    access: jump
    access_base: telnet
   auth: plain-text
   profile: default
   prompt: "tty.*> '
    password_prompt: "Password:"
   target: juniper
snmp-template:
   juniper:
      mib: ./mib-Juniper.json
      community: public
      poller: renat
    cisco:
      mib: ./mib-Cisco.json
      community: public
```

3. auth.yaml: contains authentication information

The file contains authentication information that system uses when access to a device. Each authencation type has follwing format:

Where <profile> is the name of the authentication profile specificed in the access template of the device

Example:

```
auth:
  plain-text:
    default:
      user: user
      pass: xxxxxx
    flets:
      user: user
      pass: xxxxxx
    arbor:
      user: admin
      pass: xxxxxx
  public-key: # for Public Key authentication
    default:
       user: robot
       key: /home/user/.ssh/robot_id_rsa
    test:
      user: jenkins
      key: /var/lib/jenkins/.ssh/id_rsa
```

Local Configuration

Local configuration (aka local.yaml) was used by a test case of its sub test cases. Test cases could includes several test cases (the sub level is not limited). The local configuration is defined by local.yaml in the config folder of each test case. If a test case does not has the local.yaml in its config folder, it will use the local.yaml file in its parent test case and so on. This will help users to share the test information for related test case without having the same local.yaml for each test case (**Note:** this feature is enabled from RENAT 0.1.4). The local.yaml that is really used for the test is called active local.yaml.

When user used the wizard item.sh to create a new test case, they have the ability to crete new local.yaml or not. local.yaml could be edited and inserted new information later to hold more informations for the test case.

When a test is run, it will display its current active local.yaml

The local configuration file of each test item is stored in the config folder of the item as `local.yaml

Usually the local.yaml has following parts:

■ CLI node information: started by node keyword

- WEB node information: started by webapp keyword
- Tester device information: started by tester keyword
- Default information: automatically created and started by default keyword
- And other neccessary information for the test by yaml format

Example:

```
# CLI node
node:
  vmx11:
    device: vmx11
    snmp_polling: yes
  vmx12:
    device: vmx11
    snmp_polling: yes
  apollo:
    device: vmx11
    snmp_polling: yes
# web application information
webapp:
 arbor-sp-a:
    device: arbor-sp-a
    proxy:
      http: 10.128.8.210:8080
      ssl: 10.128.8.210:8080
      socks: 10.128.8.210:8080
# Tester information
tester:
 tester01:
    type: ixnet
    ip: 10.128.32.70
    config: vmx_20161129.ixncfg
# Other local information specific for this case
port-mapping:
 uplink01:
    device: vmx11
    port: qe-0/0/0
 downlink01:
    device: vmx12
    port: ge-0/0/2
# Default information
default:
  ignore-dead-node: yes
 terminal:
    width: 80
    height: 32
 result folder: result
```

Variables

The module automatically create GLOBAL & LOCAL variable for other libraries. It also creates global list variables GLOBAL, LOCAL and NODE that could be accessed from Robot Framework` test cases.

The GLOBAL variable holds all information defined by the master files and LOCAL variable holds all variables defined by active local.yaml. And NODE is a list that hold all active nodes defined in the local.yaml.

Users could access to the information of a key in local.yaml by \${LOCAL[key']}, information of a node by \${LOCAL[node'][vmx11']} or simply \$NODE[vmx']. When a keyword need a list of current node, @{NODE} could be used.

Notes: By default, RENAT will stop and raise an exception if connection to a node is failed. But if ignore-dead-node is defined as yes (default) is the current active local.yaml, RENAT will omit an warning but keep running the test and remove the node from its active node list.

Shortcuts

Change Mod · Cleanup Result · Close Display · Convert Html To Pdf · Convert Xml · Count Keyword · Count Keyword Line · Count Match Regexp · Create Sequence · Csv Add · Csv Concat · Csv Create · Csv Merge · Csv Select · Current Usergroup · Current Username · Diff File · Err · Error Line Should Not Be Bigger Than · Error Should Not Be Bigger Than · Explicit Run · File Md5 · Fold Str · Follow Syslog And Trap · Get Config Path · Get Config Value · Get File Without Error · Get Item Config Path · Get Item Name · Get Multi Lines · Get Myld · Get Renat Path · Get Result Folder · Stable · Mib For Node · Node With Attr · Node With Tag · Node Without Tag · Pause · Ping Until Ok · Random Name · Random Number · Renat Version · Screenshot · Send · Set Multi Item Variable · Set Result Folder · Slack · Start Display · Stop Next Run · Str 2 Seq · Version · Wait

Keyword	Arguments	Documentation
Change Mod	name, mod, relative=True	Changes file mod, likes Unix chmod
		mod is a string specifying the privilege mode relative is False or True
		Examples:
		Common. Change Mod tmp 0775
Cleanup Result	ignore=^(log.html output.xml report.html)\$	Cleans up the result folder
		Deletes all files in current active folder that does not match the ignore expression and are older than the

Class Display		Note: The keyword only removes files but not folders Closes the opened display			
Close Display Convert Html	html file, pdf file				
To Pdf	nuni_nie, pai_nie	Converts html file to pdf file	Converts fittill file to pair file		
Convert Xml style, src, dst		Converts XML by using XLS stylesheet			
		Predefined stylesheets are store in tools/xls under current active RENAT folder			
		Parameters:			
		style: path to stylesheet			
		src: path to the XML sourcedst: path to the output file			
Count Keyword	keyword, *pattern_list	Count the keyword in files. Keyword is not case-sensitive			
Count Keyword	keyword, *pattern_list	Count the number of lines contains the keyword			
Line		Notes: Keyword is matched partially. For example, error or en	rorXXX will be matched b	by error keyword	
Count Match	regexp, *pattern_list	Count the number of regex found in pattern_list			
Regexp		Examples:			
		\${err_num}= Count Match RegExp .*error.* result/*.csv result/	'*.txt		
Create	start, end, interval, option=float	Creates a list with number from start to end with interval			
Sequence		Example:			
		@{list}= Create Sequence 10 15 0.5			
		will create a list of [11.0, 11.5, 12.0, 12.5, 13.0, 13.5, 14.0, 14.5]			
Csv Add	pathname, *items	Add more data define by a list items to a existed CSV file			
		Note:: do not check the consistency between item's number ar	nd header's number		
Csv Concat	src_pattern, dst_name,	Concatinates CSV files vertically If the CSV files has header,	set has_header to \${TRL	UE}	
	input_header=None, result_header=True	Examples:			
		Commmon. CSV Concat config/data0[3,4].csv result/result2.csv			
		Commmon. <u>CSV Concat</u> config/data0[3,4].csv result/result2.csv	has_header=\${TRUE}		
Csv Create	pathname, *header	Create a CSV file with headers defined by a list header			
Csv Merge	src_pattern, dst_name,	The CSV file is opend with <i>UTF-8</i> encoding mode Merges all CSV files horizontally by key key from src pattern			
		keyword assume that input files have no header and automatic	•		
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name.	ut_header will be used as ey is the column name the index of columns. Other	e. When s header and da hat used to mere	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header	ut_header will be used as ey is the column name the index of columns. Other	e. When s header and da hat used to mere	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern	ut_header will be used as ey is the column name the index of columns. Other	e. When s header and da hat used to mere	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header	ut_header will be used as ey is the column name the index of columns. Other	e. When s header and da hat used to mere	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k. When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge	ey is the column name the index of columns. Other (True or False)	e. When s header and da hat used to merç wise, they are	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common. CSV config/data0[3,4].csv	ey is the column name the index of columns. Other (True or False)	e. When s header and da hat used to mere wise, they are	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv	ey is the column name the index of columns. Other index of result/result2.csv	e. When s header and da hat used to mere	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k. When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV config/data0[3,4].csv Merge	ey is the column name the index of columns. Other index of result/result2.csv	e. When s header and da hat used to mere wise, they are input_header=0	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge	ey is the column name the index of columns. Other of columns of colum	e. When s header and da hat used to mere wise, they are input_header=0	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge dst_name=\${RESULT_FOLDER}/result.csv key=Stat Name Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv	ey is the column name the index of columns. Other of columns of c	e. When s header and da hat used to mere wise, they are input_header=0	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge dst_name=\${RESULT_FOLDER}/result.csv key=Stat Name Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge Src_pattern=\${RESULT_FOLDER}/balance*.csv Merge Src_pattern=\${RESULT_FOLDER}/balance*.csv Merge	ey is the column name the index of columns. Other index of columns in the columns in the column index of column index of columns in the column index of columns in the column index of co	e. When s header and da hat used to mergwise, they are input_header=0	
		input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header. The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge dst_name=\${RESULT_FOLDER}/result.csv key=Stat Name Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv	ey is the column name the index of columns. Other of columns of c	e. When s header and da hat used to mergwise, they are input_header=0	
Csv Select	src_file, dst_file, str_row=:, str_col=:,	input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge dst_name=\${RESULT_FOLDER}/result.csv key=Stat Name Common.CSV src_pattern=\${RESULT_FOLDER}/result.csv key=0 Select part of the CSV file and write it to other file str_row and	ey is the column name the index of columns. Other index of columns in index of columns i	e. When s header and da hat used to mergwise, they are input_header=0	
Csv Select	src_file, dst_file, str_row=:, str_col=:, has_header=None	input_header is not null (default is zero), the row define by inp is counted from the next row. select_column is a string that define the output columns and k When input_header is \${NULL}, select_column and key is the column name. The result header (column names) is decided by result_header The keyword returns False if no file is found by the pattern Examples: Common.CSV config/data0[3,4].csv Merge Common.CSV src_pattern=\${RESULT_FOLDER}/balance*.csv Merge dst_name=\${RESULT_FOLDER}/result.csv Merge dst_name=\${RESULT_FOLDER}/result.csv	ey is the column name the index of columns. Other (True or False) result/result2.csv result/result2.csv input_header=0 result_header=\${FALSE} select_column=Valid Frames Rx. input_header=\${FALSE} select_column=5 str_col are used to specifor Python list.	e. When s header and da hat used to mergwise, they are input_header=0	

		CSV Select result/data05.csv result/result6.csv 0:3 : CSV Select result/data05.csv result/result7.csv 0:5:2 :	
Current		Returns current usergroup	
Usergroup			
Current Username		Returns current username	
Diff File	path1, path2, newline=True	Shows difference between files	
		Returns the diff result (multi lines) path1, path2 are absolute paths.	
Err	msg	Prints error msg to console	
Error Line Should Not Be Bigger Than	num, *pattern_list	Checks whether the number of lines that contains error be less than a number	
Error Should Not Be Bigger Than	num, *pattern_list	Checks whether the number of error be less than a number	
Explicit Run		skip the test case if global_variable RUN_ME is not defined	
		Examples: 00. Cabling Common. Explicit Run Log To Console cabling	
		run.sh will bypass 00. Cabling by default. In other to run this test case \${FORCE} needs declared globally run.sh -X -v FORCE	
File Md5	path	Returns MD5 hash of a file	
		path is an absolute path	
Fold Str	str	Folds a string by adding Non-Width-Space char (0x200b) at 6th char	
Follow Syslog And Trap	pattern, log_file_name=syslog-trap.log, delay_str=1s	Pauses the execution and wait for the pattern is matched if the file log_file_name located in the current result folder. By default the log_file_name is /result/sys/og-trap log which is created by Follow Sys/og and Trap	
		By default the log_file_name is ./result/syslog-trap.log which is created by Follow Syslog and Trap keyword. The keyword should be in tests between Follow Syslog adn Trap Start and Follow Syslog and Trap Stop keywords.	
Get Config Path		keywords. Returns absolute nath of RENAT confin folder nath	
-		Returns absolute path of RENAT config folder path	
Get Config Value	key, base=default, default=None	Returns value of a key for renat configuration with this other LOCAL[base][key] > GLOBAL[base][key] > None	
Get File Without Error	file_path	Get content of the file and return null string if the file does not exist	
Get Item Config Path		Returns absolute path of current item config folder	
Get Item Name		Returns the name of the running item	
Get Multi Lines	data, index	Returns multiple lines from text data using <i>index index</i> uses python rule.	
Get Myid		Returns ID uniq for this test case	
Get Renat Path		Returns the absolute path of RENAT folder	
Get Result		Returns current result folder name. Default is result in current test case.	
Folder		Note : the keyword only returns the name of the result folder not its absolue path.	
Get Result Path		Returns absolute path of the current result folder	
Get Test Device		Return a list of all test device that is used in this test	
		Notes: Device number could less than node number	
Get Tmp Path		Returns temporary path	
Is Stable	seq, threshold, percentile=90	Checks if the value sequence is stable or not	
Keyword Line Should Not Be Bigger Than	num, keyword, *pattern_list	Checks whether the number of line containing the keyword be less than a number	
Keyword Should Not Be Bigger Than	num, keyword, *pattern_list	Checks whether the number of keyword be less than a number	
Load Plugin		Load plugin in renat/plugin folder	
Log	msg, level=1	Logs msg to the current log file (not console) The msg will logged only if the level is bigger than the global level \${DEBUG} which could be defined at runtime. If \${DEBUG} is not defined, it will be considered as the default level as 1.	
		Examples: Common. Log XXX # this always be logged Common. Log AAA level=2 # this will not be logged with common run.sh	

		Notes: For common use level 1: is default	
		level 1: is default level 2: is debug mode	
		■ level 3: is very informative mode	
Log Csv	csv_file, index=False, border=0	Logs a content of csv_file into default log.html	
		index, border are table attributes	
Log To Console	msg, level=1	Logs a message to console	
		See Common. Print for more details about debug level	
Loop For Node	var, tags, *keywords	Repeatly executes RF keyword for nodes that has tag tags	
Tag		multi tags are separated by : keywords has same meaning with keywords used by <i>Run Keywords</i> RobotFramework (keyword and its arguments are separated by AND with the others.	
		Example:	
		Loop For Node Tag \\$(node) tag1	
		Switch \\${node} AND Cmd show system user AND	
		Cmd show system uptime	
		Note: \$ in variable name must be escaped	
Md 5	str	Returns MD5 hash of a string	
Merge Files	path_name, file_name	Merges all the text files defined by path_name to file_name	
. 5		Example:	
Mails Francis	l na de	Merge Files /result/*.csv /result/test.csv	
Mib For Node	node	Returns the mib file name for this node mib file is define by mib keyword under the node in loca	
		 node:	
		vmx11:	
		device: vmx11	
		snmp_polling: yes mib: mib11.txt	
		Default value is defined by mib keyword from global config/snmp-template.yaml for the type of the	
		Example:	
		\${mib}= Common. <u>MIB For Node</u> vmx11	
Node With Attr	attr_name, value	Returns a list of nodes which have attribute attr_name with value value	
Node With Tag	*tag_list	Returns list of node or webapp from local.yaml that has ALL tags defined by tag_list	
		Tag was defined like this in local.yaml	
		vmx11: device: vmx11	
		device. VIIX I I	
		snmp_polling: yes	
		tag:	
		tag: - tag1	
		tag: - tag1 - tag2	
		tag: - tag1 - tag2 Examples:	
Nedo With	then liet	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3	
Node Without	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list	
Node Without Tag	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3	
_	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3} Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11:	
_	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml	
_	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag:	
_	*tag_list	tag: -tag1 -tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes	
_	*tag_list	tag: -tag1 -tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3} Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: -tag1 -tag2	
_	*tag_list	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3} Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples:	
Tag		tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3	
_	*tag_list msg=, time_out=3h, error_on_timeout=True, default_input=	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3} Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3} Displays the message msg and pauses the test execution and wait for user input	
Tag	msg=, time_out=3h,	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3	
Tag	msg=, time_out=3h,	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3} Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3} Displays the message msg and pauses the test execution and wait for user input In case of error_on_timeout is True(default), the keyword will raise an error when timeout occurs. Otherwise, it will continue the test.	
Tag	msg=, time_out=3h,	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3 Displays the message msg and pauses the test execution and wait for user input In case of error_on_timeout is True(default), the keyword will raise an error when timeout occurs. Otherwise, it will continue the test. Inf succeed, the keyword returns the input from user.	
Tag	msg=, time_out=3h,	tag: - tag1 - tag2 Examples: \${test3}= Common. Node With Tag tag1 tag3 Returns list of node from local.yaml that does not has ANY tags defined by tag_list Tag was defined like this in local.yaml vmx11: device: vmx11 snmp_polling: yes tag: - tag1 - tag2 Examples: \${test3}= Common. Node Without Tag tag1 tag3 Displays the message msg and pauses the test execution and wait for user input In case of error_on_timeout is True(default), the keyword will raise an error when timeout occurs. Otherwise, it will continue the test. Inf succeed, the keyword returns the input from user.	
Tag	msg=, time_out=3h,	tag:	
Tag	msg=, time_out=3h,	tag:	
Tag	msg=, time_out=3h,	tag:	
Tag	msg=, time_out=3h,	tag:	

		Example:	
		\${FOLDER}= Random Name capture_%05d 0 99	
Random Number	a=0, b=99	Returns a random number between [a,b]	
Renat Version		Returns RENAT version string	
Screenshot	file_path	Capture whole display to a file specified by file_path	
		Notes : This keyword saves the whole virtual screen(monitor), while the familiar WebApp. <i>Screenshot Capture</i> only saves the portion of the web browser. But in contrast, the WebApp. <i>Screenshot Capture</i> could do <i>fullpage capture</i> depending on the content of the browser.	
Send	sock, data, recv_buffer_size=1024,	Sends bytes of data by socket sock and reicve the response	
	encode=utf-8	When recv_buffer_size is zero, the function does not execpt a response from the remote.	
Set Multi Item	*vars	Set multiple varibles to be suite variable at the same time	
Variable		Suite variables (or item variable) could be access anywhere in all the item scenario.	
Set Result Folder	folder	Sets the result folder to folder and return the old result folder. The result folder contains all output files from the test likes tester ouput, config file	
		folder is a folder name that under current test case folder	
		The system will create a new folder if it does not exist and set its mode to 0775	
		Note: Result folder should be set at the begining of the test. Changing result folder only has effect on up comming connection	
Slack	msg, channel=#automation_dev, user=renat, host=10.128.3.103:4713	Post a message to Slack	
Start Display		Starts a virtual display	
Stop Next Run	msg=Case run was stopped by user	Stops next run (specified by -n) using a .stop file with reason	
Str 2 Seq	str_index, size	Returns a sequence from string format	
		Examples:	
		Str2Seq :: 5 # (0,1,2,3,4) Str2Seq :2 5 # (0,1) Str2Seq 1:3 5 # (1,2) Str2Seq 0:5:2 5 # (0,2,4)	
Version		Returns the current version of RENAT	
Wait	wait time, size=10	Waits for wait-time and display the proress bar	
		wait time used RF DateTime format.	
		Examples:	
		Common. Wait wait_time=30s size=10	

Altogether 65 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:28.



VChannel

Library version: RENAT 0.1.14
Library scope: test suite
Named arguments: supported

Introduction

A basic library that provides Terminal connection to routers/hosts

VChannel is a core RENAT library that maintains input/output to nodes with an attached virtual terminal. It encapsulates the SSH/Telnet connections behind and provides common usage of access and execute commands to the nodes. Each channel instance has its own log file and a virtual terminal.

Table of Contents

- Device, Node and Channel
- Connections
- Shortcuts
- Keywords

Device, Node and Channel

RENAT has 3 types of connection target. Device, Node and Channel.

Device

Each device stands for a real physical box that has its own IP address and is defined in the master file device.yaml. Users do not directly use device in keywords.

Node

Node is a logical instance of a device. It could stand for a logical instance of a router or just a virtual terminal to the router. Nodes were defined in local.yaml of the test case. Several nodes could point to a same device.

Channel

Each channel holds a session to a node. Each channel has its own log file and a virtual terminal. Any command used by <u>Cmd, Write</u> or <u>Read</u> will be logged to the log file. Each channel is identified by a name when it is created with <u>Connect</u> keyword and is released with <u>Close</u> keyword.

Notes: multi sessions to a same device could be done with predefined multi nodes to same device in the local.yaml file or by using multi <u>Connect</u> with different <u>name</u>.

Connections

The library provides a channel to a target node. Each channel is attached with a virtual terminal. Input and output to the node are made through this virtual terminal. This will help to provide the output looks like the output when operator is using the real terminal.

When keywords <u>Read</u>, <u>Write</u>, <u>Cmd</u> are used, if the connection is not available anymore, the system will try to reconnect to the host with the information provided in the 1st connect. It will try max_retry_for_connect times and wait for interval_between_retry seconds between retries. The values of max_retry_for_connect and interval_between_retry are defined in ./config/config.yaml

Usually when RENAT could not make the connections to the target, the system will raise an exception. But if the ignore_dead_node is defined as yes in the current active local.yaml, the system will ignore the dead node, remove it from the global variable LOCAL[node] and NODE and keep running the test.

Shortcuts

Broadcast Write With Tag · Change Log · Change Prompt · Close · Close

Keyword	Arguments	Documentation
Broadcast Write With Tag	cmd, *tag_list	Broadcasts <u>cmd</u> to all channels
Change Log	log_file, mode=w	Stops current log file and create a new log file.
		Default $mode$ is w which overwrite the existed logs. Change to a or $a+$ to append the current existed log files.
		Every log from that point will be saved to the new log file.
		Return old log filename
Change Prompt	str_prompt	Changes the current prompt of the channel
		Returns previous prompt. User should change the prompt before execute the new command that expects to see new prompt.

		Poutor Cwitch	vmv11	
		Router. Switch	vmx11	24 04
		\${prompt}=	VChannel. <u>Change Pror</u>	<u>npt</u> %
		VChannel. <u>Cmd</u>	start shell	
		VChannel. <u>Cmd</u> VChannel. <u>Change Prompt</u>	(Caramat)	
		Vchannel. <u>Cmd</u>	exit	
01	was with time False want ***		!	
Close	msg=, with_time=False, mark=***	Closes current connection a msg is the last message is		
Close All	msg=, with time=False, mark=***	Closes all current sessions		
	, <u>_</u>	msg is the last message the	_	
		Current node name was rese		
Cmd	command=, prompt=None, timeout=None,	Executes a command and v	vait until for the prompt	
	error_on_timeout=True, remove_prompt=False, match_err= (unknown command. syntax error, expecting <command/> .)	This is a blocking keyword. until the prompt appears.	Execution of the test c	ase will be postpon
	onpooning toominates y	If prompt is a null string (de ./config/template.yaml . Other temporarily prompt for this c	wise, it is a regular exp	
		timeout is the timeout for the vchannel/cmd-timeout or glo		
		The keyword returns error w default config value <i>cmd-au</i>		s the match_err and
		When remove_prompt is \${\text{will be remove from the retu}} information is unchanged.		
		Output will be automatically	logged to the channel	current log file.
		See Common for details about	out the config files.	
		Sample:		
		Router.Cmd version		
		Router.Cmd no prom	npt=\[yes/no\]:\${SPACE} npt=\[confirm\]	# reload a Cisco rou [is escaped twice
Cmd And Wait	command, keyword, interval=30s, max_num=10,	Router.Write Execute a command and ex	spect keyword occurs in	n the output. If not
For	error_with_max_num=True	for interval and repeat the process again After max_num, if error_with_max_num is True then the k		·
O A 10/ 1	and the state of t	Ortherwise the test continues.		
Cmd And Wait For Regex	command, pattern, interval=30s, max_num=10, error_with_max_num=True	 Execute a command and expect pattern occurs in the output for interval and repeat the process again 		the output. If not w
		When the keyword contains revsersed.	not: at the beginning, t	he matching logic i
		After max_num, if error_with Ortherwise the test continue		en the keyword will
Cmd More	cmd=, wait_prompt=.*\(more.*\), press_key= , prompt=None	Execute a command and pruntil the prompt	ess <i>press_key</i> when w	ait_prompt is displa
Cmd Yesno	cmd, ans=yes, question=? [yes,no], timeout=5s	Executes a cmd, waits for		
Connect	node, name, log_file, timeout=20m, w=80, h=32, mode=w	Connects to the node and create a VChannel instance		
	mode=w	Login information is automated defaullt a virtual terminal (vt channel.	•	-
		If a login was successful, V the connection in the curren contain any command input	t result folder of the tes	t case. This log file
		Multi sessions to the same <u>Switch</u> to change the curren	· · · · · · · · · · · · · · · · · · ·	
		Examples:		
		Connect vmx11 vmx11 vmx11 Connect vmx11 vmx11 vmx11	-	
		See Common for more deta	il about the yaml config	files.
Connect All	prefix=	Connects to all nodes that a		

		A prefix prefix was appended to the alias name of the connection. A new log file by <alias>.log was automatiocally created.</alias>	
		See Common for more detail about active local.yaml	
Current Prompt		Return current prompt	
Exec File	file_name, vars=, comment=#, step=False, mode=cmd, str_error=syntax,rror	Executes commands listed in file_name Lines started with comment character is considered as comments	
		Parameters:	
		file_name is a file located inside the config folder of the	
		test case	
		 mode: could be cmd or write which define that if the cmd is exectued by VChannel. <u>Cmd</u> or VChannel. <u>Write</u> if step is True, after very command the output is check agains 	
		an error list. And if a match is found, execution will be stopped. Error list i define by str_err, that contains multi regular expression separated by a comma. Default value of str_err is error	
		 vars are additional variables in format var1=value1,var2=value2 	
		The command file could be written in Jinja2 format. Default usable variables are LOCAL and GLOBAL which are identical to Common.LOCAL and Common.GLOBAL. More variables could be supplied to the template by vars.	
		A sample for command list with Jinja2 template:	
		show interface {{ LOCAL['extra']['line1'] }} show interface {{ LOCAL['extra']['line2'] }}	
		{% for i in range(2) %} show interface et-0/0/{{ i }} {% endfor %}	
		Examples:	
		Router. <u>Exec File</u> cmd.lst Router. <u>Exec File</u> step=\${TRUE} str_error=syntax,error	
		Note: Comment in the middle of the line is not supported For example if comment is "#"	
		# this is comment line < this line will be ignored ## this is not an comment line, and will be enterd to the router cli,	
		but the router might ignore this	
		step is ignored in write mode	
Flush All		Flushes all remain data into the logger	
Get Channel	name	Returns a channel by its name	
Get Channels		Returns all current vchannel instances	
Get Current Channel		Returns the current active channel	
Get Current Name		Returns the current active channel's name	
Get Ip		Returns the IP address of current node Examples:	
		\${router_ip}= Router. <u>Get IP</u>	
Log	msg	Writes the log message msg to current log file of the channel	
Read	silence=False	Returns the current output of the virtual terminal and automatically logs to file.	
		In normal mode this will return the unread output only, not all the content of the screen.	
Reconnect	name	Reconnects to the name node using existed information	
0.11.		The only difference is that the mode of the log file is set to `a+` by default	
Set Log Separator	sep=	Set a separator between the log of read, write or cmd keywords	
Snap	name, *cmd_list	Remembers the result of a list of command defined by cmd_list	
		Use this keyword with <u>Snap Diff</u> to get the difference between the command's result. The a new snapshot will overrride the previous result.	
Cnon Diff	nome	Each snap is identified by its name	
Snap Diff	name	Executes the comman that have been executed before by name snapsho and return the difference.	

		Difference is in context diff format
Start Screen		Starts the screen mode.
Mode		In the screen mode, the output is just the same with the real terminal. It means that any real-time application likes top will be captured as-is. Consecutive <u>read</u> from this VChannel instance may produce redundancy ouput.
Stop Screen		Stops the screen mode and returns to normal mode
Mode		In screen mode, <u>Write</u> does not return any thing and no output is logged. In normal mode, escape sequences are not processed by the virtual terminal.
Switch	name	Switches the current active channel to name. There only one active channel at any time
		Returns the current <i>channel_id</i> , <i>local_channel_id</i> and the output of current terminal.
		Notes: There is no assurance that the output of previous <u>Write</u> command will be in the retur output because keywords like Logger. Log All will update every channels.
		Examples:
		VChannel. <u>Switch</u> vmx12
Write	str_cmd=, str_wait=0s, start_screen_mode=False	Sends str_cmd to the target node and return after str_wait time.
		If start_screen_mode is True, the channel will be shifted to Screen Mode. Default value of screen_mode is False.
		In normal mode, a new line char will be added automatically to the str_cmd and the command return the output it could get at that time from the terminal and also logs that to the log file.
		In screen Mode, if it is necessary you need to add the new line char by your own and the ouput is not be logged or returned from the keyword.
		Parameters:
		 str_cmd: the command str_wait: time to wait after apply the command start_screen_mode: whether start the screen mode right after writes the command
		Special input likes Ctrl-C etc. could be used with global variable \${CTRL- <char>}</char>
		Returns the output after writing the command the the channel.
		When str_wait is not $0s$, the keyword read and return the output after waiting str_wait . Otherwise, the keyword return without any output.
		Notes: This is a non-blocking command.
		Examples:
		VChannel. Write monitor interface traffic start_screen_mode=\${TRUE} VChannel. Write \${CTRL_C} # simulates Ctrl-C

Altogether 30 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:34.



Logger

Library version:RENAT 0.1.14Library scope:test suiteNamed arguments:supported

Introduction

Provides advanced logging functions. Every <u>Logger</u> instance has one <u>VChannel</u> object and the is synchronized with the current active <u>VChannel</u>.

Notes: log file is not updated pararelly. Anytime a terminal is switched to, it will update its log file.

Shortcuts

Log · Log All · Switch

Keywords

Keyword	Arguments	Documentation
Log	msg, with_time=False, mark=***	Inserts a message msg to the current <i>VChannel</i> log file. A default mark of *** will be added at the beginning ant the end of this message. Example: Logger. Log START TRAFFIC FROM HERE \${TRUE} Logger.Log START TRAFFIC FROM HERE \${False} ===
Log All	msg, with_time=False, mark=***	Inserts a message msg to current all VChannel log files. A default mark of *** and newline will be added at the beggining and the end of this message. Example: Logger.Log All START TRAFFIC FROM HERE \${TRUE} Logger.Log All START TRAFFIC FROM HERE \${TRUE} === The log file will look likes this: user@vmx12> *** 06:01PM on August 13, 2017: START TRAFFIC FROM HERE *** === 06:01PM on August 13, 2017: START TRAFFIC FROM HERE === configure
Switch	name	Switches the current VChannel instance to name is the name of the VChannel (usually is the node name defined in the current active local.yaml). Example: Logger. Switch vmx11

Altogether 3 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:29.



OpticalSwitch

Library version:RENAT 0.1.14Library scope:test suiteNamed arguments:supported

Introduction

A library provides control for L1 Optical Switch

Unlike other device, there is no Switch keywork with optical switch. Usually user only need to care about the interfaces not the ports of the switches.

Shortcuts

 $\textbf{A} \texttt{d} d \cdot \textbf{C} \texttt{lear} \ \texttt{By} \ \texttt{File} \cdot \textbf{C} \texttt{lose} \ \texttt{All} \cdot \textbf{C} \texttt{onnect} \ \texttt{All} \cdot \textbf{D} \texttt{elete} \cdot \textbf{G} \texttt{et} \ \texttt{Connection} \ \texttt{Info} \cdot \textbf{L} \texttt{oad} \ \texttt{From} \ \texttt{File} \cdot \textbf{S} \texttt{ave} \ \texttt{To} \ \texttt{File} \cdot \textbf{S} \texttt{oad} \ \texttt{From} \ \texttt{File} \cdot \textbf{S} \texttt{oad} \ \texttt{From} \ \texttt{File} \cdot \textbf{S} \texttt{oad} \ \texttt{oad} \ \texttt{From} \ \texttt{File} \cdot \textbf{S} \texttt{oad} \ \texttt{oad} \$

Keywords

Keyword	Arguments	Documentation	
Add	dev1, intf1, dev2, intf2, direction=bi, force=False	Adds a connection. See details in each module help	
Clear By File	file_name=, comment=#	Clears all x-connections defined in the connection file	
		Default connection file is defined in optic/connection of config/local.yaml	
Close All		Close all connections	
Connect All		Connect to all L1 switch and read all neccesary information	
Delete	dev1, intf1, dev2, intf2, direction=bi, force=False	Deletes a connection. See details in each module help	
Get Connection Info	dev, intf	Returns connection information. See details in each module help.	
Load From File	file_name=, force=True, comment=#	Loads the connection file and set the connections filename is the name of the connection file under the current config folder. If filename is empty, the value of optic/connection from config/local.yaml will be used. The connection file supports jinja2 template language. Besides, # is the default comment char which could be changed	
		The format of connection file follows: ■ each connection is described by 1 line ■ source and destination are separated by `- or > , which mean `bidirection or unidirection (unidirection connects source tx to dest rx Connection file sample:	
		device1:port1 - device2:port2 device1:port3 > device2:port	
		Examples: OpticalSwitch. Load From File OpticalSwitch. Load From File save1.conn	
Save To File	file_name	Saves the current connection of all devices in this test. By default, all interfaces of the devices are save. If a connection file is given, only interfaces specified in the connection file are saved Examples: OpticalSwitch. Save To File save1.conn	

Altogether 8 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:33.



calient

Library scope: global **Named arguments:** supported

Introduction

A library provides control for Calient Optical Switch

Table of Contents

- Master file
- Connection file Format
- Shortcuts
- <u>Keywords</u>

Master file

The L1 switch provides a mechanism to remotely connect device interface. Each device interface has been wired to L1 switch already. The connection was described in the master file located specific by *calient-master-path* in the configuration file *renat/config/config.yaml*.

The master file includes several Calients in each tab. The column meaning and order is trivial.

Connection file Format

Keywords Load From File, Clear By File and Save To File use the x-connection file. X-connection files are text files and have the following format:

this is the comment device1,interface1,-,device2,interface2 device1,interface1,>,device2,interface2

The separator - means a bidirection connection and > means a unidirection connection. For a unidirection connection, device1/interface1 TX will be connected to device2/interface2 RX.

Note: The separator character must be surrounded by spaces or commas.

The connection file also support jinja2 template format. After the template is evaluated, comment could be used by comment char

There is no need to specify which L1 switch for the x-connection. The system will automatically find the appropriate switch.

Shortcuts

 $\textbf{A} \texttt{dd} \cdot \textbf{D} \texttt{elete} \cdot \textbf{G} \texttt{et} \, \texttt{Connection Info}$

Keyword	Arguments	Documentation	
Add	self, dev1, intf1, dev2, intf2,	Adds x-connection between dev1:intf1 and dev2:intf2	
	direction=bi, force=False	direction is bi for bi-direction or uni for uni-direction. If direction is uni, the tx of dev 1:port 1 will be connected to dev 2:port 2.	
		With force mode, existed connection that use those ports will be deleted. Without force mode, an existed connection will make the keyword fails	
		Examples:	
		OpticalSwitch. <u>Add</u> mx2008-31-33 xe-3/0/0 mx2008-31-33 xe-3/0/1 bi \${TRUE}	
		Note : when force is False but the current ports is owned by the same connection endpoints, keyword will succeed.	
		For a bidirection connection, 2 single uni-direction connection will be made instead of 1 bidirection connection. This will make the link could be simulated tx/rx failure later.	
Delete	self, dev1, intf1, dev2, intf2, direction=bi, force=False	Deletes the connection between dev1:intf1 - dev2:intf2	
	unection=bi, force=raise	Examples:	
		OpticalSwitch. <u>Delete</u> mx2008-31-33 xe-3/0/1 mx2008-31-33 xe-3/0/1 uni	
Get Connection Info	self, dev, intf	Returns information of the optic switch port that connected to dev:intf. The information is in jason format.	
		Examples:	
		OpticalSwitch. Get Connection Info mx2008-31-33 xe-3/0/1	
		return information looks like below:	
		result = {u'outoc': u'NOHW', u'outopwdh': u'-20.0', u'inos': u'OOS', u'outalias': u", u'inowner': u'TRANSIT', u'outopwct': u'-23.0', u'inpower': u'-3.4', u'inas': u'IS', u'outpower': u'-4.8', u'outas': u'OOS-NP', u'inopt': u'-17.0', u'inopth': u'13.0', u'incircuit': u'3.3.1>3.3.2', u'inalias': u",	
		u-17.0, u mopur. u 15.0, u monut. u 5.0.1>5.3.2, u manas. u ,	

 $u'inoc': u'NOHW', u'inoptc': u'-20.0', u'outos': u'OOS', u'port': u'3.3.1', u'outowner': u'NONE', u'outcircuit': u"\}\\$

Altogether 3 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:40.



g4ntm

Library scope: global **Named arguments:** supported

Introduction

A library provides control for Telescent Network Topology Management (NTM) robot patch.

Shortcuts

Add · Delete · Get Connection Info

Keywords

Keyword	Arguments	Documentation	
Add	self, dev1, intf1, dev2, intf2, direction=bi, force=False		
Delete	self, dev1, intf1, dev2, intf2, direction=bi, force=False	Deletes the connection between dev1:intf1 - dev2:intf2	
Get Connection Info	self, dev, intf	Returns information about the connection by router/interface	

Altogether 3 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:41.



Router

Library version:RENAT 0.1.14Library scope:test suiteNamed arguments:supported

Introduction

A class provides keywords for router control. An instance of Router class automatically assigned methods of a VChannel class (**Note**: this is not an inheritance but rather 1-to-1 relation)

See VChannel for more details about VChannel.

Device's type is defined in master device.yaml. The system will load appropriate modules for each device.

Details about keywords provided by modules could be found in document of each module likes:

- Juniper module
- Cisco module
- GR module

Keywords provides by above module could be executed through Xrun keyword or directly called from Router. Examples:

Router. Switch	vmx12
Router. Xrun	Load Config
Router.Load Config	

Shortcuts

Follow Mib · Xrun

Keywords

Keyword	Arguments	Documentation
Follow Mib		Waits until all the nodes defined in node_list become stable.
	percentile=80, threshold=75, max_len=300, factor=1	Stableness is checked by SNMP polling result. The MIB list is define by mib in node section Parameter:
		 wait_time(1): the time before the evaluation starting interval_time(2): interval between SNMP polling time threshold: below this value is evaluated as stable len(3): the size of the evaluation window (number of values that are used in each valuation) percentile: real useful percentage of data (ignore top 100-percentile percent) max_len(4): maximum waiting lend for this checking time sequence:(1)[-(2)- <(3)> poll poll <(4)>
Xrun	cmd, *args, **kwargs	Runs the vendor independent keywords.
		Parametes: cmd: a keyword args: other argumemts Examples:
		Router. Xrun Flap Interface ge-0/0/0 This keyword will then actually calling the correspond keyword for the device type.

Altogether 2 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:30.



cisco

Library scope: global Named arguments: supported

Introduction

Documentation for test library cisco.

Shortcuts

Get User · Get Version

Keywords

Keyword	Arguments	Documentation	
Get User	self	Return the current login user	
Get Version	self	return router version information	

Altogether 2 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:35.



gr

Library scope: global Named arguments: supported

Introduction

Provides keywords for Hitachi GR platform

Shortcuts

Get Chassis Serial · Get Version

Keywords

Keyword	Arguments	Documentation
Get Chassis Serial	self	Returns the serial number of the chassis
Get Version self		return router version information

Altogether 2 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:35.



juniper

Library scope: global **Named arguments:** supported

Introduction

Provides keywords for Juniper platform

Notes: Ignore the self parameters when using those keywords.

Shortcuts

Copy Config · Copy File · Create Best Path Select Data · Disable Interface · Enable Interface · Flap Interface · Get Chassis Serial · Get Cli Mode · Get Config · Get Current Datetime · Get File · Get Intf Addr · Get Route Number · Get Version · Link Status · Load Config · Number Of Bgp Neighbor · Number Of Ospf Neighbor · Number Of Ospf3 Neighbor · Push Config

Keyword	Arguments	Documentation	
Copy Config	self, dst_name=None	Gets the configuration file of the router	
		This keyword directly copy the configuration file from the router	
Copy File	self, src_path, filename=None,	Copies a file from router	
	pre_config=None, pos_config=None	Parameters:	
		 src_path: a absolute path insides the router filename: a file name under result folder 	
Create Best Path Select Data	self, route_content, output_excel=best.xlsx	Creates the matrix of best path selection Provides the test described in smb://10.128.3.91/SharePoint01/31_VerificationRoom/31_13_検証環境セット/BGP- Best-Path-SelectionのAll-in-One設定_20161118改良/ The test uses predefined Ixia config and follows predefined steps	
Disable Interface	self, intf	Disables an interface intf	
Enable Interface	self, intf	Enables an interface intf	
Flap Interface	self, intf, time_str=10s	Simulates an interface flap for interface intf	
		Disables the interface and wait for a while before turning it up again	
Get Chassis Serial	self	Returns the serial number of the chassis	
Get Cli Mode	self	Returns current mode of the CLI.	
		Return value is config for configuration mode or command for command mode	
Get Config	self, dst_name=None	Gets the current configuration file of the router to current result folder.	
		Default dst_name is juniper.conf.gz This keyword push the configuration from FROI the router to the RENAT server	
Get Current self, time_format=%H:%M:%S, Datetime delta_time=0s, dir=+, **kwargs		Returns the current date time with vendor format delta_time will be added or subtracted to current time, default is 0s	
		time_format decides the time part of the output. Example result are :	
		May 24 04:14:25 May 4 04:14:25	
		Note: The date part is padded by space, and the result is allways 15 characters	
Get File	self, src_file, dst_file=None	Gets a file from router	
		Parameters:	
		 src_file: a absolute path insides the router dst_file: a file name under result folder 	
		if dst_file is not defined, it will be the filename of the src_file .	
		The keyword copy the specific file FROM the router to the RENAT server	
Get Intf Addr	self, intf_name, family=inet	Returns the tuple of address and netmask of an interface	
		family should be inet or inet6 If the address is not set, (",") will be returned.	
Get Route	self, table=inet.0	Returns number of active route in the table	
Number		table could be inet.0 or inet.6	
Get Version	self	Returns router version information	

Link Status	self, if_name	Returns link physical status as string (aka: "up down", "up up")		
Load Config self, mode=set, config_file=, confirm=0s, vars=, err_match=(error: unknown command:)		Loads configuration to a router. Usable mode is set, override, merge and replace set mode uses configuration that contains set command. Mode override, merge and replace use ordinary JunOS configuration file with appropriate mode. config_file is a configuration file inside the config folder of the current test case. Config file could includes jinja2 template. The template will be evalued with LOCAL, GLOBAL and varibles defined by vars. The vars has the format: var1=value1,var2=value2 If the loading has no error that match the error_match, the configuration will be commited. The keywordl waits for confirm seconds before rollback the commited configuration.		
Number Of Bgp Neighbor	self, state=Established, cmd=show bgp neighbor match "Type"	A zero value indicates an immediatly commit Returns number of BGP neighbor in state state		
Number Of Ospf Neighbor	self, state=Full, cmd=show ospf neighbor	Returns number of OPSF neighbors with status state		
Number Of Ospf3 Neighbor	self, state=Full, cmd=show ospf3 neighbor	Returns number of OPSFv3 neighbors with status state		
Push Config	self, mode=set, config_file=, pre_config=None, pos_config=None, confirm=0s, vars=, err_match= (error: unknown command:)	Pushes configuration directly to the router Usable mode is set, override, merge and replace set mode uses configuration that contains set command. Mode override, merge and replace use ordinary JunOS configuration file with appropriate mode. config_file is a configuration file inside the config folder of the current test case. Config file could includes jinja2 template. The template will be evalued with LOCAL, GLOBAL and varibles defined by vars. The vars has the format: var1=value1,var2=value2 If the loading has no error that match the error_match, the configuration will be commited. The keywordl waits for confirm seconds before rollback the commited configuration. A zero value indicates an immediatly commit pre_config and pos_config is extra configuration commands separated by ; that would be excuted before and after the configuration is loaded. It could be used to add extra firewall rules to the router. Note: by default the keyword will activate the SSH service on the router if the service is not activated and disable the service after loading the configuration.		

Altogether 20 keywords. Generated by <u>Libdoc</u> on 2019-03-31 15:26:35.



WebApp

Library version: RENAT 0.1.14
Library scope: test suite
Named arguments: supported

Introduction

A library provides common keywords for web applications (aka Samurai, Arbor TMS)

The library utilize Selenium2Library and adds more functions to control Samurai application easily.

The WebApp uses the configuration in local.yaml in webapp section. The webapp device has following format:

ssl: <

Where <device name> is defined in master device.yaml, proxy section could be optional.

In order to download files from link, a dowload-path and MIME of that download need to be listed in profile section of the application setting. Default download-path is the current active result folder.

Examples:

... webapp: samurai-1: device: samurai-b

profile: auto-save-mime: application/octet-stream

proxy:

http: 10.128.8.210:8080 ssl: 10.128.8.210:8080

arbor-1:

device: arbor-sp-a

profile: auto-save-mime: application/xml,application/octet-stream

proxy:

http: 10.128.8.210:8080 ssl: 10.128.8.210:8080

Selenium2Library keywords still could be used along with this library like this:

Click Link	//a[contains(.,'ユーザ設定')]
Sleep	2s
Click Link	Home設定
Sleep	2s
Samurai.Capture Screenshot	

See Selenium2Library for more details.

The module Samurai and Arbor based on this module. See Arbor, Samurai for details about keywords of each application.

Shortcuts

Capture Screenshot · Close · Close · Close · Close · Mark Element · Open Ff With Profile · Reset Capture Counter · Set Ajax Wait · Set Capture Counter · Set Capture Format · Set Verbose · Switch · Verbose Capture · Wait Until Element Changes

Keyword	Arguments	Documentation			
Capture Screenshot	filename=None, extra=	Captures the current screen to file Using the internal counter for filename if filename is not specified. In this case, the filename is defined by a pre-set format. Set Capture Format could be used to change the current format. An extra information will be add to the filename if extra is defined Examples:			
		Samurai. <u>Capture Screenshot</u> Samurai. <u>Capture Screenshot</u> extra= list	# samurai_000000001.png # samurai_0000000002_list.png		
		Arbor. <u>Capture Screenshot</u>	# arbor_0000000001.png		
		Arbor. <u>Capture Screenshot</u> extra=_xxx	# arbor_000000001_xxx.png		
		Samurai. Capture Screenshot filename=1111.png	# 1111.png		

Close		Close the web application	
Close All		Closes all current opened applications	
Get Verbose		Get current verbose mode	
Mark Element	xpath	Marking an element to check its stattus later	
Open Ff With Profile	app, name		
Reset Capture Counter		Resets the counter of the screen capture	
Set Ajax Wait	wait_time=2s	Set the ajax wait time	
Set Capture Counter	value=0	Sets the counter of the screen capture to value	
Set Capture Format	format	Sets the format for the screen capture file The format does not include the default prefix .png The default format is <mod>_%010d. mod could be samurai or arbor See https://docs.python.org/2/library/string.html#format-specification-mini-language for more details about the format string. Examples: Samurai. Set Capture Format \${case} %010d #\${case} is a predefined variable</mod>	
Set Verbose	verbose=False	Set current verbose mode to verbose	
Switch	name	Switches the current browser to name	
Verbose Capture	*args, **kwargs	Capture screenshot if verbose mode is True otherwise do nothing	
Wait Until Element Changes	interval=5s, timeout=180s, error_on_timeout=False	Wait until the marked element has been changed	

Altogether 14 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:42.



Samurai

Library version: RENAT 0.1.14
Library scope: test suite
Named arguments: supported

Introduction

A library provides functions to control Samurai application

The library utilize SeleniumLibrary and adds more functions to control Samurai application easily. Without other furthur mentions, all of the concepts of user, user group are Samurai concepts. By default, RENAT will try to connec to all Samurai nodes defined in active local.yaml at the beginning of the test and disconnect from them at the end of the test automatically. Usually user does not need to use Connect All and Close explicitly.

Currently, this module supposed that Samurai is used in Japanese locale. When Samurai module has error, it tried to make the last snapshot in result/selenium-screenshot-x.png. Checking this capture will help to understand the reason of the error.

Currently the module support Samurai 09/14/16

Some keywords of Samurai is using xpath to identify elements. See Selenium2Library for more details about xpath.

See WebApp for common keywords of web applications and how to configure the local.yaml file.

Selenium2Library keywords still could be used together within this library. See Selenium2Library for more details.

Shortcuts

Add Policy Group · Add User · Capture Screenshot · Change Policy View Group · Click All Elements · Close · Close All · Close Window · Connect · Connect All · Delete Policy · Delete Policy Group · Delete User · Edit Mitigation Controller · Edit Policy · Get Mitigation List · Get Verbose · Left Menu · Login · Logout · Make Item Map · Mark Element · Open Ff With Profile · Reconnect · Reset Capture Counter · Select Items In Table · Select Window · Set Ajax Wait · Set Capture Counter · Set Capture Format · Set Verbose · Show Detail Mitigation · Show Policy Basic · Show Policy Detection · Show Policy Display · Show Policy Mitigation · Show Policy Monitor · Show Policy Notify · Show Policy Nw Monitor · Show Policy Traffic · Start Mitigation · Stop Mitigation · Switch · Update Mitigation Controller Info · Verbose Capture · Wait Until Element Changes

Keyword	Arguments	Documentation				
Add Policy	**policy	Adds a new Samurai policy	Adds a new Samurai policy			
		policy is a map containing the	policy is a map containing the below information to create the new policy.			
					-	
		key name	meaning name of the	mandatory yes	sample test001	
			policy	yes		
		basic_alias	alias name of the policy		test001	
		basic_port_id	another alias			
		basic_facing	customer or backbone		customer	
		basic_intf_list	list of router and interface pair, separated by comma	yes	10.128.18.31:xe-0/0/0.1	
		basic_cidr_list	list of CIDR separate by comma			
		basic_option_filter	optinal filter			
		basic_direction	direction of the traffic (incoming or outgoing)		incoming	
		traffic_enabled	Enable traffic monitoring or not	yes	\${TRUE} or \${FALSE}	
		detection_enabled	Enable detection or not	yes	\${TRUE} or \${FALSE}	
		detection_direction	change detect direction fo all attack type	incomming, outgoing, `both both:check		
		mitigation_enabled	Enable Mitigation or not	yes	\${TRUE} or \${FALSE}	
		mitigation_zone_name	Name of the zone for mitigation		zone001	
		mitigation_zone_prefix	Prefixes that could mitigate		1.1.1.1/32	
		mitigation_thr_bps	Upper limit (bps)		800,000,000	
		mitigation_thr_pps	Upper limit (pps)		54,000,000	
		mitigation_auto_enabled	Enable automitgation or not		\${TRUE} or \${FALSE}	
		mitigation_auto_level	Automitgation level		0:overLow 1:overMedium 2:High	
		mitigation_auto_time	Automitigation detect attack time (min)		default is 15	
		mitigation_mo_enabled	Using Arbor TMS MO or not	yes	\${TRUE} or \${FALSE}	

ทาแบลแบท_สนเบ_รเบp_ยาสมเยน	automitgation stop or not		هر ١٦٠٠ ١ مر ١٦٠١ مر ١٦٠١ مر
mitigation_auto_stop_level	Automitgation level		0:overLow 2:High
mitigation_auto_stop_time	Automitigation stop detect attack time (min)		default is 15
mitigation_device_list	Devices used for TMS, separated by comma		ArborSP-A
mitigation_mo_name	MO name, separated by comma		OCN12(ALU)_LOOSE
mitigation_comm_list	commna separated peer/community list		1.10(180.0.1.10)/2914:666,1.11(180.0.1.11)/2914:777
nw_monitor_gre1	1st GRE address for NW monitor		210.0.1.1
nw_monitor_gre2	2nd GRE address for NW monitor		210.0.1.1
nw_monitor_ce1	1st CE address for NW monitor		210.0.1.2
nw_monitor_ce2	2nd CE address for NW monitor		210.0.1.2
nw_monitor_pe1	1st PE for NW monitor (list)		edge01hige-MX2020-15(118.23.176.244)
nw_monitor_pe2	2nd PE for NW monitor (list)		edge01hige-MX2020-15(118.23.176.244)
event_name	name of the message event to make		info1
event_addr	address to send the events		user@mail.com
view_group	user group that could view this policy, separated by comma	yes	SuperGroup,test_group_007

Example:

Samurai. Switch	samurai-1	
Samurai. <u>Add</u>	name=\${POLICY_NAME}	basic_alias=\${POLICY_NAME}
<u>Policy</u>		
	basic_facing=customer	basic_intf_list=10.128.18.31:xe- 0/0/0.1
	basic_cidr_list=1.1.1.0/24	basic_direction=incoming
	traffic_enabled=\${TRUE}	
	detection_enabled=\${TRUE}	
	mitigation_zone_name=test_zone001	mitigation_zone_prefix=1.1.1.1/32
	mitigation_device_list=ArborSP-A,ArborSP-B	
	mitigation_mo_enabled=\${TRUE}	
	mitigation_mo_name=N000000012_LOOSE	
	mitigation_comm_list=1.10(180.0.1.10)/2914:666,1.11(180.0.1.11)/2914:777	
	event_name=test	event_addr=user@mail.com
	view_group=SuperGroup	

Add Policy	group_name,	
Group	policy_list=*,	
	limit_bps=4000000000,	
	limit pps=2700000	

Add a new policy group

group_name is the name of the new group. policy_list is a comma separated of existed policy that should be bound to this policy. An asterisk for this parameter (*) means all of the existed policy. limit_bps and limit_pps are the mitigation capacity threshold of this group.

Add User group, **user_info

Adds user to the current group user_info is a dictionary contains user information that has following keys: name, password, privilege and policy

privilege is existed privilege that has been created (e.g. system_admin.

policy could be * for all current policies or a list of policy names that are binded to this user.

group is the user group. Dot(.) means current group

Examples:

Samurai. <u>Add User</u>	OCNDDoS	name=user000	password=Test12345678
	privilege=system_admin	policy=*	
Samurai. <u>Add User</u>	OCNDDoS	username=user001	password=Test12345678
	privilege=system_admin	policy=OCN11,OCN12	

Capture Screenshot

filename=None, extra=

Captures the current screen to file

Using the internal counter for filename if filename is not specified. In this case, the filename is defined by a pre-set format. <u>Set Capture Format</u> could be used to change the current format.

An extra information will be add to the filename if extra is defined

Examples:

Samurai. <u>Capture Screenshot</u>	# samurai_000000001.png
Samurai. Capture Screenshot extra=_list	# samurai_0000000002_ <i>list.</i> png
Arbor. Capture Screenshot	# arbor_000000001.png
Arhor Cantura Screenshot Avtra- vvv	# arbor 000000001 vvvnna

		Samurai. Capture Screenshot filename=1111.png # 1111.png		
Change Policy	name, *group_name	Changes the groups that could see this policy		
View Group	, 3 p	name is the policy name. group_name is a list of policies		
		Example:		
		Samurai. Change Policy View Group super_admin test_group001		
Click All Elements	xpath	Click all element in current page defined by xpath		
Liements		Returns the number of elements that have been clicked		
Close		Close the web application		
Close All		Closes all current opened applications		
Close Window		Closes the current window		
Connect	app, name	Opens a web browser and connects to application and assigns a name.		
		■ app is the name of the application (e.ge. samurai-1)		
		■ name is the name of the browser		
		If not defined in local.yaml those following key will have defaut values:		
		browser firefox optional		
		login_url / optiona		
		proxy: optional		
		http: 10.128.8.210:8080 optional		
		ssl: 10.128.8.210:8080 optional socks: 10.128.8.210:8080 optional		
Connect All				
Connect All		Connects to all applications defined in local.yaml		
		The name of the connection will be the same of the webapp name		
Delete Policy	*policy_names	Deletes poilcies by their names		
		Returned the number of deleted users		
		Notes: If the policy does not exists, the system will not report any error.		
		Examples:		
		Samurai. Delete Policy test001 test002		
Delete Policy	*group_list			
Group	group_nst	Deletes policy groups		
		See <u>Select Items In Table</u> for more detail about how to choose group_list		
		Returns the number of deleted policy groups Example:		
		Samurai. <u>Delete Policy Group</u> test_group001 test_group002		
Delete User	group, *user_list	Deletes user from the user group		
		group is the user group. And . means current group Returns the number of deleted users		
		Examples:		
		Samurai. <u>Delete User</u> SuperGroup user001 user002		
		Samurai. <u>Delete User</u> . user002		
Edit Mitigation	controller, **config	Change the setting of the mitigation control		
Controller	, ,	■ control: name of the mitigation controller		
		 config: configuration need to be changed. Currently only tms_group is configurable with the following format: 		
		groupname1:action1,groupname2:action2. groupname is currently set TMS group name and action could be click,check		
		or uncheck.		
		Example:		
		Samurai Edit Mitigation Controller controller=vSP-A tms. group=l ogical0_SOCN_IPv4_uncheck		
Edit Policy	**policy	Samurai <u>Edit Mitigation Controller</u> controller=vSP-A tms_group=Logical0_SOCN_IPv4:uncheck Edits a Samurai policy		
	T. Control of the Con	policy contains information about the policy. See <u>Add Policy</u> for more details about policy format		
		pone, contains about the pene, cost and about pone, contains about pone, contains		
Get Mitigation	status=実行中	Gets current mitigation list		
Get Mitigation List	status=実行中			
_	status=実行中	Gets current mitigation list		
_	status=実行中	Gets current mitigation list Return current active mitgation name, ID and the number of them Example:		
List	status=実行中	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List}		
List Get Verbose		Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode		
_	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name		
List Get Verbose		Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MIT}} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string.		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //div[@id="infoareain2"]*//td[1]/a means the list of link of all elements in a 1st column of a table insides a		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //div[@id="infoareain2"]*//td[1]/a means the list of link of all elements in a 1st column of a table insides a div with id infoareain2.		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MITI} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //div[@id="infoareain2"]*//td[1]/a means the list of link of all elements in a 1st column of a table insides a		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MIT}} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //divi@id="infoareain2"/"//td[1]/a means the list of link of all elements in a 1st column of a table insides a div with id infoareain2. Examples: Samurai.Left Menu Traffic		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MIT}} \${IDS} \${NUM}= Samurai.Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //divi@id="infoareain2"/*//td[1]/a means the list of link of all elements in a 1st column of a table insides a div with id infoareain2. Examples: Samurai.Left Menu Samurai.Left Menu Detection		
List Get Verbose	menu, locator=None,	Gets current mitigation list Return current active mitgation name, ID and the number of them Example: \${MIT}} \${IDS} \${NUM}= Samurai. Get Mitigation List} Get current verbose mode Chooses the left panel menu by its displayed name When locater is not null, the keyword will return a list of text attribute of all elements specified by the locator. locator could be a xpath or a predefined string. locator predefined strings are: MITIGATE_REALTIME, MITIGATE_LIST, DETECT_LIST For example, a xpath //divi@id="infoareain2"/"//td[1]/a means the list of link of all elements in a 1st column of a table insides a div with id infoareain2. Examples: Samurai.Left Menu Traffic		

		User and password is set by the template and authentication methods in the master files	
Logout		Logs-out the current application, the browser remains	
Make Item Map	xpath	Makes a item/webelement defined xpath	
		The map is a dictionary from item to the WebElement Items name found by xpath are used as keys	
Mark Element	xpath	Marking an element to check its stattus later	
Open Ff With Profile	app, name		
Reconnect		Reconnects to the server	
Reset Capture Counter		Resets the counter of the screen capture	
Select Items In	xpath, xpath2, *item_list	Checks items in Samurai table by xpath	
Table		xpath points to the column that used as key and xpath2 is the relative xpath contains the target column.	
		item_list is a list of item and its action that need to check. Item in the list could be a regular expression with the format re: <regular expression=""> action.</regular>	
		The default action for the item could be click '(default), 'check or uncheck	
		The keyword is called with assuming that the table is already visible.	
		Returns the tupple of all items and selected items	
		Note: Non-width-space (\u200b) will be take care by the keyword.	
		Note: if the first item list is *then the keywork will try to click a link named すべてを選択.	
Select Window	title	- , ,	
	wait time=2s	Selects a window by its title	
Set Ajax Wait	value=0	Set the aparter of the agree continue to unlike	
Set Capture Counter	value=0	Sets the counter of the screen capture to value	
Set Capture	format	Sets the format for the screen capture file	
Format		The format does not include the default prefix .png The default format is <mod>_%010d. mod could be samurai or arbor</mod>	
		See https://docs.python.org/2/library/string.html#format-specification-mini-language for more details about the format string.	
		Examples:	
		Samurai. Set Capture Format \${case} %010d # \${case} is a predefined variable	
Set Verbose	verbose=False	Set current verbose mode to verbose	
Show Detail	id	Shows detail information of a mitigation	
Mitigation		Onows detail illumination of a militigation	
Show Policy	policy_name	Makes the virtual browser show basic setting of the policy name.	
Basic		A following Samurai. Capture Screenshot is necessary to capture the result.	
Show Policy Detection	policy_name	Shows the detction pannel of <i>policy_name</i> policy	
Show Policy	policy_name	Make a virtual browser show the display setting of a policy	
Display		Notes : Depending on the setting of the policy, MO panel may not be existed. In this case, if <i>strict</i> is True, then the keyword will fail.	
Show Policy Mitigation	policy_name	Make the virtual browser show the mitigation setting of a policy	
Show Policy	policy_name,	Make the virtual browser show the MO setting of a policy	
Мо	strict=False	Automatically expand the MO section of other devices. Notes : Depending on the setting of the policy, MO panel may not be existed. In this case, if <i>strict</i> is True, then the keyword will fail.	
Show Policy Monitor	policy_name		
Show Policy Notify	policy_name	Make a virtual browser show the mitigation setting of a policy	
Show Policy	policy_name,	Make a virtual browser show the NW monitor setting of a policy	
Nw Monitor	strict=False	Notes : Depending on the setting of the policy, MO panel may not be existed. In this case, if <i>strict</i> is True, then the keyword will fail.	
Show Policy	policy_name	Makes the virtual browser show the traffic setting of the policy <i>name</i> .	
Traffic		A following Samurai. Capture Screenshot is necessary to capture the result.	
Start Mitigation	policy, prefix,	Starts a mitigation with specific prefix	
_	comment=mitigation started by RENAT, device=None,	device is used for matching real device name configured by Samurai If force is TRUE then the keyword will fail if selected device does not contain device	
	force=False	Returns mitigation id and selected arbor device	
		Example:	
		\$\(\frac{1}{3}\) \$\(\frac{1}\) \$\(\frac{1}{3}\) \$\(\frac{1}{3}\) \$\(\frac{1}{3}\) \$\(
Stop Mitigation	id, raise_error=True		
own winganon	ia, raise_enui=nue	Stops a mitigation by its ID The leaves and will raise an error if raise array in True. Otherwise it will impact any arrays.	
		The keyword will raise an error if raise_error is True. Otherwise it will ignore any errors.	
		Example:	
		Samurai. Stop Mitigation 700	
Switch	name	Switches the current browser to name	
l Indata	controller wait-10c	Undates information of controller	

Mitigation Controller Info	controller, water 100	Opuates information of controller
Verbose Capture	*args, **kwargs	Capture screenshot if verbose mode is True otherwise do nothing
Wait Until Element Changes	interval=5s, timeout=180s, error_on_timeout=False	Wait until the marked element has been changed

Altogether 48 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:43.



Arbor

Library version:RENAT 0.1.14Library scope:test suiteNamed arguments:supported

Introduction

A library provides functions to control Arbor application

The library utilize SeleniumLibrary and adds more functions to control Arbor application easily.

See WebApp for common keywords of web applications.

SeleniumLibrary keywords still could be used along with this library. See SeleniumLibrary for more details.

Notes: From 0.1.10, move from Selenium2Library to SeleniumLibrary

Shortcuts

Capture Screenshot · Clean Status Msg · Close · Close All · Commit · Connect · Connect All · Detail First Mitigation · Get Status Msg · Get Verbose · Login · Logout · Mark Element · Menu · Open Ff With Profile · Reconnect · Reset Capture Counter · Set Ajax Wait · Set Capture Counter · Set Capture Format · Set Verbose · Show All Mitigations · Show Detail Countermeasure · Show Detail First Mitigation · Show Detail Mitigation With Order · Switch · Verbose Capture · Wait Until Element Changes

Keyword	Arguments	Documentation		
Capture	filename=None, extra=	Captures the current screen to file		
Screenshot		Using the internal counter for filename if filename is not specified. In this case, the filename is defined by a pre-set format. <u>Set Capture Format</u> could be used to change the current format.		
		An extra information will be add to the filename if extra is defined		
		Examples:		
		Samurai. Capture Screenshot # samurai_000000001.png		
		Samurai. Capture Screenshot extra=_list # samurai_0000000002_list.png		
		Arbor. Capture Screenshot # arbor_000000001.png		
		Arbor. Capture Screenshot extra=_xxx # arbor_000000001_xxx.png		
		Samurai. Capture Screenshot filename=1111.png # 1111.png		
Clean Status Msg		Disposes any alert or status messgae at the top of the current page		
Close		Close the web application		
Close All		Closes all current opened applications		
Commit	strict=True	Commit the current changes		
		If <i>strict</i> is \${TRUE} then the keyword fails if there is not change to commit. Otherwise, it does nothing		
Connect	app, name	Opens a web browser and connects to application and assigns a name. Extra information could be added to the webapp sections likes login-url, browser or profile-dir. Default values are: browser firefox login-url /		
Connect All		Connects to all applications defined in local.yaml The name of the connection will be the same of the webapp name		
Detail First Mitigation				
Get Status Msg		Get current status message		
		Return null string if no message exists		
Get Verbose		Get current verbose mode		
Login		Logs into the Arbor application		
Logout		Logs-out the current application, the browser remains		
Mark Element	xpath	Marking an element to check its stattus later		
Menu	order, wait=2s, capture_all=False, prefix=menu_, suffix=.png,	Access to Arbor menu		

	partial_match=False	Parameters			
		 order is the list of top menu items sep wait is the wait time after the last item if capture_all is True then a screenshot automtically. In this case, the image file items 	is clicked It is captured for each menu item		
		prefix and suffix.			
		by default, the system try to match the True, partial match is applied.	menu item in full, when partial_match is		
		Examples:			
		Arbor. Menu order=Alerts/Ongoing			
		Arbor. <u>Capture</u> <u>Screenshot</u>			
		Arbor. Menu order=Alerts/All Alerts			
		Arbor. <u>Capture</u>			
		Screenshot Arbor.Menu order=System/Status/I	Deployment Status		
		Arbor. <u>Capture</u>			
		Screenshot Arbor.Menu order=System/Status/S	Signaling partial_match=\${TRUE}		
		Status/Appliance Statu			
Open Ff With	ann nama	Arbor. <u>Capture</u> Screenshot			
Profile	app, name	<u>Gordinatio</u>			
Reconnect		Reconnect to server if necessary			
Reset Capture Counter		Resets the counter of the screen capture			
Set Ajax Wait	wait_time=2s	Set the ajax wait time			
Set Capture Counter	value=0	Sets the counter of the screen capture to value			
Set Capture Format	format	Sets the format for the screen capture file			
		The format does not include the default prefix .png The default format is <mod>_%010d. mod could be samurai or arbor See https://docs.python.org/2/library/string.html#format-specification-mini-language for more details about the format string. Examples:</mod>			
Set Verbose	verbose=False	Samurai. Set Capture Format \${case}_%010d # \${case} is a predefined variable Set current verbose mode to verbose			
Show All	Volume Tales	Shows all mitigations			
Mitigations					
Show Detail Countermeasure	name, *method_list	name is used to search the the mitigation a	Shows detail informatin about a countermeasure name is used to search the the mitigation and method_list is a list of countermeasures that are listed in Arbor Countermeasures panel Example:		
		\${NAME} \${ID}=	Show Detail First Mitigation		
		Arbor. Show Detail Countermeasure Arbor. Capture Screenshot	E) DNS Malformed		
		Sleep 10s			
		Arbor. Show Detail Countermeasure Arbor. Capture Screenshot	Zombie Detection HTTP Malformed		
Show Detail		Shows details about the 1st mitigation on the	ne list		
First Mitigation		The keyword returns the <i>mitigation ID</i> and it			
Show Detail Mitigation	search_str	Shows detail information of a mitigation by	its search_str		
Show Detail	order	Note: the result could include multi mitigation			
Mitigation With Order	order.	Shows details about the <i>order</i> (th) mitigation in the current list order is counted from 1. The keyword returns the mitigation_id and its name			
		Example:	1 7		
		\${NAME} \${ID}=	Arbor. Show Detail Mitigation With Order 3		
		Log To Console \${NAME}:\${ID}			

Switch	name	Switches the current browser to name
Verbose Capture	*args, **kwargs	Capture screenshot if verbose mode is True otherwise do nothing
Wait Until Element Changes	interval=5s, timeout=180s, error_on_timeout=False	Wait until the marked element has been changed

Altogether 29 keywords. Generated by <u>Libdoc</u> on 2019-03-31 15:26:43.



Tester

Library version: RENAT 0.1.14
Library scope: test suite
Named arguments: supported

Introduction

A class provides keywords for controlling testers and traffic generators.

It could load predefined traffic file, manipulate traffic items, start and stop traffic flows. It also could generate traffic reports and support QuickTest for IxNetwork.

Testers are defined in global device.yaml likes this:

ixnet01_8010: type: ixnet description: TCL server 8.01 ip: 10.128.4.21 port: 8010 chassis: -10.128.4.40 -10.128.4.41

ip is the the IP of Ixia application server and chassis section is optional which describe all the chassis in the chain.

Tester information is stored in the active local.yaml. The syntax is slightly different depending on the tester platform. Below is sample for IxNetwork.

tester:
tester01:
device:ixnet03_8009
config:vmx_20161129.ixncfg
real-port:
- description: to egde router
chassis: 10.128.32.71
card: 6
port: 11

 description: to backbone router chassis: 10.128.32.71 card: 6

port: 9

where device is the tester defined in the master device.yaml file. If real-port does not exist, port remapping will not take place. Otherwise, port remapping will use the real-port information to reassign all existed ports and map to Ixia ports.

In this case, the order will be the order when user created the port in Ixia GUI.

Note: User can always confirm the created order by clear sorting in Ixia GUI.

Examples:

Tester. Switch	tester01
Tester.Load And Start Traffic	
Sleep	30s
Tester.Stop Traffic	

Time format used in this module is same with time string format of Robot Framework. For more details about this, see DateTime library of Robot Framework

Note: See IxNet module, IxLoad module for details about keyword of each module.

Shortcuts

Close All · Connect · Connect All · Switch

Keywords

Keyword	Arguments	Documentation
Close All		Closes all connections
Connect	name	Connect to the tester name
Connect All		Connects to all testers
Switch	name	Switchs the current tester to name

Altogether 4 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:31.



ixload

Library scope: global **Named arguments:** supported

Introduction

provides functions for IxLoad

To use IxLoad module, a IxLoad TCL server should be started properly.

RENAT runs a virtual IxLoad client locally in the background that connects to a Windows App server. Keywords from test case will send control messages to the client, which in turn will control the test ports.

Different to IxNetwork, an IxLoad test case usually stops within predefined time before Stop Traffic was called.

Notes: Ignore the self parameters when using those keywords.

Shortcuts

 $\textbf{C} \textbf{lose} \cdot \textbf{C} \textbf{ollect} \ \textbf{Data} \cdot \textbf{G} \textbf{et} \ \textbf{Test} \ \textbf{Report} \cdot \textbf{L} \textbf{oad} \ \textbf{Config} \cdot \textbf{Load} \ \textbf{Traffic} \cdot \textbf{S} \textbf{tart} \ \textbf{Traffic} \cdot \textbf{S} \textbf{top} \ \textbf{Traffic} \ \textbf{Traffic} \ \textbf{Traffic} \cdot \textbf{S} \textbf{Traffic} \ \textbf{Traffi$

Keywords

Keyword	Arguments	Documentation		
Close	self	Disconnects the current tester client		
Collect Data	self, prefix=, more_file=, ignore_not_found=True	Collects all result data and save them to the current active result folder A prefix will be automatically added to the file names. Currently the follow data will be downloaded to the local machine HTTP_Server.csv HTTP Client.csv HTTP Client - Per URL.csv HTTP Server - Per URL.csv L2-3 Stats for Client Ports.csv L2-3 Stats for Server Ports.csv		
		■ L2-3 Throughput Stats.csv ■ Port CPU Statistics.csv Extra files could be add by more_file which is a comma separated filename string When ignore_not_found is True, the keyword will not terminate even when the expected file is not found.		
Get Test Report	self, prefix=	Get the test report(PDF) and put it into the active result folder		
Load Config	self, config_name=	Loads the test traffic defined by config_name file_path is the path of the test file on the remote App server A path to a remote network drive could be use to load a config file on Renat server.		
Load Traffic	self, file_path			
Start Traffic	self	Starts the test traffic		
Stop Traffic	self	Stops the current running test Returns the elapsed time in seconds		

Altogether 7 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:37.



ixnet

Library scope: global **Named arguments:** supported

Introduction

provides functions for IxNetwork

To use IxNetwork module, a IxNetwork TCL server should be started properly.

RENAT will connect to the App server and control the test ports. Test files and result will be insde the RENAT server.

In order to run RENAT test case with IxLoad, the TCLServer must be activated with Administrator privileges on the Ixia App server.

Notes: Ignore the self parameters when using those keywords.

Shortcuts

Add Port · Add Quicktest · Apply Traffic · Change Frame Rate · Change Frame Rate Dynamic · Change Frame Size · Close · Collect All Data · Collect Data · Csv Logging · Csv Snapshot · Get All Test Result · Get All Views All Csv Logs · Get All Views Csv Log · Get Csv Log · Get Quicktest List · Get Quicktest Result · Get Quicktest Result · Get Test Composer Result · Get Test Result · Get Test Result · Get View All Csv Logs · Get View Csv Log · Link Up Down By Index · Link Up Down By Name · Load And Start Traffic · Load Config · Load Traffic · Loss From File · Ping · Regenerate · Reset Config · Run Quicktest · Set All Traffic Item · Set Bgp Items · Set Bgp Neighbor · Set Capture Port · Set Traffic Item · Should Be Pingable · Start Capture · Start Trest Composer · Start Traffic · Stop All Protocols · Stop And Save Capture · Stop Quicktest · Stop Test Composer · Stop Traffic · Wait Until Connected

Keyword	Arguments	Documentation		
Add Port	self, force=True,	Add ports using the real-port information from active local config		
	time_out=2m, learn_time=2m	 time_out is the wait time until port is connected (default is 2m) learn_time is the time waiting for arp to be learned (default is 2m) 		
		Sample of local config tester:		
		tester: device: ixnet03_8009 config: quicktest.ixncfg real-port: - chassis: 10.128.4.41 card: 4 port: 3 ip: 10.100.11.2 mask: 24 gw: 10.100.11.1 - chassis: 10.128.4.41 card: 4		
		port: 4		
		ip: 10.100.14.2 mask: 24 gw: 10.100.14.1		
Add Quicktest	self, name, test_type=rfc2544throughput, tx_mode=interleaved, clear_all=True	Create a new Quicktest with default value		
		Type could be one of following: rfc2544throughput, rfc2544frameLoss, rfc2544back2back. Use Tester. <u>Load Config</u> to load a customized quicktest		
		When clear_all is True, any existed quicktests will be cleared.		
		Transmit mode tx_mode takes following values: interleaved (default) or sequential. The mode should be identical with the transmit mod of the ports.		
		Notes : The keyword does not create necessary ports. It should be used with a existed configuration by Tester. <i>Load Config</i> or Tester. <i>Add Port</i> keyword.		
Apply Traffic	self, refresh=True	Applies the current traffic configuration		
		refresh: Refreshed the learned information before apply the traffic or not Note: This is a blocking command		
Change Frame Rate	self, value, pattern=.*, flow_pattern=.*	Changes the frame rate Parameter:		
		 value: value to set. Depends on the current configuration, this could be percent line rate or bit per second etc. pattern: a regular expression to identify`traffic item name, default is everything.* flow_pattern: a regular expression to identify flow group inside the item 		
Change Frame	self, value, pattern=.*	Changes the traffic flow rate on-fly		
Rate Dynamic		No need to stop the running traffic to change the rate		
		Parameter:		
		value: value to set. Depend on the current configuration, this could be percent line rate or bit per second etc.		
	I	= ==== : a regular oversacion to identify traffic item name default is avanything t		

Change Frame Size	self, type, value, pattern=.*, flow pattern=.*	Changes the frame size					
Size	now_pattern=.	Parameter:					
		type: could be fixed size, increment_from`,`increment_step or increment_to					
		 value: value to set pattern: a regular expression to identify traffic item name, default is everything .* 					
		• flow_pattern: a regular expression to identify flow group inside the item					
Close	self	Disconnects the current tester client					
Collect All Data	self, prefix=stat_	Deprecated. Use					
Collect Data	self, view, prefix=stat_	Depricated. Use <u>Get Test Result</u>					
Csv Logging	self, enabled=True, *views	Toggles enable/disable CSV loggin for a view					
		Parameters:					
		■ views: is a list of views. None means all views.					
		Result files will have format <view name="">.index.csv, when index is automatically increased everytime to view is disable and re-enable again in the same test.</view>					
		Samples:					
		Tester. CSV Logging STRUE Flow Statistics Sleep 10s					
		Tester. CSV Logging \${FALSE} Flow Statistics					
		Note: Long time enable fof CSV loggin could returns in very big file					
Csv Snapshot	self, prefix=snapshot_, *views	, ,					
		Parameters:					
		 prefix: prefix that be added to the filename. Default is snapshot_ views: list of target views (eg: Port Statistics, Flow Statistics). If view is None, all current available views will be target 					
		Samples:					
		Tester. CSV Snapshot snapshot03_ # collect all views					
		Tester <u>CSV Snapshot</u> snapshot03 Port Statistics Flow Statistics # collect specific views Note: the name of result file will be modified so <i>space</i> will be replaced by <i>underbar</i> .					
		Depending on the traffic status, the available views could be varied. For example, the view <i>Flow Statistics</i> not available when there is no traffic.					
Get All Test Result	self, prefix=stat_	Collects all Ixia traffic data after traffic is stopped.					
nesuit		Results are CSV files that are stored in result folder. The prefix prefix is appended to the original view					
Get All Views All Csv Logs	self, prefix=	Gets all CSV logs for all available views					
Get All Views Csv Log	self, prefix index 1 *views	Gets the newest CSV log of all available views					
Get Csv Log	seir, prefix=, Index=-1, "Views	Gets all CSV log for a specific views or all from current test folder Parameters:					
		 views is a list of views. None is all views. prefix will be appended automatically to the beginning of the result range: number of files from the newest data1 for only 1 newest and : for all files. 					
		Samples:					
		Tester. Get CSV single - # get the newest CSV logging data for all					
		Log 1 views Tester.Get CSV all : Flow Statistics # get all CSV logging data for or					
		Tester. <u>Get CSV all : Flow Statistics # get all CSV logging data for or view</u>					
Get Quicktest List	self	Returns current loaded Quicktest list					
Get Quicktest	self, test_index=-1, prefix=,	Get the result.csv file from the latest Quicktests					
Result	enable_all=True	test_index is a index of the current Quicktest1 means that last one.					
Get Quicktest	self, test_index=-1	Returns the path of the newest run of a Quicktest					
Result Path		test_index is a index of the current Quicktest1 means that last one.					
Get Test Composer	self, result_file=composer.log	Get the result of test composer script					
Result Get Test Report	self,	Generates and get report of the current active test in PDF format					
•	local_name=ixnet_report.pdf, enable_all=True	local_name: name of the report on local machine. Default is ixnet_report.pdf					
Get Test Result	self, view, prefix=stat_	Collects traffic data of a view and export to a CSV file in result folder					
		Currently, supported views are:					

Get View All Csv Logs	self, view, prefix=	Aggregated Statistics, OSPF Aggregated State Counts, OSPFv3 Aggregated Statistics, OSPFv3 Aggregated State Counts, L2-L3 Test Summary Statistics, Flow Statistics, Flow Detective, Data Plane Port Statistics, User Defined Statistics, Traffic Item Statistics Result were store as CSV files in result folder. If there is no valid data, view will be silently ignored The prefix prefix is appended to the view name for the CSV file. Note: the name of the result files are modified so that space will become underbar, hyphen will be deleted. Gets the newest CSV log file of ALL available views	
Get View Csv	self, view, prefix=	Gets the newest CSV log file of the specific view	
Log Link Up Down By Index	self, port_index=0, state=up	Simulates a LinkUpDown by port index Parameters: port_index: zero-started port index state: is up or down Samples: Tester.Link Up Down By Index 0 down Sleep 5s Tester.Link Up Down By Index 0 up	
Link Up Down By Name	self, port_name, state=up	Simulates a LinkUpDown by port name Parameters: port_index: zero-started port index state: is up or down Samples: Tester.Link Up Down By Name Sleep 5s Tester.Link Up Down By Name Ethernet - 001 up	
Load And Start Traffic	self, wait_time1=10s, wait_time2=10s	Combines Load Traffic and Start Traffic to one keyword.	
Load Config	self, config_name=, wait_time=2m, wait_time2=2m, apply=True, protocol=True, force=True, wait_time3=30s		
	wait_time2=2m, apply=True, protocol=True, force=True, tx_mode=interleaved		
Loss From File	self, file_name=Flow_Statistics.csv, index=0	Returns packet loss by miliseconds and delta frame. Parameters: • file_name: flow information (csv format). Default is Flow_Statistics.csv • index: row index of the result(counted from zero)	

		- mass. for mass of the result/estitled from Estay
		Samples:
		\${LOSS} \${DELTA}= Tester. Loss From File Flow_Statistics.csv \${LOSS} \${DELTA}= Tester. Loss From File Flow_Statistics.csv Index=1
		Note : The calculation should be performed when traffic is stopped. The calculation supposed traffic is configured by frame per second.
Ping	self, dst_ip, src_port_index=0,	Ping from Ixia to dst_ip
	src_intf_index=0	The keyword return the output string as it is. The return could be
		- Port <portname>: ping failed: port not assigned - Response received from <source p>/unknown . Sequence Number <sequencenumber> - Ping request to <destination p>/unknown ip failed: <genericpingerror>/<error>: <genericerror>unknown reason - Error: Couldn't find any source interface for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to <destination p> on <portname> Id <id> - Error: Couldn't find any source IP for Send Ping to</id></portname></destination p></id></portname></destination p></genericerror></error></genericpingerror></destination p></sequencenumber></source p></portname>
		Parameters:
		 src_port_index: index of Ixia port (starts from 0) src_intf_index: index of interface insides the port (starts from 0)
		Examples:
		Tester. <u>Ping</u> 1.1.1.1 0 0 Tester. <u>Ping</u> 1.1.1.1 \
Regenerate	self	Regenerates all flow of current traffic items
Reset Config	self	Clears current config and creates new blank config
Run Quicktest	self, test_index=0,	Runs the Quicktest and wait until it finishes
	wait_until_finish=True	Warning: it could take a long time to finish a quicktest
Set All Traffic Item	self, enabled=True	Enables/Disables all traffic items at once
Set Bgp Items	self, port_index, neighbor_index, route_range_index, is_enable	Enables/Disables BGP entry by a set of port,neighbor,route_range index Parameters: port_index: index of the port neighbor_index: index of the neighbor or * route_range_index: index of the route range or * is_enable: \${TRUE} or \${FALSE} Note Examples:
		Tester. <u>Set BGP Items</u> 0 * * \${FALSE} Tester. <u>Set BGP Items</u> 0 * * \${TRUE}
Set Bgp Neighbor	self, *indexes, **kwargs	Enables/Disables BGP entry by neighbor index kwargs contains following parameters: indexes: is a list of index of BGP neighbor (index is started from zero) vport_index: is the target vport index enabled: TRUE or FALSE Examples: Tester.Set BGP Item 0 1 vport_index=0 enabled=\${FALSE} Tester.Set BGP Item 0 1 vport_index=1 enabled=\${TRUE}
Set Capture	self, data_mode=True,	Capture packets for follow port
Port	control_mode=True, port_index=0	port_index: is a index of current test port (start from 0) data_mode: capture data packets and save in <intf>_HW.cap file control_mode: capture controls packets and save in <intf>_SW.cap file Note: control_mode saves all control packets and data_mode only saves data packets. Note: control_mode saves all control packets and data_mode only saves data packet Examples: Tester. Set Capture Port 0 Tester. Set Capture Port control_mode=\${TRUE} 0 1</intf></intf>
Set Traffic Item	self, *items, **kwargs	Enables/Disables some traffic items items
		Parameters: litems: a list of Ixia traffic item name enabled: False or True, the mode to set traffic item to, default is True (enabled) Note: traffic item could be specified by :: <num> format. In this case the num is the order of traffic item count from zero.</num>
		Returns True if all items are set coordinately or otherwise
		Examples:
		Set Traffic Item Traffic Item 1 Traffic Item 2
		Set Traffic Item @{item list}

		Set Traffic Item Traffic Item 1 enabled = \${FALSE}			
Should Be	self, dst_ip, src_port_index=0,	Ping from Ixia and raise an error if ping fails			
Pingable	src_intf_index=0	The keyword return <i>True</i> if succeeds			
Start Capture	self, wait_time=30s	Start packet capture			
		Target ports are set by the configuration file or by [Set Capture] keyword			
Start Protocol	self, wait_time=1m	Starts all protocols and wait for wait_time			
		Default wait_time is 1 minute. Make sure wait_time is big engouh to start all protocols.			
Start Test	self,	Run a test composer script.			
Composer	script_name=Main_Procedure, run_num=1, wait_for_test=True,	The test composer script should be included in an Ixia Network configuration file and loaded properly with <u>Load Config</u>			
	parameter=, wait=10s	Parameters:			
		 script_name is the name of the script to run. Default value is Main_Procedure. wait_for_test: if \${TRUE} then wait until the script finishes. parameter: parameter that is passed to the script. Parameter could be in 2 formats: {{VAR1 VALUE1} {VAR2 VALUE2}} or simply as VALUE1 VALUE2. 			
		The script must prepare <i>VAR1</i> and <i>VAR2</i> properly by <i>Test parameter</i> . See Ixia Network anout composer script for more details.			
		wait: wait time before go to next keyword			
		Examples:			
		Tester. <u>Start Test Composer</u> parameter=XXX YYY			
		Tester. Get Test Composer Result result_file=script1.log			
		Tester. Start Test Composer parameter={{VAR1 AAA} {VAR2 BBB}}			
Ot T ##		Tester. Get Test Composer Result result_file=script1.log			
Start Traffic	self, wait_time=30s	Starts the current traffic settiing and wait for wait_time.			
		Note: This is a asynchronus action. After called, the keyword finishes immediatly but it will take a while before traffic starts			
		By default the keyword will wait for 30 seconds.			
Stop All Protocols	self, wait_time=30s	Stop all running protocols			
Stop And Save	self, prefix=,	Stop current capture and save the resuls to folder specified by path			
Capture	wait_until_finish=True, monitor_interval=5s	Captured files will be saved in current result folder with prefix appended in their names.			
		Examples:			
		Tester. <u>Start Capture</u>			
		Sleep 10s			
		Tester. Stop And Save Capture \${RESULT_FOLDER}/capture.zip			
Stop Quicktest	self, test_index=0	Stops a running test			
Stop Test Composer	self, wait=10s	Stop a running composer			
·		Do nothing when a test composer has already stopped or no composer has been prepared.			
Stop Traffic	self, stop_protocol=False, wait_time=10s	Stops the current traffic and wait for wait_time			
		Parameters:			
		 stop_protocol: if True also stops all running protocols wait_time: time to wait after apply the command 			
Wait Until	self, timeout_str=5m	Waits until ports become enabled and connected			
Connected					

Connected
Altogether 49 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:36.



ixbps

Library scope: global **Named arguments:** supported

Introduction

provides functions for Ixia Breaking Point

Breaking Point testers setting is set by tester section in local.yaml . Users need to specify the physical ports used by the test by its card and port number.

Setting example:

ixbps01:
 device: ixbps01
 config: test.bpt
 real-port:
 - card: 1
 port: 0
 - card: 1

Notes: Ignore the self parameters when using those keywords. The module requires Breaking Point Python library installedd properly to work.

Shortcuts

 $\textbf{C} \textbf{leanup Tests} \cdot \textbf{C} \textbf{lose} \cdot \textbf{G} \textbf{et Card Config} \cdot \textbf{G} \textbf{et Card Mode} \cdot \textbf{G} \textbf{et Test Report} \cdot \textbf{Load Config} \cdot \textbf{S} \textbf{et Card Config} \cdot \textbf{S} \textbf{tart Test} \cdot \textbf{S} \textbf{top Test} \cdot \textbf{W} \textbf{ait Until Finish} \textbf{C} \textbf{et Card Config} \cdot \textbf{S} \textbf{et Card Config} \cdot \textbf{C} \textbf{et Card Config} \cdot \textbf{$

Keyword	Arguments	Documentation			
Cleanup Tests	self	Cleans up running test and release their ports			
Close	self	Closes the connection to the BP box			
Get Card Config	self, slot_num	Get card configuration for slot_num			
		Parameter:			
		■ slot_num is all or an integer start from 1			
		Result is a json formatted string contains the information for specific slot or <i>all</i> slots.			
Get Card Mode	self, slot_num	Gets the mode of a specific slot			
Get Test Report	self, report_name=result,	Gets and saves the test report to local disk			
	format=csv	The report will be in PDF format. If export_csv is True then test results are also exported by CSV format.			
Load Config	self, config_name=, force=True	Loads test configuration config_name is defined in local.yaml or specific by user in the main scenario.			
Set Card Config	self, slot, action=mode, param=ixload	Changes the configuration of BPS card			
		Parameters:			
		■ slot: slot number			
		action: mode or perfaccparam: depending on action			
		Values of param:			
		■ if action is mode then param should be ixload, bp or bpl23 (BreakingPoint L2/3)			
		if action is perface then param should be \${TRUE} or \${FALSE}			
Start Test	self, test_name=None, force=True	Starts a test by its name			
		The system automatically reserve the ports defined in local.yaml. The reserved ports are released when the test is stopped			
		test_name is the name of the testmodel saved in the configuration. If test_name is None, the 1st testmodel will be used.			
		If force is True then all running tests and their reserved ports will be released.			
Stop Test	self, wait=5s	Stops a running test			
Wait Until	self, interval=30s, timeout=30m,	Waits until the test finished or timeout			
Finish	verbose=False	Notes: This is a blocking keyword			

avaproxy

Library scope: global
Named arguments: supported

Introduction

Provides Spirent Avalance keywords

Table of Contents

- <u>Usage</u>
- Test Result
- Keywords

Usage

The module need to be used with a AVA proxy server with topology looks like this:

this module <=> AVA proxy server (32bit) <=> AVA 32bit library <=> AVA hardware

SPF test files should be exported from AVA GUI.

Sample local.yaml setting for AVA

```
# tester information
tester:
ava01:
device: ava01
config: config.spf
real-port:
- chassis: 10.128.64.231
card: 1
port: 1
- chassis: 10.128.64.232
card: 1
```

The device ava01 is define as below in global device.yaml:

```
ava01:
type: avaproxy
description: a AVA proxy (32bit)
license-server: 10.128.64.222
ip: 10.128.64.104
port: 5001
```

Note: the license-server field is optional.

and the account is define in auth.yaml under avaproxy section

```
avaproxy:
user: admin
```

Test Result

The AVA result is collected and save into the foler ava under current active result folder. The merged resuls for client/server is a XML file as ava/result/merged/results.xml.

Some predefined stylesheets are provided under tools/xslt folder and could be use to reformat this result like belows samples:

Common.Convert XML	\${RENAT_PATH}/tools/xslt/merged2html.xls	\${CURDIR}/\${RESULT_FOLDER}/ava/merged/results.xml	\${CURDIR}/\${RESULT_FOLDER}/ava_merged.html
Common.Convert XML	\${RENAT_PATH}/tools/xslt/merged2csv.xls	\${CURDIR}/\${RESULT_FOLDER}/ava/merged/results.xml	\${CURDIR}/\${RESULT_FOLDER}/ava_merged.csv

Note: AVA proxy server is not a part of Spirent solutions.

Shortcuts

Close · Get Test Result · Load Config · Start Test

Keywords

Keyword	Arguments	Documentation	
Close	self	Disconnect to the remote server	
Get Test Result	self, name=ava	Get test result folder	
		The resuls will be saved under <i>current result</i> folder with the name <i>name</i>	
Load Config	self, config_name=	Loads the SPF config file and reseres necessary port	
Start Test	self, trial=0, timeout=5m	Starts the test and wait until it finishes or timeout	

Generated by Libdoc on 2019-03-31 15:26:39.

Hypervisor

Library version:RENAT 0.1.14Library scope:test suiteNamed arguments:supported

Introduction

A module controls Hypervisors

A hypervisor is declared in local.yaml like this:

esxi information hypervisor: esxi-server: device: esxi-3-15

Notes: Currently support VMWare(Esxi) only

Shortcuts

Capture Mks Screenshot · Click Mks · Close · Close · Close · Clonnect · Connect · Mks · Get Mks Ticket · Get Vm Id · Get Vm List · Get Vm Power State · Open Console · Power Off · Power On · Reset Capture Counter · Send Mks Cmd · Send Mks Key · Send Mks Keys · Set Capture Format · Switch · Xrun

Keywords

Keyword	Arguments	Documentation
Capture Mks Screenshot	*args, **kwargs	
Click Mks	*args, **kwargs	
Close		Closes and disconnects from a hypervisor
Close All		Closes all current opend hypervisor connection
Connect	hyper, name	Connects to a Hypervisor
Connect All	prefix=	Connect to all hypervisor listed in local config yaml
Get Mks Ticket	*args, **kwargs	
Get Vm Id	*args, **kwargs	
Get Vm List	*args, **kwargs	
Get Vm Power State	*args, **kwargs	
Open Console	*args, **kwargs	
Power Off	*args, **kwargs	
Power On	*args, **kwargs	
Reset Capture Counter	*args, **kwargs	
Send Mks Cmd	*args, **kwargs	
Send Mks Key	*args, **kwargs	
Send Mks Keys	*args, **kwargs	
Set Capture Format	*args, **kwargs	
Switch	name	Switch the current hypervisor to a new one
Xrun	cmd, *args, **kwargs	

Altogether 20 keywords.

Generated by <u>Libdoc</u> on 2019-03-31 15:26:45.

Q

vmware

Library scope: global **Named arguments:** supported

Introduction

provides function for VMware ESXI

Athough this module provides some keywords for interact with the console (WebConsole), they only suppport very primitive actions. Do not use this to accomplish complex tasks. Instead, using VChannel through a SSH/Telnet channel.

Shortcuts

Capture Mks Screenshot · Click Mks · Get Mks Ticket · Get Vm Id · Get Vm List · Get Vm Power State · Open Console · Power Off · Power On · Reset Capture Counter · Send Mks Cmd · Send Mks Key · Send Mks Keys · Set Capture Format

Keyword	Arguments	Documentation				
Capture Mks	self, filename=None, extra=	Captures the current web console to	filename			
Screenshot		If <i>filename</i> is None, the captured filename will be decided by the current format with an auto-increment counter and a extra at the end.				
		Example:				
		''	will create a file	01.png		
		Hypervisor.Capture MKS > Screenshot	xxx.png		# will create a file xxx.png	
		, , , , , , , , , , , , , , , , , , ,	will create a file console_00000000	02.png		
Click Mks	self, xoffset, yoffset	Click on the MKS console at xoffse	et, yoffset coordina	te		
		Notes: The coordinate (0,0) is at the	e left corner of the	console screer	1	
Get Mks Ticket	self, vm_name	Returns a MSK ticket for WebCons	ole			
Get Vm Id	self, vm_name	Returns a VMID of a VM				
Get Vm List	self	Returns current VM name list of the	hypervisor			
Get Vm Power	self, vm_name	Get vm power status	•			
State		Return on of off				
Open Console	self, vm_name, width=None,	Opens a web console for a VM vm	name			
	height=None	· -	-			
		Returns the width and height of the				
		Hypervisor. Set Capture Format	console_%010	d		
		Open Console	\${VM_NAME}			
		Hypervisor. <u>Capture MKS Screensh</u> <u>Send MKS Cmd</u>	root			
		Send MKS Cmd		wait=10s		
		Send MKS Cmd	password	wait=105		
		Hypervisor. <u>Capture MKS Screensh</u>				
		Send MKS Key	\${CTRL_L}			
		Send MKS Cmd	whoami			
		Hypervisor.Capture MKS Screensh				
Power Off	colf vm namo gracoful-True		Ot			
Fower OII	self, vm_name, graceful=True					
		If graceful is True, a graceful shutde	own is tried before	a power off.		
		Note: if VMware tools is not install	on the VM, gracef	ul shutdown is r	not available	
Power On	self, vm_name	Power on a VM				
Reset Capture Counter	self					
Send Mks Cmd	self, cmd, wait=5s	Sends command to current web console and wait for a while				
		By default, wait time is 2s and the the cmd	keyword will autor	maticall add a N	ewline char after sendin	
Send Mks Key	self, key, wait=5s					
Send Mks Keys	self, keys, wait=5s	Sends key strokes to current web console				
-				:TRI 7\		
		Special Ctrl char could be used as \${CTRL_A} to \${CTRL_Z}				

		Examples: Send MKS Key \${CTRL_L} Notes: For other usable key value, see Selenium document
Set Capture Format	self, format	Set console capture format
		Initialized format is 'vmware_%010d'

Altogether 14 keywords.
Generated by <u>Libdoc</u> on 2019-03-31 15:26:46.

