## juniper

**Library scope:** global **Named arguments:** supported

## Introduction

Provides keywords for Juniper platform

Notes: Ignore the self parameters when using those keywords.

## **Shortcuts**

Create Best Path Select Data · Disable Interface · Enable Interface · Enable Interface · Get Chassis Serial · Get Cli Mode · Get Config · Get Current Datetime · Get File · Get Intf Addr · Get Route Number · Get Version · Link Status · Load Config · Number Of Bgp Neighbor · Number Of Ospf Neighbor · Numb

## Keywords

Keyword	Arguments	Documentation
Create Best Path Select Data	self, route_content, output_excel=best.xlsx	Creates the matrix of best path selection
		Provides the test described in <i>smb://10.128.3.91/SharePoint01/31_VerificationRoom/31_13_検証環境セット/BGP-Best-Path-SelectionのAll-in-One設定_20161118改良</i> / The test uses predefined Ixia config and follows predefined steps
Disable Interface	self, intf	Disables an interface intf
Enable Interface	self, intf	Enables an interface intf
Flap Interface	self, intf, time_str=10s	Simulates an interface flap for interface intf
		Disables the interface and wait for a while before turning it up again
Get Chassis Serial	self	Returns the serial number of the chassis
Get Cli Mode	self	Returns current mode of the CLI.
		Return value is config for configuration mode or command for command mode
Get Config	self, dst_name=None	Gets the current configuration file of the router to current result folder.
		Default dst_name is juniper.conf.gz
Get Current Datetime	self, time_format=%H:%M:%S, delta_time=0s, dir=+, **kwargs	Returns the current date time with vendor format delta_time will be added or subtracted to current time, default is 0s
		time_format decides the time part of the output. Example result are :
		May 24 04:14:25 May 4 04:14:25
		Note: The date part is padded by space, and the result is allways 15 characters
Get File	self, src_file, dst_file=None	Gets a file from router
		<ul> <li>src_file is a absolute path insides the router</li> <li>dst_file is a file name under result folder</li> </ul>
		if dst_file is not defined, it will be the filename of the src_file
Get Intf Addr	self, intf_name, family=inet	Returns the tuple of address and netmask of an interface
		family should be inet or inet6 If the address is not set, (",") will be returned.
Get Route Number	self, table=inet.0	Returns number of active route in the table
		table could be inet.0 or inet.6
Get Version	self	Returns router version information
Link Status	self, if_name	Returns link physical status as string (aka: "up down", "up up")
Load Config	self, mode=set, config_file=, confirm=0s, vars=, err_match=(error:)	Loads configuration to a router. Usable mode is set, override, merge and replace
		set mode uses configuration that contains set command. Mode override, merge and replace use ordinary JunOS configuration file with appropriate mode. config_file is a configuration file inside the config folder of the current test case.
		Config file could includes jinja2 template. The template will be evalued with <i>LOCAL</i> , <i>GLOBAL</i> and varibles defined by <i>vars</i> . The <i>vars</i> has the format: var1=value1,var2=value2
		If the loading has no error that match the error_match, the configuration will be committed.
		The keywordl waits for confirm seconds before rollback the committed configuration. A zero value indicates an immediatly commit

Neighbor	self, state=Established, cmd=show bgp neighbor	Returns number of BGP neighbor in state state
Number Of Osp Neighbor	match Type self, state=Full, cmd=show ospf neighbor	Returns number of OPSF neighbors with status state
Number Of Ospf3 Neighbor	1 '	Returns number of OPSFv3 neighbors with status state

Altogether 17 keywords.
Generated by <u>Libdoc</u> on 2019-02-19 13:08:51.

Q