


Figure 9. UFQFPN48 pinout

Package top view




DT74259V1

Note: There is an exposed die pad on the underside of the UFQFPN package. This backside pad must be connected and soldered to PCB ground.

Figure 10. LQFP64 pinout

Package top view



DT74260V1