


Figure 5. LQFP48 pinout


Package top view



DTT4258V1

Figure 6. UFQFPN48 pinout

Package top view



DTT4259V1

Note: There is an exposed die pad on the underside of the UFQFPN package. This backside pad must be connected and soldered to PCB ground.