

4.4 Pin Assignment Table

Pin No.	Symbol	Description
1	GND	Power ground.
2	U/D	Up/down scan setting. When U/D=H, reverse scan. When U/D=L, normal scan.
3	L/R	The shift direction of device internal shift register is controlled by this pin as shown below: L/R=H: STH->SO1->•••->SO960->STHO L/R=L: STH->SO960->•••->SO1->STHO
4	GND	Power ground.
5-12	R0-R7	Red data input.
13-20	G0-G7	Green data input.
21-28	B0-B7	Blue data input.
29	GND	Power ground.
30	HSYNC	Horizontal sync input in digital RGB and CCIR601 mode. (Short to GND if not used)
31	VSYNC	Vertical sync input in digital RGB and CCIR601 mode. (Short to GND if not used)
32	DE	Input data enable control. When DE mode, active High to enable data input. Default pull low.
33	DCLK	Clock signal. Latching data at the rising edge.
34	GND	Power ground.
35	LCD_STBY	“0” for Standby mode, “1” for normal mode.
36	LCD_RST	External Reset
37	PWM_DIM	Backlight brightness control, “H” is the brightest, “L” is the darkest.
38	GND	Power ground.
39	CTP_SCL	Touch panel control PIN
40	CTP_SDA	Touch panel control PIN
41	CTP_RET	Touch panel control PIN
42	CTP_INT	Touch panel control PIN
43	GND	Power ground.
44-45	VDD	Power supply.
46-48	VLED	Power supply for BLU LDO circuit.
49-50	GND	Power ground.