# LESSON I – SAFETY PROCEDURES FOR WORKING WITH ELECTRICAL SYSTEMS

### INTRODUCTION

Automotive electrical systems are low in voltage (typically 12 volts), but they carry very high current, making them dangerous if handled incorrectly. Mistakes like using bare hands on a battery, touching energized terminals, or working without personal protective equipment (PPE) can lead to shock, burns, explosions, or fire. Safety is not just a policy—it is a life-saving practice that must be learned and repeated every day.

## **©** LEARNING OBJECTIVES

- I. Identify common electrical hazards found in an automotive servicing environment.
- Explain the proper use and importance of Personal Protective Equipment (PPE) when working with electrical systems.
- 3. Describe the standard safety procedures such as lockout/tag-out (LOTO), tool inspection, and workshop cleanliness that reduce the risk of electrical accidents.

### UNDERSTANDING THE RISKS

Even a 12-volt battery can release hundreds of amps enough to melt metal and ignite flammable vapors. Batteries can explode if improperly connected or overcharged. A short circuit in a crowded engine bay can cause arc flashes, resulting in burns and fire.

## **!** COMMON HAZARDS EXAMPLES

- Shorted tools or wires
- Working in damp conditions
- Wearing metal jewelry near live circuits
- Faulty equipment and ungrounded tools

## PERSONAL PROTECTIVE EQUIPMENT (PPE)

 PPE is a technician's first line of defense against electrical hazards.

**Insulated gloves**: Protect hands from electric current

Safety goggles: Shield eyes from sparks or acid splashes

Rubber boots: Prevent grounding and shock

Apron or overalls: Provide full-body protection from burns

**Important**: Always remove jewelry and wear dry, properly rated protective gear.

## TOOL AND EQUIPMENT INSPECTION

#### Before beginning any work:

- Inspect wires, tools, and meters for cuts, corrosion, or burns.
- Ensure all test equipment is functioning and calibrated.
- Do not use damaged cords or plugs, even temporarily.
- Use tools rated for automotive electrical applications.

Even a minor oversight—like a cracked test lead—can result in equipment failure, shock, or system damage.

## LOCK-OUT/TAG-OUT (LOTO)

Purpose: To prevent accidental energization of electrical circuits during servicing.

#### Procedure:

- Turn off the ignition switch.
- Disconnect the negative battery terminal first.
- Place a visible tag or lock stating "Do Not Reconnect Work In Progress."
- Confirm zero voltage using a multimeter or test light.
- Only the technician who installed the lock/tag may remove it.

This ensures no one else accidentally energizes the system while you are working.

## ENVIRONMENTAL AND FIRE SAFETY

#### Good housekeeping is part of electrical safety:

- Keep work area clean and dry.
- Store oily rags and flammable liquids away from the battery or wiring zones.
- Have a Class C fire extinguisher (for electrical fires) within reach.
- Never use water on an electrical fire—it may cause shock or spread the flame.

### KEY SAFETY REMINDERS

- Always treat all circuits as live until verified safe.
- Never substitute electrical tape for proper insulation or tools.
- Never rush when working with batteries, starters, or ignition systems.
- Double-check connections and verify voltage before and after repairs.

### REFERENCES

 Auto Electrical System Module – Competency-Based Learning Material

https://www.scribd.com/document/601714455/Auto-Electrical-System-Module-PDF

TESDA – Training Regulations: Automotive Servicing NC II <a href="https://www.tesda.gov.ph">https://www.tesda.gov.ph</a>

YouTube – Girlie Garage

"Basic Automotive Electrical Safety – THE HUB"

<a href="https://www.youtube.com/watch?v=milXq7mdQr8">https://www.youtube.com/watch?v=milXq7mdQr8</a>