4 PI_Dot_matrix module

1 Project process

```
P pi@raspberrypi: -/keyes_螺鎖板锅鹃珮编x增廉榆欢望勤枡/PI Dot matrix module/program/Dot_test
pi@raspberrypi ~ $ 1s
bcm2835-1.45
                             Desktop
                                                                                                 python games
                             keyes_树莓派高级版套件资料 PI Dot matrix module
                                                                                                 wiringPi
pi@raspberrypi ~ $ cd keyes 树莓派高级版套件资料/
pi@raspberrypi ~/keyes_树莓派高级版套件资料 $ ls
MQ-5 PI Dot matrix module water_senor
pi@raspberrypi ~/keyes_树莓派高级版套件资料 $ cd PI\ Dot\ matrix\ module/
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module $ ls
program 原理图 文档
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module $ cd program/
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program $ 1s
pi@raspberrypi ~/keyes 树莓派高级版套件资料/PI Dot matrix module/program $ cd Dot test/
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program/Dot_test $ 1s
Dot_test.c Dot_test.o Makefile
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program/Dot_test $ make gcc Dot_test.c -o Dot_test -1bcm2835
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program/Dot_test $ 1s
Dot test Dot test.c Dot test.o Makefile
pi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program/Dot_test $ sudo ./Dot_te
^Cpi@raspberrypi ~/keyes_树莓派高级版套件资料/PI Dot matrix module/program/Dot_test $
```

2 Project source code

```
0
pi@raspberrypi: ~/keyes_复数核妈鹃珊煌x增廉揃欢聖動枡/PI Dot matrix module/program/Dot_test
  blink.c
   Example program for bcm2835 library
  Blinks a pin on an off every 0.5 secs
   After installing bcm2835, you can build this
  with something like:
   make or gcc -o led led.c -1bcm2835
   sudo ./led
             define from bcm2835.h
                                                          define from Board DVK511
                 3.3V | | 5V
                                                                3.3V | | 5V
    RPI V2 GPIO P1 03 | | 5V
                                                                SDA |
    RPI_V2_GPIO_P1_05 | | GND
                                                                 SCL |
                                                                         GND
       RPI_GPIO_P1_07 | RPI_GPIO_P1_08
                      RX
                  GND
                                                                 GND
    RPI_GPIO_P1_11
RPI_V2_GPIO_P1_13
                                                                 I00
                                                                         101
                        GND
                                                                         GND
       RPI GPIO P1 15
                      | | RPI GPIO P1 16
                                                                 103
                                                                         104
                  VCC | | RPI GPIO P1 18
                                                                VCC
                                                                         105
       RPI GPIO P1 19 | | GND
                                                                MOSI
                                                                         GND
       RPI_GPIO_P1_21 | RPI_GPIO_P1_22
                                                                MISO
                                                                         106
       RPI GPIO P1 23 | RPI GPIO P1 24
                                                                SCK |
                                                                       | CEO
                  GND | RPI_GPIO_P1_26
                                                                GND | CE1
::if your raspberry Pi is version 1 or rev 1 or rev A
RPI V2 GPIO P1 03->RPI GPIO P1 03
RPI V2 GPIO P1 05->RPI GPIO P1 05
RPI V2 GPIO P1 13->RPI GPIO P1 13:
                                                                                      1,1
```

3 Project result & circuit connection

