USB4 1.0 ENGINEERING CHANGE NOTICE FORM

Title: Changes Flow for Re-Enabling a Lane in a DFP Applied to: USB4 Specification Version 1.0

Brief description of the functional changes:
Removes requirements that a Lane restart Lane Initialization after it is re-enabled. Instead, the Connection Manager is required to do a Downstream Port Reset (DPR).
Benefits as a result of the changes:
Simplifies the flow to re-enable a Lane, and aligns with existing Connection Managers and Active Cables.
An accompant of the impact to the existing revision and exetems that ourrently conform to
An assessment of the impact to the existing revision and systems that currently conform to the USB specification:
None
An analysis of the hardware implications:
None
An analysis of the software implications:
A Connection Manager must initiate a DPR after enabling a Lane.
An analysis of the compliance testing implications:
No need to verify behavior after re-enabling a Lane and just need to verify a DPR will cause a disconnect an Link bring up "as usual".

USB4 1.0 ENGINEERING CHANGE NOTICE FORM

Actual Change

(a). 4.4.6.2.2, Enable Flow

From Text:

When the *Lane Disable* bit transitions from 1b to 0b, the Lane Adapter enters the CLd state (see Section 4.2.1.2.2).

After receiving a Broadcast RT Transaction with the *Lane0Enabled* bit set to 1b, the Lane 0 Adapter begins Lane Initialization starting from Phase 4.

After receiving a Broadcast RT Transaction with the *Lane1Enabled* bit set to 1b, the Lane 1 Adapter begins Lane Initialization starting from Phase 4.

To Text:

When the *Lane Disable* bit transitions from 1b to 0b, the Lane Adapter enters the CLd state (see Section 4.2.1.2.2).

After receiving a Broadcast RT Transaction with the *Lanc0Enabled* bit set to 1b, the Lane 0 Adapter begins Lane Initialization starting from Phase 4.

After receiving a Broadcast RT Transaction with the *Lanc1Enabled* bit set to 1b, the Lanc 1 Adapter begins Lanc Initialization starting from Phase 4.



CONNECTION MANAGER NOTE

After setting the *Lane Disable* bit to 0b in a Lane Adapter, the Connection Manager shall initiate a Downstream Facing Port Reset in the Port that contains the Lane Adapter. See Section 6.9 for more details.

(b). 6.9, Downstream Facing Port Reset

From Text:

When the *Downstream Port Reset* bit in a Downstream Facing Port is set to 1b, a Router shall initiate a disconnect on the Downstream Facing Port by driving its SBTX line low.

To Text:

When the *Downstream Port Reset* bit in a Downstream Facing Port is set to 1b, a Router shall <u>discard any pending Sideband transactions and</u> initiate a disconnect on the Downstream Facing Port by driving its SBTX line low.

(c). 4.4.5, Disconnect

From Text:

This section defines how a disconnect on a USB4 Port is handled.

To Text:

This section defines how a disconnect on a USB4 Port is handled. When a disconnect is required, it takes precedence over all other pending requirements.