# IoT project template

## IoT : Sensors, LoRa link & Gateway


#### Content

loT project template	1
loT : Sensors, LoRa link & Gateway	
1.1 Sender side on CubeCell based boards	2
1.1.1 Code explanation	
1.1.2 Complete code	
1.2 Receiver/gateway side on Pomme-Pi ZERO	Ç
(AirM2M-CORE ESP32C3)	ç
1.2.1 Code explanation	
1.2.2 Complete code	
To do 13	


In this exercise we are going to use two different IoT DevKits

- Pomme-Pi ZERO (AirM2M-CORE\_ESP32C3) with LoRa HAT DevKit and
- CubleCell: Pico Devkit and ESP32C3-CORE based board CubeCell-Board (HTCC-AB01)

as shown on the following figure:



We also can take CubeCell board and ESP32-(LOLIN D32) based boards.



Both boards are programmed with Arduino IDE or PlatformIO.

#### Attention:

The code for CubeCell and CubeCell Pico DevKits operating as terminal nodes are completely compatible. The receiver/gateway boards Pomme-Pi ONE with ESP32 LOLIN D32 main board and Pomme-Pi ZERO with AirM2M-CORE\_ESP32C3 main board have different pin-outs for LoRa modem.

```
//For LOLIN D32:
#define SCK 18 // GPIO18 -- SX127x's SCK
#define MISO 19 // GPIO19 -- SX127x's MISO #define MOSI 23 // GPIO23 -- SX127x's MOSI
#define SS
#define RST
                 5 // GPI005 -- SX127x's CS
#define RST 15 // GPI015 -- SX127x's RESET #define DI0 26 // GPI026 -- SX127x's IRQ(Interrupt Request)
//For AirM2M-CORE_ESP32C3
               // GPIO07 -- SX127x's CS
#define SS 7
                       // GPI006 -- SX127x's RESET
#define RST 6
                      // GPIO11 -- SX127x's IRQ(Interrupt Request)
#define DIO 11
                       // GPI002 -- SX127x's SCK
#define SCK 2
                       // GPIO10 -- SX127x's MISO
#define MISO 10
#define MOSI 3
                       // GPI003 -- SX127x's MOSI
```

#### 1.1 Sender side on CubeCell based boards

The proposed code operates with the "transparent" gateway to ThingSpeak .com (TS) server. The LoRa packet format contains the place for TS channel number that identifies at the same time the terminal application and the place for a 16-byte write key to this channel. The total size of the packet is 36 bytes. Four floating point variables are reserved for the sensor data, that are:

- battery state
- temperature (SHT21 on any other temperature sensor)
- humidity (SHT21 on any other humidity sensor)
- distance from the detected surface (VL53L1X ToF sensor)

#### 1.1.1 Code explanation

Note that the sender operates in 4 stages:

- 1. low\_power stage (seconds, minutes, hours,..)
- sensing stage
   transmission stage (data), and
- reception stage (ACK)

```
typedef union
 uint8_t frame[36]; // frames with bytes
 struct
 unsigned int channel; // 4 bytes - device and channel identifier
 char wkey[16];  // 16 bytes
float sensor[4];  // 16 bytes
                         // 16 bytes
                         // payload
 } pay;
} pack_t ; // packet type
```

The LoRa (SX1262) modem is connected internally via SPI bus. We need however define Lora radio link parameters:

```
868500000 // Hz
#define RF_FREQUENCY
#define TX_OUTPUT_POWER
                                                      14
                                                                // dBm
                                                                 // [0: 125 kHz,
#define LORA BANDWIDTH
                                                      0
                                                                 // 1: 250 kHz,
// 2: 500 kHz,
                                                                 // 3: Reserved]
                                                                 // [SF7..SF12]
#define LORA SPREADING FACTOR
                                                      9
                                                                 // [1: 4/5,
#define LORA_CODINGRATE
                                                      1
                                                                 // 2: 4/6,
                                                                 // 3: 4/7,
                                                                 // 4: 4/8]
#define LORA_PREAMBLE_LENGTH
                                                      8
                                                                 // Same for Tx and Rx
#define LORA_SYMBOL_TIMEOUT
                                                      0
                                                                 // Symbols
#define LORA_FIX_LENGTH_PAYLOAD ON
                                                      false
#define LORA_IQ_INVERSION_ON
                                                      false
```

You can modify these values but they should be the same at the receiver side.

The synchronization/communication between the MCU (ARM-CORTEX-M0) and the modem is controlled by the **radio events**. To these events 3 "**automatic**" functions are attached. They allow to signal that the end of transmission (BUSY line) or transmission/reception timeouts.

```
#define RX_TIMEOUT_VALUE 2000  // time to wait for ACK packet
static RadioEvents_t RadioEvents;

void OnTxDone( void );
void OnTxTimeout( void );
void OnRxTimeout( void );
```

In the setup () function the code uses the defined parameters and functions to initialize the LoRa modem and direct radio events to the execution routines.

```
void setup()
 Serial.begin(9600);
// activated radio events ! With links (addresses) to routines
 RadioEvents.TxDone = OnTxDone;
 RadioEvents.TxTimeout = OnTxTimeout;
 RadioEvents.RxDone = OnRxDone;
 RadioEvents.RxTimeout = OnRxTimeout:
 Radio.Init( &RadioEvents );
 Radio.SetChannel( RF_FREQUENCY );
 Radio.SetTxConfig( MODEM_LORA, TX_OUTPUT_POWER, 0, LORA BANDWIDTH,
                                  LORA_SPREADING_FACTOR, LORA_CODINGRATE,
                                  LORA_PREAMBLE_LENGTH, LORA_FIX_LENGTH_PAYLOAD_ON,
                                  true, 0, 0, LORA_IQ_INVERSION_ON, 3000 );
 Radio.SetRxConfig( MODEM_LORA, LORA_BANDWIDTH, LORA_SPREADING_FACTOR,
                                   LORA_CODINGRATE, 0, LORA_PREAMBLE_LENGTH,
                                   LORA_SYMBOL_TIMEOUT, LORA_FIX_LENGTH_PAYLOAD_ON,
                                   0, true, 0, 0, LORA_IQ_INVERSION_ON, true );
```

In the **first operational stage** the sender enters into **low\_power** mode (deep-sleep). This function is provided via **lowPowerSleep(uint32\_t sleeptime)** function. This function uses a **sleepTimer** and **wakeUp** function that captures the end of sleep period.

When sleepTimerExpired is set to true, the low power stage terminates.

```
TimerEvent t sleepTimer:
bool sleepTimerExpired; //Records whether our sleep/low power timer expired
static void wakeUp()
  sleepTimerExpired=true;
static void lowPowerSleep(uint32_t sleeptime)
  sleepTimerExpired=false;
  TimerInit( &sleepTimer, &wakeUp );
  TimerSetValue( &sleepTimer, sleeptime );
  TimerStart( &sleepTimer );
  //Low power handler also gets interrupted by other timers
  //So wait until our timer had expired
  while (!sleepTimerExpired) lowPowerHandler();
  TimerStop( &sleepTimer );
The sensing stage starts with the reading of battery state (analog value):
uint16_t read_Bat()
  uint16_t v;
  delay(40);
```

pinMode(VBAT\_ADC\_CTL,OUTPUT);
digitalWrite(VBAT\_ADC\_CTL,LOW);
v=analogRead(ADC)+550; //\*2;
pinMode(VBAT\_ADC\_CTL, INPUT);

return v;

Note that the analogRead (ADC) function **should be calibrated** in order to correspond to the real voltage values. Then follows the sequence of sensor readings. The sensors are attached (mainly) to I2C bus that should be alimented before the activation and use:

```
pinMode(Vext, OUTPUT); delay(100);
digitalWrite(Vext, LOW); delay(100);
Wire.begin();delay(100);
// sensor readings
```

Depending on your application, it is provided TS channel number you may provide up to 4 sensor values. We have prepared 3 functions to get: **temperature** (T), **humidity** (H), and the **distance** (D).

```
float read_Temp()
  float t;
  t = sht.getTemperature(); // get temp from SHT
 return t;
int distance=0;
void read_Dist()
  if (distanceSensor.begin() != 0) //Begin returns 0 on a good init
    Serial.println("Sensor failed to begin. Please check wiring. Freezing...");
    while (1);
  Serial.println("Sensor VL53L1X online!");
  //distanceSensor.setDistanceModeShort();
  distanceSensor.setDistanceModeLong();
  distanceSensor.startRanging(); //Write configuration bytes to initiate measurement
  while (!distanceSensor.checkForDataReady())
  {
    delay(1);
  }
  distance = distanceSensor.getDistance(); //Get the result of the measurement from the sensor
  distanceSensor.clearInterrupt();
  distanceSensor.stopRanging();
float read_Humi()
{
  float h;
  h = sht.getHumidity(); // get temp from SHT
  return h;
The sensing stage terminates with:
  Wire.end(); delay(100);
  digitalWrite(Vext, HIGH); delay(100);
to cutoff the power for sensors.
Then starts the transmission stage to send our data packet with 36 bytes:
  turnOnRGB (COLOR_SEND, 0);
                                      // red color
  Radio.Send((uint8_t *)sdp.frame,36);
  delay(400); // min sending time before the reception
The transmission stage ends with:
void OnTxDone( void )
{
  Serial.print("TX done!\n");
  turnOnRGB(0,0);
  lora_idle = true;
```

LP IoT: LoRa link: Terminal & Gateway

to signal the correct transmission

or with:

```
void OnTxTimeout( void )
{
    turnOffRGB();
    Radio.Sleep();
    Serial.print("TX Timeout....");
}
```

to signal transmission problem and timeout

The **last**, **fourth stage**, is the **reception** of the **ACK** packet. This is done within the following loop waiting for the packet:

```
lora_idle = true;
while(lora_idle) // waiting for ACK packet or timeout
    {
    turnOffRGB();
    lora_idle = false;
    Serial.println("RX mode");
    Radio.Rx(0);
}
```

As in the transmission stage, we can have here two issues, the correct one, or the timeout. They are captured by the following "automatic" functions:

```
void OnRxDone( uint8_t *payload, uint16_t size, int16_t rssi, int8_t snr )
{
  pack_t rp;
  memcpy(rp.frame, payload, size );
    turnOnRGB(COLOR_RECEIVED,0);
    Radio.Sleep();
    Serial.printf("\nrssi=%d ,length=%d, timeout=%d\n",rssi,size, (int)rp.pay.sensor[0]);
    ttsleep = (int)rp.pay.sensor[0]*200;delay(100);
    lora_idle = true;turnOffRGB();
}

void OnRxTimeout( void )
{
    turnOnRGB(COLOR_RECEIVED,0);
    Radio.Sleep();
    Serial.print("RX Timeout.....");delay(100);
    lora_idle = true;turnOffRGB();
}
```

#### 1.1.2 Complete code

```
#include "LoRaWan_APP.h"
#include "Arduino.h"
#include <SHT21.h>
SHT21 sht;
#include "SparkFun_VL53L1X.h"
//Click here to get the library: http://librarymanager/All#SparkFun VL53L1X
SFEVL53L1X distanceSensor;
static uint16_t counter=0;
#ifndef LoraWan_RGB
#define LoraWan_RGB 0
#endif
#define RF_FREQUENCY
                                                       868500000 // Hz
#define TX_OUTPUT_POWER
                                                       14
                                                                 // dBm
#define LORA_BANDWIDTH
                                                                 // [0: 125 kHz,
                                                       0
                                                                 // 1: 250 kHz,
// 2: 500 kHz,
                                                                 //
                                                                 // 3: Reserved]
                                                       9
                                                                 // [SF7..SF12]
#define LORA_SPREADING_FACTOR
#define LORA_CODINGRATE
                                                                 // [1: 4/5,
                                                       1
                                                                 // 2: 4/6,
// 3: 4/7,
                                                                 // 4: 4/8]
#define LORA_PREAMBLE_LENGTH
                                                       8
                                                                 // Same for Tx and Rx
#define LORA_SYMBOL_TIMEOUT
                                                       0
                                                                 // Symbols
#define LORA_FIX_LENGTH_PAYLOAD_ON
                                                       false
#define LORA_IQ_INVERSION_ON
                                                       false
#define RX_TIMEOUT_VALUE
                                                       2000
                                                              // time to wait for ACK packet
```

```
static RadioEvents_t RadioEvents;
void OnTxDone( void );
void OnTxTimeout( void );
void OnRxTimeout( void );
int16_t rssi,rxSize;
uint8_t sent=0;
//Some utilities for going into low power mode
TimerEvent_t sleepTimer;
bool sleepTimerExpired; //Records whether our sleep/low power timer expired
static void wakeUp()
{
  sleepTimerExpired=true;
static void lowPowerSleep(uint32_t sleeptime)
  sleepTimerExpired=false;
  TimerInit( &sleepTimer, &wakeUp );
  TimerSetValue( &sleepTimer, sleeptime );
  TimerStart( &sleepTimer );
  //Low power handler also gets interrupted by other timers
  //So wait until our timer had expired
  while (!sleepTimerExpired) lowPowerHandler();
  TimerStop( &sleepTimer );
typedef union
 uint8_t frame[36]; // frames with bytes
 struct
 unsigned int channel; // 4 bytes - device and channel identifier
                        // 16 bytes
// 16 bytes
 char wkey[16];
float sensor[4];
                        // payload
 } pay;
} pack_t ; // packet type
pack_t sdp; // packet to send
uint16_t read_Bat()
  uint16 t v;
  delay(40);
  pinMode (VBAT_ADC_CTL, OUTPUT);
  digitalWrite(VBAT_ADC_CTL,LOW);
  v=analogRead(ADC)+550; //*2;
  pinMode (VBAT_ADC_CTL, INPUT);
  return v;
float read_Temp()
  float t;
  t = sht.getTemperature(); // get temp from SHT
  return t;
int distance=0;
void read_Dist()
  if (distanceSensor.begin() != 0) //Begin returns 0 on a good init
    Serial.println("Sensor failed to begin. Please check wiring. Freezing...");
    while (1);
  Serial.println("Sensor VL53L1X online!");
  //distanceSensor.setDistanceModeShort();
  distanceSensor.setDistanceModeLong();
  distanceSensor.startRanging(); //Write configuration bytes to initiate measurement
  while (!distanceSensor.checkForDataReady())
  {
    delay(1);
```

```
distance = distanceSensor.getDistance(); //Get the result of the measurement from the sensor
  distanceSensor.clearInterrupt();
  distanceSensor.stopRanging();
float read_Humi()
  float h:
  h = sht.getHumidity(); // get temp from SHT
  return h;
unsigned long myChannelNumber =1538804;
const char *myWriteAPIKey="YOX31M0EDKO0JATK" ;
const char *myReadAPIKey="20E9AQVFW7Z6XXOM" ;
void setup()
  Serial.begin(9600);
  rssi=0;
// radio events links to routines
  RadioEvents.TxDone = OnTxDone;
  RadioEvents.TxTimeout = OnTxTimeout;
  RadioEvents.RxDone = OnRxDone;
  RadioEvents.RxTimeout = OnRxTimeout;
  Radio.Init( &RadioEvents );
  Radio.SetChannel( RF_FREQUENCY );
  Radio.SetTxConfig( MODEM_LORA, TX_OUTPUT_POWER, 0, LORA_BANDWIDTH,
                                   LORA_SPREADING_FACTOR, LORA_CODINGRATE,
                                   LORA_PREAMBLE_LENGTH, LORA_FIX_LENGTH_PAYLOAD_ON,
                                   true, 0, 0, LORA_IQ_INVERSION_ON, 3000 );
  Radio.SetRxConfig( MODEM_LORA, LORA_BANDWIDTH, LORA_SPREADING_FACTOR,
                                    LORA_CODINGRATE, 0, LORA_PREAMBLE_LENGTH,
LORA_SYMBOL_TIMEOUT, LORA_FIX_LENGTH_PAYLOAD_ON,
                                    0, true, 0, 0, LORA_IQ_INVERSION_ON, true );
}
int ttsleep=20000;
bool lora_idle = true;
void loop()
{
  counter++:
  Serial.printf("\ntime_to_sleep=%d ms\n", ttsleep);delay(100);
  lowPowerSleep(ttsleep);
  Serial.printf("\nBack from sleep %d, counter=%d\n", millis(),counter);
  sdp.pay.sensor[0] = (float) read_Bat(); Serial.println(sdp.pay.sensor[0]);
  pinMode(Vext, OUTPUT); delay(100);
  digitalWrite(Vext, LOW); delay(100);
  Wire.begin();delay(100);
  sdp.pay.channel=myChannelNumber;
  memcpy(sdp.pay.wkey,myWriteAPIKey,16);
  sdp.pay.sensor[1]=(float)read_Temp();Serial.println(sdp.pay.sensor[1]);delay(100);
  sdp.pay.sensor[2]=(float)read_Humi();Serial.println(sdp.pay.sensor[2]);delay(100);
  sdp.pay.sensor[3]=(float)distance;Serial.println(sdp.pay.sensor[3]);delay(100);
  Wire.end(); delay(100);
  digitalWrite(Vext, HIGH); delay(100);
  turnOnRGB (COLOR_SEND, 0);
  Radio.Send((uint8_t *)sdp.frame,36);
  delay(400); // min sending time before the reception
  lora_idle = true;
  while (lora_idle)
    {
    turnOffRGB();
    lora_idle = false;
                                      // works without timeout
    Serial.println("ACK wait");
    Radio.Rx(0);
}
```

```
void OnRxDone( uint8_t *payload, uint16_t size, int16_t rssi, int8_t snr )
  pack_t rp;
    memcpy(rp.frame, payload, size );
    turnOnRGB(COLOR_RECEIVED, 0);
   Radio.Sleep();
Serial.printf("\nrssi=%d,length=%d, id=%u, timeout=%d\n",rssi,size,rp.pay.channel,
(int)rp.pay.sensor[0]);
    ttsleep = (int)rp.pay.sensor[0]*200;delay(100);
    lora_idle = false;turnOffRGB();
void OnTxDone( void )
  Serial.print("TX done!\n");
  turnOnRGB(0,0);
 lora_idle = true;
void OnTxTimeout( void )
    turnOffRGB();
    Radio.Sleep( );
    Serial.print("TX Timeout....");
void OnRxTimeout( void )
    turnOnRGB(COLOR_RECEIVED, 0);
    Radio.Sleep( );
    Serial.print("RX Timeout....");delay(100);
    lora_idle = false;turnOffRGB();
```

### 1.2 Receiver/gateway side on Pomme-Pi ZERO

#### (AirM2M-CORE\_ESP32C3)

At the receiver side we have a complete Lora-WiFi gateway to ThingSpeak server.

The gateway is "transparent", it knows neither the channel number nor the write key necessary to register the data packet on the ThingSpeak server. He knows however the IP address of the ThingSpeak.com server (port number 80);

#### 1.2.1 Code explanation

The initialization of the gateway communication links is done in setup() function. The WiFi connection is activated via WiFiManager that creates a soft AP on the board and a simple WEB server to capture the WiFi credentials (SSID,PASS) using an external client (PC,smartphone,..).

```
WiFi.mode(WIFI_STA);
WiFiManager wm;
// wm.resetSettings(); // to clear the registered credentials in EEPROM
bool res;
res = wm.autoConnect("ESP32AP",NULL); // no password
if(!res) Serial.println("Failed to connect");// ESP.restart();
else Serial.println("connected...yeey :)");
ThingSpeak.begin(client); // TCP connection to ThingSpeak server
delay(1000);
```

After the initialization, the board WiFi switches to station mode and is ready to send the data to external server such as **ThinSpeak.com**.

LoRa modem (RFM-SX1276) is "connected" and activated in the next step by:

```
#define BAND 8685E5
int sf=9;
long sbw=125E3;
 SPI.begin(2,10,3,7); // SCK, MISO, MOSI, SS
 LoRa.setPins(7, 6, 11); // SS, RST, DIO - interrupt
 delay(1000);
 Serial.println(); Serial.println();
  Serial.println("Starting LoRa Receiver");
 if (!LoRa.begin(BAND)) {
    Serial.println("Starting LoRa failed!");
    while (1);
 else
   Serial.println("Starting LoRa ok!");
  LoRa.setSpreadingFactor(sf);
  LoRa.setSignalBandwidth(sbw);
  LoRa.setCodingRate4(5);
```

Finally, if LoRa modem is correctly initialized, we create ParseTask to read cyclically the LoRa modem input buffer looking for a new packet. When a new packet is found it is read and sent to the ts\_queue. In this queue we can store up to 4 messages 36 byte each.

The ParseTask looks in the input buffer, and if a new packet with the correct number of bytes is found (packetLen==36), the task reads data to the pack\_t type union. Then, after a short delay, the task sends back the corresponding ACK packet.

In the ACK packet the task sends back the channel number ( sdp.pay.channel=rdp.pay.channel;) and a new timeout value in sdp.pay.sensor[0] that is a random value (random (60,80)). This value is multiplied at the receiver/terminal side by 20 to get a number in milliseconds.

Note that **only the terminals** with the same identifier – channel number, should be concerned by the received ACK packet.

```
void ParseTask( void * pvParameters )
 pack_t rdp,sdp;
  while (true)
  {
    int packetLen;
    packetLen=LoRa.parsePacket();
    if (packetLen==36)
    {
      int i=0;
      while (LoRa.available()) {
      rdp.frame[i]=LoRa.read();i++;
    rssi=LoRa.packetRssi();
    delay(1000);
    LoRa.beginPacket(); // sending ACK packet
    sdp.pay.channel=rdp.pay.channel;
    sdp.pay.sensor[0] = (float) random(60,80); sdp.pay.sensor[1] = (float) random(10,80);
    LoRa.write(sdp.frame, 36);
    LoRa.endPacket();
    xQueueReset(ts_queue); // to keep only the last element
    xQueueSend(ts_queue, &rdp, portMAX_DELAY);
 }
```

The last instruction in the ParseTask is:

```
xQueueSend(ts_queue, &rdp, portMAX_DELAY);
```

It allows the task to communicate the received packet to another task that is the main loop () task.

```
void loop()
pack_t rp;
char d1[32],d2[32],d3[32],d4[32], d5[32];
  xQueueReceive(ts_queue,rp.frame,portMAX_DELAY); // 6s,default:portMAX_DELAY
  if(millis()> lastsent+15000)
    ThingSpeak.setField(1,rp.pay.sensor[0]);
    ThingSpeak.setField(2,rp.pay.sensor[1]);
    ThingSpeak.setField(3,rp.pay.sensor[2]);
    ThingSpeak.setField(4,rp.pay.sensor[3]);
    ThingSpeak.setField(5,rssi);
    Serial.printf("d1=%2.2f,d2=%2.2f,d3=%2.2f,d4=%2.2f\n",rp.pay.sensor[0],rp.pay.sensor[1],
                                                           rp.pay.sensor[2],rp.pay.sensor[3]);
    while (WiFi.status() != WL_CONNECTED) { delay(500); }
    int x = ThingSpeak.writeFields(rp.pay.channel, rp.pay.wkey);
    if(x == 200){Serial.println("Channel update successful.");}
    else { Serial.println("Problem updating channel. HTTP error code " + String(x));}
     \texttt{sprintf(d1,"B(mV): $2.2f",rp.pay.sensor[0]);sprintf(d2,"Temp: $2.2f",rp.pay.sensor[1]); } \\
    sprintf(d3,"Humi: %2.2f",rp.pay.sensor[2]);sprintf(d4,"Lumi: %2.2f",rp.pay.sensor[3]);
    sprintf(d5, "RSSI: %d", rssi);
    disp(d1,d2,d3,d4,d5);
    lastsent=millis();
    }
}
```

The main task reads the received packets in the ts\_queue and if time moment allows sends the sensor values from the packet to ThingSpeak server.

The **time moment** is controlled by:

```
if(millis()> lastsent+15000)
{
.
   lastsent=millis();
}
```

That provides a **dynamic delay** of 15 seconds.

#### 1.2.2 Complete code

```
#include <LoRa.h>
#include <Wire.h>
#include <WiFiManager.h>
#include "ThingSpeak.h"
#include "SSD1306Wire.h"
SSD1306Wire display(0x3c, 4, 5); // OLED: ADDRESS, SDA, SCL
// the following parameters are not required for transparent gateway
//unsigned long myChannelNumber =1697980;
//const char *myWriteAPIKey="4K897XNNHTW7I4NO";
//const char *myReadAPIKey="V9GT1RN2FIP0YRAY" ;
WiFiClient client;
// with LoRa modem RFM95 (HAT) - AirM2M-CORE_ESP32C3
#define SS 7
#define RST 6
#define DIO 11
#define SCK 2
#define MISO 10
#define MOSI 3
#define BAND 8685E5
int sf=9;
long sbw=125E3;
typedef union
 uint8_t frame[36]; // frames with bytes
 struct
 unsigned int channel; // 4 bytes - device and channel identifier
                       // 16 bytes
 char wkey[16];
 float sensor[4];
                       // 16 bytes
 } pay;
                       // payload
} pack_t ; // packet type
QueueHandle_t ts_queue; // queues for data packets
int rssi=0:
void ParseTask( void * pvParameters )
  pack_t rdp,sdp;
  while(true)
    int packetLen; char b1[32];
    packetLen=LoRa.parsePacket();
    if (packetLen==36)
    {
      while (LoRa.available()) {
      rdp.frame[i]=LoRa.read();i++;
    rssi=LoRa.packetRssi();
    delay(1000);
    LoRa.beginPacket(); // sending ACK packet
    sdp.pay.sensor[0]=(float)random(60,80);sdp.pay.sensor[1]=(float)random(10,80);
    LoRa.write(sdp.frame, 36);
    LoRa.endPacket();
    xQueueReset(ts_queue); // to keep only the last element
    xQueueSend(ts_queue, &rdp, portMAX_DELAY);
  }
  }
void disp(char *11, char *12, char *13, char *14, char *15)
  display.init();
  //display.flipScreenVertically();
  display.setFont(ArialMT_Plain_10);
  display.setTextAlignment(TEXT_ALIGN_LEFT);
  display.setFont(ArialMT_Plain_10);
  display.drawString(0, 0, 11);
  display.drawString(0, 9, 12);
```

```
display.drawString(0, 18, 13);
  display.drawString(0, 27, 14);
  display.drawString(0, 36, 15);
display.drawString(0, 52, "SmartComputerLab");
  display.display();
void setup() {
  Serial.begin(9600);
  WiFi.mode(WIFI_STA);
  WiFiManager wm:
  // wm.resetSettings();
  bool res;
  res = wm.autoConnect("ESP32AP", NULL); // no password
  if(!res) Serial.println("Failed to connect");// ESP.restart();
  else Serial.println("connected...yeey :)");
  ThingSpeak.begin(client); // connexion (TCP) du client au serveur
  delay(1000);
  Serial.println("ThingSpeak begin");
  SPI.begin(2, 10, 3, 7); // SCK, MISO, MOSI, SS
  LoRa.setPins(SS, RST, DI0);
  delay(1000);
  Serial.println(); Serial.println();
  Serial.println("Starting LoRa Receiver");
  if (!LoRa.begin(BAND)) {
    Serial.println("Starting LoRa failed!");
    while (1);
  else
   Serial.println("Starting LoRa ok!");
  LoRa.setSpreadingFactor(sf);
   LoRa.setSignalBandwidth(sbw);
   LoRa.setCodingRate4(5);
   ts_queue = xQueueCreate(4,36); // queue for 4 data packets
   xTaskCreate(
                     ParseTask, /* Function to implement the task */
"ParseTask", /* Name of the task */
                                /* Stack size in words */
                     10000,
                     NULL,
                                 /* Task input parameter */
                     0.
                                 /* Priority of the task */
                     NULL);
                                  /* Task handle. */
  Serial.println("Task Parse created...");
}
uint32_t mindel=15000; // 15 seconds
long lastsent=0;
void loop()
pack_t rp;
char d1[32],d2[32],d3[32],d4[32], d5[32];
  xQueueReceive(ts_queue,rp.frame,portMAX_DELAY); // 6s,default:portMAX_DELAY
  if(millis()> lastsent+15000)
    ThingSpeak.setField(1,rp.pay.sensor[0]);
    ThingSpeak.setField(2, rp.pay.sensor[1]);
    ThingSpeak.setField(3,rp.pay.sensor[2]);
    ThingSpeak.setField(4, rp.pay.sensor[3]);
    ThingSpeak.setField(5,rssi);
    Serial.printf("d1=%2.2f,d2=%2.2f,d3=%2.2f,d4=%2.2f\n",rp.pay.sensor[0],rp.pay.sensor[1],
rp.pay.sensor[2],rp.pay.sensor[3]);
    while (WiFi.status() != WL_CONNECTED) { delay(500); }
    int x = ThingSpeak.writeFields(rp.pay.channel, rp.pay.wkey);
    if(x == 200){Serial.println("Channel update successful.");}
     else \ \{ \ Serial.println("Problem updating channel. \ HTTP \ error \ code \ " \ + \ String(x)); \} 
    sprintf(d1, "B(mV): %2.2f",rp.pay.sensor[0]);sprintf(d2, "Temp: %2.2f",rp.pay.sensor[1]);
    sprintf(d3, "Humi: %2.2f",rp.pay.sensor[2]);sprintf(d4, "Lumi: %2.2f",rp.pay.sensor[3]);
    sprintf(d5,"RSSI: %d",rssi);
    disp(d1,d2,d3,d4,d5);
    lastsent=millis();
    }
}
```

### To do

- Read the explanations and analyze the presented code solution for your application.
   Adapt the provided codes to your board (SPI and LoRa modem activation!)
   Analyze power consumption for your terminal node
   Add secure communication with AES