

its bottom and another slat about 12 inches from the bottom of the Back. These two distances determine the angle and height of the chair Bottom when assembled. If using hardwood, pre-drill all holes as forcing the deck screws in without pre-drilling may cause the screw to break.

Finish with exterior varnish or exterior Watco oil.

To assemble, insert Bottom into Back. To store, insert Bottom into the back of Back piece.

Lawn and Deck Chair

Design From George Kuffel Drawing by Barry Humphus