

Thank you!

Thank you for ordering a Downloadable WOOD PLAN. We hope you enjoy being a part of this new online experience and that you have fun building your woodworking project.

Please remember that this copyrighted material is for your use only. It is unlawful to share this file with someone else or to reprint it in any form.

Bill Krier Editor **WOOD**® magazine

Adobe Acrobat Troubleshooting Guide

If you can read this page, your Acrobat program is working correctly! But you may still have problems or specific issues such as printing and saving your Downloadable WOOD PLAN.

My printer won't print the text correctly

Almost all printing problems are due to not enough free system resources memory. The files are very memory intensive since they include graphics, text, and photos. Close all other programs/applications and print directly out of the Acrobat Reader program, not your Web-browser.

Patterns are not printing full size

Make sure your printer is set to print at 100% and that "print to fit" is not checked. These settings are selected in the printer setup or printer options.

I can't save my file now that it's downloaded


You must save the plan when you download the file. Download the file again, except this time try right-clicking on the red download button. A menu window will open. Select "Save target as" or "Save link as" to save the file to your hard drive. Once saved, you can open it with Adobe Acrobat Reader.

For more details on using Adobe Acrobat Reader please visit our online help section at: http://woodstore.woodmall.com/clicherforde.html

ONLINE WOODWORKING PLANS


http://www.woodonline.com


Terrific lambour Bookcase



We've seen a great many bookcases in our travels around the country, but none more good-looking and versatile than this one. And should you ever have to relocate, you'll find the modular pieces making up the bookcase a breeze to take apart and reassemble. To build the four-high bookcase, see the Bill of Materials and Cutting Diagram on page 12.

DP-00118






Bill of Materials						
	Finished Size			atl.	·	
Part	Т	W	L	Matl.	Qty.	
A* shelves	3/4"	121/2"	42"	EO	3	
B* tambour strips	3/16"	⁷ /16 ["]	14"	0	224	
C support caps	3/4"	27/8"	111/8"	PL	8	
D uprights	3/4"	6¾"	12½"	PL	4	
E backs	1/4"	37½"	141/2"	OP	2	
F feet	1 ½"	31/4"	11½"	LO	2	

*Initially cut parts marked with an * oversized. Then, trim each to finished size according to the how-to instructions.

Materials Key: EO-edge-joined oak, O-oak, PL-plywood, OP-oak plywood, LO-laminated oak

Supplies: lightweight canvas, #18 $x^3/4$ " brads, #8 $x^1/2$ " flathead wood screws, 1/4" threaded inserts, 1/4" all-thread rod, 1/4" flat washers, 1/4" lock washers, 1/4" wing nuts, stain, finish.





CUTTING DIAGRAM

*Plane or resaw to 7/16" thick, and then rip to 3/16" wide


(A)


(B)





3/4 x 91/4 x 96" Oak (2 pieces)





Start by forming the edge-joined oak shelves

- 1 From ¾"-thick hardwood (we used oak), edge-join enough narrow stock to form three panels measuring 13" wide by 44" long. You'll use one panel for the upper shelf, another for the middle shelf, and the third for the lower shelf (all labeled A).
- 2 Rip and crosscut the three shelves to 12½" wide by 42" long. Sand both faces of each panel.
- 3 Mark a 21/8" radius on each corner of each shelf. (See the Parts View drawing on *page 11* for reference.) Cut and sand the corners to shape. If you do this on the bandsaw, you'll need a helper to support the long panels when making the corner cuts. Using a pencil, label one shelf UPPER, another MIDDLE, and the third, LOWER. Labeling the parts now helps ensure the correct machining to the proper face of each shelf later.
- 4 Drill four 1/16" holes 1/2" deep into the bottom side of the upper shelf, using the same centerpoints used to mark the 21/8"-radiused corners. Using a wide-blade screwdriver, drive a 1/4"-threaded

insert squarely into each of these holes until the notched end of the insert is flush with the bottom surface of the shelf, as where shown on the Threaded Insert detail accompanying the Exploded View drawing.

- 5 Switch bits, and drill 5/16" holes through the middle shelf and lower shelf, again using the hole centerpoints you marked earlier. You'll slide the all-thread rod through these holes later when assembling the modules.
- 6 Make start and stop marks for the grooves (21/8" from the ends) along the back edge on the bottom side of the upper shelf, both sides of the middle shelf, and top side of the lower shelf, where dimensioned on the Parts View.
- 7 Fit your router with a ¼" straight bit and edge guide. If you don't have an edge guide, clamp a straightedge (a straight board will work) to the shelf. Rout a ¼" groove ¼" deep along the back edge of each shelf where marked. You'll use these grooves to house the plywood backs (E).
- 8 Rout ¼" round-overs along the top and bottom edges of each shelf. Sand the shelves smooth.

Now, let's cut the tambour strips to size

- 1 To make four tambour support columns, you'll need 56 strips (B) per column, or a total of 224 strips for the four columns. (We cut about 240 strips, giving us extras to substitute for strips with defects.) To form the strips, plane thicker stock to ½6" thick. Crosscut the ½6"-thick stock to 29" long.
- **2** Set the fence on your tablesaw ³/₁₆" from the inside edge of the blade. (For smooth cuts, we used a 40-tooth, carbide-tipped saw blade.) Rip 120 of the ³/₁₆×⁷/₁₆×29" strips (B).
- 3 Complete the B parts by crosscutting two 14"-long strips from each of the 29"-long strips.


Glue and clamp the oak strips to the canvas

- 1 Build the Tambour Clamping Jig shown in *Step 1* of the Making the Tambour drawing.
- 2 Cut four pieces of lightweight canvas to 12×30".
- 3 Starting at the end of the jig with the end cleat, position 56 of the $\frac{3}{6}$ % × 14" strips, best face down,


on the jig, where shown in *Step 2* of the drawing. Place waxed paper under the first three and last three tambour strips. Use a pair of bar clamps to lightly clamp the strips against the end cleat to remove any gaps between the strips. Then, clamp a 1/8×2×12" stopblock in position to hold the strips tightly together.

4 Mark a line 1" in from the tambour-strip ends, and spread a thin, even coat of glue on all of the strips between the pair of marked lines. Place a piece of 12×30" lightweight canvas on the glued strips where shown in *Photo A* and *Step 2* of the drawing on *page 4*. Smooth out any wrinkles or bubbles in the canvas.


5 Cover the canvas with waxed paper. Next, clamp a piece of $\frac{3}{4}\times12\times24\frac{1}{2}$ " plywood to the top of this assembly to press the tambour strips uniformly against the canvas as shown in *Photo B* and *Step 3* of the drawing. Leave the assembly clamped overnight. Remove the clamps and tambour,



Clamp the oak strips to the clamping jig good face down. Spread glue between the clamping blocks, and adhere a piece of lightweight canvas to the strips.



Place waxed paper on top of the canvas, and then position and clamp a piece of plywood on top of the waxed paper to firmly secure the canvas to the oak strips.



and repeat to form the remaining tambour assemblies.

6 Remove the tambour assembly from the jig, and sand the wood side of each tambour until the pieces are flush with each other and all machining marks are gone. (We first belt-sanded the tambour with 80, and then 120-grit sandpaper. Next, we used a palm sander and 150- and 220-grit sandpaper to finish-sand the tambour.)

Build the tambour frames for a supporting role

1 To build the tambour support


frames, cut the support caps (C) to the shape shown on the Parts View drawing. Cut the uprights (D) to size.

- **2** Using the Parts View drawing for reference, mark the centerpoints, and drill four holes in each top and bottom support cap (C).
- 3 Glue and screw the supports together in the configuration shown on the Tambour Support Frame drawing. (We used a framing square to check that the edges of the top and bottom caps [C] were aligned perfectly.)
- 4 To wrap the tambour around

the frames, drill ½6" holes ¾8" from the ends of the first two tambour strips where shown on *Step 1* of the Assembling the Columns drawing on *page 8*.

- 5 Spread glue on the mating edges and wrap the tambour tightly around the frame, where shown in *Step 1* of the drawing. Start the first strip centered on the radiused ends, where shown.
- **6** After gluing and wrapping the tambour completely around the support frame, clamp a pair of clamp blocks to the top and bottom of the assembly where shown





in *Step 2* of the drawing on *page 9*. The clamp blocks hold the ends of the tambour strips flush while the glue dries. Repeat the process to form each column. Drive brads into the last two tambour strips in the wrap to hold them firmly in place.

7 Using a hobby knife, trim the excess canvas from each column. Set the brads, and fill the holes with putty. Sand smooth.

8 Belt-sand the top and bottom


surfaces of the column flush. Hand-sand a slight round-over on the exposed edges of the tambour pieces where they wrap around the frame radiused ends.

Cut the backs, and put the pieces together

1 From ¼" oak plywood, cut the backs (E) to size. Notice that the grain runs up and down on the backs, where shown on the Exploded View drawing.

2 Cut two pieces of ¾"-thick stock for each foot (F) to the shape shown on the Parts View drawing. If you don't have a 2" Forstner bit to form the holes in the bottom pieces, drill blade start holes and cut the openings with a scrollsaw or jigsaw. Glue the pieces face-to-face with the edges and ends flush. Sand the edges smooth.

3 Drill 5/16" holes through each foot, where shown on the Parts View drawing.



4 Finish-sand all of the pieces. Stain the components, and apply a clear finish.


5 Using a hacksaw, cut two 31¼"-long pieces of ¼" all-thread rod. Assemble the bookcase in the configuration shown on the Exploded View drawing. To prevent scratching the floor, make sure that the bottom of the all-thread is above the bottom surface of the feet, where shown on the Hole detail accompanying the Exploded View drawing. Trim the all-thread rod more if necessary.


Produced by Marlen Kemmet Project Design: Parman Brothers LTD., Johnson, Kansas Illustrations: Kim Downing Graphic Design: Jamie Downing Photographs: Hetherington Photography ©Copyright Meredith Corporation 2000


The purchase of these plans does not transfer any copyright or other ownership interest in the plans, the design, or the finished project to the buyer. Buyer may neither reproduce the plans for sale nor offer for sale any copies of the finished project.

PARTS VIEW

© TAMBOUR SUPPORT CAP







Bill of Materials Finished Size Matl. Part Т W **FOUR-HIGH UNIT** A* shelves 121/2" 42" EO 5 7/₁₆" 14" 448 B* tambour strips 3/16" 0 PL 16 C support caps 3/4" 27/8" 111/8" 3/4" 63/4" 121/2" PL 8 D uprights E backs 1/4" 371/2" 141/2" OP 4 11/2" 2 F feet 31/4" 111/2" LO


*Initially cut parts marked with an * oversized. Then, trim each to finished size according to the how-to instructions.

Materials Key: EO-edge-joined oak, O-oak PL-plywood, OP-oak plywood, LO-laminated oak.


*Plane or resaw to 7/16" thick, and then rip to 3/16" wide



(for 4-high tambour bookshelf)



³/₄ x 5¹/₂ x 48" Oak






1/2 x 91/4 x 96" Oak (3 pieces)

A	A	
A	A	

³/₄ x 9¹/₄ x 96" Oak (4 pieces)



1/4 x 48 x 96" Oak Plywood

Page 12 of 12



The Internet's Largest Source for Woodworking Tools and Accessories

http://www.woodmall.com

Thanks for your order!

Now that you've got a detailed plan to build that perfect project, visit the WOOD MALL for the internet's largest source for woodworking tools and accessories. The WOOD MALL offers:

- Over two dozen woodworking-related stores
- More than 50,000 tools & accessories
- 24-Hour shopping
- Special sales & closeouts
- Nearly 40 tool comparison charts
- FREE monthly woodworking seminar

Visit Today! http://www.woodmall.com





Woodworking has never been more satisfying! With WOOD® Magazine at your side, you can take your skills to the next level. Just look at all the help you get in a year ...

- Over 56 shop-tested projects Full-size pull-out patterns
 Clear step-by-step instructions Skill-building tips, tricks, and shortcuts
 Tool reviews you can trust Handy shop jigs and fixtures
 Full-color photos And more!
- □ 2 years (18 issues) just \$44 SAVE \$63.10 off single-copy rate!
 □ 1 year (9 issues) just \$28 SAVE \$25.55 off single-copy rate!
 □ Payment Enclosed □ Bill Me

Current issue not shown

Fill out information below and mail to: WOOD® Magazine P.O. BOX 37439, Boone, IA. 50037-0439 or Subscribe Online at http://www.woodmagazine.com/subscript

My Name (please print)		
Address		Apt. #
City	State	Zip

Canadian Orders: Fill in the form above. Your rate will be 1 year (9 issues) for \$41 – SAVE \$30.55, or 2 years (18 issues) for \$67 – SAVE \$76.10. Prices include postage; 7% GST or 15% HST is added. #12348 2887 RT

U.S. and Canadian subscribers: You also may order by credit card. Call toll free 1-800-374-9663 weekdays from 7 a.m. to 10 p.m. Central Time; Saturdays, 8 a.m. to 3 p.m.; Sundays, 9 a.m. to 3 p.m.

Other International Orders: 2 years for \$89 U.S. or 1 year for \$49 U.S.; prices include postage. To order by credit card call 515/246-6952 during the same hours as listed above (toll charged). Or complete this form; mail with US funds to: WOOD® Magazine, P.O. Box 37439, Boone, IA. 50037-0439 USA.

Your Money-Back Guarantee: You must be satisfied with your subscription or you can get a refund for all unmailed issues.

WOOD® Magazine is published 9 times a year. Savings are based on \$5.95 U.S., \$7.95 Canadian single-copy rate. The first issue mails in 8-12 weeks. Subscription prices subject to change.