Tiled Cheese Board

Based on a traditional cutting-board design, this cheese board is light enough to pass around among your guests, but large enough to hold the knife and crackers too! Its hand-selected tile gives it a special flair. Choose a tile color and pattern that please you—ones that will complement your kitchen or dining-room decor.

Materials List

Birch and cherry are recommended for this project.

(2) 3/4" x 3-3/16" x 18"

Birch sides

(1) 3/4" x 3-3/4" x 18"

Cherry center

(1) 6" x 8"

Ceramic tile

Suggested Tools

Router
1/4" straight bit
3/8" roundover bit
Jigsaw
Try square
36" straightedge
Pipe clamps
Compass
Sander

Hardware & Supplies

Waterproof wood glue Latex cement adhesive Masking tape Food-grade bowl finish

Construction Procedure

- 1. Spread glue evenly along the edges of each piece, and clamp the sections together with the cherry wood in the center. Use the square or straightedge to check for a level surface before allowing the glue to dry overnight.
- **2.** If necessary, use a table saw to trim the piece to 10" x 18" dimensions. At the center of the board's width, strike a center line lengthwise.
- **3.** Measure in 6-1/2" from one end, and mark a point on the center line. Then, from this point, strike a 6-1/2" radius at the board's end (see Board Layout).
- **4.** On the same end, using the corners as centers, mark two 2" radii that intersect with the arc just made.
- **5.** Mark lines across the board, 3" and 9" from this end.



- **6.** Measure 4" to each side of the center line previously marked, and strike two parallel lines that intersect with the two lines made in Step 5.
- 7. Using a straight bit in the router, remove the material within the marked 6" x 8" rectangle to a depth of 1/4". Start in the center, and work out toward the edges to prevent the router base from slipping out of square with the wood's surface.
- **8.** On the opposite 10" end, measure in 2" from the sides and end of the board, and mark the two points.
- **9.** Strike a 2" radius at each of these points to form the rounded board's corners.

- 10. With a jigsaw, cut the board to the shape marked.
- 11. Use a 3/8" roundover bit in the router to round both sides of all edges.
- 12. After sanding the wood, cover the tile bed with masking tape.
- 13. Finish the wood with several coats of food-grade bowl finish.
- 14. Remove the masking tape, and glue the tile in place with latex cement adhesive. Use a damp cloth to remove any excess glue.