Materials, Supplies, & Cutting Diagram No. 155

Craftsman-style Morris Chair

| | - | | | | |
|---|----------------------|--|-----|-------------------------------|------------------|
| Α | Front Legs (2) | 21/4 x 21/4 - 235/8 | 0 | Back Frame Stiles (2) | 1 x 15/8 - 291/4 |
| В | Back Legs (2) | 21/4 x 21/4 - 22 rgh. | Ρ | Back Frame Upper Slat (1) | 3% x 3% - 2034 |
| C | Lower Side Rails (2) | 1 x 3 - 283/8 | Q | Back Frame Lower Slats (4) | 3/8 x 2½ - 203/4 |
| D | Upper Side Rails (2) | 1 x 5½ - 25½ | R | Adjustment Pins (2) | 1 x 1 - 4½ |
| Ε | Filler Strips (4) | ½ x ½ - 24 % | S | Pivot Pins (2) | 1 x 1 - 5½ |
| F | Spindles (34) | 5/8 x 5/8 - 12 3/8 | Т | Washers (2) | 1 x 1 - 3/8 |
| G | Front Rail (1) | 1 x 4½ - 26¾ | U | Seat Frame Front/Back (2) | 1 x 2 - 22% |
| Н | Back Rail (1) | 1 x 3 ³ / ₄ - 26 ³ / ₄ | V | Seat Frame Sides (2) | 1 x 2 - 25% |
| 1 | Front Cleat (1) | 5⁄8 x 1 − 231⁄4 | | | |
| J | Back Cleat (1) | 5⁄8 x 1 − 231⁄4 | • (| 8) Metal Chair Webbing Clamps | |

M Back Mortise Caps (2) Corbels (4)

Front Mortise Caps (2)

Arms (2)


K


1 x 5 - 37 • 10 Lineal Ft. Elastic Chair Webbing

 $1\frac{1}{2} \times 1\frac{1}{2} - \frac{3}{8}$ • (1) $\frac{5}{8}$ "-dia. x 36" Oak Dowel

 $1\frac{1}{2} \times 1\frac{1}{2} - \frac{3}{8}$ • (1) 1"-dia. x 36" Oak Dowel

 $1 \times 1^{3}/_{4} - 11$ • (2) $^{3}/_{8}$ "-dia. x 36" Oak Dowel





5/4 x 9 - 96 (7.5 Bd. ft. Quartersawn White Oak)




5/4 x 9 - 96 (7.5 Bd. ft. Quartersawn White Oak)



5⁄4 x 6 - 60 (3.1 Bd. ft. Quartersawn White Oak)



3/4 x 6 - 96 (4 Bd. ft. Quartersawn White Oak)





Craftsman-style Ottoman

Side Rails (2)

| Α | Legs (4) | 1 ³ / ₄ x 1 ³ / ₄ - 15 | G | Stretchers (2) | | ³ / ₄ x 1½ - 20¼ |
|---|---------------------|--|-----|------------------------------|-----|--|
| В | Upper End Rails (2) | 1 x 2 ³ / ₄ - 15 | Н | Cleats (2) | | 3⁄8 x 1 − 18½ |
| C | Lower End Rails (2) | 1 x 2 - 15 | 1 | Seat Panel (1) | 3/4 | ply 13 x 181/4 |
| D | Filler Strips (4) | ½ x ½ - 12½ | | | | |
| Ε | Spindles (16) | 5/8 x 5/8 - 71/4 | • (| 1) 3/8"-dia. x 36" Oak Dowel | | |

1 x 2³/₄ - 21



NOTE: Also need 3/4" plywood for seat panel

