
## Project 15410EZ: Cooling Rack



This cooling rack uses dovetail slat-and-groove construction for both strength and beauty. It's a great low-cost, clever project, with a construction that's ideal for making multiples. Our illustrations show stock sized to yield five cooling racks.


## **Cooling Rack Step-by-Step Instructions**

- 1. Select stock from which to make the cooling rack. The rack in the photograph is made from oak.
- 2. Cut the center dovetail groove (see **Figure 1**).
- 3. Place a 7/8" wide spacer strip between the stock and the router table fence to cut the two grooves adjacent to the center grooves (see **Figure 2**).




- 4. Add one more 7/8" spacer between the workpiece and the fence for each subsequent pair of grooves that you cut.
- 5. Set the table saw fence just a hair over 9/16" from the blade.
- 6. Use the table saw to rip off the feet (see **Figure 3**).
- 7. Sand the feet to just a little over 1/2" wide.

- 8. Set up the table saw with the blade angled to equal the angle of the dovetail bit that you used to establish the slat grooves in the feet.
- 9. Locate the fence 1/2" away from the blade.
- 10. Test your fence and blade setting on some scrap first to make certain the slats fit snugly within the dovetail grooves. **NOTE: The fence setting should allow for a little finish sanding to remove any blade marks from the slats.**
- 11. Cut the 1/2" wide slats (see **Figure 4**).



- 12. Make each consecutive slat cut by flipping the board end-over-end, as shown in **Figure 5**.
- 13. Drill for the 1/8" diameter dowel pins that anchor the slats to the feet (see **Figure** 6).



- 14. Glue the pins into place.
- 15. Sand the ends of the dowel pins flush.
- 16. Apply a nontoxic natural oil finish to complete the project.

These plans were originally published in Volume 15, Issue 5 of *The Woodworker's Journal* (Sept./Oct. 1991, pages 58-59).