Acme LaserPro 400 Office Printer - Troubleshooting Manual

Sample vendor manual (fictional) used to demo document upload + retrieval.

Error Codes

E-13 Paper Jam in Tray 2

Open the right-side door and pull the green lever down. Remove the jammed sheet slowly with both hands. Fan the paper stack before reloading Tray 2 and never fill it above the max-fill line.

E-49 Fuser Communication Error

Turn the printer off and wait 60 seconds. Remove any USB drive from the front port, then power on. If E-49 returns, the fuser unit must be replaced by an authorized technician; do not open the rear cover, the fuser is hot.

E-81 Toner Cartridge Not Recognised

Remove the toner cartridge, rock it gently side to side five times, remove the orange shipping tab if present, and reinsert it until it clicks.

Network Setup

The LaserPro 400 gets its IP address by DHCP. Print a configuration page by holding the Cancel button for 5 seconds; the IP address is listed under "Network Status". If the IP starts with 169.254 the printer can't reach the router: check the Ethernet cable and switch port.

Faded or Streaky Prints

Run the cleaning page from Settings > Maintenance > Clean Drum. Replace the toner when the panel shows "Toner Low" and prints are faded.