

TOYOTA

REPAIR MANUAL

TYPE F ENGINE

CONTENTS

Section	Pages
I General description	1
II Minor service operations	9
III Major service operations	45
IV Trouble shooting	99
V Engine Fits and tolerances	107
VI Torque wrench specification	117
VII Fuel system	119
VIII Cooling system	153
IX Lubricating system	167